

The Cockworker's Journal





Included in this issue: Pencil Post Nightstand • Oak Bookcase Desk Captain's Clock • Bird Push Toy • Harvest Basket Rooster Silhouette • Coffee Table • Miter Cutting Jig

FOR THOSE WHO STILL TAKE THE TIME TO HANDCRAFT WOODWORK, WE MAKE HANDCRAFTED TOOLS.



If you take the time to make it's time you learned about Elu Because for the first time ever, offering its line of Elu tools in the U.S. Sanders, routers, a power planer and a jointer/spliner—all with a wide range of accessories.

Take our newest plunge router, the 3338. Like all our tools, it's built for precision and accuracy.

Its case hardened, polished steel guide rods, set in bronze bushings, guarantee a perfect 90 degree entry and a consistently smooth plunge movement.

ensured constant speed under load and a fine finish. Precision-machined collets are slotted on six sides to clamp the cutter evenly and minimize vibration and runout. And like every Elu tool, our plunge router is hand

assembled in Switzerland. So you can be sure it will run like clockwork.

No wonder the name Elu has stood for high quality tools throughout Europe for the last 50 years.

© 1988 Black & Decker (U.S.) Inc.

BLACK & DECKER Tested And Trusted By The World's Finest Craftsmen.

To find out more, please write: Black & Decker, Elu Woodworking Tools, 10 North Park Drive, Hunt Valley, MD 21030.

VOLUME 12, NUMBER 5 SEPTEMBER/OCTOBER 1988

Editor and Publisher James J. McQuillan

Managing Editor Thomas G. Begnal

Associate Editor David F. Peters

Staff Editor

Thomas Clark

Art Director Dan Thornton

Illustration/Page Design Michael Gellatly Maria Meleschnig

Project Designer/Craftsman F. Phillip Bacon

Circulation/Promotion Lynne Streeter, Manager JoAnne Finkle, Subscriptions Patricia Malumphy, Distribution Maureen Murphy, Subscriptions

> Computer Operations Kathy Shook, Supervisor

Advertising Kimberly S. Gellatly, Manager

> Production Manager Jane Manley

> > Office Manager Patricia McLean

Receptionist Karen M. Roberts

Photography John Kane/Silver Sun Studios

The Woodworker's Journal (ISSN 0199-1892) is published bi-monthly in January, March, May, July, September and November by The Madrigal Publishing Co., Inc., P.O. Box 1629, New Milford, CT 06776. Telephone: (203) 355-2694.

Copyright 1988 by The Madrigal Publishing Co., Inc. No part of this publication may be reproduced by any method without permission from the publisher.

Second class postage paid at New Milford, CT 06776 and additional offices.

Subscription Rates: In the United States and its possessions — One year (6 issues) \$15.00, Two years (12 issues) \$26.00. Canada — One year 524.95 (CAD), Two years \$42.95 (CAD), Foreign countries — One year \$20.00 (USD), Two years 335.00 (USD).

To Subscribe, Renew or Change Address: Write to The Woodworker's Journal, P.O. Box 1629, New Milford, CT 06776, including mailing label for renewals and changes. For gift subscriptions, include your own name and address as well as those of gift recipients.

Postmaster: Send Change of Address to The Woodworker's Journal, P.O. Box 1629, New Milford, CT 06776.

Contributions: We welcome contributions in the form of manuscripts, drawings and photographs and will be glad to consider such for possible publication. Contributors should include a stamped, self-addressed envelope of suitable size with each submission. While we cannot assumersponsibility for loss or damage, all materials will be made upon acceptance. Address all contributions to: Editor, The Woodworker's Journal, P.O. Box 1629, New Milford, CT 06776.

U.S.A. Newsstand Distribution by Eastern New Distributors, Inc., 1130 Cleveland Rd., Sandusky, OH 44870.


DEPARTMENTS


- Shoptalk
- Letters 6
- Readers' Information Exchange
- **Events**
- 10 Cabinetmakers' Supplies Hardwood Suppliers
- 12 Woodworking Basics Why Worry About Wood Movement?
- 17 Special Techniques Joining Ring Segments
- In The Shop Drill Bits and Boring: The Hole Story
- 26 Finishing Filling Open-Grained Woods
- 40 Gift Shop
- Shop Tips

PROJECTS

- Oak Bookcase Desk
- Miter Cutting Jig
- 33 Captain's Clock
- Country Coffee Table
- 40 Rooster Folk-Art Silhouette
- 42 Harvest Basket
- Bird Push Toy
- Pencil Post Nightstand 47
- 18th-Century Pencil Post Bed









Woodbine and sumac are turning scarlet now and the afternoons are vibrant with the buzz of cicadas in the treetops. Another summer is coming to an end, and I expect that the passing of this one with its widespread drought and record heat will not be greatly mourned.

Make An Heirloom

This issue launches the Fall season with a great group of projects that I hope will keep you happily occupied for many weeks. The outstanding jewel in the crown, so to speak, is the Pencil Post Bed shown on the cover and detailed on page 50. This elegant adaptation of an 18th-century classic is one of the very few tall-post beds that can be built without the need of a large-capacity lathe.

It's also one of the few heirloom quality reproductions that can be built by woodworkers with limited equipment and experience. Careful layout of the posts, attention to grain direction, and the use of a sharp plane are the main requirements for the successful completion of this fine piece. What a wedding present this and its companion nightstand would make!

Trouble In River City

I love old woodworking books, especially the ones which date back to the late 19th or early 20th century. There's a certain no-nonsense quality to most of them that, although appropriate to that time, comes across as a bit droll in our present so-called enlightened age.

I have in hand a nice little volume called *Hand Craft Projects* by F. Solar that was written for the use of young shop students. It was published in 1921 and addresses itself only to boys, it being inconceivable at the time that girls would engage in such an unladylike activity as woodworking.

The preface states that "parents who can interest their boys in tools and let them have a shop at home, will know where to find them evenings, and many hours of worry will be saved, as the boys might be out in the streets or in the pool room."

Reading this, I couldn't help but think of Robert Preston in his great portrayal of "The Music Man," expounding to the residents of River City on the evils of pool. The reasons may be different today, but encouraging boys . . . and girls . . . to develop woodworking skills is still a very fine idea.

Country Style Projects

One of the greatest collections of Country style woodworking projects ever assembled is now available in our newest book, Country Projects for Woodworkers. There are 85 projects, from candlesticks to a hutch, selected from the 1980-84 issues of The Woodworker's Journal. The price for this handsome softcover book is only \$16.95, plus \$1.45 shipping and handling. A convenient order form can be found on page 16 of this issue.

Jim McQuillan





STRAIGHTER CUTS NO KICKBACKS NO ADJUSTMENTS KEEPS FINGERS SAFE!

The RIPSTRATE is now an indispensible tool in tens of thousands of amateur, professional, school, corporate, government and military shops. Isn't it time you joined them?



RIPSTRATE®



...ON ADVANCED LASER-CUT BLADES!

Laser Cut Blade Bodies

Laser Technology allows Freud to produce one of the quietest running, safest, and accurate running saw blades in the world.

Expansion slots on the Freud industrial saw blade are cut with a laser and are only .003 or less wide (about the thickness of a human hair). This assures tensioning strength for a true cut. It creates a quieter blade because there are no large holes or wide expansion slots for the air to whistle through. It guarantees a safer saw blade as there are no plugs in the expansion slot that can fly out when the blade is in use

With this advanced technology, all shoulders and gullets are identical in shape and most important strength. The arbor holes are perfectly centered and rounded by precision grinding. An extra step to guarantee a true running blade.

Special Carbide Mix

Freud produces a special mix of carbide at their own factory. It is produced from titanium and carbon using cobalt as a binder. Producing this important part of the saw blade within their own factory assures the consistency and quality needed to hold a sharp edge.

The carbide is induction brazed onto Freud's laser produced blade bodies. This process is computer controlled to guarantee uniformity of brazing. A razor edge is then put on the teeth with a 400 grit diamond wheel. This guarantees you of a blade that will provide a maximum of production hours before sharpening is needed.

Item No.	Diameter	Teeth/ Grind	General Purpose	Cross Cut Wood	Plywood	Plastic	Rip Wood	List	Sale
LM72M008 LM72M010 LM72M012	8 10 12	24 Rip 24 Rip 30 Rip	NR	NR	NR	NR	E	68.48 77.93 104.03	51.48 50.68 65.98
LU78M008 LU78M010 LU78M012 LU78M014	8 10 12 14	64 TCG 80 TCG 96 TCG 108 TCG	G	G	E	E	NR	112.57 140.63 169.29 199.80	93.98 104.48 135.68 141.98
LU84M008 LU84M009 LU84M011 LU84M012 LU84M014	8 9 10 12 14	40 Comb 40 Comb 50 Comb 60 Comb 70 Comb	E	G	G	NR	G	85.96 85.31 89.54 135.31 161.34	59.58 59.58 52.18 97.98 116.48
LU85M008 LU85M009 LU85M010 LU85M012 LU85M014	8 9 10 12 14	64 ATB 72 ATB 80 ATB 96 ATB 108 ATB	NR	E	G	G	NR	112.08 122.56 133.25 161.40 179.06	73.98 76.98 85.58 114.98 124.88

E=Excellent G=Good F=Fair NR=Not Recommended 8'', 9'', and 10'' have 5/8'' Bore. 12'' and 14'' saws have 1'' Bore.

..ON ADVANCED LASER-CUT DADO SETS!



A 18 18 18 18 18 18 18 18 18 18 18 18 18		Bore	List	Sale
DS306	6" set	5/8"	176.54	110.98
DS308	8" set	5/8"	216.18	118.98

Freud Carbide Tipped Dado Sets will produce a smooth and accurate groove when cutting either with or across the wood grain. Properly stressed and tensioned outside blades feature extremely sharp and steeply beveled carbide teeth that leave clean edges.

The laser cut blade bodies ensure the

quietest running dado you can buy.
The 4 chippers and 2 outside blades
can cut a width up to 13/16 of an inch. Can
be used on softwood, hardwood and
veneered plywoods with excellent results.



218 Feld Ave., High Point, NC 27264 (919) 434-3171 1570 Corporate Drive, Suite G Costa Mesa, CA 92626 (714) 751-8866



Letters

The Miter Gauge Stop in your May/June 1988 issue was an excellent idea. There is, however, another good use for it. By shortening it to $3\frac{1}{2}$ in., I found that it can be used as a fence stop on my radial-arm saw.

Wilson E. Ayers, Norfolk, Va.

In the "Letters" section (page 6) of your July/August 1988 issue, a reader wrote saying "... the best book that's available today for puzzle enthusiasts is Puzzles Old And New, How To Make And Solve Them by Jerry Slocum (University of Washington Press, \$19.95)." However, you didn't tell us where to order it.

R.W. Terrell, Branford, Conn.

The book can be ordered through your local bookstore. Just tell them the title, author, and publisher.

The May/June 1988 issue featured plans for a Bud Vase. One reader (see "Letters", July/August 1988 issue) modified it to accept PVC tubing and a

rubber stopper so that the vase could be filled with water without affecting the wood. Back about 1935, when I took a high school woodturning class, we found glass test tubes worked nicely for this same application.

R.L. Rosecrans, Miami, Fla.

If you make the Bud Vase slightly bigger, and bore a $\frac{7}{16}$ in. diameter center hole, a $\frac{3}{8}$ in. diameter test tube will work just fine. There was a time when you could buy a test tube at just about any pharmacy, but not so any more it seems. Some hobby shops carry them, but it may take some searching. Perhaps our readers can tell us of a mail-order source?

I recently completed the Oak Magazine Rack project on page 30 of your July/August 1988 issue. I'm very happy with the results and plan to make a couple more as gifts. However, I did notice a mistake. On the Bill of Materials, the bottom (part E) is

shown as $\frac{3}{4}$ in. thick. It should be $\frac{1}{4}$ in. thick.

Bill Phares, San Diego, Calif.

The Kansas City Woodworkers' Guild, 3023 Holmes Street, Kansas City, MO 64109 meets the second Wednesday of each month. All interested are welcome to attend. Call Bob Hoffman (816) 756-0128 for more information.

I'd like to use eastern white pine for many of my projects, but living in Texas I can only get western ponderosa pine. Can you give me the name of a supplier?

James R. Woehr, Richardson, Tex.

The Craftsman Lumber Company, Box 222, Groton, MA 01450 sells eastern white pine and will ship anywhere in the country. Unfortunately, we don't know of a source that's closer to Texas. You might try writing to a few of the hardwood dealers we've listed in our Cabinetmakers' Supplies



column on page 10. Some of them carry softwoods, so with a little luck you may be able to find a source closer to home.

Thanks for the Workshop Layout article in your July/August 1988 issue. As a newcomer to woodworking, I was afraid a subject as basic as this would be old hat to your magazine.

Everett G. Sillers, Catonsville, Md.

I bought a Porter Cable 7548 jigsaw based on the glowing recommendation you gave it in your shop test in the September/October 1987 issue. What a mistake! Those clever side bearings don't even come close to the blade and, according to Porter Cable, they aren't supposed to. The ram shaft fits in its bushing with all the tolerance of a broom stick in a toilet paper roll. Even with a fence it will not cut a straight line, and the slightest side pressure causes an angled cut. I can only conclude that: 1. You were paid hand-

somely to do the test; 2. You never saw the jigsaw, but relied on Porter Cable's public relations for your information instead; or 3. Porter Cable gave you the only one that worked.

Wayne Kytola, Wright, Minn.

We can understand your disappointment, although we are at a loss to explain why your saw did not measure up to the one we tested. We still feel the Porter Cable 7548 is an excellent jigsaw. We've had other readers tell us that the article prompted them to buy this saw and they are very satisfied with the tool. Like most jigsaws, the Porter Cable works best when used for what it's designed to do, and that's to cut freehand curves. This may explain why it did not cut a particularly good straight line for you, even with a fence. If a perfectly straight line is what you want, a table saw, radial-arm saw, or circular saw will do a better job.

Neither Porter Cable nor any other manufacturer has ever paid us to do a

product test. Although the jigsaws were provided to us free of charge by each of the manufacturers, it was with the clear understanding that — good or bad — we would "call them as we saw them" based on our tests. And that's what we did. Some saws, like the Porter Cable 7548, got good marks, others not so good.

Every jigsaw was tested. We did not base our decisions on any manufacturer's public relations information. The tests were done in our workshop by associate editor David Peters and designer/craftsman Phil Bacon.

As far as getting the only one that worked goes . . . well, we just aren't that lucky. However, it is possible that you were unlucky enough to get a defective saw. If that's the case, you could expect that Porter Cable would repair or replace it. We suggest you contact your nearest Porter Cable dealer. If the dealer can't or won't help you, then write directly to Porter Cable.

CABINETRY and ASSEMBLY TECHNIQUES

... Now in Video Tape!

Now you can improve your woodworking skills for professional results \dots at home and at your own pace.

This two-hour video is presented by John Parko, a woodworking expert and an experienced high school and adult education shop teacher. He will teach you the techniques that are used most often to build furniture, cabinets, chests and many other popular wood projects — using frame and panel construction. John will guide you through basic Cabinetry such as blade selection, gluing and clamping, and then on to advanced techniques of cove and tenon cuts and cutting raised panels, using the table saw as the major power tool. Unlike other video programs, this woodworking video covers a project from start to finish (including staining). Not only will you learn the proper techniques of frame and panel construction (by watching John build the Blanket Chest shown), but also all the critical woodworking know-how of assembly for professional results. With what you'll learn, you will be able to apply that knowledge to build the chest and many other wood projects of your choice. Printed chest plans are included free!

Best indication of the production quality of this tape is the fact that hundreds of high schools, vo-techs and universities are now using it in instructional settings.


in this tape is the fact that hundreds of high schools, vo-teens and shall settings.

Don't delay, send \$29.95 plus \$3.00 shipping

ROGA ENTERPRISES INC.

for your personal video cassette on woodwork-

P.U. DUX 2	2743J	CODT,	W 1 02414
MASTERCAR	(D	UVISA	CHECK
Acct. No.			Exp.
Signature			
Name			
Address			
City	State _		Zip




DOOR HARPS ANS & K

WHAT'S A DOOR HARP?

Mounted on the inside of your door, a door harp will welcome your guests with a beautiful musical tune each time the door is opened. You'll find it easy to build these door harps in your shop using only standard 3/4" stock and our special Hardware Parts Kits.

Order the project plan and the hardware parts kits below.



DOOR HARP PLANS

You'll find our jumbo 22" blueprints very clear and easy to follow. Full step by step instructions explain every step. All drawings are FULL SIZE.

#W263 Raccoon plan	\$3.50/EA
#W264 Panda Plan	\$3.50/EA
#W265 Owl Plan	\$3.50/EA
#W266 Frog Plan	\$3.50/EA
#W267 Hog Plan	
#W270 Package of all 5 d	
plans above	\$12.99/EA

HARDWARE PARTS KITS

These kits contain the hard to get parts special high resonance plywood, tuning pins, clapper balls, music wire and plastic eyes. You need to supply some 3/4" stock, and the paint.

Plan is not included with kit, order seperately above.

#7765	Raccoon HDW Kit	\$6.50/EA
#7766	Panda HDW Kit	\$5.50/EA
#7767	Owl HDW Kit	\$7.50/EA
#7768	Frog HDW Kit	\$6.50/EA
#7769	Hog HDW Kit	\$6.25/EA

ADD SHIPPING & HANDLING:

DID STIPP'ING & HANDLING:
Mail check or money order and include
\$3.50 shipping & handling. MN Res. add 6%
tax. Alaska and Hawali send \$9.50 p&h.
Canada send \$15.50 (U.S.) p&h. We accept
VISA or MC on orders over \$25.00.

Phone toll free 1-800-441-9870. MN Res. call (612) 471-8550. Catalog \$1.00 or FREE with order.

MEISEL HARDWARE SPECIALTIES P.O. BOX 70J-10 MOUND, MN 55364

Readers' **Information Exchange**

Looking for an owner's manual for an old band saw? Need a bearing for a handme-down table saw? Can't find a source of supply for an odd piece of hardware? Maybe our readers can help. Send along your request and we'll try to list it here and perhaps one of our readers will have an answer for you. Due to space limitations, we'll be unable to list all requests, but we'll include as many as we can.

I have been looking for several years for a Dremel Motosaw — the motorized coping saw which Dremel manufactured — and would appreciate hearing from anyone having one in working order which they would sell to me.

> Stacy E. Dolby 1113 South Fifth St. DeKalb, IL 60115

I need a 6 in. power disk sander accessory for a Shopcraft 14 in. commercial band saw.

Joe Lyons 204 University Blvd., West Silver Springs, MD 20901

I would like to purchase a wood 5-foot frame ladder that comes apart and has a back section that can be extended something like a five-way ladder. I would like to know where I can find one. John Marzano

100 N. Kensico Ave. White Plains, NY 10604

I'm writing to see if anyone knows where I can get plans or information on a two-passenger paddle boat. Any help would be appreciated.

> Jerry Billings 2560 N.E. 52nd St. Des Moines, IA 50317

My father, a lifetime carpenter, has a set of books that I'd like to find for myself. The books are a four-volume set titled Audel's Carpenter's and Builder's Guide, copyright 1923, 1939, 1945, 1951 by Teo. Audel and Co., New York, N.Y.

Kevin Preston 346 Drury Lane Huntsville, AL 35802

I need a front trunnion for a Delta 10 in. table saw, model TCS.204. Any help will be appreciated.

> Andy D. Miller R. 2, 17528 Kinsman Road Middlefield, OH 44062

Owner's Manuals and Parts Lists

RFD 2, Box 250, Bedford, NY 10506
Craftsman table saw, model 113.298051
Craftsman piston sprayer, model 283.1431
Sears 12 in. scroll saw, model 103.21790
Craftsman 10 in. table saw, model 113.27520 Craftsman shaper, model 103.23921 Craftsman radial arm saw, model 113.29411
Rockwell (Delta) jointer, model BF2180
Montgomery Ward Powr-Kraft lathe, model FD2002A

Craftsman 10 in. radial arm saw, model 113.63165 James J. Kasten

WM

The Woodworker's Journal

P.O. Box 10222, Portland, OR 97210

P.O. Box 452, Hallstead, PA 18822



We will gladly list as many events of interest to woodworkers as space permits. Listings are free and may include shows, fairs, competitions, workshops and demonstrations. The deadline is 60 days before publication, Sept. 1 for the Nov./Dec. issue; Nov. 1 for the Jan./Feb. '89 issue. Please address announcements to the Events Department.

Arkansas:

2nd Annual Turned Wood Objects Show, Oct. 1-Nov. 6, Gallery B, 11121 Rodney Parkham Road, Little Rock.

California:

National Working with Wood Show, Sept. 9-11, San Mateo Fairgrounds, San Mateo.

San Diego Woodworking Show, Sept. 23-25, Del Mar Fairgrounds, Crosby Hall, 2260 Durante Blvd., Del Mar.

North California Woodworking Show, Oct. 7-9, Brooks Hall, 99 Grove St., San Francisco.

Southern California Woodworking Show, Oct. 28-30, Los Angeles County Fairgrounds, Building 5, Pomona.

Connecticut:

Brookfield Craft Center, P.O. Box 122, 286 Whisconier Road, Brookfield. Fall programs: Woodturning Workshop, Sept. 19-21; Hand Joinery, Oct. 1-2; Furniture from the Lathe, Oct. 15-16; Solid Wood Furniture Construction, Oct. 22-23; Turned and Carved Bowls, Nov. 5-6; Design for Furniture, Nov. 12-13.

Georgia:

The Creative Arts Guild of Dalton Festival '88, Sept. 24-25, 520 West Waugh St., Dalton.

Illinois:

Woodworking World — The Chicago Show, Oct. 7-9, The Metro Center. Rockford.

Indiana:

National Working with Wood Show, Oct. 21-23, Indiana State Fairgrounds, Indianapolis.

Louisiana:

13th Annual Fall Crafts Festival, Oct. 21-23, North Blvd., Baton Rouge.

Maryland:

Baltimore-Washington Woodworking Show, Sept. 16-18, Baltimore Convention Center, Festival Hall, Baltimore.

Massachusetts:

Woodworking World — The New England Show, Oct. 21-23, Eastern States Exposition Center, Springfield.

The Greater Boston Woodworking Show, Sept. 30-Oct. 2, Royal Plaza Trade Center, 181 Boston Post Road West, Marlborough. September/October 1988

Michigan:

National Working with Wood Show, Oct. 7-9, Michigan State Fairgrounds, Detroit.

The Twin Cities Woodworking Show, Sept. 9-11, St. Paul Civic Center, St. Paul.

New York:

Woodworking World - The New York Show, Sept. 23-25, Westchester County Center, White Plains.

Constantine's Woodworking Classes, 2050 Eastchester Road, Bronx: Veneering, Sept. 7, 10, 14, 17; Basic Woodcarving, Oct. 1, 8, 15; Wood Finishing and Refinishing, Oct. 5, 12; Intermediate Woodcarving, Oct. 12, 19, 26; Chair Caning and Rush Seating, Oct. 22, 29.

North Carolina:

Woodworking World - The Carolina Show, Sept. 30-Oct. 2, The Merchandise Mart, Charlotte.

John C. Campbell Folk School, Brasstown. Fall courses: Woodworking, Sept. 18-24; Woodcarving, Oct. 7-9; Log Cabin Building, Oct. 30-Nov. 12.

Southern Highland Handcraft Guild, 41st Annual Guild Fairs, 1988, Oct. 21-23, Asheville Civic Center, Asheville.

The Penland School, Penland. Fall courses: Timber Frame Construction, Sept. 19-30; Focus on the Table, Oct. 3-14; From Concept to Completion, Oct. 17-28.

Woodworking World - The Cleveland Show, Oct. 28-30, International Exposition Center, Cleveland.

Pennsylvania:

The International Turned Objects Show, Sept. 17-Nov. 13, Port History Museum, Philadelphia.

Pittsburgh Tri-State Woodworking Show, Oct. 14-16, Expo Mart, East Hall, 105 Mall Blvd., Monroeville.

Olde Mill Cabinet Shoppe, RD 3, Box 547, Camp Betty Washington Road, York. Fall workshops: Tage Frid on design and woodworking, Sept. 9-11; Michael Dunbar on making a continuous arm Windsor chair, Sept. 24-25.

Wisconsin:

National Working with Wood Show, Oct. 28-30, Mecca Center, Milwaukee.

Your home



PLANE • MOLD • SAW • SAND

Four power tools in one — a real money-maker for you!

The Planer/Molder/Sander/Saw is a versatile piece of machinery. It turns out profitable precision molding, trim, flooring, furniture... in all popular patterns. Rips, planes, molds, sands separately... or in combination. Used by individual home craftsman, cabinet and picture framing shops, lumberyards, contractors and carpenters.

Never before has there been a fourway, heavy-duty woodworker that does so many jobs for so little cost. Saws to width, planes to desired thickness, and molds to any choice of patterns. Sands to a satin smooth finish. Provides trouble-free performance. And is so simple to operate even beginners can use it!

30-Day FREE Trial! EXCITING FACTS NO OBLIGATION-NO SALESMAN WILL CALL

RUSH COUPON TODAY!

Foley-Belsaw Co. 6301 Equitable Rd. Dept. 91354 Kansas Clty, Mo. 64120

F	[1] [1] 63	ley-Belsa 01 Equita	ble Rd.	FREE	
<u> </u>		pt. 91354 nsas Cit		120 BOO	
	S, please se				
er-h	es me com Molder-San	oiete jaci der-Saw	s about and full	details of	ı- n
hou	l can que	alify for a	i 30-Day	Free tric	ıl
	it in my ow			ana there i lesman wi	
No	Obligation	ana ina	INO Sai	esman wi	u
No call		ana ina	i wo sai	esman wi	11
		ana ina	ivo sai	esman wi	
call		ana ina	NO Sui	esman wi	_
call		ana ina	i wo sui	esman wi	_
call Name		ana tna	- NO Sui	esman wi	_
call		ana ina	W Sui	esman wi	



 \mathbf{W} rite today to start your FREE two-year subscription. Complete selection of all kinds of woodworking tools, competitive prices and fast, friendly service have made Woodworker's

Supply of New Mexico the preferred source for professional woodworking tools and supplies.

☐ Please start my two-year subscription.		
Name		
Address _		
City	State Zip	

Woodworker's

5604 Alameda Płace, NE • Dept WJ5 Albuquerque, NM 87113 • 505-821-0500

1-800-645-9292

ANYTIME ANYWHERE **ANYWOOD**

mold plane and edge



Professionals and hobbyists alike know the strengths of the W&H molder-planer. Superior US-made construction and quick two-minute cutter changes make it a snap to cut moldings and plane hardwoods. It's fast, easy, and

Our five-year warranty and free 30-day trial are your assurance that W&H goes

Mail this ad or call us toll-free today. 1-800-258-1380 In NH 603-654-6828

Williams & Hussey P.O. Box 1149, Dept. 188IM Wilton, NH 03086

YES! Send	you	r free
information	kit	today.

nformation kit today.	
lame	
Address	

State .



Cabinetmakers' Supplies

Hardwood Suppliers

As a service to our readers, we periodically list sources for various woodworking products. In this issue, we are listing companies that sell hardwood lumber in large and small quantities via mail order. This is by no means a complete listing, and we hope to include additional companies in future issues.

American Woodcrafters

1025 S. Roosevelt Ave. Piqua, OH 45356 Domestic, imported

Arroyo Hardwoods

2585 Nina St. Pasadena, CA 91107 Domestic, imported

Austin Hardwoods

2119 Goodrich Austin, TX 78704 Domestic, imported

Berger's Hardwoods

Route 4, Box 195 Bedford, VA 24523 Domestic

Colco Fine Woods & Tools

P.O. Box 12449 2631 Jackson Ave. Memphis, TN 38182-0449 Domestic, imported

Maurice L. Condon

250 Ferris Ave. White Plains, NY 10603 Domestic, imported

Craftwoods

109 21 York Road Cockeysville, MD 21030 Domestic, imported

Croffwood Mills

Rt. 1, Box 38-J Driftwood, PA 15832 Domestic

Croy-Marietta Hardwoods, Inc.

121 Pike St., Box 643 Marietta, OH 45750 Domestic

Dimension Hardwoods, Inc.

113 Canal St. Shelton, CT 06484 Domestic

Educational Lumber Co.

P.O. Box 5373 Asheville, NC 28813 Domestic, imported

Eisenbrand Inc. Exotic Hardwoods

4100 Spencer St. Torrance, CA 90503 Domestic, imported

General Woodcraft

531 Broad St. New London, CT 06320 Domestic, imported

Henegan's Wood Shed

7760 Southern Blvd. West Palm Beach, FL 33411 Domestic, imported

Kaymar Wood Products

4603 35th S.W. Seattle, WA 98126 Domestic, imported

Kountry Kraft Hardwoods

R.R. No. 1 Lake City, IA 51449 Domestic

Leonard Lumber Company

P.O. Box 2396 Branford, CT 06405 Domestic, imported

McFeely's Hardwoods & Lumber

712 12th St. Lynchburg, VA 24505 Domestic, imported

Sterling Hardwoods, Inc.

412 Pine St. Burlington, VT 05401 Domestic, imported

Talarico Hardwoods

RD 3, Box 3268 Mohnton, PA 19540-9339 Domestic, imported

Wood World

1719 Chestnut Glenview, IL 60025 Domestic, imported

Woodworker's Dream

P.O. Box 329 Nazareth, PA 18064 Domestic, imported



GRIZZLY IS NUMBER ONE!

If you have ever wondered, like a lot of our competitors, why we have established ourselves as the largest mail-order wood-working machinery dealers in the U.S.A., then consider this:

Honest, across-the-board dealings.

High quality merchandise at the lowest possible prices.

Tested, quality motors and switches on all machinery.

- Constant monitoring of quality, both overseas and locally.
- Huge stock of merchandise at our 2 large warehouses.

Same day shipping on 95% of the orders.

 Large quantities imported directly from the factories and sold directly to the end users.

Large inventory of parts with qualified service personnel at both locations

 And last, but not least, courteous operators who always treat you with the respect you deserve, making shopping at Grizzly a pleasure!

If you have bought from us before, you will recognize the above points, but if you haven't tried us, then we're all losing out. Our past customers make our best references!

WE HAVE THE HOTTEST MACHINES AT THE LOWEST PRICES:

15" Planer




Model G1021 SPECIAL PRICE \$695.00

20" Planer



Model G1033 Regularly \$1295.00 SPECIAL \$1175.00

10" Tablesaw



Model G1022 Regularly \$365 SPECIAL \$325.00

16" Bandsaw

LOOK -

1 yr. warranty on motors

Plus an in-house motor

rewinding shop!



Model G1538 ONLY \$495.00

6" Jointer



Model G1182 Regularly \$335.00 SPECIAL \$310.00

8" Jointer



Model G1018 Regularly \$665.00 SPECIAL \$625.00

3-HP Shaper



Model G1026 ONLY \$850.00

(All above prices are F.O.B. Williamsport, PA or Bellingham, WA)

EXPECT EXCELLENCE!

Our full color catalog (also the best in the industry) is FREE — call us.


P.O. Box 2069
Bellingham, WA 98227
(206) 647-0801



East of the Mississippi contact: 2406 Reach Road Williamsport, PA 17701 (717) 326-3806

88-155

Why Worry About Wood Movement?




As we observe the way things constructed of solid wood are built, a certain pattern emerges. We note that wide doors are usually constructed using a frame and panel, rather than a single board; we see that case pieces, such as chests of drawers, are constructed with the grain of the sides and top all running in the same direction; and we observe that backs and drawer bottoms are often made of plywood.

The chief reason things of wood are built in specific ways is wood movement. Unlike some other mediums, wood is not stable. It expands and contracts as it responds to the relative humidity. Understanding how wood moves, how much it moves, and the relationship of this movement to geographic location and season is essential if you want the things you build to last.

Free Water and Bound Water

Wood is sensitive to changes in humidity because of its cellular structure. If you compared a piece of wood to a sponge, you would see that wood is made up of vessels, or cells (Fig. 1). When the wood is green, as in a living tree, the cells are filled with the liquid sap of the tree. The water that fills the cell cavities is known as free water.



Once the tree has been cut, and the kiln or air drying begins, the free water begins to evaporate. The wood is like a sponge that has been wrung out; it remains damp, and retains its shape. The water that had filled the cell cavities is gone, but the water within the cell walls, called bound water, remains. Just as a damp sponge shrinks as it dries out, wood shrinks when the bound water is removed through further kiln or air drying. All but about 6 to 8 percent of the moisture content of the wood is removed through kiln drying, which results in a fairly stable material for cabinetmaking. If you compare the rigidity of a dried out sponge to one that is damp and flexible, it is easy to see why woodworkers prefer well-dried wood. Conversely,

for bending, moisture must be added to the wood to make it flexible.

Bound water is lost or gained as a consequence of the surrounding environment. When wood is stickered and left to dry for several years in a shed, bound water is lost, though not as quickly as when dried in the artificial environment of the kiln. Similarly, wood that has been kiln or air dried (and perhaps by now built into furniture) can also gain moisture. During the summer in New England, for example, when the relative humidity outdoors may be 70 percent or more, the equilibrium moisture content (EMC) of wood may increase to 14 percent from its 6 or 7 percent EMC during the winter months, when indoor relative humidity is much lower.


Equilibrium moisture content is important to understand, because it is the cause of wood movement. Basically, the EMC is the moisture content of a given piece of wood when it has acclimated to the environment in which it is placed. In an area where the relative humidity is high, the EMC will be correspondingly high, whereas in the desert, or another place of relatively low humidity, the EMC will be low. EMC is not so much a factor in areas where the relative humidity is stable

year-round, but it does become a concern in places where there are wide swings in the relative humidity during the summer and winter. Since it takes wood time to come into equilibrium with changes in the relative humidity, the wood movement will be most pronounced at the end of summer or winter. Immediately after the relative humidity changes, there will be only a minimal reaction in the wood, mostly on the surface, since several months are required before the entire piece attains EMC with the new relative humidity in the surrounding atmosphere.

While this may sound somewhat technical, a little further along, after we look into how wood moves, we'll provide examples of exactly how these theories apply to woodworking.


The Way Wood Moves

The section of a tree trunk (Fig. 2) illustrates the three directions of wood movement. First, there is longitudinal movement (with the grain). In kiln dried wood, such movement is considered negligible, so we need not allow for it. Next there is tangential movement, which occurs around the concentric circles that make up the trunk. parallel to the growth rings. This is the direction of maximum movement and




has the greatest affect on boards that are flatsawn (Fig. 3). Finally, there is radial movement, which occurs perpendicular to the growth rings and is usually no more than one-half the tangential movement.

Fig. 4 illustrates a flatsawn board and a quartersawn board. As you can see, the flatsawn board has its maximum movement across the width. If you need a piece of wood where the movement across the width must be kept to a minimum, you could use a




quartersawn board. In special situations, where movement across the width is critical, we often see quartersawn stock specified. Soundboards on stringed instruments are often made of quartersawn Sitka spruce, which has very little radial movement.




Wood movement affects all wood, no matter what the shape. For example, in Fig. 3, a square changes to a slightly diamond shape as the wood moves, and a circle becomes slightly oblong. We've probably all seen dowels that had once fit tightly in their holes, but now have gaps on the sides. It is for this reason that we rarely specify dowel joinery. Over the years, as the dowels change in shape, the glue around them fails, and the piece weakens. Though the effect may be negligible at the start, as time goes by, the weakening of the joints is cumulative and can lead to the rickety old pieces that we've all seen.


Practical Applications


We've established that wood moves, and we understand the why and how of it. But what does this mean to the woodworker?





First, it means that construction must always allow for wood movement. For example, in a four-sided carcase, the sides will usually be oriented so the grain is running in the same direction (Fig. 5A). If a base is added







(continued on page 15)

13







Hand binde 12 iss open easy and a availa two s overs back up th Ian/Feb 1986;

and standard size for our more recent issues from Mar/Apr 1986 on. \$9.95 each or 3 for \$27.95. Compact box cases also come in both sizes. \$7.95 each or 3 for \$21.95.

Isome ers hold sues, I flat for reading, are able in sizes: size for issues irough	Whodworker's	


Please send your order with payment to: JESSE JONES INDUSTRIES, Dept. WWJ, 499 Erie Avenue Philadelphia, PA 19134.
Enclosed is \$ Add \$1 per unit Postage and Handling. Outside U.S.A. \$2.50 (U.S. currency only). PA residents add 6% sales tax.
Specify size: Standard (Vol. 10 No. 2 - present) Oversize (Vol. 4 No. 5 - Vol. 10 No. 1)
Please send Binders; Cases for The Woodworker's Journal. Binders: 1 - \$9.95 3 - \$27.95 6 - \$52.95 Cases: 1 - \$7.95 3 - \$21.95 6 - \$39.95
Name (Please Print)
Street
City
State/Prov
Zip/Postal Code


Woodworking Basics

Continued

to the carcase, it should be attached with slotted holes and screws (Fig. 5B), so that it does not restrict the movement of the bottom. If glue were used instead of slotted holes, then as the bottom of the carcase contracted, it would probably split, or the glue joint would fail (Fig. 5C). If a single board were used for the door, it could contract across its width in relation to the carcase and leave a gap (Fig. 5D), or it could expand and jam against the sides (Fig. 5E).

A properly constructed frame and panel (Fig. 6) takes several factors into







account, including the season, the moisture content of the wood, and the geographic location, and therefore accommodates whatever movement might occur across the width of the panel. If we look closely at a typical frame and panel, which utilizes a groove in the stiles and rails in which the panel is free to "float," we'll see that these three variables are what will determine how the panel is sized.

First, we'll assume that the wood used to build the frame and panel has been kiln dried, and then allowed to acclimate in the workshop and reach the EMC of the surrounding air. In the summer in New England, this moisture content will be about double what it is in the winter, meaning that the board selected for the panel would probably be as wide as it would ever be.

In constructing the frame and panel in New England during the summer, the panel would be sized so that it is almost the actual groove-to-groove dimension across the width of the frame. In the example shown in Fig. 7A, the stiles and rails of the frame are 2 in. wide, with ½ in. deep grooves for the panel, which means that the panel should be about $14\frac{7}{8}$ in. wide.


If the same frame and panel were built in New England during the winter, the panel would probably be as narrow as it would ever be. Therefore it should be sized to allow for the ex-






pansion that will occur during the summer. Over a panel that is roughly 14 in. wide, an increase of as much as $\frac{3}{8}$ in. in the panel width can be anticipated. As illustrated in Fig. 7B, the panel is $14\frac{1}{2}$ in. wide, which will allow $\frac{1}{4}$ in. on either side for expansion.

You'll note that the panel is pinned at the center to the rails, top and bottom, so the movement is equalized to both sides. If the panel were not pinned, all the movement might occur to one side, creating a gap on the other side.





If the seasons were not taken into account, and a panel were sized for an exact fit in the winter, then it could force the frame apart come summer (Fig. 7C). Or, building the piece in the summer with the panel sized 14½ in. could result in gaps opening on either side during the winter (Fig. 7D).


In anything you build, think about the possibilities for wood movement before you begin, and be sure to allow for it.

Cascade Precision Tool Co. Box 848. Mercer Island. WA 98040

"Custom Grinding a Specialty"

BEST FACTORY-DIRECT

PRICES ON PROFESSIONAL QUALITY CARBIDE-TIPPED SRBAND **ROUTER BITS & SHAPER CUTTERS!** SEND \$1.00 (Refundable with first order) FOR OUR NEW 12-PAGE CATALOG FEATURING A GREAT SELECTION LIKE THESE:



CARBIDE TIPPED SHAPER CUTTER PANEL RAISER -

3 WING, 5 PROFILES, 3MM THICK CARBIDE . 4-5/8" O.D. with 3/4" BORE (1/2" BUSHING)













6 PC CARBIDE TIPPED CABINET SETS

3 mm CARBIDE 3/4" BORE W/ 1/2

ONLY \$179.95

13 Great Cabinet Sets including these popular Profiles:

(1-1/4" Bore with 1"Bushing— ONLY \$249.95)













Big 3-1/2" O D. 3 pc. set ONLY \$17995 RAIL/STILE CUTTER RAIL END CUTTER
 PANEL RAISER ALONE

\$5995





FOR THE SHAPER

3 mm thick C-2 carbide, 3/4" Bore w/1/2" Bushing Straight



SY-1212-1 SY-1212-4 1/4" \$24.95 3/4" \$32.95

SY-1212-5 SY-1212-2 3/8" \$26.95 1" \$35.95

SY-1212-3 1/2" \$28.95

Flute



SY-1223-1 SY-1223-4 1/4" \$24.95 3/4" \$32.95

SY-1223-2 SY-1223-5 3/8" \$26.95 1" \$35.95

SY-1223-3 1/2" \$28.95

Bead



SY-1224-1 SY-1224-4 1/4" \$24.95 3/4" \$32.95


SY-1224-2 SY-1224-5 3/8" \$26.95 1" \$35.95

SY-1224-3 1/2" \$28.95

Dovetail

	PART NO.	D	PRICE
	804	1/2	\$6
1 1 1	* 8041/2	1/2	\$6
	806	9/16	\$8
В	810	3/4	\$8
	*8101/2	3/4	\$8
I A C	8121/2	1	\$10

	FI	ush Tr	imn	nino
	þ	PARTINO.	А	PRICE
		S8012Y	3/8	\$7
1 72	-	S8016Y	1/2	\$8
		S8016Y 1/2	1/2	\$8
HIII	8	\$8020	5/8	\$10



\$80201/2

Corner Round



SY-1225-1 SY-1225-4 3/4" R \$35.95 1/4"R \$24.95

SY-1225-2 SY-1225-5 3/8" R \$26.95 1"R \$49.95

SY-1225-3 SY-1225-6 1/2" R \$28.95 11/4" R \$49.95

FOR THE ROUTER!

Cove Bits



PART NO.	Α	PRICE
\$702Y	1/16	\$11
\$70.4Y	1/8	\$11
\$7064	3/16	\$11
\$708Y	1/4	\$12
S710Y	5/16	\$12
\$712Y	3/8	\$12
S716Y	1/2	\$13
' \$716Y1/2	1/2	\$14

Roundover PART NO.



\$10

S502Y	1/16FI	\$10
S504Y	1/8FI	\$10
S506Y	3/16R	\$10
\$508Y	1/4FI	\$10
S510Y	5/16R	\$11
\$512Y	3/8R	\$13
\$516Y	1/2R	\$15
* S516Y1/2	1/2R	\$15
* S520Y1/2	5/8R	\$18
* S524Y1/2	3/4Pl	\$18
\$528Y1/2	7/8R	\$30_
· S532Y1/2	1R	\$30
· SE36Y16	1.1/API	\$38

Core Box



PART NO.	Α	PRIC
S408	1/4	\$9
8412	3/8	\$10
5416	1/2	\$11
\$420	5/8	\$12
\$424	3/4	\$14
54241/2	3/4	\$14
34321/2	1	\$15

Beading



PAHT NO.	A	PRICE
S602Y	1/16R	\$11
S604Y	1/8R	\$11
S506Y	3/16F	\$11
S608Y	1/4B	\$12
\$610Y	5/16R	\$13
S612Y	3/8R	\$15
\$616Y	1/2R	\$15
S616Y1/2	1/2R	\$15
\$624Y1/2	3/463	\$18

Bull Nose PARTNO



PART NO.	A	PHICE
SY9-1	1/4	\$12
SY9-11/2	1/4	\$12
SY-9-3	3/8	\$14
SY\$ 31/2	3/8	\$14
Sya-a	1/2	\$14
9Y9-41/2	1/2	\$14
5Y9-5	5/8	\$15_
SY9-51/2	5/8	\$15
\$Y9.5	3/4	\$16
SY9-61/2	3/4	\$15
* SY9.81/2	1	_ \$17
- SY9-91/2	1-1/8	\$25
SY9-161/2	1-1/4	\$30
579-11/2	1-1/2	_\$38

Roman Ogee



PART NO.	A	PRICE
\$5705Y	5/32_	\$15
55705Y1/2	5/32	\$15
96708Y	1/4	\$16
\$5708Y1/2	1/4	\$16

Slot Cutter - 4 Flutes



PART NO.	Α	PRICE
SY7002	1/8	\$20
SY700/21/2	1/8	\$20
SY7004	5/32" (4mm)	\$20
SY70041/2	5/32" (4mm)	\$20
\$77006	3/16	\$20
5Y70061/2	3/16	\$20
5Y7008	1/4	\$20
5.4300@1/5	1/4	\$20

Slot Cutters/ Rabbeting Bit



PART NO.	В	PRICE
S1702Y	1/16	\$10
S1794Y	1/8	\$10
\$1704Y1/2	1/8	\$10
\$1706Y	1/4	\$11
S1706Y1/2	1/4	\$11
\$1708Y	3/8	\$11
\$170891/2	3/8	511
31712Y	1/2	912
51712Y1/2	1/2	\$12

MC / VISA / COD USERS ORDER TOLL FREE 1-(800)-235-0272 IN WASHINGTON STATE CALL 1-236-0272 10 AM - 7 PM - Monday through Saturday

MasterCard

Special Techniques

Variations of the segmented ring technique appear in everything from whiskey kegs to jewelry boxes, and from ships' wheels to picture frames. The basic technique also goes under several names. It's called stave construction when used for coopered barrels, and segmented ring construction when used to build up a turning blank for a bowl or vessel. But no matter what you call it, you're joining equal segments at a set angle to make a box or frame with a particular number of sides.

One main advantage of the technique is the phenomenal number of shapes possible with segments: pentagons and octagons and circles; cylinders and barrels; even cones and spheres. The segments can be joined side-to-side as in barrels or end-to-end as in frames and wheels. They can also be joined in flat sections, and then laminated with other sections to make three-dimensional forms such as cones and spheres.


The technique of joining ring segments is often used to make turning blanks for large containers. We used it to make the blanks for the case and bezel of the Captain's Clock on page 33


Crucial for all the ring techniques is the basic joinery involved in making a multi-sided object from straight sections of wood. Once you've mastered that, it's relatively easy to build up complex shapes.

Two Miters

There are basically two types of operations used to join sections: one where the sections are joined with the angle running across the width of a board, and one where the angle runs across the thickness of a board. Examples of the first — using a 45-degree miter for illustration — are simple picture frames or the trim around windows (Fig. 1A). Another example is the eight-sided turning blank for the bezel (sometimes called the face) of the Captain's Clock project (Fig. 1B). Examples of the second are containers and boxes with mitered corners (Fig. 2A) or the turning blank for the case of the Captain's Clock (Fig. 2B). The terms for these operations can be confusing, however, and include such vague nomenclature as bevel-miter, edge-miter and flat-miter. For clarity







we'll simply describe them by the table saw operations used to make them.

In the first, or frame miter, you cut with the saw blade vertical and the miter gauge set an angle. We'll call it a gauge-tilt miter. In the second, or box miter, you cut with the saw blade at an angle and the miter gauge at 90 degrees. We'll call that a blade-tilt miter.

We used both techniques for our Captain's Clock project. The gauge-tilt miter is used for the bezel, and the

blade-tilt miter is used for the case.

Different cutting techniques are used simply because of the shape of the end product, not the grain orientation. In the clock, the case is made with the blade-tilt cut made in stave construction, but with the grain running side-to-side around the outside of the case. (The design equalizes the wood movement between the case and the bezel.) The bezel is cut like a miter around a door, with the gauge-tilt cut. The grain runs the same directions as in the case.


The end grain-to-end grain joints create a container and matching bezel that have stable diameters. That's essential for a clock where a metal dial is joined to the case. In cases that are edge-joined, the diameter will change as the wood expands and contracts with changes in relative humidity. The movement often doesn't matter. Barrels, for example, can change size slightly without affecting the strength.

The blade-tilt miter generally cuts pieces for cases or objects with depth; the gauge-tilt cuts pieces for flat objects that are essentially two-dimensional. A container can have the grain running up and down, as in a barrel, or side to side, as in our clock case. The cutting operation remains essentially the same.

Finding the Angle

Joining segments to make objects with varying numbers of sides is a matter of getting the right angle for the (continued on next page)

September/October 1988 17



OWN YOUR OWN SAWMILL

Four Models To Choose From SAVE MONEY—

CUT YOUR OWN LUMBER

- Remote hydraulic log handling
- Capacities up to 32" in dia. by 33' long
- Portable—precise—rugged
- Efficient—more lumber per log CALL FOR FREE CATALOG

1(800)553-0219

44-page catalog or use your MasterCard or VISA to order our 50-minute demonstration video-\$10.00

Wood-Mizer Products, Inc. • Dept. MM11 8180 W. 10th St., Indianapolis, IN 46214-2430



THE NEW YORK SHOW

September 23 - 25 Westchester County Center White Plains, New York

THE CAROLINA SHOW

September 30 - October 2 The Merchandise Mart Charlotte, North Carolina

THE CHICAGO AREA SHOW

October 7 - 9 The Metro Center Rockford, Illinois

THE NEW ENGLAND SHOW

October 21 - 23

Eastern States Exposition (The Big E) Springfield, Massachusetts

THE CLEVELAND SHOW

October 28 - 30 International Exposition (IX) Center Cleveland, Ohio

★ FREE SEMINARS ★ ADMISSION \$6.00

For more information: WANA, P.O. Box 706, Plymouth, NH 03264 Toll Free 1-800-521-7623 Mon.-Thurs, or (603) 536-3768

Special Techniques Continued

particular number of sides. That angle stays the same regardless of the length of the sides, whether they frame a clock bezel or enclose the Defense Department in the Pentagon. Luckily, the angle for any regular polygon is easy to calculate. The more common ones are included in our Finding Segment Lengths table.

Length of Segments

Finding the exact length of the segments becomes critical when you're trying to fit a geometric shape inside a specific area, or match it to another shape. In clocks, the bezels are usually circles, but cases are often octagons or pentagons. In the Captain's Clock, the case and bezel are both cylinders, but the turning blanks are octagons. So you need to start with the size of the bezel and find a segment length that will form an octagon the right size for a turning blank. The radius for the Captain's Clock worked out to $4\frac{1}{2}$ in.


The segment length, the circle radius and the number of segments have a specific geometrical relationship. You can find the segment length, which is the side of a triangle, if you know the radius and the angle. However, that requires a table of trigonometric functions. To simplify matters, we've supplied values for common woodworking angles. Given a radius for a container with three, four, five, six or eight sides, you can find the segment length by multiplying the radius in inches times the constant in our Finding Segment Lengths table.


Or you can simply find the lengths by drawing a full-sized view of the project. Usually you're starting with a given circle size, so you can just draw the circle and fit the object inside. For example, for an octagon you can draw out the circle, divide it into eight sections, and run lines tangent to the cir-


Cutting the Segments


Once you know the angles and the length of the segments, cutting the pieces is an easy table saw operation. However, the angles must be exact, so it's a good idea to make test cuts in scrap pieces to insure your saw is accurately set. You can also help insure accuracy by building our miter jig on page 31.

Blade-tilt segments are cut either with a rip fence or with the miter









gauge. Fig. 3 shows pieces being cut for the case of our Captain's Clock. The cut is cross-grain so the miter gauge is set at 90 degrees and the blade tilted to $22\frac{1}{2}$ degrees.


Fig. 4 shows a miter on a bezel piece being cut with the gauge-tilt method. The workpiece is flipped end-over-end

To find the length of a side: first find the angle of the miter that corresponds to the number of sides in the object (see table). Then just multiply the radius by the constant for the angle in the table. LENGTH OF SIDE Side = Radius × Constant (A) The examples below are for an eightsided object, so the constant from the table is .828.1 Example 1 finds the length of the outside of each segment (Side A). Example 2 finds the length of the inside of each segment (Side B). For most projects, you'll only need to find the outside lengths. You'll usually need to convert eighths and sixteenths to the

For the formula to work, the circle must intersect with the middle of a side, as in X. Example 1) Side A = unknown Radius A = 4.5 in. Constant = .828 Side A = 4.5 in. $\times .828 = 3.726$ in. (Round to 33/4 in.) Example 2) Side B = unknown Radius B = 3.125 in. Constant = .828 Side B = 3.125 in. \times .828 = 2.587(Round to 2%,6 in.) *The dimensions are those in the

Captain's Clock project on page 33.

decimal equivalents, i.e. 1/8 in. = .125 in.



Angle (# Sides)	Constant
22.5 (8 sides)	.828
30 (6 sides)	1.155
36 (5 sides)	1.453
45 (4 sides)	2.0
60 (3 sides)	3.464

for the second cut. When completed, the bezel pieces make a frame shape that fits flat against the clock case. The operation is sometimes called a flat miter.

Cutting Splines

End grain-to-end grain miters, as we have in the Captain's Clock, are relatively weak joints, so you'll frequently strengthen them with splines. The groove for the spline is cut perpendicular to the original miter angle, so you can easily cut the groove by rotating the piece on the saw. For small pieces, however, we use a jig to hold the segments. On the Captain's Clock we used a table saw tenon jig to hold the blade-tilt segments (Fig. 5) and a special router jig to hold the gauge-tilt segments (Fig. 6).

Both jigs are made from scrap stock, and are essentially three-sided boxes that fit over and slide along the fence for a controlled cut. The tenon jig slides on the table saw rip fence; the router jig slides on the router table fence. The workpiece is clamped to the jig for safety and control. This method insures safe, accurate cuts even in small pieces. The router jig's angled block just serves to keep each piece at the same 22½-degree angle. Raise the cutter gradually when using the router jig, taking several passes to reach the final depth.

Once the segments are cut, you need to glue them together. It's sometimes a tricky operation because of the number of pieces. The splines, however, make the job much easier. They keep the sections together during assembly and glue up. You can just fit the pieces together and then clamp them with a band clamp. The procedure is the same if you don't use splines, but it's sometimes difficult to keep the segments aligned properly while positioning the clamps.

Another method often used is to glue the segments together in pairs using a fast setting glue that only requires hand pressure, such as polyvinyl acetate. The pairs can be glued together, and then the resulting subassemblies glued together again. This method allows some adjustment for inaccurately cut pieces. The two halves can each be trimmed so they fit together. One method is to sand the edges on a piece of sandpaper taped to a flat surface, such as a table saw top.



20° A PLAN!

Back Issue Sale of early copies while stock lasts. Choose any 6 issues listed below (that's 60 plans) for only \$12.00.

S/O '80N/D '80		
J/F '81M/J '81J/A '81		
J/F '82M/J '82S/O '82		
Supply is low, so please give us your alternate selection:		
Ship to:		
Name		
Street		
City		
StateZip		
Mail this form with \$12.00 payment to		
The Woodworker's Journal		
P.O. Box 1629, New Milford, CT 06776		

Woodworking Tools of Exceptional Quality

You can buy woodworking tools in any hardware store that will help you cut, shape, join and finish almost any project - but they'll be items that are mass-produced by companies whose only concern is producing a product as cheaply as possible. Yet when you want a chisel of Sheffield steel that holds a fine edge you can shave with... a gouge that obeys your hands like your fingers, bringing out all your skill...a truly balanced plane that fairly sings through the work —where do


Since 1928, we have searched the world for tools you don't just buy, but adopt; tools made by craftsmen for craftsmen, classics of lifetime quality for people who love to work with their hands...carvers, cabinetmakers, finishers, hobbyists, builders, teachers. Our catalog details over 4,000 tools; our stores have even more.

For your Free copy of the Woodcraft



WOODCRAFT SUPPLY CORP. Dept. WJ98 41 Atlantic Avenue, Box 4000 Woburn, Massachusetts 01888

COUNTRY PROJECTS for WOODWORKERS 85 Project Plans for Furniture and Accessories



escence By the Editors of The Woodworker's Journal sessesses

GOOD NEWS!

A new book from the editors of

The bodworker's Journal

85 Complete Country Plans

By blending the craftsmanship of the early cabinetmakers with the benefit of modern tools and techniques, you can fill your home with charming Country Style furniture you've built yourself.


Country Projects for Woodworkers offers 85 complete Country Style furniture and accessory plans from the 1980-84 issues of *The Woodworker's Journal*. Projects range from quick and easy, like the Colonial Candlesticks, to the more challenging Shaker Chest of Drawers. Beginning woodworkers and master craftsmen alike will appreciate the detailed illustrations and instructions that make each project a pleasure to complete.

If you enjoy working with wood and value the warmth and simplicity of furniture from bygone days, Country Projects for Woodworkers is the book for you.


Softcover • 163 Pages • 82 Photos • Over 350 Illustrations \$16.95 plus postage and handling

18th Century Rudder Table

Please send Country Projects for Woodworkers
to:
Name
Street
City
State/ProvZip/Postal Code
\Box I am enclosing \$18.40 (U.S. funds) per book, which includes postage and handling.
☐ Charge my Visa/MC
Card #Exp. Date
Signature
Send to: The Woodworker's Journal 517 Litchfield Road, P.O. Box 1629 New Milford, CT 06776



In The Shop



Drill Bits and Boring: The Hole Story

ost of us don't spend a great deal of time deciding what bit to use or the best way to bore a particular hole. We chuck a twist drill bit in the hand drill or drill press and go to work. Yet boring a clean hole can be as much the mark of fine cabinetmaking as the selection of wood and the execution of joinery.

While there are many ways to get the job done, the quality and precision of the hole will largely depend on the selection of the right bit for the job, and the proper use of that tool.


The Best Tool for the Job

Many competent woodworkers spend too little time with details, and often compromise attractive pieces with faults that are more the result of the wrong tool than the wrong technique. Perhaps the best example of this is in the boring of holes for dowels or plugs. Tear-out around the perimeter of the hole usually indicates that a twist drill bit, rather than a brad-point bit, was used to establish the hole. With this in mind, let's look closely at the advantages, and disadvantages of the various types of bits.


Twist Drill Bits: Twist drill bits (Fig. 1) are the cheapest general-purpose bit that will drill holes in both wood and metal. They are not the best choice for boring holes in either material, but because of their low cost and different uses, we

recommend that every shop include a set. Where a fine, clean hole is not essential, or where there could be possible damage to a more costly bit, twist drill bits are the obvious choice.

Brad-Point Bits: There is no better bit for woodworking than a top-quality brad-point bit (Fig. 2). There are two distinct designs though, and the buyer should be aware of what he is buying before putting his money down. The best brad-point bits feature two scoring points that sever fibers around the (continued on page 23)



September/October 1988 2





Oregon Nov. 18-19-20 Portland Memorial Coliseum
Delaware Valley Dec. 2-3-4 Valley Forge Convention Center
Seminars by Ian Kirby - Roger Cliffe - Bob Rosendahl Rude Osolnik - and other Master Craftsmen
1-800-826-8257, In California 213-477-8521.

Nov. 4-5-6

Nov. 11-12-13

Metro-Detroit

Western Washington

Cobo Hall, Detroit

Seattle Center

Call for free brochure, 8:30-5 Pacific Time

Save \$1 off reg. \$6 admission with this ad



NOW! Plane, Mold and Sand with Infinitely Variable Power-Feed!

Put this versatile power-feed tool to work in your own shop. See how fast it pays for itself! Quickly converts low-cost rough lumber into valuable finished stock, quarter-round, casing, base mold, tongue & groove... all popular patterns...even custom designs!

NEW! Variable Feed Rate—Now, just a twist of the dial adjusts your planer from 70 to over 1000 cuts-per-inch! Produces a glass-smooth finish on tricky grain patterns no other planer can handle.






In The Shop Continued

perimeter and result in an exceptionally clean hole. The less costly variety of brad-point bits do not have scoring points. These bits are cheaper to produce because of the less complicated machining they require. Our experience has been that even at their best they do not measure up to the high-end brad-point bits, while at their worst they are not as effective as a good twist drill bit. One set that we ordered from a major retailer was so poorly ground that nearly all the edges contained burrs. Since the set in question was of German origin, one should remember that a European trademark is not necessarily a guarantee of quality.

Pilot Point Bits: Pilot Point bits (Fig. 3), marketed exclusively by Black & Decker under their "Bullet" trademark, are an innovation that combines the best features of both bradpoint and twist drill bits. The Pilot Point design is basically a brad-point bit grind tapered slightly toward the center, combined with a pilot centering section that has a relief-ground cutting edge. The bit features more acute cutting angles than twist drill bits, and enlarged flute chambers to facilitate chip clearance. The Pilot Point bits are available only in sizes from 1/8 in. to 1/2 in. Smaller bits do not include the pilot feature.

These piloted bits will not cut quite as cleanly in wood as the best brad-point bits, but they are superior to less expensive brad-point bits, and are better than twist drill bits. They are self-centering, will not "skate," and are able to bore a hole in a round piece of pipe without a center punch.




Spade Bits: Though not your best choice for drilling a clean hole, the spade bit (Fig. 4) is still an option where a large hole is required, and you do not have a Forstner or multispur bit. Most spade bits cut with a scraping action, although the bit manufacturer Irwin now makes one with a relief grind that they claim actually shears the wood, similar to the action of a conventional drill bit. Never use a spade bit in the drill press, since the excessive torque that the drill press generates may shatter the shaft or bit.

Forstner Bits: Forstner bits (Fig. 5) are the choice for boring holes larger than ½ in. diameter. They will not cut as quickly (continued on page 25)













CHANGE IN YOUR

You must inform your Postmaster if you want your copy of The Woodworker's Journal forwarded.

To insure that you will not miss an issue, please send us the latest mailing label, or your old address, along with your new address, at least six weeks before we publish.

We publish two weeks before the beginning of the month shown on the cover. Thus, the May/June issue is published on the 15th of April, etc.

128 YEARS AGO



a barometer like this hung on the wall of Admiral Robert Fitzroy, the first man to set up a localized system of weather forecasting. The inventor of the Fitzroy Barometer, and Captain of the H.M.S. Beagle, Fitzroy escorted Charles Darwin on his historic trips to the Galapagos.

C7515M-HA Fitzroy Barometer Kit 198.00* Pre-cut wood parts and all components needed.

4021X-HA Components Only 115.00* Instruments and hardware necessary to build your own.

Includes shipping charges

Send \$2 to receive a one year subscription to our 56-page color clockbuilding supply catalogue. Includes clock kits, dials, movements, weather instruments, hardware, tools, books, and accessories.

Fitzroy Mercury Barometer



Mason & Sullivan

Dept. 3971 586 Higgins Crowell Rd W. Yarmouth, Cape Cod, MA 02673

24 The Woodworker's Journal


In The Shop Continued

as brad-point bits, but they are exceptionally clean cutting, and are useful for special situations such as boring into stock at an angle, or cutting recessed half-circle drawer pulls into the edge of a board. Remember to use slow speeds with these bits.

Multispur Bits: Similar to Forstner bits, the multispur bit (Fig. 6) will cut faster with less tendency to burn, due to the cutting action of the spurs as opposed to the shearing action of the edge on the Forstner bit. Again, keep to your slowest speeds.

Auger Bits: While we generally associate auger bits (Fig. 7) with the hand brace, today auger bits are also made for power tools, and enable the woodworker to bore deep holes without having to stop and clear chips periodically. They're especially handy for boring holes through lamps and bases. We might also add that they're an option when you're working late at night and noise is a consideration. These bits also should be used at low speeds.

Specialty Bits: Expansion bits, fly cutters, and hole saws (Fig. 8) are other choices you may wish to consider when you have a large hole to bore. There are better options for boring large holes, such as Forstner or multi-spur bits, but if you are on a limited budget, these cutters will get the job done and not put a hole in your wallet.



We Recommend

If you want the very best, we suggest a set of high-quality brad-point bits up to $\frac{1}{2}$ in. for furniture making, a set of Pilot Point bits up to $\frac{1}{2}$ in. for general-purpose work including both wood and metal, a set of Forstner bits from $\frac{1}{2}$ in. up through 3 in., and a set of twist drill and spade bits for those times when you might damage your better bits.

Metallurgy

Although much is made of metallurgy, your best choice with drill bits used for woodworking is a high quality high-speed steel. If you are looking for a top quality metalworking bit, select titanium-coated bits; for stainless steel you'll need cobalt. Stay away from chrome vanadium bits. They dull quickly, and are not nearly the equal of good quality high-speed steel.

CARBIDE TIPPED ROUTER BITS

PROFESSIONAL PRODUCTION QUALITY

1000's SOL	D TO	READERS C	F FINE	WOOL	OWOBKIN	NG .
BEST CUT	ITÉM			LARGE	CUTTING	
BEST PRICE	NO.	DESCRIPTION	RADIUS	DIAM.	LENGTH	PRICE
	#01	1/4" R	1/4''	1"	1/2''	\$13.00
	#02	3/8" R	3/8''	1-1/4"	9/16''	14.00
	#03	1/2" R	1/2''	1-1/2"	5/8''	15.00
₩"	#00	1/2 11	1/2	1-1/2	3/6	13.00
1		ROUND OVER				
l Jl	#04	1/4'' R	1/4"	1''	1/2"	\$15.00
	#05	3/8'' R	3/8''	1-1/4"	5/8''	16.00
₽,	#06	1/2'' R	1/2''	1-1/2''	3/4''	19.00
П						
	#A7	ROMAN OGEE	E 100''	1 1/4"	15/00"	£10.00
	#07	5/32'' R 1/4'' R	5/32'' 1/4''	1-1/4''	15/32''	\$18.00
□ *	#08	1/4 1	1/4	1-1/2"	3/4''	20.00
П	#11	3/8''	Deep	1-1/4"	1/2"	\$14.00
] [RABBETING	3/8''			
	#09	1/8" (KERF) SLOT	CUTTER	1-1/4"	1/8''	14.00
	#10	1/4" (KERF) SLOT	CUTTER	1-1/4"	1/4''	14.00
<u> </u>				_		
_ N	#12	45°	45°	1-1/2"	5/8"	\$15.00
77	,,	Chamfer	Angle		0,0	4.0.00
<u> </u>	_	Onamor	,g.c	_		
	#15	Raised	20°	1-5/8"	1/2"	\$25.00
		Panei	Angle			
	_					
M	#35	1/4'' V Groove	90°	1/4"	1/4"	\$ 8.00
	#36	3/8" V Groove		3/8"	3/8''	9.00
U	#37	1/2" V Groove		1/2"	1/2''	11.00
	#16	3/8" Dovetail		3/8"	3/8''	\$ 7.50
М	#80	1/2" Dovetail		1/2''	13/16''	12.00
}]		(For Leigh Jig				
/ 🖍	#17	1/2" Dovetail		1/2''	1/2''	8.50
	#18	3/4" Dovetail	14°	3/4''	7/8''	10.50
m		CORE BOX (ROUN	D NCSE)			
	#19	3/8" Core Box		3/8"	3/8''	\$11.00
1 [#20	1/2" Core Box	1	1/2"	11/32"	14.00
	#21	3/4" Core Box	x 3/8"	3/4"	5/8''	18.00
	#0					
M	#056	Tongue & Gr		1-5/8''	1''	\$30.00
		(FOR WOOD THIC FROM 1/2" to 1")	XNESS			
		THAT IS				
		数数5.				
_	#24	1/4" Straight	Bit	1/4''	3/4''	\$ 7.00
l 🐧	#25	5/16" Straight		5/16"	1''	7.00
	#26	3/8" Straight		3/8''	1"	7.00
1	#27	1/2" Straight		1/2"	1"	7.00
	#28	3/4" Straight		3/4"	1"	10.50
Flush n Key	#12	1/2" FLUSH	TRUM	1/2"	1''	\$ 9 EA
Flush Key Trim Hole	#13					\$ 8.50
	#14	3/8" KEY HO (This Bit Only HSS		S 3/8" KE	Y HOLE IOUNTING	
<u> </u>					MES, ETC.	\$ 8.50

WHEN ORDERING ANY THREE OR MORE DEDUCT \$1.00 EACH ALL PRICES POSTAGE PAID

Professional Production Quality • 1/2" Ball Bearing Pilot
• 1/4" Diameter Shanks x 1-1/4" Long • One Piece Construction
• Two Flute Thick High Quality Tungsten Carbide Tips

To order by MasterCard or Visa Toll Free 7 Day—24 Hour Order Service Call 1-800-533-9298

or send check to: MLCS Ltd., P.O. Box 4053-J, Rydal, PA 19046

September/October 1988 25





Eight slabs of oak treated with various combinations of wood filler and stain.

7 ith natural finishes now so much in vogue, many woodworkers may never have occasion to resort to the can of wood filler. It's fashionable to let finish coats sink into oak or mahogany's open pores, and so retain the natural

But some woodworkers still prefer a perfectly smooth surface for table and bar tops. And open-pored woods will just never get a perfectly flat finish without some sort of filler.

The open-grained woods are hardwoods. Softwoods such as pine, fir and hemlock are anatomically different and don't have the large specialized vessels, or pores. Hardwoods, or deciduous trees, evolved later than softwoods, coniferous trees, and generally have more specialized systems. In conifers the same long and thin cell provides both strength and conduction of fluids. In hardwoods those functions are divided up, and the wood is generally stronger. Thick-walled cells provide the strength, and thin-walled vessel cells allow conduction.

The vessels are tubular cells which grow very long and thin. After formation, the end walls of the cells disappear and the cells hook up end to end. In some wood species such as red oak, you can even use a straight-grained section of wood as a straw.

Looking at an end-grain section, the pores appear as round openings, but on a long-grain section the vessels appear as grooves. When the boards are cut and surfaced, the vessels are ruptured lengthwise.

When to Fill

If you want a mirror-smooth surface on open-pored woods, you need to fill. Woods that are usually filled include oak, walnut, mahogany, chestnut, hickory and ash. In those woods the pores are easily seen with the naked eye.

But not all hardwoods require filling for a smooth surface.

In some the pores are so small that the surface finish itself will fill them. Birch, maple and cherry are examples of woods with very small pores. Some woodworkers even fill these small pores, using a liquid filler instead of the usual

The softwoods don't require filling.

What is Wood Filler

The fillers are composed of ground silica and an oil and petroleum derived solvent. They harden when the solvent evaporates, leaving behind the clay-like filler. The silica is ground very fine so it can penetrate very small pores. Don't try and use sawdust and glue as a filler. It's suitable for filling large defects, but isn't fine enough to uniformly penetrate the pores.

Although you can make your own filler from the various components, it's much easier to buy one of the varieties sold commercially. They come in a natural shade and many colors, including white and black for specialized applications. The filler is a thick paste, which you have to thin to a working consistency.

A Choice of Methods

Wood filling techniques aren't difficult, but they can add several more steps to an already lengthy finishing process. The fastest way to go about filling is to combine it with the staining process: just mix stain and filler, paint it on, and wipe it off when it's dry. This technique may do the job, but it doesn't provide much control. The filler takes stain differently from the wood, so a second application of stain will go on unevenly. And the filler may bleed into the surface finish.

Getting better control means taking more time and adding several steps. The stain is applied first, and then sealed with a thin coat of shellac after the desired color is achieved. The filler is then mixed with stain to get the same color as the already stained wood. After filling, the surface is sealed with shellac again to prevent the surface finish from dissolving the filler.

You can also buy colored fillers that eliminate the need to mix stain and filler. Although the stain and filler are premixed, you'll still have to do some experimenting and testing to get your initial stain coat the same color as the fill. When you're working with commercial stains, it's easier to get a match if you use the same brand of filler and stain.

Filling Steps

Before filling, make sure the wood is well sanded. If you use a sealer, the proportions of the sealer should be seven parts alcohol to one part shellac. The shellac should be 4-pound cut. If you're filling over stain, rub the surface down with 000 steel wool. If working with bare wood, sand with 220-grit paper.

The filler should generally be the consistency of heavy cream. For really large pores, such as in red oak, mix the filler to a sludge-like consistency. Use turpentine or paint thinner to cut the paste wood filler. If you're mixing stain with the filler, first add the stain to get the color you want, and then thin to the desired thickness. If you're not too picky about the final shade, you can just add enough stain to get the right mix and let the color fall where it may.

Apply the filler with a stiff brush, working both with and across the grain. Some woodworkers even use the brush in a stabbing action to force the filler into the pores. On end grain, take extra care to force the filler into the pores.

After the filler dries to a dull surface, generally 10 to 30 minutes, rub it off with a coarse cloth. First rub against the grain, removing most of the filler. Then, to get off the last traces, rub more gently with the grain.

Let the filler dry overnight. You may need a second application if the filler shrinks too much.

If you're brave, you can apply varnish directly over the filler. But it's possible the surface can turn gray when the two compounds interact. It's safest to use the shellac sealer again.

Although filler is used most often on woods like oak with very pronounced pores, you can also use it on maple or birch to get a mirror finish. The process is the same, but you need to thin the filler more so you can squeeze it into the smaller pores.

Filler can also highlight wood pores. A black filler on a light wood — or a white filler on a dark wood — provides stark contrasts that can have an interesting effect.

Potential Problems (And Remedies)

- Pin holes form in the filler. It isn't completely squeezed into the pores. When dry, sand and apply more filler
- The filler flows out of the pores before it's dry. The surface isn't adequately sealed. Sand and reseal before adding more filler.
- The filler bleeds into the sealer. You didn't wait long enough after sealing. Thoroughly sand the surface and start over.
- The surface finish takes on a gray cast. Some varnishes react with the fillers. Sand off the surface finish, seal with shellac and revarnish.

CONTROL THE SPEED OF YOUR ROUTER

ROUTE AT THE SPEED THAT GIVES THE BEST RESULTS WITH THE WOOD AND BIT YOU SARE USING!

- LESS TEAR OUT
- STOPS BURNING
- . FEED AT COMFORTABLE RATE
- BETTER, SAFER RESULTS WITH LARGE DIAMETER PANEL-RAISING BITS
- · LESS WEAR ON BITS
- LESS NOISE AND SOFTER STARTS AT LOWER SPEEDS



FEATURES:

- . SPEED ADJUSTABLE FROM FULL SPEED TO O RPM
- FULL HORSEPOWER AND TORQUE AT ALL SPEEDS
- GO BACK AND FORTH FROM ANY PRE-SET SPEED TO FULL SPEED AT THE FLIP OF A SWITCH
- . WORKS WITH ALL ROUTERS 3 HP OR LESS
- 120V 15 AMP
- GIVES YOUR ROUTER A FEATURE ONLY AVAILABLE ON ROUTERS THAT COST OVER \$500,00

EASY TO USE — SIMPLY PLUG IN SPEED CONTROL AND PLUG YOUR ROUTER INTO THE SPEED CONTROL — TURN DIAL FOR BEST RESULTS. (SPEED CONTROL HAS A CLIP THAT CAN BE WORN ON YOUR BELT OR HUNG ON WALL OR LEFT LOOSE.)

REDUCES SPEED ELECTRONICALLY WITHOUT REDUCING TORQUE;
 ELECTRONIC FEED-BACK MAINTAINS SPEED BY INCREASING VOLTAGE
 TO MOTOR AS LOAD INCREASES.

To order by Master Charge or Visa Toll Free 7 Day — 24 Hour Order Service, Call 1-800-533-9298

or send check to MLCS, Ltd., P.O. Box 4053J, Rydal, PA 19046

BROOKFIELD CRAFTCENTER



P R E S E N T S


Over 200 workshops by professional craftsmen in both traditional and non-traditional visual arts.

Weekend workshops/Evening and day classes.

Write or call for our quarterly catalogue.

P.O. Box 122 Brookfield, CT 06804 203-775-4526

September/October 1988



A tung oil finish on red oak gives our Bookcase Desk warm colors and a rich texture. The clean lines and simple bevels lend it a contemporary flavor.

Designed for today's small spaces, the desk offers plenty of storage space, with two ample drawers and the bookcase underneath.

As with most contemporary pieces, the crisp look depends on clean cuts and sharp edges. Take extra care in the joinery and any saw cuts for finished edges. Oak splinters relatively easily, especially when crosscutting.

Start by cutting the lumber to size. Make the stock for the top (A) and frame members (B and C) slightly oversize. You'll want to trim the top and frames to final size after joining. Also cut the two shelves (H and I) a little long. That way you can cut them to size from the actual groove-to-groove distance between the legs (F). Leave the stock for the drawer parts off to the side for now. Drawers are always made to fit the actual openings.

Next, join the boards for the top. Glue the jointed edges together without splines or dowels, which don't add any strength to long grain-to-long grain joints like this. Use blocks lightly clamped across the top to keep the boards lined up. An application of paste wax prevents glue from sticking to the blocks.

Also join the frame sections, using $\frac{1}{4}$ in. splines. Cut the grooves with a $\frac{1}{4}$ in. diameter straight cutter in the router table and use ¼ in. plywood for the splines. The splines are easier to cut than dowels, as the router-table fence keeps all the grooves lined up. Just be careful to always cut with the same face of matching boards against the fence. After the glue on the top and two frames has cured, trim them to final size. As they're rather wide, they may be too big to fit on your table saw. In that case, carefully trim them with a portable circular saw riding against a straight edge. To prevent chip-out, run a sharp knife along the line of cut before starting the saw. You don't have to cut deeply with the knife, just far enough to sever the top fibers.

Also use the knife to start the cuts on the front of the frames where they will show. Next, lay out the sliding dovetails, which join the legs (F) to the lower frame and feet (G). The $\frac{3}{8}$ in. deep grooves are centered on the feet and also centered $1\frac{3}{8}$ in. from the edge of the lower frame end. Use a $\frac{1}{2}$ in. dovetail cutter. The groove is stopped $\frac{1}{4}$ in. short of the 7 in. leg width. That way you can hide the dovetail joint and allow room for the leg to expand with changes in humidity. The matching "tail" that fits into the groove is cut back $\frac{1}{8}$ in. shorter than the groove. Use a chisel to cut it back.

The tails are cut on the router table to just shy of % in. deep. To make sure each of the four tails is the same width, don't just set the table fence once and flip the pieces over for successive cuts. That method depends on perfectly accurate stock thickness to achieve a uniform tail. Instead, for uniform tails, change the fence setting for successive cuts and always gauge off the same face of the workpiece (Fig. 1). Note that you'll need to recess the dovetail bit into the fence for the first cut.

Because you need to move the fence, make all four cuts at the first setting before moving the fence and making the final cuts. The second cut is crucial for a tight fit in the groove. If you cut some scrap at the first setting, you can use it for test cuts at the second setting.

Also to insure accurate cuts, use a high fence on the router table and a feather board to securely guide the pieces past the dovetail cutter. Feed from right to left for the first cut (Fig. 1), and from left to right for the second cut.

Next, cut the $\frac{1}{8}$ in. deep by $\frac{3}{4}$ in. wide dadoes in the legs for the shelves (H, I), as well as the dadoes in the upper and lower frames for the divider (E). Adjust the width of the cut to match the thickness of your lumber. Before cutting, make sure to orient the parts the way you'll want them during assembly. Also cut the $\frac{1}{4}$ in. deep by $\frac{3}{4}$ in. wide rabbets in the sides (D) to accept the frames.

Then, cut the ¼ in. deep by ¾ in. wide rabbets for the lower back (M) in the legs, lower shelf (I) and lower frame. Also cut the ¼ in. deep by ¼ in. wide rabbets for the upper back (L) in the sides (D), and upper and lower frames, as shown in the Rear Detail. The lower frame will have rabbets cut on both edges, leaving ⅓ in. of wood in the center.

Now, with the parts sized and the joints fabricated, cut the details on the feet and rails (J and K). To get the ½ in.

radius on the feet, clamp the two together and bore two holes with a 1 in. Forstner bit. You can then separate the feet and use the band saw to finish the cuts.

Next, cut the miters on the rail strips. Also, with the router, cut the ½ in. wide stopped spline grooves into the miters.

For the angled cuts on the feet and the rails, use a taper jig. If you don't have a jig, you can cut a scrap board to the desired angle and use that for support. Just make sure there's a block to hold the piece in place.

Before assembly, thoroughly sand all the parts, especially any interior surfaces you'll be unable to reach easily after assembly.

Assemble the desk in three steps. First, assemble the lower bookcase section. But before getting out the glue bottle, dry fit the sliding dovetails to get the exact length of the shelves, and then cut them. You can then glue and clamp the lower section, which includes the feet, the legs, the shelves, the lower frame and the lower back. The shelves are glued and screwed in place, with plugs covering the screwheads.

Next, assemble the upper section, which includes the top, rails and upper frame. The top and rails are joined with screws as shown, using slotted screw holes to allow for wood movement. Glue and clamp the miter joints. The upper frame is then screwed into

the top, also through slotted holes.

Finish assembly by joining the top and bookcase sections. The two sides

Part	Description	Size				No. Req'd.		
A	Тор	3/4	×	22	×	34	1	
В	Frame							
	(front/back)	3/4	×	23/4	×	30	4	
С	Frame	3/		03/		451/		
	(crosspieces)			. , -		151/4	6	
	Side					203/4	2	
	Divider	,				201/2		
	Leg					221/4	2	
	Feet					× 18	2	
Н	Upper Shelf	3/4	×	$6\frac{3}{4}$	×	271/4	1	
1	Lower Shelf	3/4	×	7 3	× 2	271/4	1	
J	Back Rail	3/4	×	11/2	×	331/2	1	
K	Side Rail	3/4	×	11/2	×	11	2	
L	Upper Back	1/4	×	31/4	×	30	-1	
M	Lower Back	1/4	×	20	×	271/4	1	
N	Drawer Front	3/4	×	33/4	×	141/8	2	
0	Drawer Side	1/2	×	31/4	×	201/4	4	
P	Drawer Back	1/2	×	23/4	×	131/8	2	
Q	Drawer Bottom	1/4	×	137	/6 >	× 201/4	2	
	Drawer Pull			n. b		0	2	

and the drawer divider are glued and clamped in place between the sections. Finally, nail or screw the upper back in place.

The drawers are made to the size of the actual opening, which often varies slightly from the plans. The bevels on the drawer fronts (N) can be cut on the table saw or with a panel raising bit in the router. We cut ours on the table saw and cleaned up the cut with a sanding block. First, set the saw blade for a 15-degree cut, then adjust the fence so you're removing $\frac{3}{16}$ in. from the front of the panel. When cutting the bevels, use a tenon jig for safety and cut the ends first to eliminate any chip-out on the finished surfaces.


Next, use the ¼ in. straight cutter in the router table to establish the rabbets around the drawer face. The rabbet is ¼ in. top and bottom, but ¾ in. on each side

Also use the ¼ in. cutter for the drawer bottom (Q) grooves cut into the sides (O) and the front. Use a ½ in. straight cutter to establish the dado in the sides for the back (P), which fits on top of the bottom. Cut the ¼ in. plywood for the bottoms after measuring the actual groove bottom-togroove bottom distance on the drawers. Cut them a little shy to allow some room for wood movement.


Sand the bevels thoroughly to remove the saw marks and sand the drawer parts prior to assembly.

Apply three coats of tung oil, rubbing with 000 steel wool between coats. Let each coat dry overnight.

(continued on next page)



September/October 1988 29



For those who frequently cut angles, our jig should save hours spent fine tuning the miter gauge. Truly accurate cuts often require more time for adjustments than for making parts. The obvious solution is a miter gauge that's set once for a specific angle, and put aside until needed.

We liked the idea so much we made two for our shop, one for 45 degrees and one for 22½ degrees. The 22½-degree jig described here is used for cutting octagon segments for the bezel of our Captain's Clock project on page 33. The jig remains basically the same for any angle, you just change the locating holes for the guide pieces. You may wish to change the overall dimensions, however, to fit your saw. Ours is made to fit a 10 in. Delta Unisaw table saw.

The jigs also allow cuts from both sides of the saw blade, an operation that often requires readjusting the conventional miter gauge.


First, cut the stock to the sizes shown in the Bill of Materials. We used maple for the solid stock and birch plywood for the base (A). Note that the base is two pieces of wood in the finished jig, but one during construction. The kerf along the entire jig width splits the plywood, but it's cut after assembly. When cutting the runners (B), carefully match them to the width of the mitergauge slots in your saw table. They should slide easily and move side-to-side just enough for an audible click. Also note that the distance between runners may vary from saw to saw.

If you wish, you can glue strips of wood together to build up stock for the $1\frac{1}{2}$ in. thick guide pieces (C), as well as the $1\frac{3}{4}$ in. thick cleat blocks (D).

Next, taper the cleat blocks. They're higher at the center to allow for as deep a saw kerf as possible, while still providing enough strength to hold the jig together. Use the band saw or a tapering jig in the table saw to cut the four tapered shoulders. Be sure to cut the angles on the ends of the guide pieces with the table saw for a smooth cut.

Now drill all the holes except those for the runners, which are drilled while test-fitting the jig on the saw.

First, counterbore for the carriage bolts (G) in the guide pieces. We used a 1½ in. Forstner bit and drilled ¾ in. deep. Also drill the 1 in. diameter hole in the front cleat block for the dowel handle (E), and the ¼ in. diameter by ¼ in. deep counterbore in the plywood for the carriage bolt heads. Finally, drill the shank holes for the carriage



Miter Cutting Jig

bolts. Note that two of the four holes in the guide pieces are drilled \(\frac{1}{8} \) in. oversize to allow for adjustment, but all the shank holes in the plywood are drilled to the \(\frac{3}{8} \) in. diameter of the bolt.

The next step, aligning and screwing the runners to the base, is a bit tricky because the strips are too thin to allow you to screw them in place from the top. But proper alignment is important so that the jig slides smoothly and lines up squarely to the saw blade. The second consideration is less important, however, because you cut the kerf after building the jig, and it's that kerf that serves as the reference line for adjusting the jig. (We used a protractor to roughly set the jig, and then fine tuned it by cutting a series of test octagons.)

The procedure we used is: Mark a center line on the plywood base and set it on the table saw. Line up the center line with the center of the saw blade. (You may have to scribe a line from the saw blade to the front edge of the table saw.) Mark the slot locations on the base (A), both at the front and back. Remove the plywood and use a square to connect the marks.

Clamp the two runners in place on one end, test the jig in the slots and drive two screws in near the edge. Remove the clamps. Slide the jig so the unsecured ends of the runners hang over the table edge, clamp the ends again and screw them in. Now remove the jig and set the rest of the screws, but just tighten them snug, not fast. Test the jig in the slots and tap the runners for adjustment. When it slides smoothly, tighten the screws.


Note that the screws may spread the strips slightly, so you may have to sand them lightly to get them to slide easily again.

With the strips in place, complete assembly by bolting the guide pieces in place, screwing on the cleat blocks and gluing on the handle and guard (F). The handle is a safety feature that allows you to operate the jig without putting a hand on the cleat block, where a careless move could cost you a finger. The guard also helps keep fingers out of harm's way.

Set the saw blade for a 2½ in. high cut and establish the kerf. Adjust the guide pieces by snugging up the bolts and tapping the sides lightly with a hammer. To be sure the miter gauge jig is set accurately, cut all eight sides of an octagon and fit them together. Adjust the guide pieces as needed until you get a test octagon where the miters are perfect, and then tighten the bolts.

XXV)


(continued on next page)





22½° JKG		SAW KE	RE-	
15½	2222		- 15	- 2 3 2 2 2 2 3
12		1 1 - 2 - 30 -	泽泻	

	Dill	OI Materiais	
Par	t Descriptio	n Size	No. Req'd.
Α	Base	$\frac{3}{4} \times 20 \times 30$	1
В	Runner	$\frac{3}{8}$ [$\frac{3}{4}$ × 20*	2
С	Guide Piece	$1\frac{1}{2} \times 2\frac{1}{4} \times **$	2
D	Cleat Block	$1\frac{3}{4} \times 4 \times 12$	2
Ε	Handle	1 in. dia. \times 5 in. c	lowel 1
F	Guard	$\frac{3}{4} \times 2 \times 4$	1
G	Bolt	$\frac{3}{8}$ in. \times 2½ carriage bolt, nut, and was	
*	Size runner te	o vour miter gauge	slot.

*Size runner to your miter gauge slot.
**131/4 long for 45° jig; 151/2 long for 221/2° jig.







A clock at the Mystic Seaport Museum inspired Connecticut woodworker Dennis Preston to take measurements and build this reproduction.

The clock typically hung in the officers' dining quarters, or wardroom, of 19th-century ships. The original was built by Connecticut clockmaker Seth Thomas about 1880. Preston's clock substitutes a quartz movement for the original key-wound mechanism, but the clock still sounds out the watches. On ships the day was divided into six four-hour watches, and the bells sounded every half hour. Seafarers knew the time by counting the chimes. Eight bells sounded at noon, 4 p.m., 8 p.m., midnight, 4 a.m. and 8 a.m.

Construction of the clock is fairly straightforward. The clock case (A) and bezel (B) are each made from eight

sections of mahogany. The sections are joined with splines and then turned on the lathe. Rabbets on the inside edges of the case and bezel hold the back (C), glass (D), and dial face (F).

The eight-sided mahogany rings are joined according to the instructions in our "Joining Ring Segments" Special Techniques article on page 17. The grain on the eight segments in each ring runs tangent to the edge of the clock for both the case and bezel. The grain arrangement keeps the clock stable. All wood movement is directed to the front or back, rather than side to side, where the metal dial face would constrict it.


The segment lengths in both octagons are $3\frac{3}{4}$ in. The stock is $1\frac{3}{8}$ in. thick for the case, $1\frac{3}{4}$ in. thick for the bezel. Both parts are turned to a 9 in. diameter.

Once the two octagons are ready, mount them on ¾ in. plywood backs (see Detail). Use eight 1½ in. by no. 8 screws for attaching each mahogany octagon to the plywood, one screw for each segment. Keep the screws well away from the outer edges so they don't interfere with the turning. File any protruding splines flush with the case and bezel.

The actual turning of the case is similar to that for the outside of a bowl. You can transfer our full-sized pattern to plywood and use it as a guide or template.

The turning job can be tricky because the changing grain direction tends to grab the chisel and make it chatter, especially when roughing out the case. Be careful and use your slowest lathe speed, both for the chat-

(continued on next page)



tering and because you're turning a large diameter. When starting, use a heavy gouge and let the bevel ride against the case before you raise the handle and gently engage the cutting edge. Work with the gouge angled slightly away from you, toward the direction of cut.

You may need to use a scraping rather than a cutting action of the gouge, with the tool edge angled slightly down. The scraping cut is often used in difficult situations where the grain grabs the cutting edge. Angling the tool down makes the edge tear off small fragments, rather than slicing into the wood. It's not as smooth as cutting, but it's easier.

Part	Description	Size	No. Req'd
A	Case	9 in. dia. as sh	nown 1
В	Bezel	9 in. dia. as sh	nown 1
C	Back	$\frac{1}{4}$ × 7% in. dia	a. 1
D	Glass	$\frac{1}{8}$ × 7 $\frac{1}{8}$ in. dia	a. 1
E	Keeper Strip*	1/4 × 22	1
F	Dial Face*	as shown	1
G	Mounting Plate*	as shown	1
Н	Movement*	as shown	1
1	Hands*	as shown	1
J	Hinge*	1½ × 1	1
K	Hanger	as shown	1
L	Locating Pin	1/8 × 1/2 dowel	1

*Hardware available in kit from Mason & Sullivan, Dept. 3974, 586 Higgins
Crowell Rd., West Yarmouth, MA 02673.
Order part no. C-3629X for the ship's
bell quartz movement, \$82, or part no.
C-3609X-14 for the alternate movement
\$19.95. The alternate movement doesn't
include chimes. Each kit includes movement (H), face (F), hands (I), mounting
plate (G), hinge (J), keeper strip (E) and
wire brads. The shipping charge for the
ship's bell movement is \$3.25; for the
alternate movement it's \$2.39.

After roughing the cylinder, cut the bead details with the skew chisel. Use a small gouge or roundnose to cut the concave sections. Again, if you have trouble handling the tools, you may need to use a scraping action. After rough-shaping the outside of the case, sand it thoroughly. Start with 120-grit paper and finish with 220-grit.

Next, remove the case from the faceplate and mount the bezel. The bezel is turned much the same as the case, except that the tool rest is angled across the front of the faceplate for most of the work. You'll probably need to cut into the plywood mounting block to get the fully rounded profile on the bezel.

Now, cut the two case rabbets and the bezel rabbet on the router table as shown in the Detail. The case rabbets hold the dial face (F) and back (C). The bezel rabbet holds the glass (D). The two blocks ride against the outside edge of the turnings and keep them aligned with the ½ in. diameter straight cutter. The bezel and back rabbet are cut to the same width, but to the depths shown. You'll have to move the guide blocks and readjust the depth for the wider rabbet for the dial face.

After cutting the rabbets, drill the four $\frac{3}{8}$ in. diameter sound holes and the $\frac{1}{8}$ in. diameter by $\frac{1}{4}$ in. deep holes in the case and bezel for the $\frac{1}{2}$ in. long dowel locating pin (L). The pin is glued into the case and fits into the face hole when the bezel is closed.

The bezel swings on the single hinge (J) mounted on top. Mortise the hinge carefully into the case and bezel using a sharp chisel. Also mortise the brass hanger (K) into the back. The hanger is cut and drilled from a piece of $\frac{1}{16}$ in.

thick brass. If you can't find brass locally, you can also mount the clock by drilling a $\frac{3}{8}$ in. hole in the back of the case.


The plywood back and the glass are both cut after the clock is completed. That insures that they match the actual openings. You can have the glass cut at any glass shop. Have them make it slightly smaller than the actual opening. Although we've used flat glass, a convex glass crystal to fit the bezel is available from Mason & Sullivan (see Bill of Materials for address). Order their part no. 2778G, which lists for \$3.95. The flat glass is held into the bezel with a keeper strip (E) and wire brads. For the convex glass crystal you'll need to use glazier's points and glazing compound instead.


Finally, oil the case and face with tung oil for a close-to-the-wood finish. You could also use spar varnish for a marine flavor. If you use the spar varnish, apply several coats to give the surface a good thick finish. Sand well between coats.

The movement (H), hands (I), brass hinge (J), dial face (F), and keeper strip (E) are available in a kit Mason & Sullivan has prepared for the project (see Bill of Materials).

Installing the movement itself only takes a few minutes. Drill three holes in the case to match those on the dial face, and use the brass screws provided to attach the face to the case. Then screw the movement onto the mounting plate (G) with the self-tapping screws, and the mounting plate to the dial face with the black machine screws. The hands are added next.

Finally, secure the back to the case with brass flathead wood screws and install the battery, not included with the kit.








35

September/October 1988



To the Shakers, function and form were as surely linked as the spoke and rim of a wheel. Every line of every board took its measure from its use.

Our Country Coffee Table would have been a puzzle to the Shakers. It's too short for a decent bench, too low to eat on, too big for a stool.

But the Shakers didn't sit on couches and they took no time for sipping coffee. If they had, they might have created this simple table, because its form also matches its function. The table top has ample room for coffee cups, nut bowls, and cheese platters. The large drawer easily holds the clut-

ter swept off the top moments before the guests arrive.

Massachusetts woodworker Gene Cosloy designed and built the Country Coffee Table along traditional Shaker lines. He used cherry, but with walnut drawer pulls and pegs.

Start by joining several boards for the top (A). Leave them a little long and make the panel slightly wide. You'll trim it to exact size after the glue dries. Keep the boards aligned during glue-up by lightly clamping waxed blocks across the assembly. Another way to insure proper alignment is to use splines or dowels in the joints. Next, cut stock to size for the front apron (B), the side aprons (C) and the rear apron (D), as well as the drawer guides (E) and drawer runners (F). Cut the 12 mounting blocks (G) from a ¾ in by 1½ in. strip with a rabbet notched into the side (See Detail). Make the strip about 14 in. long and crosscut it into the blocks. You can make the cutout for the drawers in the front apron with the hand-held jigsaw, or with hand saws.

Now, prepare the thick stock for the legs (H), truing and planing a plank before ripping it into four legs. Clean up the legs with a plane or a jointer.

Leave the lumber for the drawer parts off to the side. Drawers are always made to fit the actual opening.

Next, assemble all the parts the way you want them, paying close attention to the way the wood grains meet. When you have a pleasing arrangement, label the parts. Now, carefully lay out the location of the mortises and tenons, as well as the dadoes for the drawer guides, and the slot for the mounting blocks.

The mortises are open at the top, so you can cut them easily by hand. Use a dovetail saw to cut with the grain along each shoulder of the mortises. You'll only be able to cut a slanted kerf along the mortise shoulder (Fig. 1A). But the


triangular cut serves as a guide for the chisel while removing the rest of the wood (Fig. 1B).

The tenons can also be cut by hand. First, use a handsaw to cut the $\frac{1}{16}$ in. deep shoulders on all the apron ends. Then cut into the end grain with a backsaw, carefully halving the line down to the shoulder (Fig. 2). If you're tentative about the cut, stay off the line and pare the tenon to size with a file. The tenon should slide easily into the mortise. If you have to force it in, it's too tight.


Next, drill the holes for the walnut pegs. Bore all the holes in the legs first, and then mark the matching holes in the tenons while dry-fitting the parts. Note that the mortise in the legs only leaves a $\frac{3}{16}$ in. shoulder. The thin stock requires extra care when drilling the holes and clamping the legs to the aprons. You might want to drill for the pegs while dry-fitting the mortises. That way the tenon backs up the cut and prevents vibration while boring.


Cut the leg tapers next. Each leg has its two inside edges tapered from just below the apron. These can be cut on the table saw with a tapering jig (Fig. 3). But for the secondary taper toward the bottom, use a block plane. That taper, or chamfer, is cut along the inside corner. Lay out the taper, and cut down to the line with the plane (Fig. 4). Make sure you clamp the leg into the (continued on next page)


37




September/October 1988









V-block for stability.

Next, cut the beads into the outside corner of each leg. Use a ¼ in. beading bit in the router table.

Also using the router, cut the dadoes in the aprons for the drawer guides, and plough the grooves for the mounting blocks.

Now, assemble the table. When clamping the legs, be careful to apply pressure so each clamp pulls the tenon into the mortise. If the clamps squeeze the mortise, or apply cross pressure, they will distort the joint. It's best to work with two gluing sessions. First, glue the front and back aprons to the legs, and then glue the whole piece together. Use screws as shown to hold the drawer guides into the aprons. Glue the runners onto the guides.

The drawer is traditional dovetail construction. There are half-blind dovetails where the sides meet the front, and open dovetails where the sides meet the back. But you should note that the drawer front (I) only has a lip on the two sides. All four edges, however, have a ¼ in. bead detail.

To start, cut all the drawer parts except the bottom to size, then orient the parts and label them. Next, establish the $\frac{1}{4}$ in. deep lips on the sides of the drawer front.

Scribe the depth of cut for both tails and pins with a marking gauge. (The tails are the portion that resemble a dove's tail; the pins are the matching beveled shoulders.) Set the gauge a hair over ½ in., the thickness of the drawer sides (J). Scribe lines on the inside of

Part	Description	Siza	No. Req'd	
A	Тор	3/4 × 30 × 431/2	1	
В	Front Apron	$\frac{3}{4} \times 4\frac{3}{8} \times 37$	1	
C	Side Apron	$\frac{3}{4} \times 4\frac{3}{8} \times 26$	2	
D	Rear Apron	$\frac{3}{4} \times 4\frac{3}{8} \times 37$	1	
E	Drawer Guide	$\frac{3}{4} \times 4\frac{3}{8} \times 27$	2	
F	Drawer Runner	3/4 × 5/8 × 231/2	2	
G	Mounting Blocks	See Detail	12	
Н	Leg	2 × 2 × 17	. 4	
1	Drawer Front	$\frac{3}{4} \times \frac{3}{8} \times \frac{22}{2}$	1	
J	Drawer Side	1/2 × 31/8 × 191/8	2	
K	Drawer Back	1/2 × 21/2 × 22	1	
L	Drawer Bottom	1/4 × 181/8 × 211/2	, 1	
M	Drawer Pull	See Detail	2	


the drawer front, on both ends of the drawer back (K), and on both ends of each side. When marking the sides and back, run the lines on all four surfaces. When marking the front, be sure to gauge off the inside of the lip, not the outside edge of the drawer.

After scribing the depths, mark the tails on the sides as shown in the dovetail layout. Extend those lines across the end grain. Use a sharp knife or similar implement for marking. Mark the waste sections with an "X."

Use a dovetail saw to cut the tails to depth. Stay on the waste side of the line. Use a chisel to cut along the depth line. But, for the first chisel cut, stay just off the line. The chisel creeps a bit toward the line when you first hit it with a mallet.

Next, trace the tail profiles onto the end grain of the drawer front and the back. Use a try square to run lines from the end grain to the depth marks.

Also use the dovetail saw and chisel to cut out the pins. For the half-blind dovetail in the front, you won't be able to cut all the way through with a saw. However, you can make a triangular




cut from the inside. Hollow out the remainder of the cut with a chisel.

You may need some final chisel work to get the dovetails to fit correctly. They should go together snugly. If you have to bang on them, they'll split after gluing. The glue swells the wood.

After cutting the dovetails, make the $\frac{1}{4}$ in. deep by $\frac{1}{4}$ in. wide groove in the drawer sides and front to accept the bottom (L) and the ¼ in, bead on the drawer face. The drawer back fits on top of the bottom, which runs to the end of the side grooves. This arrangement allowed traditional drawer bottoms to expand toward the rear without distorting the drawer. You'll probably use plywood for the bottom, eliminating expansion problems, but it's still an elegant way to build a drawer. The bottom is cut after the drawer parts are dry-fit together to get the actual groove-to-groove dimensions.

Finish construction by gluing the drawer together and drilling holes for the pulls. You can either turn the pulls to the dimensions shown, or purchase similar ones. Pulls are available in maple from Woodcraft Supply, 41 Atlantic Ave., P.O. Box 4000, Woburn, MA 01888. Order part no. 50L41, \$3.25 for 10, postpaid.

To finish the Country Coffee Table we recommend two coats of tung oil over a well-sanded surface. You should use at least 220-grit paper. The tung oil gives a nice close-to-the-wood finish, although it's not as durable as a varnish. Use a polyurethane varnish if you anticipate plenty of spills.



September/October 1988 39

The Gift Shop • Easy-To-Make Gift Projects

Our rooster adds a slice of barnyard to your windowsill, but comes without the predawn wake-up call. Don't be surprised, however, if the house cat resents the intruder on the perch.


We made the rooster from ¾ in. maple, but almost any wood will do. Softwoods work more easily, so you may choose to use pine, at least for the silhouette.


First transfer the full-size profile to the wood. Rough cut the rooster, preferably with a scroll saw. You can also use a band saw or jigsaw, although it will be harder to form all the facets. The inside details must be cut with a coping saw or scroll saw.

The most time-consuming part of the project is cleaning up the cuts. You'll need several shapes of small wood files to get into the corners. We used two sizes of half-round files, a round file, and a small triangular file. For sanding the edges, we used a dowel and some small slips of scrap wood wrapped with sandpaper to get into the facets.

Use a ½ in. half-round bit in the router table to cut the details on the base, which is built up with two ¾ in. boards.

We painted the silhouette with barn red milk paint. The paint, which covers in one coat, is available from The Old Fashioned Milk Paint Co., P.O. Box 222, Groton, MA 01450.







Those who have a backyard garden will find a basket like this handy for collecting the daily harvest. It's an easy weekend project that also doubles as a picnic basket.

We used ¾ in. pine for the pumpkin cutouts and birch dowels to connect them. The handle is ¾ in. dowel, and the basket is ¾ in. dowel.


The full-size pattern we provide makes cutting out the pumpkin shape

easy. Just transfer the shape to tracing paper, mark it onto the wood and cut it out with a coping saw or band saw. Clean up the rough edges with wood files and sandpaper.


You'll need eight 36 in. lengths of $\frac{3}{8}$ in. dowel and one length of $\frac{5}{8}$ in. dowel. You can buy the dowels locally or order them from Craftsman Wood Service Co., 1735 W. Cortland Court,

Addison, IL 60101.

We used oil paints on the pumpkin. First we applied a coat of flat paint to make a good base, then we used semigloss colors: orange for the pumpkin body, brown for the stem and green for the handle. Sand with 150-grit paper between coats of paint.



42 The Woodworker's Journal



September/October 1988

This bird is one of toymaker Skip Arthur's most popular designs, and is also one of the easiest to make. A cam on the wheels generates a flapping motion of the wings. Although he builds these birds of birch, with mahogany wings, you may want to try other woods.


The construction is very straightforward. After sizing the stock for the body (Step 1), you'll lay out the body profile, the eye, axle, wing screw holes, and the wing-pin slot (Step 2). Drill out the various holes and rout the wing-pin slot (Step 3) before you cut the body profile on the band saw (Step 4). The wing-pin slot is routed freehand and need not be precise, since it only provides a stop for the dowel pin mounted in the wing. Note that a scrap block protects the piece from being marred by the clamp. Next, round over the body profile using a $\frac{1}{8}$ in. diameter round-over bit (Step 5). Note that the bit depth should be set slightly less than the full $\frac{1}{8}$ in., so you'll have a small flat for the bearing to ride on.

Resaw stock for the wings using a pivot point guide on the band saw (Step 6). The pivot point enables you to accurately follow a line for resawing if your blade does not track absolutely parallel to the fence. After hand-planing the resawed stock for the wings, transfer the wing profile, the wing pin


and the wing screw holes, and drill these holes out. Don't forget that you'll be working with mirror images on the wings, so get the wing-pin hole and the wing-screw countersink on the proper side of each wing relative to whether it is the left-side or right-side wing. Next, cut the wings on the band saw (Step 7).

You'll need 11/4 in. thick stock for the two wheels. Although you could lathe-turn the blanks for the wheels, it's just as easy to rough out the blanks with the band saw, and then sand them on the disk sander. Lay out the cam profile using the full-size pattern as a guide, and then use the dovetail saw and chisel to shape the cam (Step 8). Drill out the $\frac{1}{16}$ in. diameter axle hole, and round the outside edge of the wheels (Step 9) before final assembling the bird (Step 10). Note that the dowel pin riding in the wing pin slot prevents the wings from pivoting too far. The wing movement depends on how you align the cams on the opposing wheels when the wheels are glued to the axle dowel. The cams aligned together will make the wings move in unison; 180-degree opposition of the cams will result in alternating wing movement. As with most wooden things for small children, no finish is always the best choice.






Step 1: Size stock for bird body.




Step 2: Transfer bird profile, including eyehole, axle hole, wing screw hole, and wing-pin slot.


44 The Woodworker's Journal




Step 3: Drill eye and axle holes; rout wing-pin slot.




Step 4: Cut out bird profile on band saw.




Step 5: Round over edges with $\frac{3}{8}$ in. radius round-over bit in router table.




Step 6: Resaw stock for wings.




Step 7: Lay out wing profile, drill screw and pin holes in wing, then cut to shape on band saw.



Step 8: Lay out, cut and shape wheels, using dovetail saw and chisel to shape cam.




Step 9: Drill axle hole in wheels; round outside edge to $\frac{1}{4}$ in. radius.




Step 10: Assemble bird.

(continued on next page)

September/October 1988 45





his nightstand was designed as a companion piece to the Pencil Post Bed on page 50, but it also works well on its own. You'll note how the tapered legs and the arched backsplash of the nightstand reflect the posts and headboard on the bed. Both projects are crafted in cherry, which darkens naturally to a deep, rich hue.

Begin by preparing and gluing up stock for the legs (A) and top (H). While you're waiting for these parts to

dry, dress material for all the remaining parts, including the aprons (B, C, and D), cleats (E, I), drawer guides (F), backsplash (G), and drawer (J, K, L, and M). Note that the front apron part, long cleats, and drawer guides are oversize, since they are cut to fit later. Also, all the drawer parts should be oversize, since the drawer must be made to fit the actual opening after the stand has been constructed.


The front apron is cut from a single


board. Rip a 1 in. wide strip, a 4 in. wide strip, and a 1 in, wide strip in that order, then crosscut the ends of the center section to create the drawer opening. If you are careful to match the grain when assembling the front apron, glue lines should be undetect-

The mortises in the legs to accept the apron tenons are cut before the legs are tapered. Cut the matching tenons on

(continued on next page)

September/October 1988





Bill of Materials (all dimensions actual)

t Description	Sizo ''	lo. q'd.
Leg	1¾ × 1¾ × 29¼	4
Front Apron	$\frac{3}{4} \times 6^* \times 16\frac{1}{2}$	1
Side Apron	$\frac{3}{4} \times 6 \times 11\frac{1}{4}$	2
Back Apron	$\frac{3}{4} \times 6 \times 16\frac{1}{2}$	1
Long Cleat	$1 \times 1\frac{3}{4} \times 11$	4
Drawer Guide	$\frac{3}{4} \times \frac{3}{4} \times 11$	2
Backsplash	$\frac{3}{4} \times 1\frac{3}{4} \times 16\frac{3}{4}$	1
Тор	$\frac{3}{4} \times 14 \times 20$	1
Short Cleat	$\frac{3}{4} \times \frac{3}{4} \times 3$	1
Drawer End	$\frac{1}{2}$ × 4 × 13 $\frac{1}{2}$	2
Drawer Side	$\frac{1}{2} \times 4 \times 11\frac{1}{2}$	2
Drawer Bottom	$\frac{1}{4}$ × 11 × 13	1
Drawer Face	$\frac{3}{8} \times 4\frac{1}{2} \times 14$	1
Knob	See Detail	1
	Leg Front Apron Side Apron Back Apron Long Cleat Drawer Guide Backsplash Top Short Cleat Drawer End Drawer Side Drawer Bottom Drawer Face	Leg $1\frac{3}{4} \times 1\frac{3}{4} \times 29\frac{3}{4}$ Front Apron $\frac{3}{4} \times 6^* \times 16\frac{3}{2}$ Side Apron $\frac{3}{4} \times 6 \times 16\frac{3}{2}$ Side Apron $\frac{3}{4} \times 6 \times 16\frac{3}{2}$ Long Cleat $1 \times 1\frac{3}{4} \times 11$ Drawer Guide $\frac{3}{4} \times \frac{3}{4} \times 11$ Backsplash $\frac{3}{4} \times 1\frac{3}{4} \times 11$ Backsplash $\frac{3}{4} \times 1\frac{3}{4} \times 16\frac{3}{4}$ Top $\frac{3}{4} \times 14 \times 20$ Short Cleat $\frac{3}{4} \times \frac{3}{4} \times 3$ Drawer End $\frac{1}{2} \times 4 \times 13\frac{1}{2}$ Drawer Side $\frac{1}{2} \times 4 \times 11\frac{1}{2}$ Drawer Bottom $\frac{1}{4} \times 11 \times 13$ Drawer Face $\frac{3}{8} \times 4\frac{1}{2} \times 14$

*Width of stock for front apron must be wider before machining to allow for ripping cuts during apron assembly. the aprons, and test-assemble the legs and aprons. If everything fits, you can establish the leg tapers now. This process is the same outlined in the instructions for making the tapered pencil posts for the bed. Finish sand the legs and aprons before gluing and assembling them. This assembly should be done upside down, and on a flat surface such as your saw table, to keep the legs and aprons square.

Now cut and fit the long cleats and drawer guides. The slotted holes in these cleats will direct any movement in the top toward the back. Cut out the backsplash, and glue it to the top with

several locating dowels, as shown. The dowels aren't needed for strength, but prevent the pieces from slipping as clamp pressure is applied. Add the short cleat along the front apron, and mount the top.

We chose to make a dovetailed drawer box with an applied face. The use of an applied face makes it easier to cut the dovetails. Note the chamfer around the face, softening the edge. You could lathe-turn the knob (N), or a similar knob, made of maple, can be ordered from Shaker Workshops, P.O. Box 1028, Concord, MA 01742. Specify their part no. 531.

ur photo of the Pencil Post Bed speaks far more eloquently of it than any description we might attempt. Suffice it to say that as handsome as it is in the photo, it is this and much more in person. With its companion piece, the nightstand, the bed makes an impressive statement in any bedroom.

The design is versatile enough to complement and fit comfortably with many different styles, from country and traditional to contemporary.

We selected cherry for this piece, because of its strength, workability, and the rich warmth of the wood. Traditionally, pencil post beds were made of maple with wide pine stock for the headboard. Rope served both to hold the parts of the bed frame together and to support the mattress. Bed bolts, which became common around 1750, kept the bed frame rigid, even when the rope spring supports stretched and sagged. Noted bed-



builder Charles E. Thibeau tells us that the wooden bed frame, called the bedstead, was valued far less than the bedclothes, covers, and hangings, which were called the "furniture." The tester frame, mounted on the ends of the pencil posts, supported the hangings, which consisted of a tester cover, valance, head cloth, head curtains, foot curtains and base. This bed furniture was an essential item in the small and poorly insulated homes of our forebears, where both warmth and privacy merited great value. The tester cover, head cloth, and valances are fastened to the tester frame with tack strips and tacks, although you could tack directly into the tester frame. Velcro also works well. The cover photo of the bed shows it dressed with base and valance curtains. We might add that the tester frame and the bed furniture are optional, and that the bed is just as handsome without all the trappings.

Thibeau also tells us that many of the original pencil post beds were finished with milk paint, although we shudder to think that anyone would consider covering a cherry bed with

paint. If you decide to paint the bed and you are a stickler for authenticity, milk paint can be ordered from: The Old-Fashioned Milk Paint Company, Box 222, Groton, MA 01450.


We started by gluing up 8/4 stock to get the required thickness for the four posts (A). If you have access to 12/4 stock, you'll save some time here. You'll also need to edge-glue material to get the needed width for the headboard (D). Dimension stock for the rails (B, C) and tester frame (E, F) while you are waiting for the other parts to dry. Next, lay out the mortise locations on the posts. Note that you'll need to identify the left and right posts. and mark out the mortises for the headboard. As shown in the detail, the headboard mortises are ¼ in. longer than the ends of the headboard, which allows for possible expansion of the headboard as equilibrium moisture content changes (see Woodworking Basics, page 12). The top of the mortise starts 38 in. from the bottom end of the leg. Once these mortises are cut. drill the hole for the dowel pin at the top of the mortise. The dowel pin anchors the headboard flush with the top

end of the mortise, and directs movement down, so that any small gap remaining at the bottom end of the mortise will be less visible.

Next, using a 1 in. diameter Forstner bit, counterbore to a 3/4 in. depth for the bed bolts (G). As illustrated, the end rail bolts are centered 20½ in. from the floor, while the side rail bolts are centered 191/2 in. from the floor. This offset is important so the bolts don't intersect. Drill through with a 13/32 in. brad-point bit to accept the bolt shanks, and chamfer the edge of the counterbore. The 3/8 in. diameter testerpin holes in the top ends of the posts are drilled next. Use a drill guide to insure squareness. We made ours from a block of wood.

You could establish the leg tapers now, but we found that it's best to first drill the bed bolt holes in the rails, cut all the tenons, and test-assemble the bed, since it's easier to make adjustments on the legs while they are square. Use a ¼ in. diameter Forstner bit to drill the 11/8 in. deep bed-bolt nut recess in the rails, then use a chisel to square the half of the recess closest to

(continued on next page)



the leg so it will accept the nut. Next, drill the bolt holes through from the ends using the jig shown. You'll need to make the guideblock $1\frac{1}{2}$ in. square, and drill a $1\frac{1}{32}$ in. diameter hole through the center. This same type of jig, made with a $2\frac{1}{2}$ in. square block, could be used to drill the tester-pin holes. Finally, cut the tenons on the rail ends.

We outlined this sequence of steps since some woodworkers may not have a set of auger bits, but an auger bit will simplify drilling the bolt holes into the rail ends. Cut the tenons on the rail ends first, dry assemble the bed, and using the shank holes through the posts as a guide, continue these shank holes into the rails.

To establish the tapers on the posts, first lay out an octagon on the top end, and mark the point 29 in. from the bottom where the tapers end. Mark the first four tapers, which are on the same plane as the four sides of each post, and rough them in with the band saw. You'll need to shim under the end with one of your waste pieces to make the last band saw cut. Now, using a sharp jack or jointing plane, smooth these tapers down to the line. The next four tapers are cut on the corners. After laying the tapers out, mount the post in the jig as shown, establish a saw kerf, chisel out an area until you can use the plane, and plane and smooth these tapers until you are satisfied with the results. Then establish the 45-degree beveled shoulder with the chisel, as indicated, and very lightly bevel the top and bottom ends of the posts.

The easiest way to lay out the radius on the headboard is to mark the center point at the top edge, and points on either side 6 in. down, and ½ in. from the ends. Then, with a pencil tied to a long string anchored with a nail, scribe the radius so you'll hit all three points. Our string was about 78 in. long, but you may need to adjust the length slightly to hit the three points. After shaping the headboard, drill the dowelpin holes, and glue these pins into the posts.

If you decide to make the tester frame, select good straight quarter-sawn stock for the greatest strength. Half-lap the ends, and drill through for the $\frac{3}{8}$ in. diameter steel pins (I) that anchor the tester frame to the bedstead.

After sanding all parts up through 220-grit, finish with three coats of tung

CUTTING FOUR PARE CHISEL AND LANE CHAMFER TOP OF LEG. PLANE CUT BEVEL SHOULDER WITH CHISEL


oil. Locate for the hardware, and drill pilot holes for all screws and brads before mounting the angle-iron boxspring supports (J) and the bed-bolt covers (H).

We've arranged with the mail-order supplier, Paxton Hardware, to offer a package deal on all the hardware (except the tester frame pins) required to make one bed, at a substantial savings off the same parts ordered separately. Ordering information is provided in the Bill of Materials. The tester frame pins are cut from 3/8 in. steel rod, sold at most hardware stores. Our bed is sized to accept a queen-size mattress and boxspring. No glue is used in the assembly of the bed, since all parts, including the headboard, should have knock-down capability to facilitate moving. WM

Bill	of	Materials
(all di	mer	sions actual)

(all dimensions actual)						
Pa	rt Description	Size No. Req'o				
Α	Post	$2\frac{1}{2} \times 2\frac{1}{2} \times 80$	4			
В	Side Rail	$1\frac{1}{2} \times 4 \times 81$	2			
С	End Rail	$1\frac{1}{2} \times 4 \times 61$	2			
D	Headboard	$\frac{3}{4} \times 18 \times 62$	1			
Ε	Tester Frame Side	$\frac{3}{4} \times 2 \times 84\frac{1}{2}$	2			
F	Tester Frame End	$\frac{3}{4} \times 2 \times 64\frac{1}{2}$	2			
G	Bed Bolt	6 in. long*	8			
Н	Bed Bolt Cover	1% in. dia. brass*	8			
1	Tester Frame Pin	$\frac{3}{8}$ in. dia. \times 2 long	4			
J	Spring Support	3 × 8*	8			


*Included in bed hardware package. Available from: Paxton Hardware, 7818 Bradshaw Rd., Upper Falls, MD 21156. Order part no. 8700. Cost is \$88.50 postpaid. If you don't have a 12-point mechanic's socket set, you'll need a special cast bronze bed-bolt wrench, also available from Paxton Hardware. Order part no. 6012. Cost is \$15.82 plus shipping if ordered separately.



September/October 1988

Shop Tips

An inexpensive yet sturdy cabinet hanger can be made from \(\frac{1}{8} \) in. thick by 3/4 in. wide aluminum. Many hard-




ware stores carry aluminum in that size. If the cabinet is heavy, make sure the hanger attached to the wall is well secured.

It's usually difficult to find a small part once it falls on the shop floor especially if the floor is covered with sawdust and woodchips. However, if the part is made of steel (or contains iron), try this trick before giving up. Carefully sweep the floor and collect the sweepings in a shallow box. Now run a strong magnet through the sweeping. You'll be surprised at how often you find the lost part sticking to the magnet.

Myron Magsig, Marysville, Ohio

For the sake of appearance, I often apply a solid stock edging to the front of a plywood shelf. And when several



shelves are needed, I find it's easier and faster to apply the edging to two at once. To do it, cut the edging a bit wider than necessary, then glue and clamp it between a pair of shelves. Once the glue dries, remove the clamps and rip the edging down the middle. It results in two shelves with an identical edging along the front.

> Brian J. O'Connor Wolverine, Mich.

When applying stain or paint with a small, round artist's or modelmaker's brush, I first slide an appropriately sized nut down the handle until it wedges near the brush end. This allows me to put the brush down without getting stain or paint on anything.

D. Harrison, Trenton, N.J.

The Woodworker's Journal pays \$25 for reader-submitted shop tips that are published. Send your ideas (including sketch if necessary) to: The Woodworker's Journal, P.O. Box 1629, New Milford, CT 06776, Attention: Shop Tip Editor. We redraw all sketches so they need only be clear and complete. If you would like the material returned, please include a self-addressed stamped envelope.

THE WOODWORKER'S MARKETPLACE



SIMPLE TO MAKE * FUN * PROFITABLE

- 200 pattern packet for scroll, band & jigsaws 'Country Critters"-100 patterns, unique projects
- 6 enjoyable "Wind-Action" whirligigs
- ☐ "Country Classics" best selling country projects
- ☐ 100 yard ornaments, animals, birds and more ☐ 17 "Show Stoppers" - craft show best sellers

Send \$7.00 per packet or 3 FOR ONLY \$14.00.

Fast Service • Satisfaction Guaranteed!

ACCENTS Dept. MJ98, Box 7387, Gonic, NH 03867

Catalog of 1000 patterns - \$100 (Free with order)

FTHE MODERN WOOD FINISHER 1904 REPRINT

"A Practical Treatise On Wood Finishing In All Its Branches'

Provides a wealth of information about woods and their proper finish, staining, varnishing, shellacking, refinishing, French Polishing and old stain formulas.

If you are a woodworker, refinisher, antique collector, restorer or just like the old ways, you will find this reprint very useful and informative.

176 pages (18 pages of old ads) softcover. \$8.00 plus .90 postage. Ed Hobbs, Dept. WWJ. 4417 Inwood Rd., Raleigh, NC 27603

DOMESTIC AND IMPORTED **VENEERS**

Over 140 varieties of Veneers, Complete Line of Tools for Veneering, Laminating and Marquetry.—Cements and Glues. Simplified Veneering Instructions and price list sent for \$1.00. HOMECRAFT VENEER 901 West Way; Latrobe, Pa. 15650





871-0722

SEND \$1.00 FOR CATALOG

HORTON BRASSES Nooks Hill Road P. O. Box 120 WJ Cromwell, CT 06416 (203) 635-4400

HORTON BRASSES are authentic copies of 17th, 18th, 19th & early 20th century pulls.



of Cabinet & Furniture Hardware for Homes & Antiques.

Send \$3.00 for a Catalogue

Sleeveless **DRUM SANDER** - no pre-made sleeves to buy! Uses regular sandpaper -Twist of key tightens sandpaper to drum. Rubber backing insures long sandpaper wear. \$13.95 \$15.95 \$16.95 \$17.95 \$27.95 \$56.95 1" x 3" long 2" x 3" long 2½" x 3" long 3" x 3" long 3" x 3" long 1" and 2½" above Set of 4 above %" x 3" long ... 2½" x 4½" long ... 3" x 4½" long ... 2½" x 6" long ... 3" x 6" long ... 3" x 6" long ... 3" x 6" long ... 4" ... 4" long \$14.95 \$21.95 \$23.95 \$25.95 Lifetime Guarantee \$27.95 3" x 6" long \$27.95 Add \$2.50 per order for shipping. USE ON AVAILABLE WITH: Drill priess, motor, lathe, combo-tools, radial saw, drills. "1/2" bore with 1/2" or 1/4" shaft "1/2-20 RH thread (except 3/4" x 3") "5/4" bore (except 3/4" x 3" and 2" x 3")

SINGLEY SPECIALTY CO. INC

CALL: (919) 852-8581

54

VISA

THE WOODWORKER'S MARKETPLACE







TURNING

DUPLICATORS SOLD WORLD

WIDE FOR OVER 34


YEARS Use it for PROFIT

or PLEASURE



ELAT TEMPLATE DUPLICATION Literature \$1.00 refundable with first order.

TURN-O-CARVE TOOL CO., P.O. Box 8315-WJ Tampa, Florida 33674



Ideas and plans for dozens of Holiday Projects to make in your shop.

Whether you make projects to resell or to give to friends, you'll love this all new 24 page catalog. Features dozens of project plans and hard-to-get parts. This catalog is a must if your planning a Holiday Boutique.


Send \$1.00 to help cover p & h. to: Christmas Catalog %Meisel Hdw. Sp. P.O. Box 70J10C Mound, MN 55364



PLUS MANY MORE PLANS SAVE BIG MONEY BUILDING THEM YOURSELF

Send Stamped Envelope for a FREE Brochure

SANDER - J P O Box 39081 Charleston, SC 29407








Xenia, Ohio 45385

woods... 150 veneers... 500 plans... cabinet hardware... 96 How-To Books... 118 carving tools and chisels... 76 inlay designs... and lots more for One-Stop, Right-Price Shopping without leaving home!







US 800 452-9999 VA 800-468-1778

September/October 1988

081

Top


THE WOODWORKER'S MARKETPLACE

Furniture Refinishing

Earn \$500 - \$1000 in a single day! Part-time, full-time opportunity. FREE catalog stripping, repairing, refinishing, mirror resilvering, veneering supplies & systems. Complete training provided. Send \$1 for postage & handling to: MINUTEMAN, INC., Dept. 06

115 N. Monroe St., Waterloo, WI 53594











The Classified Rate is \$1.50 per word. payable with order, Minimum ad length is 15 words, and the deadline date is the 25th of the 3rd month preceeding the issue (10/25 for the January/February issue). Send copy (count each word and initial) and check to The Woodworker's Journal, Classified Dept., P.O. Box 1629, New Milford, CT 06776.

Triad Clamp — The old original Black Bros. heavy-duty double bar clamps. Saw horse style featuring two $\frac{5}{16}$ " \times 2" spring steel bars clamping to 32" with pads 3\%' wide by 4" high using \%" square thread screw. Hardwood feet swivel to allow nesting, Shipping wt. 49 lbs, Each \$89,00 or two for \$169.00. Send check or C.O.D. Write or call: Triad Merrick Machine Co., P.O. Box 130, Alda, NE 68810. (308) 384-1780.

Ideal Woodworking Business. Work home. Unusual money-maker. Free brochure. Pine Shop, 897-3 Mammoth, Manchester, NH 03104.

Spray-On Suede Lining. Finish any project with a soft touch. Free brochure, sample enclosed. DonJer Products, Ilene Court -Bldg. 8R, Bellemead, NJ 08502. (800) 336-6537.

56

Country Woodcraft Patterns! Create decorative profitable "Country Cut" designs. Over 50 patterns, hundreds of projects plus woodcraft catalog \$7.00. Satisfaction Guaranteed! Accents (CJ-98), Box 7387, Gonic, NH 03867.

Make Wooden Toys, whirligigs, doll houses, clocks, music boxes, weather instruments, crafts, furniture with our plans, parts, kits, books, supplies - Catalog \$1.00 — (614) 484-4363 — Cherry Tree Toys, Belmont, OH 43718-0369.

Swing: Comfortable old-time platform family lawn swing. Detailed, illustrated plan with material list. Send \$8.00 to: Edward G. Mason, 8322 S. Howell Ave., Oak Creek, WI 53154.

Wanted: More Doo-Dads to try our fullsize woodworker's plans for wood toys, wagons, carts, sleds, rocking horses, cradles, carriages, playhouses, etc. Wood toys parts. Catalog \$3.00. L.O.G. Woodcraft, Box 39B, Grand Cascapedia, Quebec, Canada GOC 1T0.

Dealers and Distributors Wanted. Complete line of imported fine plank flooring, parquet, wall panel, decor panel. Sao Paulo International, P.O. Box 35149, Decatur, GA 30035.

Musical Instrument Kits — dulcimers, hammered dulcimers, banjos, mandolins and more. Color brochure 65° stamp. Folkcraft Instruments, Box 807-K, Winsted, CT 06098. (203) 379-9857.

Dulcimer Builder Supplies - Precision milled and fine sanded dulcimer and hammered dulcimer woods. Cherry, walnut, paduk, rosewood, birdseye, and curly maple, Sitka spruce, W.R. Cedar; related hardware, strings and accessories. 65° stamp for brochure. Folkcraft Instruments, Box 807-W, Winsted, CT 06098. (203) 379-9857.

Wood Moulding Knives made for Belsaw type planer molders. Custom knife grinding specialist. Wanager Custom Knives, 536 East B, Kingman, KS 67068. (316) 532-5391.

Silhouettes — Over 400 include Old-Time, Trains, Sports, Horses, Carriages, etc. For decor, signs, windvanes, whatever. Directions to enlarge. Refund guarantee. \$10.00 postpaid. Geecraft, Box 391, Blue Earth, MN 56013.

Post Office Box Bronze Doors: No. 1 & No. 2 \$5.00 ea., No. 3 \$8.00 ea. Postpaid 10 or more assorted; \$1.00 ea. shipping less than 10. SASE: Hubbert, P.O. Box 1415, Fletcher, NC 28732.

The Woodworker's Journal

CLASSIFIED

Discounted Woodworking Machinery — List your machinery needs on postcard for quote. You'll be surprised! Conestoga Wood Machinery, Box 810-WJ, Route 1, New Holland, PA 17557-9792.

Quartz Clock Movements — digitals \$1.50, epoxy resin \$7.50, foil prints 95°, music movements \$1.40, complete clock kits \$6.50, components, plans, much more! 64 page wholesale catalog \$3.00 (credited). Steebar, Box 980-E, Andover, NJ 07821-0980.

I made \$3,000 monthly woodcrafting toys, gifts, novelties . . . Why not you? Free details. Gundaker, Dept. 5G, Box 3628, Erie, PA 16508.

Blueprints . . . 77 Classic Barns, Minibarns, Craftshops, Garages. DIY Catalog \$4.00 (refundable). Ashlandbarns, 990WJ Butlercreek, Ashland, OR 97520.

Bandsaw Boxes! Create profitable jewelry boxes, mini-drawers, desk accessories . . . more! Fourteen plans/patterns plus woodcraft catalog \$7.00. Satisfaction Guaranteed! Accents (XJ-98), Box 7387, Gonic, NH 03867.

Wood Supplies Wholesale: Shaker pegs, candle cups, hearts, dowels, toy parts. Free catalog. Rainbow Woods, 20 Andrews St., Newnan, GA 30263.

Hardwood lumber, kiln dried, large variety of species in several thicknesses and grades. We also carry basswood carving stock, spalted blocks, curly and wormy maple, steam bending woods, flooring, paneling, and finishing supplies. No minimum order, size selection available. Call or send stamp for listing. Garreson Lumber, Dept. B, RD 3, Bath, NY 14810. (607) 566-8558.

White Cedar Blocks for carving decoys, birds, or any carving project that requires soft, workable wood. Send SASE for free pricelist. Seaside Forest Products, RR #2 Box 51, Lubec, ME 04652.

Chair Caning Supplies — cane webbing, rush, splint, ash, rawhide, cord. Catalog \$1.00 (refundable). Caning Shop (WJ), 926 Gilman, Berkeley, CA 94710.

Start Moneymaking Woodcraft Business making "Easy-Quick" toys, gifts, novelties. Free details. Williams, 3600J San Sebastian, Tucson, AZ 85715.

Full-size wooden toy patterns, unique new designs, fast service. Catalog \$1.00 refundable. Yesteryear Toy Shop, RD 1, Knox, PA 16232.

Full-size peg rack patterns — dogs, cats, moose, duck, train. \$5.00. C. Blackwood, 4901 County Farm Rd., Jackson, MI 49201.

Bookcases, Entertainment Centers, Waterbeds, Bedroom and Children's Furniture, etc. Catalog \$3.75 (refundable). Over 70 professionally designed plans! Kraemer Furniture Designs, 1350 Main St., Plain, WI 53577.

Woodentoy — patterns, project books, hardwood wheels, pegs, cargo, people and more. Send \$1.00 for catalog, \$3.00 for catalog plus 2 patterns, or free brochure. Woodentoy, Box 40344-WWJ, Grand Junction, CO 81504.

It's possible to turn \$1's wood into \$16 necessity in five minutes flat, using elementary procedure, and meet brisk demand or refund. \$5.00: APCO, Box 1025A, Cambridge, MA 02140.

Patterns/Instructions — Wood Cutouts — "Santa"; "Deer"; "Sleigh"; "Snowman"; "Goose"; each \$3.50. Indoor-outdoor-"country" catalog \$1.00. Fourth Dimension (WW98), 85 Helmar Dr., Spencerport, NY 14559.

Exotic Woods: Bought out supply of established company. Have many varieties. Send for catalog. SASE. Acacia Hardwoods, Route 4 Box 130, Dept. WJ, Lubbock, TX 79424. (806) 794-5099.

Woodturning Workshops. Two, three and five-day classes include functional and artistic turnings. Gallery B, 11324 Arcade Dr., Little Rock, AR 72212. (501) 221-0266.

300 + Plans — Build shop machines and accessories. Catalog \$1.00 refundable. Wood-Met (WJ), 3314 Shoff, Peoria, IL 61604.

Custom Turning — Have turnings made to your exact specifications. Furniture reproduction, porch railings and stairway balusters a specialty. For free brochure send to: River Bend Turnings, Box 364 Dept. WJ, RD #1, River Rd., Wellsville, NY 14895.

Special Offer — 60 days only. 50 Full Size Patterns \$12.95 postage paid. Satisfaction Guaranteed. J & R Woodcraft, Three Forks Church Rd., Route 2 Box 473, Taylorsville, NC 28681.

White Cedar Lumber for all your indoor and outdoor projects. Please send \$1.00 (refundable) for price list and sample. Seaside Forest Products, RR #2 Box 51, Lubec, ME 04652.

Woodworkers: Make \$100 every Saturday with your shop scraps! Complete instructions \$3.75. Cedartree, Box 744E, Oregon City, OR 97045.

Hardwoods by UPS. Pennsylvania mountain hardwoods at reasonable prices. Quality selected kiln-dried wood for the discriminating craftsman at below retail prices. Custom sizes or random lots mailed to your door. Write for price listing: Croffwood Mills, Route 1 Box 38-J, Driftwood, PA 15832.

Thin Hardwoods, ½2" to ½" thick, Cherry, Walnut, Butternut, Oak, etc. Large SASE. Shaker Miniatures, Dept. WJ, 2913 Huntington Rd., Cleveland, OH 44120.

Stainless steel and brass, screws and bolts. Small quantities, free catalog. Elwick, Dept. 704, 230 Woods Lane, Somerdale, NJ 08083.

Bagpipe plans. Highland \$11.00; Fireside \$8.00. Practice Chanter \$3.00. Mailing \$2.00. Dougan, 138 Lochview Drive, Glasgow, G33 1QF, Scotland.

Wheels (per 100) 1" \$5.25, 1½" \$7.75, 2" \$16.25, Wood barrels or drums \$2.00 per 10, Shaker pegs \$11.00 per 50, Smokestacks \$7.00 per 25. Add \$3.25 S & H, Free Catalog, K & K Woodcrafters, RD #4 Box 270A, Scotia, NY 12302.

INDEX TO ADVERTISERS Meisel Hardware Specialties Floral Glass & Mirror Accents 8,55 Woodworking Association Foley-Belsaw 9 Minuteman, Inc. 18 **Advanced Machinery Imports** 14 56 of North America Benny's Woodworks 5 MLCS 22, 24, 25, 27 Wilke Machinery 23 56 Freud Furniture Designs 56 Nova Tool 24 Williams & Hussey 10 Black & Decker 2 Brookfield Craft Center 27 Grizzly Imports 4. 6. 11 Nutty Co. 56 The Winfield Collection 55 **Brown Wood Products** Ed Hobbs Roga Enterprises Woodcraft Supply 19 55 54 Byrom International 14, 55, 56 Homecraft Veneer Sakura, U.S.A. 55 Woodmaster Tools 22 Cascade Precision Tool Horton Brasses 54 Sander 55 Wood-Mizer 18 16 Woodworker's Supply Imported European Hardware 54 Singley Specialty 54 Constantine 55 Dakota Wind 55 Jesse Jones 14 The Source 55 of New Mexico 24 Madrigal Publishing 19, 20 56 22 Tarjany Designs The Woodworking Show 22 Excalibur Mason & Sullivan 24 Turn-O-Carve Tool 55 Fisher Hill 56 54 McCall House Van Dyke's Restorers 55 Flexiplans



BACK ISSUES

Back issues are \$3.50 each ppd. (\$4.50 Canada funds). To order use the form bound between pages 30 and 31 of this issue.

Vol. 7 No. 1 Jan-Feb '83

Workshop Tote Box, Tinsel-Art Mirror, European Spinning Wheel, Key Holder, Dump Truck Toy, Bang-a-Peg Toy, Puzzle, Wall Cabinet w/ Reverse Glass Stencil, End Grain Table Lamp, Butler's Tray Table, Contemporary Clock, Pine Cabinet, Articles: Miter & Spline Joints; The Added Costs of Being in Business; Selecting Clear Finishes.

Vol. 7 No. 2 Mar-Apr '83

Porch Swing, Homemade Jigsaw, Cheval Mirror, Punched Tin Spice Cabinet, Television Stand, Nautical Table Lamp, Wooden Balance, Nesting Cube Tables, Steam Roller Toy, Back Massager, Mailbox, Wall Shelf, Chippendale Mirror, Clock Parts and Suppliers, Articles: Flat Miter Joints with the Table Saw and Router; Woodworking for Fun vs. Woodworking for Work; Applying a Clear Finish.

Vol. 7 No. 3 May-June '83

Not Available

Vol. 7 No. 4 July-Aug '83

Turned Lamp, Decoy Carving, Antique Sugar Chest, Record Album & Tape Cabinet, Chinese Tea Table, Old-World Weather Forecaster, Toy Tractor & Cart, Display Pedestal, Two Planter Projects, Collector's Plate Stand, Hardware Suppliers, Articles: Dovetail Joints: Part I; Keep Track of Costs or You'll Be Overtaxed; Some Spraying Techniques; Inlaid Edging.

Vol. 7 No. 5 Sept-Oct '83

Not Available

Vol. 7 No. 6 Nov-Dec '83

Not Available

Vol. 8 No. 1 Jan-Feb '84

Shaker End Table, Medicine Cabinet, Cassette Tape Rack, Captain's Clock, Stacking Storage Unit, Veneer Bracelets, Toy Car Carrier, Infant Bead Toy, French Bread Cutter, 19th Century Kitchen Clock, Early American Trestle Table & Benches, Table Saw Cut-Off Table, Coaster Set, General Woodworking Suppliers, Articles: Doweling Details; Sources of Information; Restoring Hopeless Cases; Mirror Image Panels.

Vol. 8 No. 2 Mar-Apr '84


Not Available

Vol. 8 No. 3 May-June '84

Country Vegetable Bin, Folding Deck Chair, Shaker Pedestal Table, Wall Hung Display Cabinets, Wooden Coat Hanger, Toy Car and Trailer, Paper Towel Holder, Carved Hand-Mirror, Writing Desk, Carved Walking Stick, Laminated Clock, Oak and Glass End Table, Articles: How to Lay Out and Make Circular Cuts; Mail Order Selling; Stripping Old Finishes; Carving the Ball-and-Claw Foot.

Vol. 8 No. 4 July-Aug '84

Wag-on-Wall Clock, Oak Swing, Candy Dispenser, Coffee and End Tables, Tugboat and Barge, Lazy Susan, Early American Mirror, Colonial Pipe Box, Sewing Machine Cabinet, Cam Clamp, Hamper, Articles: What Sells Best?; Homemade Removers; Buying a Basic Set of



Hand Tools; Kerf Bending; Suppliers of Caning & Wood Finishing Products.

Vol. 8 No. 5 Sept-Oct '84

Contemporary Stereo Cabinet, Shaker Woodbox, Bongo Box, Nesting Tables, Shop Trammel, Jack-knife Letter Opener, Salt Shaker and Pepper Mill, Toy River Ferry and Car, Toy Top, Cookbook Holder, Hall Table, Grandfather Clock: Part I, Articles: Starting a Business: Part I; Applying Filler; Building a Basic Workbench; Making Specialty Moldings with the Table Saw and Scratch Beader.

Vol. 8 No. 6 Nov-Dec '84

Stickley Chair, Tool Cabinet, Shaker Sewing Stand, Lighted Display Pedestal, Teardrop Clock, Pierced Tin Cabinet, Toy Hook and Ladder Fire Truck, Busy Bee Toy, Colonial Doll House, Kitchen Organizer, Wine Server, Grandfather Clock: Part II, Articles: Starting a Business: Part II; Applying the Final Finish; The Fundamentals of Wood; Inlays and Inserts; Gustav Stickley and American Mission Furniture.

Vol. 9 No. 1 Jan-Feb '85

Early American Step Table, Oak Barrister's Bookcase, Parquet Table, Shaker Trestle Table, Bandsawn Wooden Scoops, Toy Biplane, Book Ends, Contemporary Candle Holders, Necktie and Belt Holder, Keyed Miter Jig, Modular Coffee Table and Bar, Magazine and Book Rack, Contemporary Chest of Drawers, Articles: Toys and Children's Articles: An Outline of The Consumer Product Safety Commission Standards; Shellac; Truing and Squaring Lumber; The Fingerjoint Spline; Suppliers of Furniture Kits; The Shakers; Special Section: Back Issue Index.

Vol. 9 No. 2 Mar-Apr '85

Queen Anne Lowboy, Television/VCR Stand, Early American Pine Corner Cupboard, Toy Tool Set, Windspinner, Woodchopper Whirligig, Chinese Puzzle, Cut-off Jig, Blanket Chest, Shaker Harvest Table, Blacksmith's Tool Tray, Articles: A Guide to Photographing Your Work; Applying Shellac and Lacquer; Sharpening Plane Blades and Chisels; Installing Machine Woven Cane; American Queen Anne, 1715-1755; General Woodworking Suppliers.

Vol. 9 No. 3 May-June '85

Jacobean Joint Stool, Wall Cabinet with Recessed Finger Pulls, Shaker Desk, Kitchen Cart, Contemporary Wall Clock, Colonial Wall Sconce, Card Box, Towel Bar with Glass Shelf, Marble Race Toy, Cradle, Vanity Mirror, Miter Clamping Jig, Articles: Product Liability: Part I; Restoring an Antique Mirror Frame; Coping with Wood Movernent; Making Recessed Finger Pulls; The Jacobean Period.

Vol. 9 No. 4 July-Aug '85

Gate-Leg Table, Computer Desk, Shaving Horse, Stamp Dispenser, Crumb Collecting Breadboard, Toy Trucks, Early American Wall Shelf, Pivot-Top Game/Coffee Table, Settle Bench, Shaker Single-Drawer Cupboard, Fold-up Workbench, Articles: Product Liability: Part II; Caning and Wood Finishing Supplies; Spray Finishing; Table Saw Basics; Making the Rule Joint; The William and Mary Period.

Vol. 9 No. 5 Sept-Oct '85

Colonial Schoolmaster's Desk, Contemporary Sideboard, Mahogany End Table, Victorian Hall Tree, Cutiery Wall Cabinet, Swing-out Plant Hanger, Prancing Hoxse Silhouette, Block Puzzle, Iron Caddy, Toy Ironing Board, Early American Water Bench, Wooden Smooth Plane, Shaker Sewing Box, Articles: A Craft Fair Visit; How to Use Stick Shellae; A Guide to Circular Saw Blades; Making Bent Laminations; Country Colonial Furniture.

Vol. 9 No. 6 Nov-Dec '85

Moravian Chair, Dulcimer, Oak Dining Table, Shaker Washstand, Marking Gauge, Veneered Wall Clock, 4 x 4 Off-Roader, Teddy Bear Puzzle, Duck Pull-toy, Landscape Cutting Boards, Early American Tall Clock, Pine Desk Organizer, Articles: Secrets of Success; Weaving a Fiber Rush Seat, Part I; Table Saw Ripping Problems and Their Solutions; 4-Piece Book Match Veneering; Pennsylvania Dutch Furniture.

Vol. 10 No. 1 Jan-Feb '86

Freestanding Shelf System, Chippendale Bachelor's Chest, Oriental Serving Tray, Country Bench, Antique Knife Tray, Tape Dispenser, Valentine Box, Toy Tow Truck & Car, Shaker Drop-leaf Table, Shop-made Bow Saw, Child's Settle Bench, Plate Shelves, Articles: On Getting



Paid for Your Work; Weaving a Fiber Rush Seat, Part II; Table Saw Crosscutting: Techniques & Tips: Router-Lathe Fluting: A Shop-made Approach; Chippendale Furniture; Special Section: Back Issue Index.

Vol. 10 No. 2 Mar-Apr '86

Not Available

Vol. 10 No. 3 May-June '86

Victorian Whatnot Shelf, Contemporary Lamp, Early American Bench, Steam-bent Clock, Pine Hutch/Cupboard, Canada Goose Basket, Toy Crane, Condiment Holder, Shop Workstation, Parsons Table, Shaker Lap Desk, Articles: An Interview with Toymaker Clare Maginley; How to Flatten a Warped Board; A Guide for Choosing Your First Router; Supported Steam Bending; Victorian Period.

Vol. 10 No. 4 July-Aug '86

Shaker Slat-Back Side Chair, Wall-Hung Display Cabinet, Latticework Planter, Country Bucket Bench, Adirondack Chair, Coffee Mill, Clamdigger's Basket, Box of Shapes Toy, Disk Clock, Tenon Jig, Dictionary Stand, Articles: Selecting the Right Project for Production; More About Warped Boards; All About Router Bits; The Sliding Dovetail Joint; Furniture Kits Suppliers.

Vol. 10 No. 5 Sept-Oct '86

Desk with Tambour Top, Vanity Case, Stool, Coffee Table, Blanket Chest, Mortar and Pestle, Whale Folk Art Silhouette, Toy Wagon, Cranberry Rake, Router Bit Box, Shaker Dropleaf Table, Articles: Are Your Prices Competitive?; Restoring a Rosewood Chair; Basic Router Operations; Making Tambour Doors; General Woodworking Suppliers.

Vol. 10 No. 6 Nov-Dec '86

Early American Hamper, Cube Table, Rabbit Pull Toy, Old-Time Sled Wall Shelf, Cassette Tape Holder, Dog/Cat Bed, Vanity Mirror, Early American Washstand, Router Table, Victorian Sleigh, Articles: Wholesale and Discount Sources of Supply; Sandpaper Abrasives; Using the Router Table; The Mitered Bead Frame and Panel; Clock Parts Suppliers.

Vol. 11 No. 1 Jan-Feb '87

Shaker Blanket Chest, Glass-Top Dining Table, Dovetailed Stool, Jewelry Box, Door Harp, Toy Firetruck, Canada Goose Mobile, Balancing Sawyer Folk Toy, Early American Style End Table, Jointer Push Board, Articles: Direct Mail Promotions - Defining the Market for Your Work; Old Wood; The Mortise and Tenon, Part I; Combination Hand/Router Dovetailing; Special Section: Back Issue Index.

Vol. 11 No. 2 Mar-Apr '87

Shaker Sewing Desk, Garden Bench and Table, Mirrored Wall Shelf, Rhombohedron Puzzle, Wood Sawyer Whirligig, Folk Art Door Stop, Kangaroo Pull Toy, Colonial Pine Wall Shelf, Contemporary Hall Table, Articles: How to Create a Direct Mail Promotion; Types of Finish An Overview; The Mortise and Tenon, Part II; Making Bevel-Edged Drawer Bottoms.

Vol. 11 No. 3 May-June '87

Display Pedestal, Kitchen Canister Set, Riding Biplane, Contemporary Serving Cart, Napkin Holder, Decorative Planter, Country Vegetable Bin, Pine Medicine Cabinet, Shop Drum Sander, Vienna Regulator Clock, Articles: Penetrating Oils and How to Use Them; The Jointer; Veneer, Part I; Decorative Joinery: Dovetail Key Butt-Miter; Caning and Wood Finishing Suppliers.

Vol. 11 No. 4 July-Aug '87
TV/VCR Cabinet, Early American Style
Bookcase, Pine Trash Container, Sturdy Low-cost Workbench, Country Basket, Desk Calendar with Pen & Pencil, Butterfly Pull Toy, Vanity Mirror with Drawer, Apothecary Chest, Articles: Shellac; The Hand Plane; Veneer, Part II; Incised Carving; Hardwoods Suppliers.

Vol. 11 No. 5 Sept-Oct '87


Pine Woodbox, Contemporary Love Seat, Two-Drawer Oak Platform Bed, Snail Pull Toy, Routed Trivets, Spice Rack with Chip Carving, Joiner's Tool Chest, Shaker-style Step Stool, Turned Shop Mallets, Articles: French Polishing Made Easy; Plane Iron Sharpening; Making a Splayed Leg Drill Guideblock; Traditional Chip Carving; Shop-Tested: 12 Jigsaws.

Vol. 11 No. 6 Nov-Dec '87

Curio Cabinet, Rocking Horse, Three-drawer Jewelry Chest, Tapering Jig, Rolling Toy, Folk Art Silhouette, Two Towel Racks, Early American Style Wall Shelf, Corner Cupboard, Stacking Wine Racks, Articles: On Glues and Gluing; Band Saw Setup; Making the Continuous Bracket Foot; Step-By-Step To A Flawless Finish On Pine (Or Any Other Wood); Hardware Suppliers.

Vol. 12 No. 1 Jan-Feb '88

Early American Pierced Tin Cabinet, Contemporary Coffee Table, Puss 'n Books Bookends, Cookbook Holder, Wooden Jewelry, Child's Duck Puzzle, Shaker Wall Clock, Stereo Cabinet and Speakers, Country Occasional Table, Drill Press Jig, Articles: Edge-gluing; The Drill Press; Pierced Tin; Four Shopmade Finishes; General Woodworking Suppliers.



Vol. 12 No. 2 Mar-Apr '88

Folk Harp, Oak & Glass Tier Table, Crystal Regulator Clock, Early American Candlesticks, Arrow Wall Decoration, Three-Drawer Country Wall Box, Key Cabinet, Contemporary Box, Shaker Carrier, Articles: Use and Sharpening of the Hand Scraper; The Lathe: Basic Setup; Quartered Turnings; Lacquer; Stationary Tool Suppliers.


Vol. 12 No. 3 May-June '88

Hunt Table, Loon Carving, Early American Dry Sink, Contemporary Dresser, Old-Time Pipe Box, Antique Knife & Fork Tray, Dutch Tulip Folk-Art Silhouette, Colonial Salt Box, Bud Vase, Miter Gauge Stop, Articles: Spindle Turning; Selecting and Sharpening Lathe Tools; Recessed Finger Pull Step-By-Step; Types of Stain; Clock Parts Sup-

Vol. 12 No. 4 July-Aug '88


Four-Drawer Lamp, Oak Magazine Rack, Occasional Table, Mitered-Corner Box, Heart Stool, Decorative Cutting Boards, Kids' Piggy Bank, Turned Bowl, Country Cupboard, Articles: Faceplate Turning; Workshop Layout; Cutting Dovetails on the Table Saw; Staining Basics; Schools and Craft Centers.

BOOKS from The Woodworker's Journal




Projects for Woodworkers, Volume 1

Beginning and advanced woodworkers alike will appreciate this selection of 75 projects from the 1980-81 issues of *The Wood*worker's Journal. Includes furniture, accessories, lamps, clocks, toys and gifts.




Projects for Woodworkers, Volume 2

Originally published in the 1982 issues of *The Woodworker's Journal*, all 60 projects were chosen with a wide variety of styles and skill levels in mind. From household accessories to major furniture, each project is presented with complete instructions and thorough illustrations.



101 Projects For Woodworkers

An unparalleled variety of classic projects from the 1977-80 issues of *The Woodworker's Journal*. From the eager amateur just starting out to the craftsman with a shop full of tools, 101 Projects for Woodworkers has plans for everyone.



Contemporary Woodworking Projects

The author guides woodworkers of all skill levels through roomby-room chapters of coordinated furniture and accessories. The graceful lines, clean angles, sturdy joinery and special techniques are made easy to master with step-by-step instructions and illustrations.

You'll find the handy order form for these books bound between pages 30 and 31.

Next Issue . .

is already taking shape in our shop. Here are just three of the projects you'll get: Shaker High Chest crafted in butternut, Classic Pickup in contrasting hardwoods and the Whale Pull Toy. Plus, you'll find six more projects for all levels of woodworkers, with the down-to-earth instructions and clear illustrations you need to build them.

