

Use the figure above for reference when positioning the parts. Attach the front End Rail and Stretchers to the Side Rails using exterior-grade glue and 2 1/4" pocket hole screws. Attach the Front Legs and Back Legs to the Rail/Stretcher Assembly using glue and 2 1/2" deck screws. Be sure to position the Back Legs so the end with the pocket holes is at the top and on the inside of the assembly. Attach the back End Rail to the Side Rails using glue and 2 1/2" deck screws. Note: Use three screws (both pocket hole and deck) at each joinery point.

Back Leg -

Side Rail


30 3/4"_






PARTS
End Rails - (2) 1 1/2 x 3 1/2 x 27
Stretchers - (2) 1 1/2 x 3 1/2 x 24
Side Rails - (2) 1 1/2 x 3 1/2 x 69 5/8
Front Legs - (4) 1 1/2 x 3 1/2 x 14
Back Legs - (2) 1 1/2 x 3 1/2 x 37 1/4
Back Stiles - (2) 1 1/2 x 3 1/2 x 37 1/8
Back Rail - (1) 1 1/2 x 3 1/2 x 21
Wide Seat Slats - (5) 1 1/2 x 3 1/2 x 31 1/2
Narrow Seat Slats - (4) 1 1/2 x 3 1/2 x 31 1/2
Storage Slats - (5) 1 1/2 x 3 1/2 x 31 1/2
Back Slats - (7) 1 1/2 x 3 1/2 x 31 1/2

LUMBER 5 - 2 x 4 x 8 2 - 1 x 6 x 8 5 - 1 x 4 x 8







SUN LOUNGER





End Rails - (2) 1 1/2 x 3 1/2 x 27 Stretchers - (2) 1 1/2 x 3 1/2 x 24 Side Rails - (2) 1 1/2 x 3 1/2 x 69 5/8 Front Legs - (4) 1 1/2 x 3 1/2 x 14 Back Legs - (2) 1 1/2 x 3 1/2 x 37 1/4 Back Stiles - (2) 1 1/2 x 3 1/2 x 31 7/8 Back Rail - (1) 1 1/2 x 3 1/2 x 21 Wide Seat Slats - (5) 1 1/2 x 3 1/2 x 31 1/2 Narrow Seat Slats - (4) 1 1/2 x 3 1/2 31 1/2 Storage Slats - (5) 1 1/2 x 3 1/2 x 31 1/2 Back Slats - (7) 1 1/2 x 3 1/2 x 31 1/2

LUMBER 5 - 2 x 4 x 8 2 - 1 x 6 x 8 5 - 1 x 4 x 8



Position one Wide Seat Slat overhanging the front edge of the assembly by 3/4-inch and centered across the width of the assembly. Attach using glue and 1 1/2" deck screws. Alternate placement between the Narrow Seat Slats and Wide Seat Slats, spacing them 1/4" apart, and attach using glue and 1 1/2" deck screws.



Position the Storage Slats centered across the width of the assembly, spaced 1/8" apart, and attach using glue and 1 1/2" deck screws.



Position the Back Slats centered across the width of the Back assembly, spaced 3/4" apart, and attach using glue and 1 1/2" deck screws.





End Rails - (2) 1 1/2 x 3 1/2 x 27

Stretchers - (2) 1 1/2 x 3 1/2 x 24

Side Rails - (2) 1 1/2 x 3 1/2 x 69 5/8

Front Legs - (4) 1 1/2 x 3 1/2 x 14

Back Legs - (2) 1 1/2 x 3 1/2 x 37 1/4

Back Stiles - (2) 1 1/2 x 3 1/2 x 31 7/8

Back Rail - (1) 1 1/2 x 3 1/2 x 21

Wide Seat Slats - (5) 1 1/2 x 3 1/2 x 31 1/2

Narrow Seat Slats - (4) 1 1/2 x 3 1/2 x 31 1/2

Storage Slats - (5) 1 1/2 x 3 1/2 x 31 1/2

Back Slats - (7) 1 1/2 x 3 1/2 x 31 1/2

LUMBER 5 - 2 x 4 x 8 2 - 1 x 6 x 8 5 - 1 x 4 x 8

CUTTING DIAGRAM

Use treated, cedar, or redwood for the 2x4s; cedar or redwood for the 1x4s and 1x6s

