

This is a book with a fresh approach. Not simply a do-it-yourself and not a book of designs. The Book of Furniture Making is a practical and comprehensive manual which caters for all levels of skill and for all tastes. Laymen and skilled carpenters alike will be able to build their own furniture for every room in the house — as well as for out of doors.

Each chapter is devoted to a different area of the home – kitchen, bedroom, living room, study/work room, children's area and garden/patio – each with a wide range of projects and designs. Each project includes a shopping list and cutting list, as well as detailed step-by-step instructions, diagrams and photographs.

A major feature of the book is the comprehensive Tools and Techniques section, which is really a complete book in itself. There is advice on how to use tools, from the simplest hammer, screwdriver and saw to power tools – and scores of tips are given on how to achieve attractive and economic results, even how to cover up your mistakes.

All this is the work of a skilled craftsman and designer. Alf Martensson, who has created a practical book to combine the basic step-by-step approach with a unique design flair.

THE BOOK OF FURNITURE MAKING

THE BOOK OF FURNITURE MAKING

Alf Martensson

The Book of Furniture Making was conceived, edited and designed by Martensson Books Limited, Albion Yard, Balfe Street, London N1

Managing editor Wendy Martensson

Editor Pamela Tubby

Technical editor Alison Louw

Assistant editor David Parker

Design Flax + Kingsnorth

Zena Flax, Carole Hay, Linda Murphy, Colin Stone

Photography Chris Overton

Illustration Terry Allen Designs Limited

Lyn Brooks, Roger Courthold,

Robert Stoneman

Copyright © 1979 by Alf Martensson All rights reserved. For information, write: St. Martin's Press, Inc. 175 Fifth Ave., New York, N.Y. 10010 Printed in Great Britain

First published in the United States of America in 1979

Library of Congress Cataloging in Publication Data

Martensson, Alf.
The book of furniture making.

Includes index.
1. Furniture making.
TT194.M36 684.1'042 79-4722
ISBN 0-312-08973-2

HOW TO USE THE BOOK OF FURNITURE MAKING

In this book we have tried to overcome the limitation of most books on woodworking by showing specific instructions for actual projects as well as general woodworking techniques. And to make the projects section and the techniques section work together, we have included frequent cross references from one section to the other to help illustrate points more clearly.

Before starting a project, make sure to read through the instructions at least twice to get a good, overall impression of the work involved. If there are techniques with which you are not familiar, follow the cross references and read the appropriate techniques pages for complete instructions.

Notice that the shopping list includes all the items you will need to make the project with the exception of things like sandpaper and glue which you may already have on hand. It is a good idea to have all the materials together before you start so that you will have no interruptions when you work. Make a copy of the shopping list and take it with you when buying wood or hardware. Notice that the wood lengths shown already allow for about ten per cent waste, so don't add anything to the lengths given.

For all but the most complicated projects, you can use readily available standard softwood sections. We have also specified standard 4 × 8ft sheets of plywood or chipboard throughout.

Since large sheets are difficult to transport and to cut up accurately, it is a good idea to find a wood supplier who will cut it up for you. Take the cutting lists and diagrams with you and make sure to take a tape measure and try square to check the work. Remember that the success of any project depends very much on accurate cutting.

Keep in mind that all the project instructions can be varied where necessary to suit specific needs and personal tastes.

CONTENTS

How to use this book	5	CHILDREN'S PROJECTS	80
KITCHEN AND DINING PROJECTS	8	Bunk beds	82
Trivets and cutting boards	10	Baby's bed and playpen	88
Pine dining table	12	Baking kit	92
Dishracks		Doll's cradle	93
	14	Truck	94
Country kitchen	16	Convertible high chair	96
Kitchen storage racks	22	Doll's house	98
Kitchen work island	24	Cradle	100
Gate leg table	28	Rocking elephant	104
Dining chairs	32		
Welsh dresser	36	WORKROOM AND STORAGE PROJECTS	106
Director's chair	42	Versatile trestles	108
Town kitchen	44	Honeycomb wall unit	110
BEDROOM AND BATHROOM		Simple shelving system	112
PROJECTS	50	Upright bookcase	114
Traditional pine bed	52	Storage cabinets	116
Night table	56	Large work table	120
Simple double bed	58	Boxes and cubes	124
Captain's bed	60	Roll top desk	128
Chest of drawers	64	Workbench	136
Bedroom closets	70	Tool cabinet	140
Sauna bench	74	Tool cabillet	140
Bathroom cabinet and		LIVING ROOM PROJECTS	142
toothbrush holder	76	Two coffee tables	144
Towel rail and soap dish	78	Sofa with storage	148
		Dual height table	152
		Oak corner cupboard	155
		Table and floor lamp	158
		Convertible sofa	160
		Plywood end grain coffee tables	166
		Veneer lampshades	168

OUTDOOR PROJECTS	170	MATERIALS AND FITTINGS	220
Picnic table and benches	172	Wood characteristics	220
Indoor planters	178	Sheet materials	223
Outdoor planters	180	Nails and screws	224
Outdoor lounge seat and table	182	Adhesives	225
Barbecue cart	186	Connectors	226
WOODWORKING TECHNIQUES	192	Hinges	228
WOODWORKING TECHNIQUES	192	Miscellaneous fittings	229
HAND TOOLS AND HOW TO USE THEM	193	WOODWORKING JOINTS	230
Measuring and marking	193	Preparing the wood	230
Hammers and mallets	194	Edge to edge joints	231
Drills	195	Dowel joints	232
Handsaws	196	Mortise and tenon joints	234
Chisels and gouges	199	Dovetail joints	236
Planes	200	Mitre joints	238
Clamps	202	Halving and bridle joints	239
Shaping tools	204	Housing joints	239
Screwdrivers	205	Working with sheet materials	240
Miscellaneous hand tools	205	BASIC FURNITURE CONSTRUCTION	242
POWER TOOLS AND THE HOME WORKSHOP	206	Decorative touches	242
Workbench and accessories	206	Bookcases	243
Circular saw	208	Cabinets and doors	244
Table saw	210	Tables	246
Radial arm saw	213	Drawers	247
Electric drill	214	FINISHING TECHNIQUES	248
Power jigsaw	215	Wood finishing	248
Sanders	215	Spray finishing	250
Router	216		
Other woodworking machines	219	INDEX	252

Cutting board



Kitchen work island



Slat unit

KITCHEN AND DINING PROJECTS



Country kitchen



Dining chair



Standing dishrack



Town kitchen

A custom made kitchen is special not only because it can be made to fit the exact measurements of a room, but also because it can be designed to reflect your taste. This chapter has instructions for two complete kitchens which use inexpensive materials and which will give you a lot of good design ideas. The section also includes a classic pine dining table, an elegant beech and cork gate leg table with matching chairs, a kitchen work island and an array of smaller projects like dishracks, cutting boards and storage racks.



Country kitchen



Gate leg table



Town kitchen



Trivets



Welsh dresser




Pine dining table


TRIVETS

Teak trivet

These trivets look best made in a dark hardwood such as teak or mahogany. As an alternative, use softwood stained a dark tone.



To make the small trivet, cut four $\frac{1}{2} \times 1\frac{1}{2}$ in teak strips, 6in long. Clamp them together and mark a $\frac{1}{2}$ in wide slot about $1\frac{1}{2}$ in from each end. Hold a $\frac{1}{2}$ in strip against the marks to check the slot width. Cut within the





waste area to half the depth and use a chisel to clear out the waste.

Make sure that the pieces fit snugly together without glue.

Finish the trivet by rubbing in two coats of linseed or teak oil.

Follow the same procedure for making the larger 9in square trivet which requires 14 strips of teak $\frac{1}{2} \times 1\frac{1}{2}$ in, 9in long. Remember to take extra care in marking and cutting as the slots must line up exactly for all the pieces to fit together without breaking.


Plywood trivet

To make this trivet you will need a 7×13 in piece of $\frac{1}{2}$ in plywood and two pieces of 1 in diameter dowel, 8 in long. Cut the plywood into seven $1\frac{3}{4}$ in wide strips each 7 in long. To drill the holes for the dowels, use a

lin bit. The holes should be centred 1½in from each end. Clamp the pieces to the bench with waste underneath.

Use a centre punch to mark the exact location then drill the two holes all the way through. Make sure that you hold the drill vertical.





Before unclamping, mark a diagonal line down one edge as shown so that the pieces can be reassembled in the same order. Sand all the pieces including the dowel.

Then push the plywood pieces onto the dowels and space them out evenly. Add glue or small nails from underneath if the pieces fit loosely. Finish the trivet either with clear polyurethane or, as here, with a teak shade polyurethane stain.


CUTTING BOARDS

Plywood end grain chopping board



This unusual chopping board measuring 9½ in square is made up of strips of birch plywood turned on edge and glued together like the coffee tables on page 166. It is best to use a fairly thick plywood, at least ¼ in, so you will need fewer strips. From a piece of ¼ in plywood, 14 × 35 in, cut about twenty strips 1¼ in wide and 14 in long. Glue the pieces together with waterproof resin glue making sure that the edges line up. As you glue each piece on, secure it with two 1 in nails. This keeps the pieces from sliding when they are clamped together.

After clamping, use a block plane or belt sander to smooth the surface. Finally mark a diamond shape on the board using a mitre square (page 193) or a 45° triangle. Saw carefully along the lines and then sand the edges well.



Seal the board by applying several coats of polyurethane. It may be necessary to re-seal the board from time to time to keep it waterproof.



Oval meat platter

Make a board about 12 × 20 × 1in thick by gluing up smaller boards if necessary. Use teak, mahogany, cherry or, as shown here, American black walnut. Plane and sand the board before marking out the oval shape. If you have difficulty in drawing an oval, start with a rectangle and draw a semi-circle at either end. Cut out the oval with a sabre or coping saw. Then smooth out the curve using a file or rasp, checking often by eye that the curve is regular and smooth on both ends of the board.

The groove which catches the meat juices can be cut out with a gouge, but only by someone with a steady



and experienced hand. It is far easier to use a router with a core box cutter. Set the guide designed to follow curves so that the groove is cut about 1 in from the edge of the board. (page 216)

Finishing the board

Scrape the board with a cabinet scraper (page 205) and sand the groove and edges carefully. After the final sanding wipe the surface with a damp cloth to raise the grain and then sand again. Finally apply one or two coats of salad oil or olive oil.

Pine board with dowel insets

By simply insetting a few ordinary dowels in a pine board, you can make a novel and beautifully decorated chopping board.

Make sure the drill bit matches the diameter of the dowel exactly by first drilling a trial hole in a piece of waste wood. Dowels vary slightly in diameter so it may be necessary to reject any which are smaller than the sizes required.

Use a pine board about 9 × 15in and at least 1in thick. Start with the largest diameter dowel. Drill a hole about 3/4in deep making sure not to go all the way through the board. Cut off a length of dowel just slightly longer than the hole is deep and glue it in place.

After the glue sets, plane the dowel flush using a block plane.

Continue drilling holes and setting in dowels of various sizes in the four corners until you build up a pleasing pattern.



PINE DINING TABLE

This elegant dining table is simple and straightforward in its design and it would look equally good in a traditional or in a modern setting. The top is made from pine boards glued together to make up a smooth surface. If you use butt joints they must be well made, close fitting and joined with a resin glue to hold firmly. However, to be sure the joints won't open up when the wood expands or contracts it is better to reinforce the joints with dowel pegs as explained in the instructions below.



Assembling the rails and legs


CUTTING LIST 15×4in

2 pieces 64in long, for rails 2 pieces 21¼in long, for rails × 3in


4 pieces 281 in long, for legs

After cutting and squaring the legs and rails, make dowel joints for the leg to rail connections. Use two 4in long dowel pegs for each joint and space them about 2½ in apart (page 232). Be careful to mark all the pieces and joints in turn as each one is drilled so that they will be assembled in the correct order.


After drilling all the dowel holes, sand the pieces so that the edges are gently rounded. A useful trick furniture makers use is to bevel the front edge of the rail ends and also the edges of the legs with a block plane. This tends to make any errors in alignment between the rail and the leg less obvious.



Join each long rail to its two legs, allow the glue to set and then join the assembled pair with the short rails. The joints shouldn't need clamping, but because of the size of the framework it is advisable to use



clamps to hold the final assembly together until the glue sets.




Making the top

CUTTING LIST 1 × 6in 5 pieces 75in long (to be trimmed)


Start by laying the five boards on the bench and selecting the best face. Try various combinations of boards to get the most pleasing grain patterns on the top. Arrange the boards so that the end grains alternate to minimize warping.



Mark the boards as shown to remember the order. Then check that matching boards are straight and true by holding them together in pairs to check for gaps. Thin boards tend to slide a little under clamping pressure so, to hold them in place and to strengthen the joint, add four short dowel pegs along each joint (page 232). Lay the clamps on the bench or on sawhorses, add glue and join up the boards according to the markings.



Remember to alternate the clamps over and under the boards to prevent the top from arching up or down (page 231). As an alternative to using bar clamps, make your own clamping jig (page 203). Be sure to protect the work with pieces of waste wood so that the clamps do not mar the edges.



Using a damp rag, wipe up any glue that squeezes out of the joints. When the glue has set, remove the clamps and clean up the top with a plane or a power sander to make it smooth and even. Finally, trim the top to length and finish sanding it smooth. Use a sanding block, block plane or router to round the edges so that they feel smooth to the touch.

SHOPPING LIST

to make a standard size table, 29 x 72in to seat 8

softwood 34ft of 1 × 6in (choose straight clear pieces)

16ft of $1\frac{1}{2} \times 4$ in 11ft of 3×3 in

hardware 30 no.8 round head screws, 2 in long

10 metal shrinkage brackets with slotted holes

plus 3ft of \(\frac{1}{2} \) in diameter dowel for pegs, cut into 16 pieces 1\(\frac{1}{2} \) in long,
6ft of \(\frac{1}{2} \) in diameter dowel for pegs, cut into 16 pieces 4 in long


clear polyurethane



As an alternative, make a top out of 1×2 in lengths of pine, glued and pinned in the same way as the plywood table on page 166. Mixing dark stain with the glue emphasizes the thin lines of the boards and adds an elegant touch to the table.

Final assembly

Carefully lay the top face down on a blanket on the bench or on the floor and centre the leg assembly to even the overhang on all sides. Then mark the holes for the brackets and drill the screw holes carefully to avoid going straight through the top. Fit a depth stop to the drill to be sure you don't drill too deep. Three shrinkage brackets per side and two per end is about right. Use the slot which allows the screw to move across the



boards as the table top will expand and contract with the seasons (page 220). Then turn the table over and inspect the top for marks and scratches. Carefully sand these smooth before you apply the first coat of polyurethane.

Finishing the table

Sanding is all important for a good finish. Start with medium paper (80 to 100 grit) and finish with fine (about 150 grit). An orbital sander makes the job easier but sometimes leaves small circular marks on the surface. Sanding by hand still achieves the best results. Before applying the first coat of thinned polyurethane, wipe the top with a damp rag to raise the grain. Allow to dry and sand smooth. Apply three or four coats, sanding with very fine paper or fine steel wool between each application (page 248).

DISHRACKS

Hanging dishrack

Making the shelves

CUTTING LIST

 $\frac{3}{4} \times \frac{3}{4}$ in

15 pieces

85 in long, for top shelf

13 pieces

95in long, for middle shelf

3 pieces

105 in long, for bottom shelf

 $\frac{1}{2} \times 1\frac{1}{2}$ in

2 pieces

6in long, for top shelf

2 pieces

7in long, for middle shelf


2 pieces

8in long, for bottom shelf


6 pieces

24in long, two for each shelf

Start by making the top shelf. Join the two 6in lengths of $\frac{3}{4} \times 1\frac{1}{2}$ in between the 24in lengths with one $2\frac{1}{2}$ in long dowel peg per corner. Clamp the pieces together and drill through from the outside. Then simply tap the pegs into the glued hole and cut the dowel off flush. One dowel per joint is enough because the nailed strips will make the shelf more secure.



Glue and nail the 8% in lengths to this frame. Use a piece of waste wood as a spacer, leaving a 1 in space between the strips. Set the nails and fill the holes.




The other two shelves are made in exactly the same way except that the spacing between the nailed strips should be increased to 1½ in to hold larger plates.



SHOPPING LIST			
softwood	40ft of $\frac{3}{4} \times \frac{3}{4}$ in / 22ft of $\frac{3}{4} \times 1\frac{1}{2}$ in / 5ft of 1×2 in		
dowel	3ft of ¼in diameter for pegs		
hardware	24 no.6 countersunk brass screws. 1½in long 12 no.6 brass screw cup washers about 100 finishing nails or brads, 1in long 2 brass mirror brackets with ¾in screws		
plus	wood filler / clear polyurethane		

Assembling the dishrack


CUTTING LIST 1 × 2in 2 pieces 28in long ½ × 1¼in 6 pieces 10in long



Before joining the pieces, sand all the shelves well, then mark the two 1×2 in pieces as shown to determine the location of the shelves. Attach the 1×2 in to the back of each shelf first with a nail to hold it temporarily, then with two $1\frac{1}{4}$ in screws per joint. Notice the wood blocks under the shorter shelves to help support them.

To attach the diagonal bracing, first hold one 10in piece in place and mark the angle to be sawn. Then cut six identical pieces and screw them in place to the 1×2 in and to the shelf using one $1\frac{1}{4}$ in screw with a screw cup washer.

Finish with three coats of clear polyurethane and attach the mirror brackets to hang the dishrack.





Standing dishrack

CUTTING LIST

\$\frac{3}{2} \times 1 \frac{1}{2} \times 1\$

4 pieces \$17\frac{1}{2} \times 1 \text{ong} \$

4 pieces \$12 \times 1 \text{ong} \$

\$\frac{2}{2} \text{ pieces } 7 \times 1 \text{ong} \$

2 pieces \$3 \times 1 \text{ong} \$

2 pieces \$3 \times 1 \text{ong} \$

3 pieces \$3 \text{ong} 1 \text{ong} \$

4 \text{one} \$

5 \text{one} \$

6 \text{one} \$

6 \text{one} \$


7 \text{one} \$

7 \text{one} \$

8 \text{one} \$

9 \text{one}

Begin by marking one of the 17½in lengths into fourteen equal 1½in spaces. Mark along the narrow edge starting 1¼in from one end. Transfer the marks to the other three lengths with a try square. Then use a centre punch or nail to mark the thirteen centres for the dowels on each strip.




SHOPPING LIST softwood 11ft of 3 × 13in

dowel 17ft of gin diameter


hardware 8 no.6 countersunk brass screws, 1in long 8 no.6 countersunk brass screw cup washers



Drill thirteen in diameter holes in each strip, using a depth stop to make the holes in deep (page 195). Before inserting the dowels, taper the ends slightly with sandpaper so that they will fit into the holes more easily. Add a drop of glue to each hole and tap thirteen dowels into the holes of one strip. Then fit the second strip onto the dowels by tapping lightly with a mallet. Repeat this procedure with the second pair of 17½ in lengths and the remaining thirteen dowels to make the two sides of the dishrack.




Then simply screw the 12in lengths to the frames and join the two assemblies by slotting them together and drilling and installing the 3in lengths of dowel through each pair of legs to allow the dishrack to be folded flat when not in use.



Cutlery stand

A flower pot is perfect for drying and storing everyday cutlery. Make this stand for a 5in pot by dowel jointing four pieces of 1 × 2in together; two pieces should be 4in long and two pieces 74in long. Clamp the four pieces together to drill the holes and tap in 3in long 1in diameter dowel pegs, two per corner. Instead of cutting the dowels off flush, leave the ends sticking out about in as a decorative feature. Mark and cut a circular shape along the inside to fit the diameter of the flower pot. For the legs, cut four pieces of 14 or 14 in diameter


dowelling, long enough to allow the base of the flower pot to hang clear of the worktop. Attach the legs by dowel jointing from the top. Sand smooth and finish with at least two coats of clear polyurethane.



COUNTRY KITCHEN

Having a brand new kitchen installed can be an expensive business and may come at a time when there is a lot of other building and decorating work to pay for. At first glance this kitchen looks much too complicated, but if you examine each component on its own, you will see that it is not as difficult as it looks.

The small alcove in the corner was used to advantage by filling it with a full height spice rack large enough to hold a collection of cookbooks too. Adapt the basic instructions on page 116 for making the unit using plywood or chipboard. Then paint the shelf to give a touch of bright colour to the kitchen.





Measuring and planning

Kitchens differ very much from house to house. The size and shape vary as do the number of appliances and the location of plumbing, windows, doors, and so on. As a result, specific measurements of units are not given here. Make up your own cutting and order lists, starting by drawing a plan of your kitchen to scale on graph paper with each square representing, say, a 3in area of floor space. Locate the stove, sink, refrigerator and any other appliances where you want them and then determine the lengths of the units in between, allowing 1in clearance on each side of the appliances.

The best way to plan each unit is to divide it up into several subdivisions about 18in wide and then leave any remaining space for things like tray storage, towel rails or broom closets.

Large department stores and specialist suppliers sell many handy kitchen gadgets such as pull-out towel rails, plastic-coated wire baskets, door-mounted bins and the like which you can incorporate into your unit design. Other accessories such as a pull-out ironing board and extension tables can also be fitted into your cabinets.


Choosing materials

The insides of the cabinets should be easy to clean so the best material to use is plastic laminate-covered chipboard which is both inexpensive, good looking and washable. It is available in several colours from larger suppliers in standard 4 × 8ft sheets or in handy lengths of varying width. The 21in width is ideal for these units. Alternatively, use an inexpensive grade of plywood and finish it with several coats of polyurethane to make it washable.

The front edges can be treated in several ways. For laminate-covered chipboard apply matching iron-on edging (page 267), or cover as shown by gluing and nailing on darkstained strips of pine.

The backs of the units can be of ordinary hardboard or thin plywood. The main function of the back, besides keeping out the dust, is to stabilize the cabinets and to keep them square.





locating bracket

First cut the base piece A to the full width of the cabinet. Then lay out the 18in divisions separated by the thickness of the dividing panels. Make the base piece A and all the dividers 21in from front to back. Since the worktop will be 24in wide, this allows a 1in overhang at the front and a 2in clear space at the back for the plumbing.

Cut the 21in wide dividers 30in long, then lay the base and dividers on edge on the floor to assemble them,

Notice that the divider under the sink has been cut off to accommodate a panel fitted under the sink.

First put in two or three 14in nails hammered from the outside to hold the pieces until the screws are added. Then add three 13in no.8 screws at each joint, either screw


Then glue and nail the 30% in high panel to the back with 3in pins. It is best to nail along the bottom edge first, then nail into each divider in turn making sure that each one is absolutely square with the base.

Cut out the fascia piece, 21in wide and about 3 in thick, and screw it to the top front. Countersink the screws, then hide them with plugs for pine fascias as here, or with

plastic screw covers to match the plastic laminate surface.

Locate 18 x 21in shelves within the cabinets. supporting them on 1 × 1 in battens screwed to the sides. Make the separate 18in wide base out of 43in wide boards nailed together.

Finally screw metal shrinkage brackets flush with the top edges of the dividing panels and the fascia. Also add two or three locating brackets to the underside of the base A, 3in back from the front edge as shown, to make it easier to locate and attach the unit to the base.



Installing the units

First place the base in its exact location 2in out from the wall. Then, using a spirit level, check to make sure it is completely level both along the length and also across the width. Most often the floor will not be quite level so wedge the base with scraps of hardboard to get it firm and level,


and then attach it to the floor with a few metal brackets to fix the cabinet permanently in place and keep it level.

Place the unit on top of the base. sliding it back so that the brackets locate on the front. Finally screw these brackets to the base to fix the cabinet firmly in position.

Making the doors

These doors consist of a 1×2 in pine frame dowel jointed and fitted with a in plywood panel. The panels here are covered with an attractive gift wrapping paper printed with a William Morris tile design. Glue the paper to the plywood with a rubberbased cement and give it two coats of polyurethane to make it water-

The panels can be covered with any attractive paper, as they have been here, or with a washable wallpaper, sturdy fabric or even with cane which is available in sheet form (page 70). You could also paint the panels or use plastic laminate.



Measure each opening to get the exact size for each door, allowing about in for clearance. Then cut and join the 1 × 2in pieces (page 232). The centre panel can be located either in grooves or rabbets cut into the frame. Or, to make it very easy, the panel can simply be screwed to the back of the frame with brass screws and matching cup washers.

Fit two small brass hinges and a knob to each door before hanging it in its opening. Then fit small magnetic stops behind each door.

Making the drawers

These drawers are made from 1 × 5in pine boards with in plywood bases set into grooves. These exposed corner box joints were machine cut but you can cut them by hand (page 237)

It is very convenient to have most of the top drawers quite shallow for cutlery and the like, but a few deeper drawers are also useful. Make the sides for the deep drawers by gluing two boards together.




The worktops

In the kitchen shown here, the worktops have been made quite easily by laminating $1\frac{1}{2} \times 1\frac{1}{2}$ in strips of pine together. To do this, just follow the instructions given on page 12 for making the pine dining table.

As an alternative, you can buy a ready-made counter top and have it cut to the required length. A maple butcherblock top, like the one used as the work surface on the kitchen island on page 24, would be ideal.

You could also, if you prefer, make the counter tops with a chipboard or plywood base and cover them with a plastic laminate as shown on page 46. There are many possibilities and you can select the one that best suits your decorative scheme and your budget.


Make the 4in high splashback from the same materials as the worktop. It is useful and hygienic, preventing food from falling behind the cabinets



Kitchen storage

The conventional approach to storage in kitchen design is to enclose everything in cabinets; cooking utensils, groceries, pots and pans and the like. But today, many kitchen implements are so colourful and attractive that they can be used to decorate the kitchen. This makes the job of designing your kitchen much easier because, instead of the standard wall-hung cabinets, you can build attractive open storage units to keep everything within easy reach and on show.

The overhead pot hanger is a great idea. Instead of searching for a pan in a cabinet and having to move everything to get it, you just reach up to get the one you want off its hook. The simple slat unit not only holds all the bits and pieces but can also be used to cover any ugly pipes on the wall. The hooks are very easy to make from wire coathangers using the method shown on page 23.




Making the overhead pot hanger

Cut four 1 × 8in pine boards so that one pair spans the full length of the kitchen in one direction and the other pair spans the room in the other direction.

They should be located about 18in out from each wall and placed high enough so that the pots and pans will be above head height but low enough to be within reach.

Cut halving joints in each board,




Left:

Instead of the usual stainless steel draining board, make one out of solid teak boards glued together with waterproof glue. Because it contains natural oil which repels water, teak is the ideal wood to use for this purpose. If maintained by regular oiling it will look like new for many years. Cut a hole for your sink with a sabre or coping saw and then cut the \{\frac{1}{2}\in deep grooves of the draining board using a router fitted with a core box cutter. Mount the draining board at a slight angle for easy drainage.



This slat wall unit is a wonderful way of hanging up everything in the kitchen from scissors, to colanders and pot lids. Adapt the instruction on page 22 to make a slat unit that fills the whole wall. It becomes the focal point of the kitchen when hung with brightly coloured and useful kitchen items.




18in from the end, then attach the boards to the wall with the homemade brackets painted to match the spice shelf.

Make the brackets from two pieces of shaped $\frac{1}{4}$ in plywood sandwiched around a 1×1 in strip. Screw the 1×1 in board to the wall with two no.10 screws, adding wall plugs into masonry walls. Then attach the 1×8 in boards with $\frac{3}{4}$ in brass screws from both sides.


Making the open shelving unit

The sturdy uprights are made from \$\frac{1}{8}\$ in thick hardboard which is nailed around 2 × 2in sections of softwood. They are deep enough to allow the shelving unit to incorporate a dishwasher, washing machine, dryer or, as here, a refrigerator.

For the uprights, cut standard 4 × 8ft sheets of hardboard in half to make two pieces 2 × 8ft. Then glue and nail them to three 2 × 2in lengths. Cover the front edge with a 2in wide piece of teak or stained pine. Place the uprights on a base as for the kitchen units.



The 22in wide shelves, supported on 1×1 in battens screwed to the uprights, are made as shown from chipboard and strips of 1×1 in so that they will slide onto and thereby hide the supporting battens.



Cover the top, front and bottom of each shelf with white plastic laminate to create an attractive contrast to the dark uprights and to make the shelving unit easier to keep clean. To keep the structure rigid, nail 4 × 8ft sheets of hardboard to the back of the uprights.



KITCHEN STORAGE RACKS

Here are three useful storage racks which are very easy to make. The slat unit allows you to hang within arm's reach all the everyday utensils which tend to clutter up kitchen drawers. It is a useful rack not only for the kitchen, but for a workroom or study and it is so simple to make

that you can easily adapt the instructions to make the rack to any size required. The towel rack holds aluminium foil and plastic bags as well as paper towels. Finally, the knife rack makes ingenious use of slotted dowels to hold both the handle and blade of each knife.



Slat unit

The instructions here are for a rack 24×32 in, but it can be made to fit any space or to cover a wall, as it is on page 21.


CUTTING LIST

3×14in

18 pieces 24in long

2 pieces 32in long, for uprights

2 pieces 33 in long, for surround



Start by lining up sixteen 24in slats on the workbench. Draw a light line across each end about $\frac{3}{4}$ in from the edge as a guide for the screw holes.

Then drill a clearance hole centred on the marked line at each end of the sixteen slats to take the no.8 screws.

To assemble the unit, screw on the first and last slats to align with the top and bottom of the 32in uprights. Check that these are square before

SHOPPING LIST

softwood about 52ft of 3 × 14in

hardware 2 no.10 round head brass screws, 1½ in long

40 no.8 countersunk brass screws, 11 in long


40 no.8 brass screw cup washers

8 finishing nails or brads, 11in long

2 brass mirror brackets with 3in screws

plus clear

clear polyurethane




Knife rack


Mark and drill the backing board. The in dowels are mounted in pairs centred in apart. There is a lin space between the centres of

deach pair of dowels. Centre the 1½in dowel holes directly below each pair of ½in dowels. Drill both the ½in and 1½in holes §in deep. It is best to use an electric drill fitted with a depth stop and mounted in a drill stand so that the holes are straight.


Mount the 1½ in dowel in the vice, cut a groove 1 in deep in one end and use a bench hook to cut off a 2 in length. Return the dowel to the vice, cut another groove, then cut off the next piece. Repeat, to make ten pieces each with a slot in one end.



Glue all the dowels in place. Finally, drill a small hole in each corner to attach the knife rack to the wall and then seal with polyurethane.



softwood 20in of 1 × 8in dowel 6ft of ½in diameter, cut into 20 pieces 2½in long 2ft of 1½in diameter hardware 4 no.8 countersunk brass screws, 2in long 4 no.8 brass screw cup washers plus clear polyurethane




gluing and screwing the other fourteen slats in place using a spare slat on edge as a spacer. The spacing may not work out exactly, so space the last few slats out evenly by eye.

Screw the surround in place using the four remaining $\frac{3}{4} \times 1\frac{1}{2}$ in strips. Start with the two 24in pieces A on

top and bottom. Hold them in place temporarily with nails and add two screws and washers per side. Then nail one 33¼ in long strip B to each side. Finish with one or two coats of polyurethane. Finally, screw the mirror brackets to the back of each upright. Attach the slat unit to the wall with the two round head screws.


Make simple hooks from wire coathangers. Straighten the wire and with a strong pair of pliers, bend each piece to form a hook.



Towel holder

softwood	5ft of 1 × 6in cut into 2 pieces 12½in long and 2 pieces 16¾in long
plywood	2 pieces 5⅓ × 15in, ∮in thick
dowel	39in of lin diameter, cut into 3 pieces 12 gin long
hardware	2 no.8 round head brass screws, 1½in long 16 finishing nails or brads, 1½in long 12 finishing nails or brads, ¾in long 2 brass mirror brackets with screws

Cut the $1\frac{1}{4}$ in wide diagonal slots in the two plywood pieces. Use a sabre or coping saw and sand the edges smooth. Then glue and nail the plywood to each $16\frac{3}{4}$ in piece of softwood, leaving an equal space at top and bottom. Use six $\frac{3}{4}$ in nails per side.



Finally glue and nail the top and bottom 12½ in pieces between the sides using four 1½ in nails per joint.

Seal with two coats of polyurethane, attach the mirror brackets and hang the holder. Push the three $12\frac{3}{8}$ in long dowels through the rolls of paper towel or aluminium foil and drop them in place in the diagonal slots.



KITCHEN WORK ISLAND

If your kitchen is large enough to have a central work island, this is a wonderful project to make for your home. The easiest thing to do is to buy a maple or beech butcherblock chopping board, 30 × 48in to use as the top, and to make the base yourself. Alternatively, you can make the top out of 2in thick maple, beech or pine following the instructions on page 12 for the pine table. The base is made from maple to match the worktop but the project is designed to use standard sections so that you can make it out of a more easily available softwood. The rails are connected to the legs using old-fashioned metal corner brackets which are very easy to fit and which are extremely sturdy. These are available from large hardware suppliers or from mail order firms specializing in woodworking supplies.

Preparing the legs and rails

CUTTING LIST

3 × 3in

4 pieces 35in long,
for legs A

1½ × 6in

1 piece 39½in long,
for rail B

1½ × 4in

3 pieces 39½in long,
for rails C

4 pieces 21½in long,
for rails D

2 pieces 24½in long,
for drawer supports E

Cut the pieces to length and as usual, make sure that the ends are square. This is particularly important for legs and rails because the rails must connect squarely with the legs and the legs must be square so that they will stand firmly on the floor.

Then prepare all the pieces by rounding the edges using a plane or rasp. If you have a router, use a ½ or ½ in radius rounding-over bit. Rounding all the edges of the legs will make them look more graceful, despite the fact that they are quite heavy.

SHOPPING LIST

hardwood 30×48 in butcherblock top / $3\frac{1}{2}$ ft of $1\frac{1}{2} \times 6$ in / 24ft of $1\frac{1}{2} \times 4$ in 13ft of 3×3 in / 7ft of $\frac{3}{2} \times 4$ in / 2ft of $\frac{3}{2} \times 5$ in

13ft of 3×3 in / 7ft of $\frac{1}{4} \times 4$ in / 2ft of $\frac{1}{4} \times 5$ in 30ft of $\frac{3}{4} \times 3$ in / 14ft of 1×1 in / 4ft of $\frac{1}{4} \times 1$ in

plywood $19\frac{1}{4} \times 19\frac{1}{4}$ in, $\frac{1}{4}$ in thick for drawer bottom

hardware 35 no.8 countersunk steel screws, 1½in long 6 no.6 countersunk steel screws, ½in long

6 no.8 countersunk brass screws, 14in long 8 steel corner plates, 2in wide, with screws and bolts


8 slotted shrinkage brackets with 3in round head screws

a few finishing nails or brads, 3in long

plus about 2ft of in diameter dowel for pegs


one wooden knob

clear polyurethane or teak oil




You should also round the four outside edges of the rails. By rounding the edges at the ends, the connection between the rails and the legs need not be precise. This is a trick that professional furniture makers often use to mask slight errors in alignment at joints and it makes the joint look more attractive, as shown left.

To connect the metal corner brackets to the legs, first drill the holes for the threaded bolt supplied with each



KITCHEN WORK ISLAND




bracket. The bolt goes into the leg at a 45° angle, so to make the drilling easier, make the jig shown below to hold the leg.

Drill two 45° holes in each leg, the first $1\frac{1}{2}$ in down from the top and the second 8in up from the bottom, to take the brackets for the upper and lower rails.

The metal corner bracket has two flanges which fit into shallow slots cut into the inside of the rails. Determine the position of the groove by holding the bracket against the rails and legs.







Cut the grooves with a tenon saw or a table saw and drill the holes at each end of the eight rails for the brackets as shown. Cut the groove first, then hold the bracket in the groove while you mark the hole through the bracket for the \(\frac{3}{4}\)in long screws. Put the legs and rails aside for assembly.

Making the drawer

CUTTING LIST


- 3/4 × 4in 4 pieces 20in long, for sides F
- 3/4 × 5in 1 piece 22in long, for front G
- ½×1in 2 pieces 20in long, for runners H






Cut F and G, then cut finger joints in the sides (page 237) and cut $\frac{1}{4} \times \frac{1}{4}$ in grooves to hold the bottom.

Glue three sides together, then trim the bottom to size. Slide the bottom into the groove with a little glue to keep it firm and then add the final side. The drawer is supported by battens which slide in grooves cut in the sides. Cut the $\frac{3}{8}$ in deep grooves using a plow or router plane, then try the battens in the grooves to make sure they slide smoothly. The grooves can be cut before or after assembly.




Shape the edges of the drawer front G with an appropriate router bit (page 216), or simply round them with a plane. Screw the wooden knob on to the drawer front from behind with a 1¼ in long screw before screwing the front to the drawer from inside with the six brass screws, lining up the bottom edges.




Assembling the top rails

CUTTING LIST 1 × I in 2 pieces 34in long


First cut a 4in deep opening as shown in the centre of the front rail B to take the drawer. Measure the width of the drawer and add \$\frac{1}{8}\$ in for clearance to get the width of the opening. Use a sabre saw to make the cuts and then clean up the edges with a block plane.




Assemble the rail structure by dowel jointing the two drawer supports E to the front rail B and the back rail C. Use two sin diameter dowel pegs, 2in long, per joint and place the supports E so that they are exactly the same distance apart as the opening cut in B.




Attach the shrinkage brackets which will hold down the top and then




connect the rail structure and the two end rails D to the legs by screwing through the brackets at each corner.



Connect the two ½ × 1in runners H to the drawer supports E. Locate them carefully so that the grooves will match, leaving the bottom edge flush with the bottom edge of the front rail B. First tack the runners in place, then try the drawer to make sure you have it right before attaching the runners with three ¾in no.6 screws to each batten.



Before attaching the lower rails, two C and two D in exactly the same way, glue and screw a 1 × 1in batten to the inside of each long rail C with four 1¼in long no.8 screws per batten. Place it 1½in down from the top edge as shown.




Assembling the slat structure

CUTTING LIST 1 × 1 in 2 pieces 39 in long

Determine the length of the twelve $\frac{1}{4} \times 3$ in slats by measuring the inside distance between the longer rails C at the bottom. Then cut the twelve slats and sand them, rounding the edges slightly before assembly.

Assemble the slat structure by gluing and screwing the 1×1 in battens across the ends of the twelve slats. Lay the first and last battens on the bench and attach them flush with the ends using one $1\frac{1}{4}$ in no.8 screw per end. Then continue attaching the successive slats, spacing them about $\frac{1}{2}$ in apart. Before the glue sets, place the whole assembly between the lower rails, resting it on the battens which you attached earlier.



Final assembly and finishing

Prepare the 30×48 in top by sanding it well and rounding the corners and edges with a router or plane. Then screw the top to the brackets from underneath with $\frac{3}{4}$ in round head screws. Make sure to use the correct slot to allow the solid wood top to expand and contract across the width with changes in the atmosphere.

The base structure should be given several protective coats of clear polyurethane, or if you prefer a more natural look, wipe on several coats of teak oil allowing the oil to penetrate into the wood between coats.

Teak oil will not be suitable for the chopping board top since it will be used to prepare food. It can either be left unfinished or given a light coat of salad or olive oil just as you would finish a wooden salad bowl. You will probably wipe and scrub the top continuously so you should renew the oil once in a while to keep the wood in good condition.



GATE LEG TABLE

Everyone occasionally needs an extra table for dinner parties, as a work desk or even as a sideboard to hold serving dishes. This fold-away design serves the purpose well and conveniently extends when you need extra seating in the dining area. You can use the table with only one leaf extended to seat two or three people, or fully extended to seat six people very comfortably. Folded flat against the wall, the table only takes up a 6in depth of floor space. It is not at all difficult to make the table. It is made with a dark cork inlay in each leaf which complements the solid beech surround. Cork is not as durable as say a painted or a veneered panel but if you buy cork which has been factory sealed it should serve very well. And it does make the table extremely attractive. Notice that the table is designed to be made using

standard planed sections such as 1×2 in, 1×3 in and 1×6 in, so you can use pine or Douglas fir boards instead of beech, dowel jointing them together to make the top of the table, as shown on page 12. To make the construction easier, you could use a sheet of $\frac{3}{4}$ in lumber core

plywood to make the leaves and the underframe of the table. Refer to the instructions for the chest of drawers on page 64 before cutting up the lumber core plywood. If you use a veneered panel, all the pieces will need matching iron-on veneer edging.

CHOPPING LICT

	9ft of 1 × 6in / 13ft of 1 × 5in 125ft of 1 × 3in / 17ft of 1 × 2in /	
	20ft of $\frac{3}{8} \times \frac{3}{8}$ in	
plywood	2 pieces 18×32 in, $\frac{1}{4}$ in thick (to be trimmed)	
dowel	6ft of åin diameter for pegs	
hardware	12 no.10 countersunk steel screws, 1½in long	
	8 no.10 countersunk steel screws, 3in long	
	35 no.4 countersunk steel screws, 3 in long	
	25 no.6 countersunk steel screws, §in long	
	six 2½in brass butt hinges with §in screws	
	about 10 finishing nails or brads, ≩in long	
plus	about 1½sq yd of cork tiles, ¼in thick (presealed) contact adhesive	
	clear polyurethane or wax	

Making the table frame

CUTTING LIST

 $1 \times 6in$

1 piece 40in long A

2 pieces 273in long B

 $1 \times 5in$

2 pieces 36½in long C

 $1 \times 3in$


2 pieces 36½in long D


Cut the pieces accurately to length and check that they are square. Before joining them, it is a good idea to sand the pieces well at this stage rather than waiting until the table is assembled.

Start by preparing the T-sections which form the cross rails of the table to hold the fold-out legs. The leg frames will be attached to the rails at the top and bottom by a $\frac{3}{8}$ in dowel peg which allows the leg to pivot.

The other vertical of the leg frame will fit into a cut-out in the rail when the table is folded flat. Before making the T-sections, drill the $\frac{3}{8}$ in diameter holes and cut the slots in pieces C exactly as shown. It is best to clamp them together as you saw and drill so that they will be identical.

Then make two T-sections by gluing C and D together in pairs. Clamp them well until the glue sets, then add four 1½ in screws to each T-section to reinforce the glued joint. Counterbore the screws carefully by drilling a $\frac{3}{8}$ in diameter hole about $\frac{3}{8}$ in deep.






B

4 in

Afterwards fill the hole with matching plugs cut from a scrap of beech with a plug cutter fitted into an electric drill.

Dowel joint the Tsections to pieces B.
Drill so that the
holes line up and
extend \$\frac{5}{8}\$ in into
pieces B. Then glue
the \$1\frac{1}{4}\$ in dowels into
the ends of the Tsections before
joining the pieces
together and
clamping across
until the glue sets.





Making the fold-out leg structure

CUTTING LIST

1 × 2in


2 pieces 27 in long E


2 pieces 21 in long F,

(to be trimmed)

4 pieces 18 in long G


Cut the pieces to exact length and sand them, rounding the edges. Then dowel joint the pieces together into two identical frames using two 2in long dowel pegs per joint. It is important that leg E extends exactly 4in below F as shown.






Assembling the table frame

Add the leg frames to the T-sections. Trim the top of F, then place each frame in position with the short leg F centred over the pivot hole already drilled. Hold it there while you extend the hole into the legs, drilling through the \(\frac{3}{2} \) in hole already drilled. Then add a little glue to the hole in the leg just before you tap the dowel in place. The dowel is now glued to





the legs while it remains free to rotate in the cross rail.

Check to make sure that the other leg E fits the slot cut for it, when the leg is folded flat. If not, enlarge the slot to correct it.

To complete the table frame, drill the dowel holes in top piece A and in the top of the ends B and the T-section. Allow a 1in overhang at each end, but do not attach the top A until later when it has been joined to the table leaves.

Making the table leaves

CUTTING LIST

 1×5 in

4 pieces 18in long H

 $1 \times 3in$

4 pieces 40in long I

2 pieces 22in long J


 $1 \times 2in$


2 pieces 3in long K

 $\frac{3}{8} \times \frac{3}{8}$ in

4 pieces 18in long


4 pieces 36in long (to be trimmed)





First dowel joint pieces H and I together using a dowelling jig, if possible, to drill the two §in holes in each connection. Use 4in long dowel pegs to make the joint very strong.

After making the two frames, glue and screw the $\frac{3}{8} \times \frac{3}{8}$ in battens to the inside edges to form a ledge to support the plywood panel. Use $\frac{3}{4}$ in no.4 screws spaced about 9in apart




making sure that the battens are flush with the bottom edge. It is easier if you first glue and pin the battens to hold them in position before you add the screws in previously drilled holes.




Before gluing the cork to the plywood, trim the plywood pieces so that they fit into the openings exactly. Trim with a plane or saw until they just drop into place and mark them so that each one will match its opening.

Then glue the cork to the plywood panel with contact adhesive. Make




sure to cut the cork pieces so that they form a regular pattern. The cork tiles are usually 12×12 in so you have to cut them to fit either to make a staggered or a symmetrical layout as shown.




Cut the cork to leave about ¼in overhanging on all four sides so that you can trim it off neatly with a sharp trimming knife after gluing down.

Add glue to the $\frac{3}{8} \times \frac{3}{8}$ in battens around the opening. Then lay the plywood panels in the opening, screwing them carefully from underneath with $\frac{5}{8}$ in screws. Be careful not to drill or screw straight through the top of the table as you work.

To reinforce the panel, especially so that the leg doesn't push against the panel itself, screw the




cross pieces J to the frame after first cutting a rabbet at the ends. Use two $\frac{3}{4}$ in no.10 screws per end.



To attach the folding leaves to the table, place piece A on the floor or bench and then attach three brass butt hinges per side. There is no need to set these into the wood. With the leaves butting against the top A, simply lay each hinge in

position, mark the screw holes, drill the screw clearance holes and attach the hinges.



Finally, attach the top A with the leaves attached to the underframe and the dowels already glued in position. If you have trouble lining up the dowels with the holes, it may be just as easy to turn the whole table upside down and screw straight through the T-section with long screws into the top A. With the table fully opened, mark the location of the fold-out support E on the cross piece J. Then glue and screw one small stop K to each cross piece using two 1½in no.10 screws. These will act as stops for the fold-out legs.

Finishing the table

The best finish for the table is clear polyurethane which will seal both the wood and the cork tiles.



DINING CHAIRS

This dining chair is both elegant and comfortable. The upholstered back, which is very easy to make, is tilted at just the right angle so that it supports your lower back when you are sitting upright and yet allows you to lean back and lounge comfortably.

The design works beautifully as an armchair too. The chair with arms is exactly the same design, but with the front legs made longer to take the extra rail and arm.

The small details on these chairs are a very important part of the design. All the pieces have rounded edges, easily done with a router or hand plane, to soften the look and feel of the wood.

These chairs are made of beech which has been left completely natural. Alternatively, before upholstering the seat and back, you can finish the wood with two or three thinned coats of clear polyurethane.

Notice that all the components, except the seat and back, are standard 1 × 3in sections so you can make the chairs just as easily using good quality pine or Douglas fir. You could even use good quality birch plywood, \(\frac{3}{4}\)in thick and paint the chairs, filling the end grain with wood filler before priming.

But, if possible, use a soft-toned

SHOPPING LIST to make one chair without arms about 15ft of 1×3 in (approx. $\frac{3}{2} \times 2\frac{3}{4}$ finished size) (beech or Note: Allow an extra 10ft of 1 × 3in for the chair with arms similar) softwood 8ft of 3 × 3 in battens plywood 18 × 36in, 1in thick dowel about 3ft of ain diameter for pegs hardware 10 no.8 countersunk steel screws, 11 in long 4 no.8 countersunk brass screws, 3in long 4 no.8 brass screw cup washers 20 finishing nails or brads, 3in long plus foam rubber: 1 firm piece $16\frac{1}{4} \times 16\frac{1}{4}$ in, 2in thick 1 soft piece 8 × 164in, 1in thick

24in upholstery fabric, 48in wide

hardwood, like beech, and choose an upholstery fabric that complements the colour of the wood. The difference in price and labour is well worth the effort and the chairs will be more hard wearing.

All connections are dowel jointed so that the construction is kept simple. Read page 232 on making dowel joints before starting work and, if possible, invest in a dowelling jig which makes the job so much easier and quicker and the joints much more accurate.

fabric adhesive

Making the dining chair

CUTTING LIST

1 × 3in

2 pieces 18½in long,
front legs A

2 pieces 32in long,
back legs B

2 pieces 14½in long,
side rails C

2 pieces 16½in long,
cross rails D


First cut all the pieces to exact length and make sure they are perfectly square. If all the pieces are correct, the assembly is really quite straightforward.

Next, mark the best face and edge in preparation for marking and drilling the dowel joints.

Use a dowelling jig if possible to drill the holes for the \$\frac{3}{2}\$ in dowel pegs. Use 2in long dowels for the end frames and \$1\frac{1}{2}\$ in long dowels to connect the cross rails D. Two dowels per joint makes a very strong connection, but all the dowels must be tight fitting for the joint to be successful. Notice that the front legs extend \$\frac{1}{2}\$ in above the rails \$C\$, and that the two cross rails D are set in \$\frac{1}{4}\$ in from the edge of the legs.

5 in

13 in



18 in

DINING CHAIRS

continued

After drilling the dowel holes, round the edges of the rails C and D. Use a router fitted with a ½ or ½in radius rounding-over bit to make all the edges uniform.


Alternatively, use a plane first to round the edges roughly and then finish with a fine file or coarse sandpaper. This is an important step so take time to do it carefully and evenly.

Notice that the legs are rounded at the top and bottom to give the chair a more delicate look. These details are not just frills; the difference would be really noticeable if the ends were left square and the design would be less graceful.

Before starting assembly, cut the top of the back legs at an angle using a saw and then plane off to a smooth finish. Round the edges slightly with sandpaper.


It is a good idea to sand all the pieces at this stage because it is much easier to do now with the chair in pieces than after assembly. Sand the wood first with medium and then with fine paper. Assemble the chair carefully so that the pieces are not scratched or marked and check for any flaws before applying a finish.

Assembling the frame



Start by gluing the dowel pegs to the rails. Use a powder resin glue mixed with water if possible, because it will fill any gaps caused by imperfect drilling. If such a glue is not available, then white woodworking glue will do.


Make the side frame by gluing the side rail C to the legs. Clamp it until




the glue sets. Continue by adding the front and back rails D.



Lay one frame on the bench, add glue to the dowel pegs and then place the other frame in position before tapping it home with a soft-faced hammer or a mallet against a piece of soft wood.



Clamp across the rails with light pressure until the glue has set. Keep a moist cloth handy to wipe off any excess glue during assembly.



Preparing the seat and back


CUTTING LIST plywood

1 piece 16½ × 16½in, for seat


2 pieces $8 \times 16\frac{1}{4}$ in, for back $\frac{3}{4} \times \frac{3}{4}$ in

2 pieces 16 in long, for seat 2 pieces 18 in long, for back

(to be trimmed) 2 pieces 8in long, for back



First glue and screw the $16\frac{1}{4}$ in long battens to the insides of the side rails C with $1\frac{1}{4}$ in screws, using three screws per batten.



Then prepare the backrest by gluing and pinning the remaining four $\frac{3}{4} \times \frac{3}{4}$ in battens to the $8 \times 16\frac{1}{4}$ in plywood. Attach the 8in battens to the sides. Trim the 18in long battens to fit in between as shown, then add these, using five or six pins per batten. Put these pieces aside until later, when you are ready to do the upholstery.



The design of the arm of the chair is a particularly pleasing detail. Not only is it an elegant, sculptured joint, but it provides good support and feels really nice to touch.


Upholstering the chair

This is the easiest part of the project. Start with the seat. Cut a piece of fabric 23×23 in, paying particular attention to the direction of the pattern so as to position it attractively. Lay the 2in thick foam and the $16\frac{1}{4} \times 16\frac{1}{4}$ in plywood panel on the fabric, leaving an equal overlap on all sides. Then fold up and wrap the fabric tightly over the plywood base, folding the corners neatly so the fabric does not bunch up.




Fasten the fabric in place with fabric adhesive spread on the plywood, then reinforce it with staples or with small brads. Allow the glue to dry and just drop the upholstered seat in position on the battens in the chair frames.

Upholster the back in the same way, starting by laying the foam on the plywood piece. On top of this place a 14 × 23in piece of fabric, turn over and secure it as before.




To attach the back, position it at an angle between the uprights so that it lines up with the angle cut at the top of the leg. The top of the fabric should be placed just below the top



of the upright. Drill and screw through the battens to attach the back to the leg. Use two 1½in screws per side.

Finally, wrap a 10 × 18in piece of fabric over the remaining piece of plywood and attach this to cover the back of the chair. Use four $\frac{3}{4}$ in brass screws with cup washers for a neat finish.



Making the armchair

CUTTING LIST 1 × 3in 2 pieces 27in long,

armrest F

front legs AA


2 pieces 32in long,
back legs B

2 pieces 14½in long,
side rails C


2 pieces 16½in long,
cross rails D

2 pieces 14½in long,
top rails E

2 pieces 18½in long,



Follow the same procedure as for the dining chair, cutting the wood to length, drilling holes for the dowel joints, rounding the edges and assembling the side frames. Notice that the extra rail E on each side frame has only one rounded edge. The top edge is left square to take the armrest.



Assemble the frame with the two cross rails D, cut notches in the armrest to go around the legs and neatly round the edges at the notches. Then attach the armrests with three dowel pegs and clamp down until the glue sets. If you want to apply a finish of any kind, do it now.



WELSH DRESSER

Making a Welsh dresser is a major project involving a lot of material, time and patience. But it is a beautiful and useful piece of furniture, well worth the time and effort that goes into making it. To make the instructions easier to follow, they are divided into two main parts — one for the base unit and one for the top section. These can be made as separate pieces of furniture and used as a sideboard and shelf unit.

Most of the connections are dowel joints and wherever possible, these are through dowels (page 232). Much of the cabinet construction is quite easy once the gluing up is done. However, the drawer support is more complicated and, like all drawer work, it requires accuracy in cutting and care in assembly. A few bar clamps will help a great deal with the assembly.

The edges, shelves, counters and drawers have been decorated by cutting a profile with a router. This is not essential as the edges would also look very good if they were simply rounded or bevelled with a block plane.

Similarly, the arches in the front and top can be cut easily using a sabre saw or, with a little more work, using a coping saw.

The lower unit

Gluing up the main panels

CUTTING LIST

1×6in

3 pieces 75in long,

top A

3 pieces 72in long, base shelf B 3 pieces 68in long,

sides C 3 pieces 44in long,

dividers D

l piece 68\frac{3}{8}in long, base rail E

 $1 \times 2in$

l piece 68% in long, back rail E'

Refer to the techniques sections on edge joints (page 231) and clamping (page 202) before starting work. The widest panel is approximately 18in

SHOPPING LIST

softwood7ft of 1×9 in / 8ft of 1×8 in / 110ft of 1×6 in(choose6ft of 1×5 in / 18ft of 1×4 in / 9ft of 1×3 inclear33ft of 1×2 in / 3ft of 1×1 inpieces of21 boards of knotty pine tongue-and-

wood) grooved cladding, 8ft long

birch 3×4 ft, $\frac{1}{2}$ in thick plywood 2×4 ft, $\frac{1}{8}$ in thick

dowel 8ft of §in diameter for pegs

hardware 10 no.8 countersunk steel screws, 2½in long 12 no.8 countersunk steel screws, 1½in long

84 no.8 countersunk steel screws, 1½in long 6 no.8 round head screws, 1½in long

54 no.8 round head screws, 3in long

17 shrinkage brackets

5 brass drawer pulls with ½in brass screws

2 straight metal brackets, 2in long with 4in screws

about 200 finishing nails or brads, 3in long

12ft of 1in scotia moulding/20ft of $\frac{1}{2} \times 1$ in beading/clear polyurethane

wide so you will not need very long clamps.

plus

All the edge joints are reinforced with \$\frac{3}{8}\$ in dowel pegs, \$1\frac{1}{2}\$ in long. These help strengthen the joint and also make it easier to glue up. Using the dowel pegs will also ensure that the boards do not separate when the wood 'moves'. Refer to the techniques section on dowel joints (page 232) for full instructions on marking and drilling.

Start with the top A. Select three matching, clear 75in long boards. Check the edges to make sure they are straight and square. Arrange the boards so that the end grain alternates from board to board. Mark and drill each one for five


dowel pegs, then apply the glue and clamp using about five clamps, three below and two above the boards to prevent bowing. Remember to protect the edges of the boards from the clamps by using strips of wood on each side.

Use white woodworking glue which takes about 60 minutes to set. While the glue is setting, prepare the next three boards for the base shelf B. After 60 minutes take out the first panel and clamp up the next. Then continue with panels C and D.

The next step is to trim all the panels to length. Refer to the list below for the exact lengths. To cut each panel, start by squaring off one end with a try square as near to the end as possible. Cut off the waste with a handsaw, portable circular saw or table saw. Measure and mark the exact length required and then trim the other end. Then, if necessary, trim one long edge, either with a plane or a circular saw. Repeat this procedure for all the panels.

TRIMMING LIST for panels 1 piece $17\frac{1}{4} \times 72$ in A 1 piece $16\frac{1}{4} \times 68\frac{3}{8}$ in B 2 pieces $16\frac{3}{4} \times 32$ in C 2 pieces $15\frac{3}{4} \times 22$ in D

Notice that two of the panels are cut in half to get two sides C and two dividers D. Cut the two 32in side panels C now, but don't trim the dividers D until later in the project.





Making the drawer supports

This is the complicated part of the job, involving cutting and joining many small pieces accurately. Make the front framework first, then the shelf framework and finally, join them together.

Front framework


CUTTING LIST 1 × 5in

1 piece 68gin F 1 × 3in


2 pieces 5gin G 1 × 2in

4 pieces 5 in H 1 piece 68 in I


First draw the arches on the 1 × 5in F, and cut out the shapes with a sabre saw or a coping saw. The best way is to make a template out of cardboard. Draw out the width of the arch and the centre line. Draw



Mark the joints along F and then along the 1 × 2in I. Keep track of which joint is which by numbering all the pieces and joints. After



drilling the holes and gluing the pegs into the short uprights H and G, join them to the 1×2 in I. Then join the 1×5 in F to the other ends.




One or two dowels may not match up exactly. If the dowel cannot be forced in with light clamping, cut the peg off flush and re-drill the hole for a new peg.

half the arch, fold the paper in half and cut out the shape. Save the template to use for the top of the dresser.

Notice that the central arch is slightly wider than the other two. Simply draw one side, then move the template along to draw the other side. Also cut out the two small notches 2in deep as shown so that the dividers D will fit snugly into the slots later.

Next set out the dimensions for the drawer openings along the 1×5 in F and the 1×2 in I. It is easiest to clamp them together and mark the location of the short uprights across both at the same time, using a try square.

To mark the centres for the \$\frac{1}{2}\$ in diameter 2in long dowel pegs, clamp each of the uprights H and G to the 1 × 5in F so that they line up exactly with the marks. Then mark the centres for the two dowel pegs in each joint first with a try square and then with a marking gauge.



CUTTING LIST

 $1 \times 2in$

2 pieces

683in long J

4 pieces

143in long K

 $1 \times 3in$

4 pieces

Illiin long L

2 pieces

143in long M

 1×4 in

2 pieces


accurately.

11 in long N


The drawer shelf support is a rectangular framework which is screwed together. Start by laying the two 1 × 2in pieces J on the bench and, using the front framework just completed, transfer the spacing of the 1 × 3in and 1 × 2in uprights G and H onto them taking care to mark them

Then, using these marks, glue and screw the two 1×3 in pieces M to the 1×2 in pieces J with the $1\frac{1}{4}$ in no.8 countersunk screws. The gap between the pieces J should be

exactly 11¼in, so that the pieces L and N fit snugly in between. Use two pieces L as spacers.




Continue by gluing and screwing the four 1 × 2in pieces K in place, then turn the frame over and glue and screw first the end 1 × 4in pieces N in place and then the four central 1 × 3in pieces L, using two 1¼in screws per piece. Allow an equal amount of overhang on each side.



These instructions make the construction sound much more complicated than it really is. Study the drawings carefully and think how the pieces function. The assembly will be quite clear if you realize that the shorter and wider pieces L and N form a shelf to support the drawers, and pieces K and M guide the drawers.

Assembly of base unit


Before joining the pieces, shape the edges of the base B as shown and round the edges of sides C. Use a block plane or a router fitted with a rounding-over bit as shown.




Before beginning assembly, screw one 1×1 in batten, 14 in long onto

Joining the front and back

To join these two assemblies, first clamp and glue them together. Then screw from the back of the 1 × 2in piece J, into the front F






with 2¼in screws. Make sure to keep the top edges of F and J exactly flush so that the drawers will slide in smoothly.

the inside of each of the sides C as shown, the top edge of the batten located 3\frac{3}{2} in from the base of C and the end \frac{1}{2} in from the edge. To prevent the sides C from splitting use 1\frac{1}{4} in round head screws, placed in slots in the batten so they are free to move sideways slightly as C expands and contracts.


Then connect the drawer assembly to the sides so that it is set ½in back from the front edge of the sides as shown, leaving a § to ½in gap at the back.

It is important to dowel joint only the front framework (pieces F, G, I) to the sides C. The shelf framework is connected with one metal shrinkage bracket per side and \{\}in screws.




Then attach the base shelf B to the battens from underneath using three 1½in screws. Set the shelf B ½in in from the back edge of the side C to allow space for the backing. Attach the base rail E to the shelf B and to

the sides C, using five shrinkage brackets.




Determine the length of the dividers D by measuring the distance between the base shelf B and the shelf frame above. Then cut the dividers D to size and cut a rounded notch in the top edge as shown to fit into the notch cut in the front F. Slide them in place and through dowel from underneath and on top. Round the corners near the joint.

Finally before attaching the top, attach the back rail E' with a bracket at each end. Then attach eight shrinkage brackets to the top edges; two to each end of C and two to the sides I and E'. Screw down the top to the brackets from underneath. Then apply the backing boards.



Making the drawers



CUTTING LIST

 $1 \times 6in$

3 pieces 15½in long, for fronts 2 pieces 6½in long, for fronts

in plywood

10 pieces 5×15 in A 4 pieces $5 \times 13\frac{11}{16}$ in B

2 pieces 5×16 in C,

for centre drawer

(to be trimmed) 4 pieces $4\frac{15}{16} \times 5$ in D


in plywood


The 2 × 4ft piece should be large enough for all the drawer bottoms. Cut to exact sizes either to fit into grooves or onto battens when the drawers are completed.

	A	A	A /		A	
	Α	А	1	А		
	Α	Α	1	Α		
	В	В	А	Α		
	В	В		D	D	
	С	С		D	D	

Make the drawer sides out of $\frac{1}{2}$ in plywood, cutting the pieces as shown from a 3×4 ft piece. It is advisable to measure the openings in the front panel first to double check the dimensions. Subract $1\frac{1}{16}$ in from the centre opening to get the exact size of pieces C. If any of the measurements are out, adjust the drawer sizes accordingly. To fit the $\frac{1}{8}$ in plywood drawer bottoms in place, either cut grooves with a table saw or router, or attach $\frac{1}{2} \times \frac{1}{2}$ in battens flush with the bottom edge.

Join the pieces by using two 1¼in countersunk screws and wall plugs in each corner.





Shape the edges of the drawer fronts with a router or by hand.

After sanding the fronts, attach the drawer pulls and screw the drawer fronts to the plywood from the back using four 1½ in screws per drawer. Allow equal overhang on the sides and top and bottom. Finally, test the drawers. It is usually necessary to plane off an edge or two before achieving a good, smooth fit.

The top unit

The top shelving unit is much easier to make than the base unit. It simply consists of three shelves, two uprights and a capping piece.

CUTTING LIST

 $1 \times 9in$

1 piece 721 in long A

 $1 \times 8in$

2 pieces 47in long B

 1×6 in

3 pieces 683in long C


 $1 \times 4in$

1 piece 72in long D

2 pieces 7¾in long E scotia 2 pieces 68¼in long


 $\frac{1}{2} \times 1$ in beading

3 pieces 684in long



Before joining the pieces, shape the edges of the shelves C as for the base unit and round off the front edges of the uprights B.

Join the shelves to the uprights by through dowelling. First mark the shelf locations on the insides of the uprights with a try square. To help in drilling straight through for the dowels, clamp two battens to one upright so the shelf fits snugly in between. Set the shelves $\frac{3}{8}$ in in from the back of the upright B to allow for the tongue-and-grooved panelling.




Insert and trim the dowels, allowing the glue to set on one side before continuing with the other upright.

To assemble the top, first glue and clamp the short 1×4 in pieces E to the sides of the uprights, flush with the top edge. Then, after cutting the arches using the same template as before, attach the front piece D by through dowelling into the uprights.

Shape the edges of the top A as before on three sides and attach it, shaped edge downward, by screwing or through dowelling to the uprights; aligning back edges.

Finally, pin the beading to the shelves to form stops for standing up plates. Also glue and pin one of the scotia pieces to the underside of the top A, \(\frac{3}{8} \) in from the back edge. This will conceal the edges of the backing panel.




Applying the backing


The 8ft boards of knotty pine have to be cut to fit the exact size required. Start with the top unit. Lay it face down and measure from the underside of the top A to the bottom of the uprights B. Subtract line to allow clearance, then cut all the boards and pin them in place, slotting the tongues into the grooves. Remember to put the V-groove down towards the front of the dresser.



Joining the two units

Stand the top on the base, adjusting it until the uprights are in line. Then screw on the 2in long straight brackets with the $\frac{3}{4}$ in screws. Using brackets like this allows the units to be taken apart and moved easily. If the top unit doesn't stay level on the base, it may be necessary to add a hidden dowel under each upright. But, remember not to glue the dowel so the pieces can be taken apart if necessary. Finally, pin the last scotia piece to the top of the base unit to hide the panel edges along the front.





Put two nails into each shelf and one into the back of the scotia. It may be necessary to trim a little bit off the width of the last board to make it fit in.

Now do the same for the base unit. Measure from the underside of the top A to the underside of the base shelf B, cut the boards and nail them in place with two nails per end.

Finishing

Sand the dresser thoroughly and finish it first with a thinned coat and then two full coats of clear polyurethane. If you don't want the surface to be shiny, use a matt finish for the final coat. Rub down between coats with very fine sandpaper or with fine steel wool.

Renew the finish every six months or so by applying a coat of furniture wax.

DIRECTOR'S CHAIR

Folding director's chairs are remarkably comfortable and will serve equally well as dining or utility chairs. This chair is made from \$\frac{3}{4}\$ in birch plywood and \$1\frac{1}{4}\$ in diameter dowel. The only awkward part in making the chair is drilling the dowel holes. Make sure that the drill bit matches the diameter of the dowels well. It is better if the dowels are not too tight a fit so that they can rotate in their holes as the chair is folded up. Fixed joints are locked with small screws.


Preparing the pieces

CUTTING LIST
plywood
4 pieces $2\frac{1}{4} \times 27\frac{3}{4}$ in,
for diagonals A
2 pieces $2\frac{1}{4} \times 27$ in,
for fronts B
2 pieces $2\frac{1}{4} \times 32$ in,
for backs C $1\frac{1}{4}$ in dowel
6 pieces $20\frac{1}{2}$ in long
2 pieces 3in long $\frac{3}{4}$ in dowel
4 pieces $1\frac{3}{4}$ in long

First cut the plywood into eight $2\frac{1}{4}$ in wide strips. With a table saw this is only a few minutes work, but it can also be done quite easily with a circular saw fitted with a rip fence (page 208).

After cutting the plywood pieces and dowels to exact lengths, prepare

birch 24 × 32in, ¾in thick plywood dowel about 12ft of 1¼in diameter / 9in of ¾in diameter hardware 4 no.4 countersunk brass screws, 1in long plus 5ft of 16in wide deck chair canvas available from large department stores in various patterns and colours strong thread to match



C C C

the plywood strips by carefully marking the centres for the $1\frac{1}{4}$ in diameter holes. Also mark and round the ends to a $2\frac{1}{4}$ in diameter. It is best to use a compass for marking the holes so that the rounded end will be concentric with the dowel hole.

Drill the holes in the plywood strips before cutting the rounded ends with a coping saw or sabre saw. Make sure not to drill straight through from one side. Turn the piece over and finish the hole from the other side to prevent the wood from splitting. Cut the diagonal slots into the middle holes on B and C.


Before assembling, sand the pieces well, rounding all the edges and making them smooth and even. Whatever the kind of finish you want to give the chair, it will be easier to varnish or paint the pieces now before they are assembled. However, be careful not to get too much varnish or paint in the holes or the dowels will be too tight fitting and the chair will not fold up as easily as it should.


Assembling the diagonals

Putting the pieces together can be like putting up a deck chair—it would be almost comical if it wasn't so frustrating. Do it carefully, step by step, and don't worry if the pieces collapse just as you are about to add the finishing touches.

Start by attaching two 1¼ in dowels to two of the pieces A to make a rectangle.


Now add dowels to a third piece A, and join it to the rectangle at the centre with a 3in length of I_4^1 in dowel locked by a $\frac{3}{2}$ in cross dowel





on both sides. Add the last piece A, again attaching it at the centre pivot with the short dowels.


Before continuing, tap the 1½in dowels into their final positions leaving 1 in or 1½in protruding as






Adding the front and back pieces

Now it will be quite straightforward to attach the other pieces. Start by joining one front B to one back C with a 1¼ in dowel placed through the top holes, leaving ¼ in protruding at each end. Notice that the diagonal slots should face the same way. Then join to the already assembled





Now stand the chair up with the dowels in the slots and add the finishing touches before sewing and fitting the fabric seat and back. It will probably be necessary to tap the pieces with a mallet here and there to make sure the dowels extend the correct amount. Add four 1 in countersunk brass screws at the bottom through the edge of the plywood pieces B and C into the dowel to lock this joint firmly.



If you prefer, you can also flatten the tops of pieces B by sawing off the top then sanding them smooth to make the armrest more comfortable. Give the chair a final touch up coat of polyurethane or paint if it is needed once this is done.

Making the fabric seat and back

Cut the fabric into two lengths; 26in for the seat and 24in for the back. To make the seat, hold the fabric stretched in place over the dowels to determine exactly where to fold it over, then sew two lines of close machine stitching, ½in apart to make the channel at either end to take the dowel. The seams must be strong, so make sure to use small stitches and strong thread. Add a line of fabric adhesive between the two rows of stitching to reinforce the seams.



To sew the back, make a $2\frac{1}{2}$ in hem on the two long 24in edges. Then fold the fabric in half lengthwise with the right sides facing, to make a piece $5\frac{1}{2} \times 24$ in. Make a seam, 1in in from each end, then after turning right sides out, make 'pockets' by sewing a seam $3\frac{1}{2}$ in from either end to fit over the back piece.



To fit the seat, free one end of both dowels of the seat so that you can slide the fabric over them. The back piece is simply pulled down over the tops of the plywood pieces C.

TOWN KITCHEN

This modern kitchen design, which incorporates built-in features like an oven and a stove top, still retains the warm feeling of wood. It includes lots of clever features such as the pull-out wire baskets and pegboard to make the cabinets into neat and useful storage places. Around the stove, where most of the work takes place, a maple chopping block and a tile stand for hot pans have been built into the counter top to make the surface more versatile. The construction of the cabinets is basically the same as in the pine kitchen on page 16, but the doors are much simpler to make. Instead of having to fit accurately within a given opening, the doors 'lay-on', that is each door rests against the front of the cabinet overlapping with the opening, so that the exact size is not so critical. The doors are made from good quality Finnish birch plywood, clear finished with the attractive plywood edges left exposed.

Notice that the plywood edge grain is also used as a design feature on the laminate-covered worktops. Several thicknesses of plywood have been glued together to make an attractive, thick edge which continues all around the worktops.

Planning the kitchen

No matter what the size or shape of your kitchen, most of the features shown here can easily be incorporated into your design. In this kitchen, most of the storage is behind cabinet doors, but you may want to have some open shelf storage as featured in the country kitchen.

The first step in planning a kitchen is to measure the space available, making a note of windows and doors and any irregularities such as pipes, alcoves or columns. The placement of the sink will usually be dictated by the location of the plumbing, but if possible, try to create at least three or four feet of counter space between the stove and the sink as the central work area.

The refrigerator, too, is in frequent use and should be near at hand. Locate other appliances as conveniently as possible depending

on how often you use them and on how many appliances there are.


In this kitchen it was important to keep as much uninterrupted work surface as possible, so the refrigerator and built-in oven were placed next to each other at one end of the room.


Draw out the plan of your kitchen on graph paper if possible, indicating the room dimensions and the locations of the various appliances and fixtures.


Making the base cabinets

The construction of these units is very similar to those in the kitchen on page 16. The main difference is that in this kitchen the front edges are covered with dark stained strips of wood. The main structure is made of the same 21in wide boards of white laminate-covered chipboard. These are available in 8ft lengths with the two long edges already edged. You just cut off the lengths you need for the uprights and shelves. Buy some 8ft lengths of matching iron-on edging to cover the few places where a cut edge will be exposed.

Screw the components together as shown on page 18. Where the screw heads will be exposed, cover them








with special white plastic screw caps which give a more finished and professional appearance to the cabinets.


After making the basic cabinets, cover the front edges with $\frac{3}{4} \times 1$ in strips of a dark hardwood or pine stained in a dark wood tone to create a contrasting background for the light coloured doors. Use $\frac{3}{4} \times 2$ in wide strips along the top as a fascia.

Use 1½ in brads to attach the strips to the framework of the cabinets. Sink the heads below the surface with a nail punch and then fill the holes to match the wood.



Fitting the wire baskets


The white plastic-covered wire baskets are sold by large department stores in a variety of depths together with pairs of metal slides which are screwed to the sides of the cabinet. Depending on the exact width of the baskets you buy, it may be necessary to screw pine battens to the insides of the cabinets as spacers. These baskets are useful for storing everything from cans to fresh fruit and vegetables. Install three or four big baskets to hold larger items like baking tins and casseroles.






Making the worktops

The plastic laminate is glued down to a base of 3 in thick birch plywood. Plan the length of the worktops carefully, then cut the plywood to the exact sizes. By cutting carefully you will get two 233in widths out of one standard sheet of plywood so there should not be too much waste. The edge of the plywood, with its thin layers of wood in alternating shades of light and dark, is left exposed. You can leave the edge 3in thick or you can choose to emphasize it even more by adding a 1in wide plywood strip glued and screwed from the underside of the front so



that the resulting edge is 11 in thick.

It is important to incorporate a board as a splashback to the back of the counter. It not only keeps food and water from falling down the back of



the cabinet it also makes a neater join with the wall, particularly if the wall is not quite straight.

Cover a 4in wide plywood board with the same laminate as that used

for the counter and then glue and screw it to the back edge of the counter. Use a resin glue and spread it on liberally so that any small cracks will be filled with the glue which is hard and waterproof.


Working with plastic laminates

Plastic laminate has many advantages as a work surface for a kitchen. It is tough and durable, easy to keep clean and quite resistant to heat. It is also inexpensive and available in an enormous range of colours and patterns.

Large sheets of laminate are extremely awkward to handle. If possible, lay the sheet on a solid base such as a sheet of $\frac{3}{4}$ in plywood supported on trestles while you work on it.


Remember to cut the laminate a little larger, about $\frac{1}{2}$ in, than the board you are gluing it to so that it can be trimmed accurately afterwards either with a plane or router.

To cut the sheet, lay it good face upwards and mark the cutting line.



Fit a special hooked blade in the trimming knife and score halfway through the laminate, using a straight edge as a guide. Change blades often to be sure the cutting edge is sharp and score with several strokes of the knife.


To break the laminate cleanly along the scored line, hold the straight edge firmly on the line and lift up the end of the laminate until it snaps off. This takes a little practice to get right so it is a good idea to first make several trial cuts on a scrap of laminate until you get the feel of it.



To glue down the laminate, turn the sheet upside down and brush off the surface to make sure it is dust and grease free. Slightly roughen the top of the surface which the laminate is to cover to provide a 'key' for the adhesive. Use coarse sandpaper and

brush off all the dust. Glue the laminate to the base with contact adhesive. Spread a thin, even layer of adhesive on both the underside of the laminate and the top of the base surface.

After ten to twenty minutes, when both surfaces are just dry to the touch, lay several thin wood strips or small dowels along the counter at about 12in intervals. Once you bring the glued surfaces together you will not be able to move them, so these strips will allow you to keep the surfaces apart while you position the laminate exactly.




After you have positioned the laminate, making sure the sides and ends are aligned, remove the first strip and press down the laminate firmly. Then remove each successive



strip until the entire surface is in contact.

Go over the surface, pressing down firmly over the whole surface to get a strong bond. Then trim the edges with a sharp block plane or with a router fitted with a special cutter designed for cutting laminates, until they are just flush with the surface underneath. Trimming off the laminate takes practice to do well.

In this case you won't need to cover the edge with matching laminate, so the edge can just be trimmed at a 45 angle to keep it from breaking off. Where a front edging is required, apply it first in the same way as the laminate was applied to the top surface before the final trimming.




Making the oven unit

There is nothing particularly difficult about building in an oven. Each manufacturer supplies exact details for the size of the opening required. You simply build a large box to hold the oven. Place the oven at a convenient working height, which is usually recommended in the manufacturer's instructions. Then within the same large box, build a cabinet above and a large drawer below the oven to store equipment such as trays and roasting pans.

Start by planning the height of the unit, and keep in mind that eight feet is the maximum length of board that you can conveniently buy. Usually the depth of the oven from front to back is about 24in so that the 21in wide boards used for the cabinets are not enough. Instead, buy a standard sheet of the same laminate-covered chipboard, available at large suppliers, and cut out the pieces as required.


This oven unit was made the full eight feet in height, so one sheet has simply been cut in half to get the two 2×8 ft sides.

Cut the four 24in deep shelves to the required width. Make sure that the opening for the oven is the exact size specified. Some ovens require vent holes cut in the shelves below and



Mark the locations of the two shelves, then screw a $1\frac{1}{2} \times 1\frac{1}{2}$ in batten to each side to hold the oven shelf. Start the assembly by screwing shelf B to the battens. Add the second side and then drill and screw the shelf in position. Finally secure the bottom and top pieces A and D and shelf C from the outside, using screws hidden by plastic caps. Then attach the hardboard back by nailing it in place. Notice that the bottom shelf is about 4in off the floor with a board added underneath set back from the front edge.


In this case it was easy to build in the refrigerator by locating it in the



Building in the sink and stove top


The sink and stove top require cutouts so they can be fitted into the worktop. It is best to glue down the laminate surface first and then mark and cut the openings as required. Follow the instructions given by the sink and stove manufacturers in laying out the openings. The manufacturers often provide a template indicating the size of the cut-out required. Put the worktop on a pair of trestles, then drill a hole within the area to be cut out to

provide a starting point for the sabre saw. Make the cut carefully and then try the appliance in place and if the fit is too tight, trim where necessary with a plane or coping



Building in the tiles and chopping block

The small area of tiles next to the stove top is useful as a hot stand. To make it easy to install, make the counter out of two §in thick pieces of plywood instead of one §in thickness.




Fit the laminate and cut the holes in the top piece of plywood and then glue the two thicknesses together, adding a few short screws from underneath to reinforce the glued joint.

Then install the tiles with tile adhesive and after it has set, grout in between the tiles.

Install the chopping board in the same way. Hold the board in place using two screws, inserted from underneath.

manently, or they



can be adjustable, resting on special plastic brackets which fit into spaced holes drilled at, say, 2in intervals along the sides.

Assemble in the same way as before, first placing the marked bottom piece and one divider on edge. Screw all the dividers in place, then the top. Finally glue and nail a ½in thick back panel to the back edges, using it to square up the cabinet.

Notice that the air vent hood situated directly above the stove top is simply screwed to a wide shelf in the unit above.


The flexible pipe from the air vent goes up through a hole cut in the top and to the outside wall behind the plywood panel fixed above the unit. Follow the manufacturer's instructions to determine the exact position and fixing of the air vent.

Hanging the top units

To make it easier to hang the units, first screw a 6in wide pine board or matching \(\frac{3}{4} \)in plywood board to the wall so that the unit will sit directly on the top edge of it.

Make sure to mark a line level on the wall first as a guide for the board.

Before installing the cabinets, screw metal fixing brackets to the top rear inside corners at each divider. Also fix two brackets along the bottom, one at each corner. You will need two helpers to lift the cabinet and hold it in position while you screw through the brackets into the wall.




Screw cuphooks and knife racks into the board so that utensils can be hung within easy reach.

Making the doors and drawers

The easiest way to make the drawers is to screw together the four ½in plywood sides with screws and fibre wall plugs. The 4½in deep drawers


can slide on wooden battens screwed to the sides of the cabinet or on special runners.

Follow the manufacturer's instructions in fixing the runners. The nylon wheels in the runner make the motion so smooth that even a full drawer pulls out with fingertip control.




Making the doors is the easiest part of the kitchen construction since they are just pieces of ½in thick birch plywood with rounded corners. Notice that the cabinet door and the drawer fronts are both cut from the same piece so that the grain is continuous.

Cut each piece of plywood so that it overlaps the cabinet opening by ½in on all four sides. Try to choose sections of plywood sheet which have the most attractive grain and the fewest flaws. Then round the corners to a lin radius before sanding well.



With the drawer in position, measure the exact height of the drawer front, then cut off the top part of the plywood piece which will serve as the drawer fronts.

Apply three coats of clear polyurethane to the sides and paticularly to the edges of the plywood before hanging the doors. The hinges, which fit into a shallow recess drilled with a special bit, allow the doors to open a full 180°. Fit the door first before carefully locating the drawer front so that there is an even ½ in gap between it and the door below. Screw the drawer front on the drawer from the inside with four ¾ in brass screws and then attach the large wooden knobs



which have been stained a dark wood shade to match the cabinet surrounds.

Use the same technique for all the doors in turn, attaching one at a time to make sure that each one fits correctly.

You can increase the storage area in the cabinets by fixing perforated hardboard to the backs of the doors for hanging lids and other kitchen utensils away neatly.

Nail each piece of perforated board to 1 × 1in battens around the edge and then screw the battens directly to the insides of the doors. But notice that the shelves behind the doors must be cut back about three to four inches to allow space for the perforated board.




Chest of drawers



Sauna bench

BEDROOM AND BATHROOM PROJECTS



Bedroom closets





Towel rail and soap dish

This section contains a good mixture of projects for the bedroom and the bathroom, both in traditional and modern designs. The elegant double bed is easy enough to make in a weekend. For a more challenging project, there is the traditional pine bed with a hand carved motif on the headboard, footboard and side rails. This bed uses old-fashioned woodworking joints like mortise and tenon joints in its construction. There are nine other projects for the bedroom and bathroom ranging from an easy-to-make hardwood towel rail to a luxurious chest of drawers in ash veneer.



Simple double bed



Traditional pine bed



Night table



Bathroom cabinet and toothbrush holder


TRADITIONAL PINE BED

This is an elegant, old-fashioned bed, decorated on the head and footboards with a simple scroll design and made to take a 54×75 in double mattress. The slatted mattress base is nice and firm to provide good support. The slats are spaced about 2in apart to allow ventilation for the mattress. If you are using a foam mattress, it is best to check the manufacturer's instructions for the amount of ventilation, and hence spacing, required.


Making the head and footboards

CUTTING LIST

1½×6in 9 pieces 54in long
1×2in 2 pieces 50in long



Dowel joint the pieces of $1\frac{1}{4} \times 6$ in into one width (page 232). Join them carefully, making sure that the edges are straight. It is best to clamp them together first without applying glue to see that the joints are a tight fit. Add five $1\frac{1}{2}$ in long dowel pegs per joint, positioning them as shown to



avoid cutting through a dowel later when shaping the boards.

Use a dowelling jig (page 233) to drill accurately placed holes, or mark the holes with a gauge and try square and then drill (page 193). Add glue to the holes and edge and clamp up

SHOPPING LIST

softwood about 70ft of $1\frac{1}{4} \times 6$ in 12ft of 3×3 in for legs

12ft of 3 × 3in for leg about 85ft of \(\frac{3}{4} \times 3in for slats\) 18ft of 1 × 2in

dowel 8ft of ain diameter for pegs

tot pegs


hardware 10 no.10 countersunk steel screws, 3in long 8 no. 10 countersunk steel screws, 1½in long 8 no.10 countersunk steel screws, 1½in long 50 no.8 countersunk steel screws, 1½in long 40 no.10 round head steel screws, 1½in long

with washers


plus clear polyurethane


the boards with bar clamps below and above (page 202).

When the glue has set, remove the clamps and trim both ends to leave them square. It will probably be necessary to plane over the surface with a long plane. Then cut the panel into two parts, one 32in deep for the headboard leaving at least 17in for the footboard. Copy the profile for the headboard onto a long piece of paper or cardboard. Trace it onto both pieces and cut out the shape with a sabre saw.



one square = 1 in








as shown. The boards must be

allowed to expand and contract

batten on rigidly could result in


splitting at the joints. To prevent

across their width and screwing the



Clean up the edges with a Surform, file or spokeshave. Round the shaped edges either with a file, or with a rounding-over bit in a router.

Trace the scroll carefully onto the headboard. Make sure when gouging it out, that the shape follows nicely from the contour of the headboard. Use a very sharp gouge about ½in



under the head. Tighten with

moderate pressure only. Use two

screws per board and position the

batten exactly 21/4 in up from the

bottom.

Making the legs


CUTTING LIST

 3×3 in


2 pieces 38in long

2 pieces 23in long


Use a try square and marking gauge to mark the locations of the mortises. Make sure to put face and edge marks on the legs so that you position the mortises correctly for the left and right legs.




The mortises are ½in wide so use a ½in diameter drill bit in a drill stand to drill a series of holes just a little over 2in deep. Then use a ½in wide chisel to cut out the mortise, paring down carefully at the end to a straight, square hole.



The tenons will be held in place with two dowel pegs, so mark out two gin diameter holes, 2in apart, exactly



1½in from the mortised edge as shown. Use a gauge to mark all four legs so that the holes will be exactly right. Centre punch the holes, then drill straight through the leg, again using a drill stand to get the holes absolutely vertical.



Finally round the edges of the legs to approximately the same radius as the headboard.

Making the rails

CUTTING LIST


 $11 \times 6in$

2 pieces 80in long


2 pieces 18in long


 $1 \times 2in$

2 pieces 48in long A




First cut the tenons at each end of the two 80in long rails. They should fit snugly into the mortises so make them ½in thick, 4in wide and 2in long, and try them in the mortise slots as you work to get the fit right (page 235). Cut the shoulders first with a tenon saw, exactly 2in from the end and then chisel away the waste leaving the tenon ½in thick.






Finally cut away both sides to make the tenon 4in wide.


To drill the holes for the mortise pegs, insert each tenon into its mortise slot and make sure it is pushed in all the way. Push the sin drill bit through the hole already drilled just far enough to make a centre mark on the tenon. Then take out the tenon and drill a sin diameter hole, sin closer to the shoulder than the marked centre. That way the dowel peg, which is sanded to a slight taper, will pull the joint tight in the final assembly.




Mark and drill all eight holes, then cut eight lengths of §in diameter dowel, 3in long. Round the ends and sand them, tapering them slightly to make them easier to insert.



To create the profiled ends of the rails, glue an 18in piece of $1\frac{1}{2} \times 6$ in to one end of each rail making sure the end lines up exactly with the shoulder of the tenon. Then mark and cut out the profile following the diagram and round the edges as before. Carve out the scroll with a mallet and $\frac{1}{2}$ in gouge and then finally glue and screw the 1×2 in batten A to the inside, $1\frac{1}{2}$ in from the bottom



edge. Position it centrally and use four no.10 1½in countersunk screws per batten.



Assembling the bed

CUTTING LIST


1½ × 6in

2 pieces 55in long B

½ × 3in

12 pieces 75 kin long


First screw the legs to the head and footboards with the 3in screws. Position the boards so that they are flush with the inside (mortise) face of the legs. Counterbore by drilling \frac{3}{8}in diameter holes, 1in deep and then filling the holes with matching pine



plugs after the screws are in place (page 214). Use two screws per leg in the footboard and three screws per leg in the headboard.




Next assemble the rails by inserting the tenon into the mortise and tapping in the locking dowel to keep the joint tight. The dowels should be tapped in so that they finish up about $\frac{1}{8}$ in above the surface. To remove the pegs and dismantle the bed, simply use another dowel of the



same diameter and tap it in from the back to unlock the joint.

The slat base is made in the same way as the base for the double bed on page 58. First screw down the two 55in long cross struts B. If these are slightly too long, cut them to fit and then screw them to the 1×2 in battens with two no.10 $1\frac{3}{4}$ in screws per end.

Finally screw down the twelve slats with the $1\frac{1}{4}$ in screws spacing them out evenly and leaving about 2in between each slat.




Sand all the pieces carefully and then give the bed two or three coats of clear polyurethane, finishing with a matt coat.

NIGHT TABLE

Once you have cut all the pieces for this traditional night table out of

veneered chipboard, it shouldn't take more than a day to finish it. The night table measures about 16in wide, 27in high and 16in deep. To make the joinery really easy, all the pieces are glued and nailed together and the drawer is made from a push-together plastic section

which is very quick to assemble. Cut the pieces either from a sheet of oak veneered chipboard or, if this is difficult to buy, from veneered chipboard shelving in oak, mahogany or any other finish. These are available in panels of various standard widths.



SHOPPING LIST oak 48 × 54in, 3in thick veneered chipboard plywood 14 × 14in, in thick for drawer bottom hardware one small drawer pull with matching screws about 70 finishing nails or brads, 13in long 4 no.6 round head screws, in long for attaching drawer front 6 no.6 countersunk steel screws, 1in long for drawer runners plus 2 strips 4 × §in softwood, 13in long for drawer runners three 8ft lengths of oak iron-on veneer edging, ain wide about 4ft of plastic drawer section with 2 corner connectors and 2 front plates light oak stain / oak coloured wood filler / clear polyurethane

Making the cabinet

CUTTING LIST

veneered chipboard

1 piece 16×16 in, top A

2 pieces $15\frac{3}{4} \times 23\frac{1}{4}$ in, sides B

2 pieces 14×15 in, shelves C

1 piece 3×14 in,
bottom front panel D

1 piece $2\frac{1}{2} \times 14$ in,
top front panel E

1 piece $14 \times 23\frac{1}{4}$ in, back F


1 piece 3×14 in, back rim G

2 pieces 3×8 in, side rims H


1 piece $4\frac{1}{4} \times 13\frac{3}{4}$ in, drawer
front I

Start by cutting out the chipboard pieces and checking that they are square and accurate. The secret of success in using panels like this is to cut the pieces exactly to size so that each piece fits together perfectly.

When cutting veneered boards, remember first to score the cutting line on the veneer with a sharp trimming knife along a straight edge, so that the veneer does not split when you saw through the board.




one square = 1 in



Before beginning assembly, cut out the three shaped pieces, E and H. Then cover all the edges which will be exposed with iron-on veneer edging (page 67).

To assemble the unit, start by gluing and nailing one side B to the back F, covering the edges of the back F.
Then continue with the two shelves C. The top shelf is located 5in down from the top edge, and the bottom shelf is 3in up from the bottom edge.


Draw guide lines on the sides to locate the shelves when nailing. Make sure to apply glue to the edges, then put in the nails and finally set them below the surface with a nail punch.



Nail on the other side B and the two front panels, D and E. Then assemble the top A by gluing and nailing it to the back rim G and the two side rims H. Locate the back G about $\frac{3}{4}$ in in from the back edge to allow you space to nail the top to the back F and the sides B.



Construct the drawer from the plastic components, the drawer front I and the $\frac{1}{8}$ in plywood bottom. See page 120 for instructions on using plastic drawer sections. Glue and screw the $\frac{1}{2} \times \frac{8}{8}$ in softwood strips to the sides of the cabinet as drawer runners.



Before finishing the cabinet, fill all the holes with matching wood filler and then sand them smooth.

Finishing the cabinet

Either apply two or three coats of clear polyurethane, or first apply a wood stain to darken the colour of the veneered boards and then finish with polyurethane. This cabinet has been stained a light oak shade and then finished with a coat of matt polyurethane. Finally, add the decorative drawer pull and fit the drawer in place.

SIMPLE DOUBLE BED


Beds with slat supports are firmer and more comfortable than most spring supports and, provided they are spaced right, the slats allow air to circulate around the mattress. The bed is made for a double mattress, 54 × 75in, but you can adjust the dimensions to fit a mattress of any size. The design would look equally attractive as a single bed. The construction is easy but the pieces must be accurately and squarely cut for the assembly to be easy. All the connections are screwed together except for the bed surround which is composed of simple halving joints. The construction is made easier if you clamp the two pieces together as shown, before drilling the holes and inserting the screws.

Making the base


CUTTING LIST

- 1 × 1in softwood
- 2 pieces 52in long
- 2 pieces 36in long
- 4 pieces 6in long
- 1 × 6in hardwood 2 pieces 63in long A
- 2 pieces 824in long B
- $1 \times 3in$
 - 2 pieces 58in long, for slat supports C (to be trimmed)


Mark and cut the joints on the four pieces A and B as shown. Mark the width of the slot using a piece of



1 × 6in as a guide. Saw on the waste side of the lines halfway across before removing the waste with a chisel.



Next assemble the bed frame on the bench or floor. If a corner of 1 × 6in should break off, glue and clamp it together adding a 3½in screw to strengthen it.






softwood 85ft of $\frac{3}{4} \times 3$ in / 18ft of 1×1 in hardwood 55ft of 1×6 in / 22ft of 1×3 in (This bed is made of ramin. You can use pine or Douglas fir equally well.) plywood 4 pieces 6×6 in, $\frac{1}{4}$ in thick hardware 28 no.12 round head screws, $1\frac{1}{2}$ in long, black japanned finish 36 no.8 countersunk steel screws, $1\frac{1}{2}$ in long 52 no.8 countersunk steel screws, $1\frac{1}{4}$ in long 16 no.8 round head steel screws, $\frac{3}{4}$ in long clear polyurethane / matt black paint

Screw the 36in long 1×1 in battens to the insides of the long rails B, $1\frac{1}{2}$ in from the top edge and placed centrally along the length to support the two supports C. Screw the two 52in long 1×1 in battens to the ends A, $\frac{3}{4}$ in from the top edge. Use four no.8 $1\frac{1}{2}$ in screws per batten.

Add the short 6in battens in the corners so that you can screw the plywood corner brackets to them from underneath, using four 3in long screws per corner.



Finally trim the two 1×3 in struts C to fit exactly inside the frame, and screw them to the battens with two $1\frac{1}{2}$ in no.8 screws per end. Place one about 20in from the head end of the bed and the other about 27in from the first.

Making the ends

CUTTING LIST

1 × 6in hardwood


5 pieces 63in long

1 × 3in hardwood


2 pieces 31½in long,
for legs

2 pieces 25in long,
for legs

To make the footboard, screw the two 25in legs to the end of rails B so that 6½in of leg extends below the rail. Clamp the pieces together first, then drill the holes before attaching with two 1½in long no.12 screws. These round head japanned screws are a feature of the bed design, so be sure to align them vertically.




For the footboard, attach two more 1×6 in lengths A using a $\frac{6}{4}$ in thick board as a spacer (a piece of $\frac{3}{4} \times 3$ in slat will do).



Again clamp the pieces together before attaching them. Make sure the top board lines up exactly with the top of the leg, even if the space is more or less than the $\frac{5}{8}$ in. Also make sure to line the screws up vertically.

Repeat this with the three remaining 1×6 in boards to make the





headboard $31\frac{1}{2}$ in high. Finally cut twelve $\frac{3}{4} \times 3$ in slats to fit lengthways inside the bed frame. Screw down each slat with four $1\frac{1}{4}$ in screws to make the mattress base. Start at one end and leave approximately 2in spaces between the boards.

Finishing

Sand the bed carefully and then apply one thinned coat of clear polyurethane to the entire bed. Before applying the second coat, carefully paint all the board ends matt black using a small brush. This adds a nice decorative touch to the bed and matches the black screw heads which are left exposed on all connections. Finally, give the whole bed a second coat of polyurethane.

BED S

Although this bed is designed to take a standard single mattress about 40 × 80in, you can easily alter the size to fit any mattress, either single or double. The structure underneath is very strong so the width can safely be increased. Don't try to cut out the shapes without a sabre saw; it is very difficult to do accurately by hand. Plan out the work carefully. marking and labelling the pieces. This bed was made from good quality birch plywood stained a light oak shade and sealed with clear polyurethane. It would look equally good left natural or stained a darker colour like mahogany or teak to match darker furniture.

Making the bed frame

CUTTING LIST

in plywood

1 sheet cut into 2 sides A and

2 drawer fronts H as shown

½ sheet cut into 2 pieces 23½ × 40½in, for ends B

in chipboard

4 pieces $13\frac{3}{4} \times 40\frac{1}{2}$ in, for dividers C

14 × 14in battens

6 pieces 40 in long D 12 pieces 12 in long E

1 × 3in slats

10 pieces 79% in long,


for slats F

2 pieces 40% in long G


First choose the best side of the plywood with the fewest marks and knots and place it face down on the bench. Following the diagrams, mark the sides carefully with a pencil, using the lid of a jar or can to trace the curves.

Cut out the shapes with a sabre saw and then use a block plane to smooth the edges.

To cut the drawer openings, first drill a ½in diameter hole within the




SHOPPING LIST [4 standard sheets, 3in thick birch plywood 3 × 5ft. \in thick 30 × 50in. Jin thick chipboard 4 × 5ft, kin thick softwood about 45ft of 14 × 14in about 80ft of 1 × 3in 20ft of 1 × lin hardware 50 no.10 countersunk steel screws, 13 in long 6 no.8 countersunk steel screws, 11 in long 12 no.6 countersunk steel screws, 11 in long 65 no.8 countersunk steel screws, 1 in long 16 no.8 countersunk steel screws, lin long 60 finishing nails or brads, 1in long 2 pairs of heavy duty extension drawer slides, 24in long with lin screws 4 brass drawer handles with in brass screws




light oak wood stain

clear polyurethane

plus






waste area as a starting point for the saw. Cut out the shapes carefully with the saw, being especially careful at the corners so you do not overshoot the marked lines. When the shapes are cut out, plane and sand all the cut edges well and round the top edges of the sides A and ends B to give a more finished look and to make them smooth to the touch.


Next, glue and screw the short battens E to the insides of both sides A, carefully positioning them as shown. Notice the $\frac{1}{4}$ in space on either end of the sides for the plywood ends B and also the $\frac{1}{2}$ in space on either side of the openings for the $\frac{1}{2}$ in thick dividers C.

Start with the side which has the drawer openings. Use two 1\frac{3}{4}in screws per batten, screwing through the batten into the plywood. After attaching the six battens, lay the two sides A next to each other to mark


the corresponding batten locations on the other side A, then screw these six battens in place.



Next glue and screw two of the battens D to the inside of each of the ends B so that the bottom edge of the batten is exactly 12½ in from the base. Use three 1¾ in screws per batten, again screwing through the batten into the plywood.



Then glue and screw one batten D at the top of each divider C. For a stronger fixing use the 1in no.8 screws to screw through the chipboard into the battens, four screws per board.



Finishing the bed pieces

Before assembling the bed, sand the pieces well, with an orbital sander if possible. Then stain both faces of the ends B and the sides A.

After you have achieved the depth of colour you want and the stain is dry, apply two coats of clear polyurethane – gloss or matt finish – to the ends and side pieces. There is no need to finish the dividers, but it is a good idea to apply at least one coat of polyurethane to the slats to protect them from moisture.

Assembling the bed


Start assembling the bed by attaching one end B to a side A. First drill two countersunk clearance holes in each connecting batten. Have someone help you by holding the two pieces so that they fit together tightly while you screw through the short battens E into the ends with two 1¾ in screws.

Then attach the other end B and the other side A in the same way. Don't apply glue to these connections since

Assembling the slat support

To assemble the bed slats, space the ten slats F out on the two cross pieces G so that the outside slats are flush with the ends of the cross pieces, making the width 40 gin. The space between the slats will be about 1 gin.

Place the cross pieces G carefully as shown, 1½ in from the ends of the slats, then glue and nail the slats to the cross pieces using three 1 in nails at each joint. Before the glue sets, check with a try square so that the slat structure will drop squarely into the bed frame. For foam mattresses reduce to nine slats.



Attach the dividers C by screwing through the chipboard into the battens E with two lin screws per end, countersunk so they won't interfere with the drawers.

you may at some time want to dis-

After attaching the four dividers, drop the slat assembly in place to check the fit. It may be necessary to push the bed into shape to make it drop in

> easily. Remove the slat assembly while you fit the drawer slides but install it again before you fit the drawers.

Making the drawers

CUTTING LIST in plywood 2 pieces 10 × 28in, for drawer fronts H (see cutting diagram) in plywood 4 pieces 8 3 × 26in, for sides I 2 pieces $8\frac{1}{4} \times 24\frac{1}{2}$ in, for back J in plywood 2 pieces 24 × 25 in. for drawer bottoms K 14 × 14in battens 8 pieces 7 in long 1 × lin battens 4 pieces 244in long 4 pieces 23 in long

Since the type of sliding hardware may vary it is best to determine the width of the drawers from the amount of clearance required for the slides you have bought. Precise instructions are usually supplied with the sliding hardware.

The drawer fronts will remain the same, 28in wide, but the back J. bottom K and the 1 × 1in batten lengths may have to be adjusted.

The four corner joints of each drawer are reinforced with 13 × 13in battens. The 1 in plywood drawer bottoms K sit on 1 × 1in battens glued and screwed to the four drawer sides.

Attach the battens to the backs J and the fronts H. Use 1in screws through the plywood at the back and 13in screws through the 11 × 11 in battens at the front, and 11 in no.8 screws through the 1 × 1in battens into the plywood at the front. The three battens are set flush with the edges of J, but are set in from the edges of the front H to allow the front to cover the opening in the bed. So, position the battens carefully so the sides will be parallel.




Then connect the sides I to the corner battens using 1in screws, and attach the bottom K to the battens underneath with 3in screws.

Mark out the locations of the handles and scribe their outlines carefully with a sharp knife. Before attaching them, sand, stain and varnish the


drawer fronts and apply at least one

coat of polyurethane to the insides of the drawers.



Then, if you are using the type of inset handle shown, chip away enough wood with a chisel to allow the handle to sit flush with the surface of the drawer front. Attach the handles with the matching \in SCIPWS

Attach part of the rolling drawer slides to the sides and corresponding part to the dividers C. Measure very carefully to get the locations correct. Then with the slat assembly in position try the drawers in place. Adjust the runners if necessary.



Finally screw down the slat unit with about twelve 14in no.6 screws, countersunk so that they will not cut into the mattress.

CHEST OF DRAWERS

Chests of drawers come in many styles but the basic construction of them all is very similar. The top, sides and back form a box structure into which the drawers fit. The drawers are supported on runners which are attached to the sides. In traditional work when boards are glued together to form the sides. much more thought and care have to go into the construction to prevent the sides from splitting. However, with modern veneered boards which don't expand and contract, this is not a problem.

This is not an easy project but you can make it a bit simpler by joining the drawers with screws as shown in the Welsh dresser on page 40. instead of the dovetailed method shown here.


A portable router is very handy to cut the housing in the top, to trim the edges of the drawer fronts for the J-shaped moulding, right, and also, with the right attachment, to do the dovetailing on the drawers. This chest of drawers is made from ash veneered lumber core plywood, but you can use any veneer you like. It is more expensive but is much better for this type of work than chipboard. Since you will be spending a lot of time and effort on making it, it is worth buying good materials.

Cutting the lumber core plywood

CUTTING LIST 1 piece $20\frac{1}{2} \times 43\frac{1}{2}$ in, for top A 2 pieces 19½ × 36½in, for sides B 2 pieces 5 × 22in, for drawer fronts C (to be trimmed) 2 pieces 7 × 42in, for drawer fronts D (to be trimmed) 1 piece 9 × 42in, for drawer front E (to be trimmed) 1 piece 5×19in, for spacer F 1 piece $3\frac{1}{4} \times 45$ in, for plinth G (to be trimmed) 2 pieces $3\frac{1}{4} \times 19\frac{1}{2}$ in, for plinth H 1 piece $2\frac{1}{4} \times 45$ in, for cornice I (to be trimmed) 2 pieces $2\frac{1}{4} \times 19\frac{1}{2}$ in, for cornice J

Note: cut G, H, I and J at a 60° angle as shown or plane them afterwards.

SHOPPING LIST lumber I standard sheet, 3in thick, in ash, oak or similar veneer core plywood birch 4 × 5ft, 4in thick 1 standard sheet, ½in thick 1 extra piece, 20 × 40in, ¼in thick plywood about 70ft of 1×2 in ($\frac{3}{4} \times 1\frac{3}{4}$ in finished) for drawer runners hardwood (use inexpensive hardwood) hardware 30 no.10 countersunk steel screws, 21in long 16 no.8 countersunk steel screws, 14in long 14 no.8 countersunk steel screws, 11in long 35 no.6 countersunk steel screws, 4in long about 60 finishing nails or veneer nails, in long a few finishing nails or brads, 3in long 4 steel shrinkage brackets with 4in round head screws 8 brass drawer pulls, 6 large and 2 small plus ten 8ft lengths of iron-on veneer edging, 3in wide to match lumber core plywood veneer about 40ft of small J-shaped moulding for drawer fronts about 4ft of in diameter dowel for pegs dark water based wood stain (ebony or walnut)




clear polyurethane or wax polish

A sheet of lumber core plywood is expensive so to avoid waste, before you make any cuts in it, double check the dimensions. Follow the cutting list and diagram carefully. Notice that the cuts marked 1 and 2 on the diagram are made first.

If you are using a circular saw, refer to page 209 for hints on making straight and accurate cuts.

Cutting with the grain of the veneered face presents no problems, but, in cutting across the grain, the veneer breaks out causing a rough and unsightly edge which is impossible to fix. To prevent this, first score along the cutting line with a sharp trimming knife and a straight edge. A couple of strokes will be enough to cut through the veneer.


Notice that all the pieces are arranged lengthwise along the sheet. This is the same direction as the laminated boards inside the lumber core plywood, in other words the strong direction. Boards cut across the width would have much less strength.






Making the interior frames

CUTTING LIST 1 × 2in hardwood 14 pieces 40in long 12 pieces 15 din long




Assemble five frames as shown. Clamp the pieces together with bar clamps, check that the assembly is square then join each corner with two through dowels. Drill two well spaced ¼in diameter holes about 3in deep, then glue in the ¼in dowel pegs and cut the ends off flush when the glue has set. The dowel ends will be covered with veneer edging later.




On frames 1 and 2 add a central batten, positioning it exactly in the middle. Join it to the sides by dowelling in exactly the same way as the frames were joined. You should now have five frames as shown, numbered one to five. To avoid confusion, it will help if you mark each frame with its number clearly in pencil.

To complete the frames, add the remaining four 40in battens (K on drawing) to frame 1 and to frame 5. These are the top and bottom frames. Glue and screw one batten flush with the front and the other flush with the back. Use three $1\frac{1}{2}$ in no.8 screws for each batten and make sure that the ends line up with the frame.




Cutting the rabbets and housings

The next step is to cut the rabbets and housings on the top A and sides B. If possible, use a portable router. A straight cutter will cut both rabbets and housings accurately and quickly.



Start by marking the two housings on the underside of the top A. They should be exactly 40in apart. Mark the pairs of lines, then cut the stopped housings 4in deep using a



fence on the router. Make them the exact width of the lumber core plywood, so that the sides B will fit tightly into the groove. Cutting them by hand is more difficult. Score the lines with a trimming knife, then continue with a tenon saw and chisel.


Notice that the housing grooves run straight through to the back edge but they are stopped exactly 1in short of the front edge. Square off the front end of the housing with a chisel.

Cut the rabbets along the back edges of the top A as shown and along the inside back of the sides B. The rabbets run straight through to the ends on the sides B but are stopped at the housing along the top A. Cut all the rabbets and deep and and in wide.

Marking the sides


The five frames made earlier must be glued and screwed to the sides B to make up the basic structure of the cabinet. So mark the locations of the frames as shown on the inside faces of both side pieces.

Measure from the bottom upward on each side, then carefully draw the lines with a straight edge or a large square. Lay the sides together to check that the lines match up. Notice that if the thickness of the planed 1×2 in hardwood pieces is not exactly $\frac{1}{4}$ in you will have to make allowance for the difference when you make the drawer fronts.



Assembling the cabinet

Stand one side B on the bench with the rabbeted edge upwards. Hold frame 1 against it with the end exactly within the marks. The batten K faces the top end of B but notice that B extends \(\frac{1}{4}\)in beyond the top edge of K.



Clamp a batten to both the side and the frame while you glue and screw the 1×2 in to the side. Drill three countersunk holes in both frame ends then attach the $2\frac{1}{4}$ in no.10 screws.

It is very important to line the frames up exactly within the lines otherwise the drawers will not fit.


After you have attached frame 1, add the other side B, again gluing and screwing with three no.10 screws per side.

Fixing the iron-on edging

This is a good stage to attach the edging along all the facing edges of the top A, sides B and the front edges of the five frames. It is quite easy to do. The edging is backed with a glue which melts at a low temperature. Hold the veneer against the edge, then run a medium hot iron along it, pressing it down with a piece of wood or a cork sanding block as the glue sets on cooling.



Trim the edges with a finely set block plane, then sand them so that it looks like one piece of wood with no edges protruding.



CUTTING LIST in plywood 1 piece 33 × 40 in, for back L

Screw the four shrinkage brackets to the two battens K at the top flush with the top edge. Then add glue to the top of the sides B and drop the top A in place so that the sides fit all the way

into their housings. Screw through the four brackets into the underside of the top.

The back panel is a useful device for squaring the cabinet. It may be


necessary to push the whole cabinet so that it becomes square and allows the back to fit into its recess.


Screw through not the underside

To fix the back, place the ¼in

To fix the back, place the ¼in plywood piece L into the rabbets and first nail it in place with a few ¾in nails. Then screw about four ¾in no.6 screws along each edge to secure it.


Attach frames 2 to 5 in order, the final frames with the battens K facing toward the bottom. To make the cabinet more rigid, it is best to join the top and bottom battens K, to the sides B with a through dowel. Drill a ¼in diameter hole about 2in





deep through the side B straight into the end of the batten, then glue in the $\frac{1}{4}$ in dowel and cut it off flush. The dowel ends will be hidden later by the plinth and cornice. Finally attach the spacer F centrally between frames 1 and 2. Use two $1\frac{1}{2}$ in no.8 screws per side.


Adding the plinth and cornice



The plinth and cornice are easily fixed by gluing and screwing them to the sides and to the battens along the front.

First attach the side pieces H, flush with the bottom of sides B. Glue and clamp them then reinforce the fixing from the inside with two 1¼in no.8 screws per side. The front edges should be exactly flush with the front edges of the cabinet.

Then trim the front piece G to exact shape as shown. To cut the pieces by hand, start the cuts with a coping saw then finish the long straight cut with a hand saw or



a tenon saw. Remember to score the veneer first to avoid having it break out along the saw cut. Glue and clamp it on before adding three screws from the inside. Make sure both ends line up with the side pieces H. To finish the plinth, cut off the tips at the corners with a fine saw so that the angle continues round evenly.

Fix the veneer edging to the angled edges and ends of the plinth, paying particular attention to making the joint at the corners very neat. Use a sharp trimming knife to cut off the excess veneer. If possible buy the edging extra wide so that it will cover the angled edges, otherwise use two widths of edging.

Fix the cornice I and J in the same way, tight against the underside of the top. Start with the two side pieces J before trimming and fixing the front piece I and attaching the edging as before. This will be easier to do if you first turn the whole cabinet very carefully upside down, after first laying a blanket on the bench or floor to protect the top.



Making the drawers

Making drawers that fit smoothly and tightly is an art and requires careful work. The dimensions of the pieces in the cutting list, both for the drawer fronts C, D and E and for the plywood backs and bottoms, have been left slightly oversize to allow you to trim each drawer to make it fit its space.

CUTTING LIST

4 pieces $5 \times 18\frac{3}{4}$ in, for sides

2 pieces $4\frac{3}{8} \times 21$ in, for backs

2 pieces 9 × 183 in, for sides

1 piece $8\frac{3}{8} \times 42$ in, for back 4 pieces $7 \times 18\frac{3}{4}$ in, for sides

2 pieces $6\frac{3}{8} \times 42$ in, for backs


in plywood

2 pieces 20 × 20in, for bottoms

3 pieces 20 × 40in, for bottoms

Measure each drawer compartment individually, then trim the backs and fronts to exact size. First cut the backs about $\frac{1}{32}$ to $\frac{1}{16}$ in smaller than the opening for clearance. Try these in place, then trim the lumber core plywood fronts to the same length. The backs are $\frac{5}{8}$ in less in depth than the fronts or sides. This is to allow the drawer back to clear the small $\frac{1}{4}$ in thick stop at the front.

The dovetailing can be done either



by hand or with a dovetail attachment on a router which is much quicker and usually neater. Refer to page 236 for complete instructions on cutting dovetails.

Make through dovetails at the backs of the drawers and stopped dovetails at the fronts. Set the front dovetails back ½in from the front edge.


After cutting the dovetails, check the joints for fit. Dovetails only fit properly once, so leave the final assembly until after you have cut the ¼in wide and ¼in deep grooves in the sides to hold the drawer bottom. The bottom of the groove should be exactly ¾in from the bottom edge.

Don't cut a groove in the back pieces. These have been cut shallow to allow the bottom to pass underneath for screwed fixings as shown.

Assemble the drawers, starting by


gluing the dovetails of the back and sides. Then measure for the bottoms and cut them the exact size before sliding them into the grooves. Fix each bottom to the back with three \$\frac{1}{2}\$ in no.6 screws.

Add glue to all the dovetails and grooves before assembly and tap them together with a rubber mallet. It may be necessary to clamp each drawer until the glue sets, checking to be sure it is square.



Fitting the moulding

CUTTING LIST
J-shaped moulding
6 pieces 42in long
(to be trimmed)
4 pieces 21in long
(to be trimmed)
6 pieces 10in long
(to be trimmed)
4 pieces 6in long
(to be trimmed)



To fit the moulding, cut a recess on all four edges of each drawer front. Make the recess the exact thickness of the beading, using a straight edge and a router fitted with a straight cutter.

Stain the moulding black with ebony stain or another dark colour such as walnut. Give the strips two or three coats to get a dark tone.

Cut the pieces to exact length for each drawer, mitring the corners.

Fix the beading by gluing and pinning it with fine brads, punching the brad heads below the surface and filling the holes with filler dyed to match the beading.

Finishing


This cabinet was simply waxed with a mixture of carnauba and beeswax (page 249), but for a more durable finish, apply a few coats of clear polyurethane with a final coat of wax rubbed in carefully.

Fitting the drawers

CUTTING LIST ¹/₄in plywood 10 pieces 1 ¹/₂ × 4in for stops

Fix the drawer pulls to the fronts so that they line up in two columns.

Fix the stops, tacking them in place and then try the drawers to make sure they stop at the correct place with the drawer fronts flush. To make the drawers run smoothly, rub candle or other hard wax along the running surfaces.




BEDROOM CLOSETS

There are many ways to build in closets like these but the easiest construction method is using sheet materials such as plywood or plain or veneered chipboard. Instead of having to make a complicated carcass assembly using wood battens, to make these closets you just cut the standard sheets into two 2 × 8ft halves to make the uprights and then simply screw on the shelves. That is all there is to it except for the finishing and making the doors.

The only cumbersome part of the project is cutting up the 4 × 8ft sheets. If you don't have the facilities to do this, take the cutting list to your supplier who will usually cut the sheets to size for a small charge.

The doors are made from inexpensive African mahogany but you can just as easily use pine or Douglas fir for the door surrounds and then apply a wood stain before finishing with clear polyurethane. The woven cane applied to the centre panels is available from specialist stores in rolls usually 22 to 24in wide. It is quite expensive so it is important to plan carefully for minimum waste. As an attractive and

less expensive alternative, use a printed wallpaper or fabric, or even gift wrapping paper, in the central panels as was done with the kitchen doors shown on page 19. You can make the closet doors extremely simple by using good quality birch plywood and finishing with clear polyurethane as shown in the kitchen doors on page 45. This closet is built across the middle of a large bedroom to divide the room into a bedroom and a dressing room. If you build the unit directly against the wall it will not require back panels. For this unit 1/2 in chipboard panels were used to cover the back and also to give the structure more rigidity.




Planning the units

Start by planning the layout of the closets on a piece of graph paper. The first step is to plan the overall size of the unit, drawing the dimensions out on the floor if necessary to see how much space it will take up in the room and then measuring with a tape measure. The front to back distance should be about 24in to allow enough depth for hanging clothes. You can make the compartments any width you like, but 18 and 24in are good minimum and maximum dimensions to work to.

Divide the overall length into compartments, allowing $\frac{3}{4}$ in for the thickness of each upright. Then draw the front of the unit to decide the height of the compartments. Keep in mind that 8ft is a convenient height to allow you to use the full length of the standard sheet.

Also plan out the spaces you will need to hang various types of




clothing. Coats and long dresses require between 48 and 60in, men's suits about 36 to 48in, shirts about 30in and trousers about 48in. The best method is to measure your clothes to decide the exact size you want the closets to be. Remember to allow an additional 3 to 4in for clearance above the clothes rail. It is also a good idea to allow a few extra inches at the bottom of each cabinet for storing shoes and handbags.

Cutting up the panels


Use either plywood or plain chipboard for the uprights and shelves and paint them after assembly, or use plastic laminate-covered chipboard. Another alternative is to use veneered chipboard, usually available in mahogany, teak and oak, which you can finish with matching iron-on edging. Each 4 × 8ft sheet is cut in half to make into two uprights or several 2ft shelves. You will also need 2ft widths for the top of the unit and as an extra shelf in each compartment at the base.

The pieces are screwed together using $1\frac{3}{4}$ in no. 10 screws with fibre wall plugs for a tighter fit. The wall plugs are especially necessary if you are using chipboard, as they give the screws something to bite into. Screws have a tendency to pull out of the brittle chipboard but, by using wall plugs, the screws hold by friction giving a stronger fixing.




Making the structure

After cutting the 2 × 8ft uprights and shelves, mark the location of the shelves on each upright. Measure from the base with a tape measure along each side and draw a line across with a straight edge. Mark a second line 31n above the first to locate the shelf.



Mark the bottom and front edge so that you will remember which way around to place the panel during assembly. Then drill three $\frac{1}{4}$ in diameter holes straight through the



panel, between the lines showing the shelf location.


These holes will take the screws to hold the shelves, so countersink the holes from the other side. On most uprights you will have one set of holes on each side for the shelves.

After drilling all the uprights, cut the top panel to the overall length of the unit. Mark the location of each divider on the underside with lines $\frac{3}{4}$ in apart. Then drill three holes between the lines for screwing the top to the uprights.




If your ceiling is too low to allow access from above for screwing the top down, you will have to use metal angle brackets or plastic block connectors (page 227) from underneath to connect the top to the uprights.






Start by assembling the first compartment on the floor. Get someone to help you to hold the shelf and first two uprights steady, while you drill through the holes into the ends of the shelves with a 4in drill bit. Drill the first hole, then push the plug through and attach the screw before going on to the next hole.

Then place the assembled end unit in position on the floor. If the unit is to lean against a wall the baseboard or skirting will get in the way, so you will either have to remove it or screw a 1 × 2in batten between the upright and the wall and then cover it with a piece of moulding. Make sure to attach the first upright to the end wall to make the entire structure rigid, and also check with a spirit level that it is exactly vertical.




Continue with each shelf and upright in turn, drilling through, inserting the plugs and screwing tight. Always check with a level and square to be sure that the components are vertical and square. If the last upright is placed against the other wall, you can't get to the other side to drill the last holes, so attach the shelves into this last compartment with metal brackets or plastic block connectors.



To fit a bottom shelf in each compartment, cut two lengths of plywood or chipboard 1½ in wide to place under the bottom shelf. Place one piece I in in from the front and the other I in in from the back edge.

Fitting the clothes rails


Buy Iin diameter chromed metal clothes rail cut to the exact inside dimension of each compartment, minus ¼in for clearance. Fit them about 2½in from the top using special chromed connectors which simply screw to the verticals with matching ¼in screws.





Nail them to the floor, finally nailing the shelf down onto them. Then screw or nail through the side of each upright into the shelf to keep it in place.

After attaching all the base pieces, screw the top down and if your structure is not against a wall, nail a backing piece made of plywood or chipboard onto the back edges.

Making the doors







The door frames can be joined together by means of dowel pegs, halving joints or simply held together by screwing on a plywood panel from the back.


Allow an kin clearance in each direction when planning the sizes of

the doors. Use $\frac{3}{4} \times 3$ in pine or use a dark toned hardwood, like inexpensive African mahogany, for the frames, as in the doors shown here.

After joining up the frames, either cut a rabbet from the back with a portable router or screw on $\frac{3}{8} \times \frac{3}{8}$ in strips to take the central panel. You can also cut a decorative moulded edge on the front side with the router, or round the edge with light sanding.


Finish the door frames with two coats of polyurethane, rubbing down between coats. Then cut the






¼in plywood infill panels to match the openings in the doors. Cut off lengths of cane and lay them on the panels, stapling around the edges so that when the doors are assembled, the staples will be hidden by the rabbet.


To trim the cane flush with the plywood, turn the panel over and carefully run a sharp trimming knife



along the edge. Don't bear down too hard or you will pull the strands of cane and distort the pattern.



The cane is quite expensive so it is a good idea to stain or paint the side of the panel that faces inward before fitting it in the door frame so that you cane only on the outside of the doors. Then lay the panel in place and secure it with lengths of fine beading pinned to the frame.




To fit the doors, attach hinges to the edge of each door, fitting them into a recess so that they will sit flush with the wood. Then hang the doors, carefully allowing a clearance on all sides so that they will open and close easily. You may have to trim off a little here and there with a plane to make them fit correctly. Finally, fit magnetic catches and pulls or knobs and you are ready to hang up your clothes.

Making the pull-out bins

It is very convenient to have drawers built into the closets. Make them out of plastic sections as shown on page 247, or, make your own drawers.

These bins were made using \$\frac{3}{2}\$ in birch plywood for the sides and \$\frac{1}{2}\$ in plywood for the bottom. The plywood is simply cut to size, glued and nailed together and then painted.




Fitting the bins is very easy. Just glue and nail $\frac{1}{2} \times \frac{3}{4}$ in battens, 23in long to the uprights and locate them so that the bins will be level.

After sliding the bottom bin onto its runners, locate the second pair of strips and so on until they are all in place. Leave room between the bins to allow for the piling up of clothes. Paint or stain the strips to match.

Cut a profile in the side of the bins to pull them out, or attach pulls or drill 14in diameter fingerholes.

SAUNA BENCH



This bench will serve not only as a seat, but also it has a towel rail at one end and a shelf to hold books or toilet articles at the other end. The simple bolt-together construction can be used equally successfully to make an attractive coffee table or a planter for indoor or outdoor use. When buying the wood, try to select straight, clear boards.



Making the framework


CUTTING LIST

1 × 4in

2 pieces 54in long,
for rails A

4 pieces 27in long,
for legs B


2 pieces 15in long,




First make two side frames. On each leg B mark the location of the top of the rails 17in from the bottom. Then arrange two legs B and one rail A on the bench so that the ends of the rail are flush with the legs and the top of the rail lines up with the marks. Either clamp the rail to the leg at each end, or nail them temporarily together from the back.




At each joint, drill two holes straight through both pieces with a 3/2 in diameter drill.



Insert the carriage bolts from the leg side and tighten the nuts with a wrench.



Glue and pin the two braces C to the legs. Get someone to hold the two frames vertically while you attach the braces. To make the nails hold better, hammer them in at a slight angle, as shown.



SHOPPING LIST

softwood about 28ft of 1 × 4in pine or Douglas fir
16ft of 1½ × 3in

dowel 16in of 1½ in diameter


hardware 8 carriage bolts §in diameter, 2in long with nuts and washers about 80 finishing nails or brads, 1½ in long

plus wood filler clear polyurethane

Attaching the slats

Cut the slats to length, then round the top edges with a file, block plane or a router with a rounding-over bit.

Glue and nail each slat to the rails using two nails per end. Drive the nails in at an angle and leave an equal overhang at both ends. It makes it easier to line up the end of the slats if you temporarily nail a batten along the rail, as shown.



Start the first slat 3in in from the leg. Use a thin batten about ½in wide as a spacer. Set all the nails well below the surface and fill the holes.


Making the towel rail and shelf

CUTTING LIST

1 × 4in


1 piece 16in long,
for shelf E (to be trimmed)
2 pieces 15in long,
for sides F

First glue and nail one side piece, F to the legs as shown. Then measure the distance between the legs at the top and cut the shelf E and the 1½ in diameter dowel to that exact length.



Alternatively, hold them in position to mark the cutting length. Then glue and nail the shelf E to the legs and to the side piece F.


To finish the shelf, glue and nail the last side F to the shelf and leg.



The dowel is nailed between the legs at the other end, about 2in from the top, using two nails per end. Set all the nail heads and fill the holes.


Finishing the bench


Sand the pieces first, making sure that the ends of the slats are smooth. The finish can be either clear polyurethane as here, or a coloured polyurethane such as green or red to add a cheerful touch to the bathroom. Apply several coats of polyurethane to the bolt heads and nuts to prevent them from rusting in the damp atmosphere.



BATHROOM CABINET AND TOOTHBRUSH HOLDER

Natural pine looks so much better for bathroom cabinets than the white plastic laminate which is normally used. This cabinet has no complicated joints, it is simply screwed together using fibre wall plugs to get over the problem of screwing directly into the end grain. The usual rule is never to drive screws into the ends of boards, but by drilling a slightly larger hole and inserting a fibre wall plug before driving in the screw, the joint will be very strong. As an alternative, nail the pieces together as for the bench on page 74





Making the cabinet frame

CUTTING LIST

 $1 \times 6in$

2 pieces 15in long, for ends A

 1×5 in

2 pieces 28in long,

for top and bottom B

 $1 \times 4in$

1 piece 15in long, for upright C (to be trimmed)

2 pieces 131 in long,

for shelves D

I piece 15in long,

for shelf E (to be trimmed)

Join the pieces by screwing through the uprights into the fibre wall plugs inserted in the end of the shelves.

First mark the locations of the shelves on the inside of the ends A with pairs of light pencil lines.

With a ruler or a marking gauge mark the hole centres for the screws between these two lines. Drill each hole with a $\frac{3}{16}$ in diameter drill, straight through the uprights.

Drill the corresponding holes in the ends of the shelves, using the same drill bit. To mark the centres for these holes, insert the $1\frac{1}{2}$ in screws in the uprights, hold the shelf in its location and tap the screws to make a mark at the end of the board.

Before joining the pieces, sand them well and round the front corners of the ends with a file.


SHOPPING LIST softwood 3ft of 1 × 6in $5ft of 1 \times 5in$ 6ft of 1 × 4in 5ft of 4 × 14in 141 × 28in, 1 in thick for back plywood 24 no.8 countersunk brass screws, 13in long hardware 6 no.8 countersunk brass screws, 1in long 30 no.8 brass screw cup washers 10 finishing nails or brads, 3in long 24 no.8 fibre wall plugs, 3in long 141 × 28in brightly coloured plastic laminate plus 2 pieces of \(\frac{1}{2}\)in mirror about 13 × 15in (to be ordered to exact size) 2 lengths of double plastic channel for in thick mirror sliding door, each 28in long contact adhesive epoxy adhesive for the door handles clear polyurethane

Drill the hole in the end of each shelf about $\frac{3}{4}$ in deep, insert the wall plug and then screw the four pieces together with $1\frac{1}{2}$ in screws. Don't forget to put the screw cup washers on the screws before attaching each one.

Make the surround for the cabinet first, attaching the top and bottom pieces B to the ends A. Notice that they are set in ½in from the back edge.

Then trim the central upright C exactly to length after trying it in place. Mark the shelf locations on it by transferring the marks from the end pieces. Notice that it supports two shelves D from the left and one E to the right so it will have three pairs of holes.

Mark and drill the holes in C as before, then attach shelves D to upright C. Lay the cabinet surround flat and place the upright and shelves into it to mark and trim shelf E to exact length.



Finally screw shelf E to the upright C and then insert and screw all the pieces to the surround.

Attaching the back and doors

First glue down the sliding door channels with contact adhesive, gluing the deeper channel to the top (page 126).



Before attaching the back, glue plastic laminate to the ¼in plywood using contact adhesive (page 225). Nail this panel to the back of the top and bottom pieces B.

Finally cut two pieces of $\frac{1}{2} \times 1\frac{1}{2}$ in, 28in long, and screw them with three 1in screws and cup washers to the top and bottom pieces to hide the plastic channels.

Now order the two 15in wide mirrors with rounded edges to the exact size. It's best to cut a piece of scrap ¼in plywood and try it in place to get the size right.


For handles, glue on two thin pieces of matching pine with contact or epoxy adhesive. Finish with two coats of polyurethane.


Toothbrush holder

Use a piece of matching plastic laminate and plywood to make this simple and attractive toothbrush and glass holder.

Glue the laminate to a piece of $\frac{3}{4}$ in thick plywood, 5×7 in, and then cut this into two pieces, 3×5 in for the shelf A and 4×5 in for the back B.

Round the corners as shown, trim the edges with a fine file and then sand the edges well before cutting the holes and slots as shown.





Drill four $\frac{3}{4}$ in diameter holes in piece A and cut slots as shown for the toothbrushes. Cut a central hole with a coping saw to hold the glass. Drill the four $\frac{3}{16}$ in diameter holes in the back B, two to attach the shelf and two for screwing to the wall.




TOWEL RAIL AND SOAP DISH

These two small, attractive projects for the bathroom require very different degrees of skill. The 3ft long towel rail is very simple to make while the veneer soap dish is quite difficult. The construction of the towel rail is straightforward; the only difficult step is to drill the holes accurately. Making the soap dish is time consuming, but assembling and then carving through the layers of veneer produces beautiful results and you may want to use this technique on other projects. Plywood end grain is also a design feature of the coffee tables on page 166 and kitchen counters on page 45.

Gluing the veneers for the soap dish


Cut the veneer strips into about 30 pieces of light and 30 pieces of dark veneer roughly 8in square.

Glue the layers together alternating



dark and light wood. Spread a thin layer of glue between each layer, then clamp between two heavy pieces of plywood and allow plenty of time for the glue to set.

Carving the shell



SHOPPING LIST

veneer

about 24ft of dark veneer strips such as teak or mahogany at least 8in wide about 24ft of light veneer strips such as sycamore or maple at least 8in wide


plus white woodworking glue clear polyurethane

Draw the shell shape on both sides of the block and then cut out the shape with a coping saw.

To hold the piece flat on the bench while you carve, you can either glue it down temporarily to a




piece of plywood or use small clamps at two corners.



Use a very sharp gouge to carve out the scallop shapes of the shell, working with firm and even strokes. If you use a real scallop shell as a model, it will make the carving easier as you can refer to the shell as you work.




After finishing the inside of the shell, hold it gently in a vice and shape the back, first with a Surform and then with a gouge to carve out the details of the scallop shapes. The flutes on the back of the shell are not nearly as deep as those on the inside.




When you are satisfied with the overall shape, finish the shell by sanding it very smooth. Then seal it with many coats of polyurethane to make it completely waterproof. Rub it down with fine sandpaper or steel wool between successive coats.

Making the towel rail


Mark and drill a 1in diameter hole through each block of hardwood, then round the corners of the blocks, as shown, with a Surform or file.



Mark the location of the escutcheon plates on the back edge of each block and cut out a small groove or hole under the keyhole to accommodate the screw head before screwing the plate to the back edge.



Before assembly drill four gin diameter holes in the large dowel and sand the dowels and blocks.



To assemble the towel rail, slide the blocks onto the 1in dowel and lock them in position with the four short lengths of §in diameter dowel. Then apply several coats of clear polyurethane. If you like, you can stain the wood a darker wood tone or a bright colour to match your bathroom fittings, but test scraps first to be sure that the dowel and the hardwood finish the same shade,

SHOPPING LIST wood 2 hardwood blocks. 31 × 6in, 11in thick 36in of 1in diameter dowel four 14in lengths of in diameter dowel hardware 2 no.8 round head steel screws, 14in long 2 no.8 wall plugs, 14in long 2 rectangular escutcheon plates with matching in screws


clear polyurethane

plus



Hanging the towel rail

Hold the rail in position against the wall and check that it is level before marking the two screw locations. Then drill the holes for the plugs and insert the screws, leaving about $\frac{1}{8}$ in extending. Finally hang the rail onto the screws.



CHILDREN'S PROJECTS



Rocking elephant

There is something especially satisfying in making things for children whether it is furniture or toys. Not only can you make individual designs, but the children can take part. This section includes the essential furniture for a child's room, a traditional cradle, bed and playpen, high chair and bunk beds with built-in ladder. The designs are simple, good looking and sturdy. A selection of delightful toys including a rocking elephant, completes the chapter.



Child's bed



Bunk beds




Truck



High chair



Doll's house




Baking kit



Cradle



Child's bed





sized single beds when the bunks have outlived their usefulness. You just undo the four screws which hold the two bunks rigidly and safely together, switch the ends and you have two identical single beds, each with a tall headboard and a low footboard.

The two spacious drawers underneath are optional as the beds will look fine without them. The two drawers slide on wooden battens which must be fixed accurately. As a simple alternative, screw four castors under each drawer.

You will need a circular saw to cut the plywood sheet into boards. Clamp a straight board to the plywood as a ripping guide for the saw as shown on page 209. Keep in mind that these instructions are for a bunk bed to suit standard 30 × 75in mattresses. If you are using mattresses of a different size, make sure to alter the cutting list accordingly.


Cutting up the plywood sheets

CUTTING LIST (see diagrams opposite) in plywood 6 pieces 5 × 84 in, rails A 10 pieces $5\frac{1}{2} \times 39\frac{1}{2}$ in, cross rails B 4 pieces $3\frac{1}{2} \times 30\frac{3}{4}$ in, legs C 4 pieces $3\frac{1}{4} \times 22\frac{3}{4}$ in, legs D 4 pieces $2\frac{3}{4} \times 30\frac{3}{4}$ in, legs E 4 pieces $2\frac{3}{4} \times 22\frac{3}{4}$ in, legs F 3 pieces $4\frac{1}{8} \times 31$ in, drawer supports G 2 pieces $5\frac{7}{8} \times 30\frac{1}{5}$ in, drawer fronts H 8 pieces $5\frac{7}{4} \times 27$ in, drawer sides I in plywood 2 pieces 27 × 25 in,

Check the cutting diagrams carefully before starting work. Because there is little waste, there is no margin for error. Notice that the order in which the cuts are to be made is indicated by the circled numbers. It is important to proceed in this order.

drawer bottoms J

The easiest way to cut up a large sheet of plywood is to lay it over two trestles with supporting battens underneath (page 207). Make each cut carefully with a circular saw, using a homemade straight edge to guide the saw in a straight line, or use a table saw.



As you cut each piece, letter it in pencil and place all the rails in one group and all the leg pieces in another, so that it will be easy to identify them when it is time to assemble the beds.

If the saw leaves rough edges, run a block plane over them lightly to smooth them off. This is also a good time to sand the pieces since they are much easier to finish when lying flat. Sand along the grain at all times paying particular attention to the edges, and remember to lightly remark each piece if you sand off the pencilled letter.

SHOPPING LIST birch 2 standard sheets, {in thick plywood I piece 30 x 54in, {in thick for drawer bottoms softwood about 26ft of 1 × 1in, for battens 90ft of 4 × 3in, for bed slats hardwood 22ft of 1 × 1in for drawer runners hardware 70 no.10 countersunk brass screws, 11 in long 70 no.10 brass screw cup washers 48 no.10 countersunk steel screws, 13in long 24 no.10 fibre wall plugs, 1in long 32 no.8 countersunk steel screws, 1 in long 20 no.8 countersunk steel screws, 11in long 24 no.8 round head steel screws, 4in long 6 steel corner brackets about 130 finishing nails or brads, 11in long plus clear polyurethane

To make finishing easier later on, try not to leave scratches or finger marks on the pieces as you work.


Professional furniture makers make a habit of always working with clean hands and keep a cloth nearby to wipe off glue drips and smudges. It is also a good idea to lay an old blanket over the bench while


sanding and assembling to avoid marring the work.

Making the legs


The legs are L-shaped to make them stronger. There are four 30\frac{3}{4}\text{in long legs for the bottom bunk and four 22\frac{1}{4}\text{in long legs for the top bunk.}


Glue and clamp the two parts of each leg together. Glue C to E and D to F making four long and four short L-shaped legs. Unless you have a lot of clamps, it will be necessary to glue one or two legs at a time with white woodworking glue, letting the glue set for 20 to 30 minutes.






After all the legs have been glued, arrange the eight legs, four left-hand and four right-hand, on the bench. Mark the ends to indicate the bottom end, then measure up as shown on each piece. Draw the marks across the board with a try square and then crosshatch the areas to indicate the rail location.








To reinforce the glued joint of the legs, drill three countersunk holes in each leg and insert the 1\frac{3}{4} in no.10 screws. Notice that the holes are located within the hatched areas, so that the crossrails B will eventually hide the screw heads.

Check to make sure that all the leg components are firmly joined together. One or two may need an additional screw to hold them tight.


Preparing the rails



A


There are six long rails A and ten cross rails B. All six rails A must have halving joints cut at each end and in addition, six of the cross rails B must have halving joints as shown.

It is important to measure and cut these joints carefully so that they fit together snugly. Measure exactly $3\frac{1}{2}$ in in from each end. Then use a scrap piece of the same plywood to mark the width of the groove. Finally, measure and mark across exactly half the width of the rail to give the depth of the groove.



A sabre saw is very useful for cutting halving joints like these. It is easy to trim off a little extra if the joint is too tight, and the rough edges make the joint fit nicely.

Then cut four 1in battens, 75in long and glue and screw them to the insides of four of the long rails A, 2½in down from the top edge, placing the best face outwards. Use five 1¼in no.8 screws per batten. The other two rails A will serve as guard rails at the top.




To cut the slots, hold the rail in a vice, if possible, then make a saw cut on the waste side of each line. To finish off, lay the rail on the bench and chisel out the waste.

→ 3½ in →




Assembling the ends

The cross rails B are simply screwed to the legs to make four ends, two high and two low. The screws should be located carefully so that they all line up above one another




when the bed is assembled. Measure in $2\frac{1}{2}$ in from the ends and drill the $\frac{7}{32}$ in diameter clearance holes for the no.10 brass screws. Drill two





holes at each end of all the rails except the two long rails A without battens. These guard rails will not be screwed in place to allow them to be removed for making the upper bunk.

Assemble the tall ends first. Lay two long legs on the bench or floor, one left-hand and one right-hand as shown. Then place the first rail, slots uppermost, between the guide lines drawn earlier, with the slot flush against the leg.



Mark the screw holes, drill the pilot holes in the legs, then attach the rail with the no.10 brass screws with screw cup washers under the heads.

Attach the next two rails within the guide marks in the same way. Notice that these two rails have no slots. Also note that the top rail extends 2½ in above the top of the leg. This rail will tie the top and bottom bunks rigidly together with one screw going into the bottom leg and one into the top leg at each corner.



Make the short ends in the same way, this time with two rails per end, both rails having slots facing upwards.




Finishing the pieces

This is a good time to polyurethane the pieces since you can lay them flat. First erase any marks or letters and give the pieces a quick sanding with fine paper, rounding the top edges of the rails slightly. Apply two or preferably three coats of clear polyurethane rubbing down between coats.

Assembling the beds

First assemble the bottom bunk using the two high ends and two



long rails with battens A. If possible, get someone to help hold the ends



while you slot the long rails in place, with the battens facing inwards. Slot both rails in place, then screw these rails to the back of the leg by first drilling countersunk holes, then driving in two no.10 brass screws and washers per end.


The two beds are assembled separately then stacked and screwed together. This requires a lot of room so it is a good idea to clear a space in preparation for this step.


Before assembling the top bed with the two shorter ends, it's a good idea to make and fit the drawers to the bottom bed while you still have the space.



Making and fitting the drawers

CUTTING LIST 1 × 1in hardwood strips 8 pieces 27in long







assembly very easy. Refer to the instructions on page 217 for cutting the $\frac{1}{4} \times \frac{1}{4}$ in groove for the drawer bottom and for assembling the sides. Use three $1\frac{3}{4}$ in no.10 screws per corner.

Clamp the front in place temporarily with 1 in overlapping at each end while you drill two small holes straight through both pieces as pilot holes for the 14 in diameter finger holes.

Remove the front and drill the 1½ in holes, using the pilot holes as guides.




Drill from the face side of the front H and from the inside of the drawer so that any splintering or breakout will be hidden when you screw the front in place.




Before securing the front to the drawer with five $1\frac{1}{4}$ in no.10 brass screws with cup washers, stand the drawer up on its side and screw on each hardwood runner to the two sides flush with the top edge, using four no.8 countersunk steel screws, $1\frac{1}{4}$ in long.

The drawer supports


The drawers are supported by the three plywood boards G which are secured to the long rails A with metal brackets. First screw the brackets to the ends of the boards G using the ½in long round head screws. Then screw the hardwood runners flush with the bottom edge and front



end of the boards G using 1½in screws. Two of the supports G have runners on one side but the central support has one on each side.



Attach the supports G to the inside of the rails A. Start by locating the central one exactly in the middle. Make a pencilled mark and then hold the support up to the mark with the top edge against the rail batten and mark the hole locations through



the brackets. Drill the screw holes and attach the support with two ½in screws per bracket. To locate the left and right supports, hold the drawers in place and mark their locations. The supports extend about 2in below the rails.

Slide the drawers in and make any slight adjustments to the runners if necessary to make them run smoothly.


Attaching the bed slats

CUTTING LIST

³/₄ × 3in

32 pieces 30⁷/₈in long

Assemble the top bunk by slotting the long rails A in place with the battens facing inwards. Screw the rails A to the back of the legs exactly



as for the bottom bunk. Leave the two removable guard rails A off until the bed is assembled.


Secure the slats to both beds, sixteen slats per bed, by gluing and nailing them to the battens with the 1¼in long nails, two per end.

Fix the first slat at one end, then space them about 2in apart, securing each one in turn.

Final assembly



Lift the top bunk onto the bottom one, lining up the legs carefully. Secure the top bunk by screwing through the rail which overlaps the joints in the legs. Then slot the guard rails A into position. The joints for these rails should be quite loose to make them easy to remove.






BABY'S BED AND PLAYPEN


The bed: making the end frames

CUTTING LIST 1 × 3in 4 pieces 41½in long A 4 pieces 21½in long B




The bed is designed to fit a 24×48 in mattress. Cut the pieces and mark the long pieces A for dowel jointing to pieces B (page 232). Drill two holes per joint for $\frac{3}{8}$ in diameter dowel pegs 3in long, and then assemble the pieces.

Tapping the frame together with a



mallet should be enough to tighten the joint but, if necessary, clamp with bar clamps across the width until the glue sets.

Mark the two upper corners and bottom of the legs with a radius of about $1\frac{1}{4}$ in, cut the corners with a coping saw and smooth the cut with a file or as shown, with a Surform, taking care to make them even.



It is a good idea to round all the edges with sandpaper so that they feel nice and smooth to the baby's touch. Make both frames and put them aside for assembly later.

Making the side frames

CUTTING LIST 1½ × 2in

6 pieces 481 in long C

2 pieces 84in long D

2 pieces 14 in long E

2 pieces 26in long F in diameter dowel


11 pieces 9½ in long

11 pieces 15½ in long


11 pieces 27 in long

There are three frames, each with eleven dowels. The two front frames are hinged together to allow easy access to the bed. The procedure for each frame is the same, the only difference between them being the height.

On the edge of one of the six pieces C, first mark the location of the $1\frac{1}{4} \times 2$ in uprights at each end. Divide the remaining distance into twelve equal spaces about $3\frac{1}{4}$ in wide. Then clamp the six pieces C together with the ends lined up and transfer the marks across to the other five pieces using a try square. Unclamp the pieces and use a marking gauge to mark the hole centres midway across the eleven centre lines before centre punching the holes.




Drill the eleven ¾in diameter holes on each piece C, preferably in a drill stand. Use a depth stop to make the holes just over §in deep (page 195).



SHOPPING LIST softwood 24ft of $1 \times 3in$ (Douglas fir 48ft of 11 × 2in 18ft of 1 x lin or pine) Douglas fir 2 pieces 234 x 28in, 4in thick plywood perforated 2 pieces 24 × 48in, 1 in thick hardboard dowel about 55ft of 3in diameter 12ft of 3in diameter for pegs 6in of 4in diameter for pegs hardware 8 no.8 countersunk steel screws, 2in long 10 no.8 countersunk brass screws, 14in long 24 no.8 countersunk brass screws, 4in long 34 no.8 brass screw cup washers about 50 finishing nails or brads, 3in long 4 metal brackets with in screws, to support base 3 brass hinges, 2in long with 1 long brass screws plus 2 plastic-covered wire baskets with matching runners and screws

Add a dab of glue to each hole and tap the 9½ in dowels into one piece C. Then tap the other piece C on top. It may be difficult to get the top piece on. To make it easier, slant the top piece so that the dowels fit progressively, each into its hole.

clear polyurethane



Get the two pieces C straight and clamp them parallel, with the uprights D in position at each end. Before the glue sets, attach the uprights D by dowelling through the pieces C using two 3in long, \$\frac{1}{3}\$ in diameter dowels per joint. Make the next frame in the same way using two pieces C, two uprights E and the 15\frac{1}{2}\$ in long dowels. The large back frame uses up the remaining pieces C and F, and the 27\frac{1}{4}\$ in long dowels. Round the corners and edges.

Finally join the two small front frames together with the three brass hinges. Remember to chisel out a recess for each hinge so that the two frames fit flush together.

Assembling the bed

CUTTING LIST

1½ × 2in


4 pieces 26½in long,
basket supports G

Screw the four sides together to form the frame leaving 24½ in inside. Clamp the side and end frames together so that they are all aligned for drilling and screwing. Position the ends so that they extend 2in above the top of the side frames. Use three 1½ in brass screws with cup washers per end on the large side frame, then two screws per end on the lower of the two front panels.



Notice that the upper hinged panel is not screwed to the ends. See the instructions for making a baby-proof lock with dowels. Next attach the plywood end panels with the ¾in brass screws and cup washers. Centre the panel over the outside of

the end, allowing 1 in overlap on each side, then drill holes and attach the screws, twelve per panel.



Finally fit the slides for the pullout baskets. There are many sizes of basket available, so follow the manufacturer's instructions for the placement of the 26½ in long battens G. Use one 2in screw per end. Then screw the runners to the insides of the battens and slide the baskets in place.




Making and installing the base

CUTTING LIST


1 × lin

2 pieces 48in long


4 pieces 22 in long




This locking mechanism for the baby's bed is much easier to make than it is to explain. The diagrams show the details. With the front flap clamped in the closed position, drill a $\frac{9}{16}$ in diameter hole X through the end piece A, into the edge of the end frame C just far enough to make a centre hole.



Then unclamp and drill a $\frac{3}{4}$ in diameter hole Y, just over $\frac{1}{2}$ in deep, into that centre, continuing with a $\frac{9}{16}$ in diameter drill bit in the centre, another $\frac{1}{4}$ in into the wood. On the inside of hole X, make a notch about $\frac{1}{4} \times \frac{1}{4}$ in and $\frac{3}{8}$ in deep.




To make the key, drill two ¼in diameter holes exactly 1½in apart in a piece of ¼in diameter dowel 2in long.




Glue a lin length of ¼in diameter dowel into one hole ¼in from the end with the ends extending equally as shown. Push the ¼in diameter dowel through hole X, then glue a second ¼in diameter dowel ¾in long in the other hole with one end flush.

To open the lock, turn the dowel until it can be pulled out so the ¼in dowel sits in the notch cut in hole X.



You can use a sheet of plywood for the bed base, but perforated hardboard with spacers between allows the mattress more ventilation. Alternatively, use two pieces of $\frac{1}{8}$ in plywood and drill holes through both.

Simply glue and nail the I × 1 in pieces first to one panel and then to the other using the \$\frac{3}{4}\$ in nails. To support the mattress base in the bed, screw the four metal brackets to the insides of pieces A, one per corner, at a height which is convenient for the baby's age; lower down for older babies so that they have room to stand up safely in the bed.



Then drop the base in place and attach it to the brackets from underneath. To adjust the height of the mattress as the baby grows, just alter the placement of the brackets.





Making the playpen

CUTTING LIST

1½ × 2in

8 pieces 38in long


¾in dowel

28 pieces 24in long

4 pieces 26½in long,
for corners

The playpen is designed to take a vinyl mat about 34×34 in. Mark the centres of nine $\frac{3}{4}$ in diameter holes, $4\frac{1}{2}$ in apart, in each of the softwood pieces, starting 1 in from each end. Before drilling the holes, cut the corner halving joints as shown, $1\frac{5}{8}$ in from each end.


When drilling the holes, remember to drill on the top edges of four of the pieces and bottom edges of the other four. Drill the seven middle




SHOPPING LIST

wood 28ft of softwood, $1\frac{1}{4} \times 2$ in 70ft of $\frac{3}{4}$ in diameter dowel clear polyurethane

holes first, using a drill stand with a depth stop to make them $\frac{5}{8}$ in deep.



After assembling them, hold the four frames together while you drill the corner holes. Assemble the playpen by pushing the 26½ in long dowels through the corner holes. Make a hardboard base for the playpen or simply tie a vinyl mat at the four corners to keep it in place.




Finishing the bed and playpen


The easiest way to finish the bed and the playpen is to apply two or three coats of polyurethane, but it would look equally nice painted a bright colour. Remember that babies will chew on the paint, so be absolutely sure to finish with a non-toxic substance. Check with the manufacturer if you are not sure about the paint and if you are still uncertain, finish with polyurethane which is safe.

BAKING KIT

This very grown-up toy is extremely easy to make and is popular with boys and girls alike.



Cut out the four pieces of plywood and cut handle slots in the ends to make it easy to carry around. Then,



after gluing and nailing the back in place, glue and nail the two side pieces on and the toy is made after about an hour's work. Now add as many small baking utensils as you have room for by hanging them from cup hooks simply screwed into the back panel.

SHOPPING LIST

plywood 24 × 24in, ½in thick, cut into 4 pieces as shown

hardware about 20 finishing nails or brads, 11 in long

several small cup hooks

two large cup hooks for the rolling pin

plus a selection of small baking utensils such as measuring spoons,

small wire whisk, pastry cutters, pastry wheel and rolling pin



DOLL'S CRADLE

This cradle is made to a doll's proportions but, by altering the dimensions and fixings, you can make a full size rocking cradle for a baby.

Making the support

CUTTING LIST

 $1 \times 2in$


2 pieces 14in long A

2 pieces 17in long B


Start by rounding one end of both B pieces then drill a and diameter hole as shown.



Attach A to B by through dowelling from underneath using two $3\frac{1}{2}$ in long dowel pegs per joint (page 232).




Make two identical ends then, to complete the support, glue and screw the $21\frac{1}{2}$ in long 1×3 in piece between the two ends. Screw the 2in screws into fibre wall plugs inserted into holes drilled in the ends of the 1×3 in piece.




Making the cradle

CUTTING LIST


\$\frac{3}{4} \times 1 \frac{1}{2} \text{in} \\
4 \text{pieces } 20\frac{1}{4} \text{in long C} \\
\frac{1}{2} \times 1 \text{in} \\
18 \text{pieces } 7 \frac{1}{2} \text{in long D} \\
\frac{1}{2} \text{in plywood} \\
2 \text{pieces } 10 \times 10 \text{in, for ends E} \\
1 \text{piece } 6 \times 20\frac{1}{4} \text{in, for base F}




Cut out the ends E to the shape shown, using a sabre or coping saw. Sand the edges smooth and drill a $\frac{3}{4}$ in hole as shown. Nail the ends E to the base F, placing F between the ends flush with the bottom edge. Use four $1\frac{1}{4}$ in nails per end. Make the sides by gluing and nailing the slats D to the pieces C, nine slats per side. Use two lin nails per end and space pieces C as shown.



Then glue and screw the sides C to the ends E using two $1\frac{1}{2}$ in screws and two fibre plugs per end. Add a few $1\frac{1}{4}$ in nails through the bottom of the sides C into the base F.



Finally assemble the cradle by pushing the ³/₄in dowel pegs through the holes from the support into the cradle.



SHOPPIN	G LIST
softwood	$21\frac{1}{2}in$ of $1\times3in$ / 6ft of $1\times2in$ / 7ft of $\frac{3}{4}\times1\frac{1}{2}in$ / 13ft of $\frac{1}{2}\times1in$
plywood	18×24 in, ½in thick
dowel	two $2\frac{1}{2}$ in lengths of $\frac{3}{4}$ in diameter / 2ft of $\frac{3}{8}$ in diameter for pegs
hardware	4 no.8 countersunk steel screws, 2in long
	16 no.8 countersunk steel screws, 1½in long
	20 no.8 fibre wall plugs, 1in long
	about 25 finishing nails or brads, 14in long
	about 80 finishing nails or brads, 1in long
plus	bright coloured paint / transfers / clear polyurethane

Finishing

Set the nails below the surface of the wood with a nail punch and fill the holes with matching filler. Sand the pieces smooth and finish by painting the cradle a bright colour. Remember to use non-toxic paint.
Alternatively, leave the pine natural and finish with clear polyurethane.
In either case, transfers or stencils can be used to decorate the ends.

TRUCK

The best wood to use for the truck is beech which is often used for toys since it is hardwearing and has a nice, warm colour.

Hardwood is usually not available already planed up, so you must find either a supplier or workshop who will plane the boards to ½in thickness. You will need about 14ft of 8¼in wide boards.

Alternatively, use in birch plywood which is also very hardwearing, and more readily available.

SHOPPING LIST

hardwood about 14ft of \(\frac{1}{2} \times 8 \) in beech or similar wood (alternatively, 3 \times 3 ft of \(\frac{1}{2} \) in bisch played (1)

(alternatively, 3 × 3ft of 1in birch plywood)

dowel 5in of 3in diameter

about 4ft of §in diameter 6in of §in diameter

hardware about 40 no.6 countersunk brass screws, 14in long


40 no.6 brass screw cup washers 8 large washers to fit over

gin diameter dowels behind wheels

plus 8 toy rubber wheels about 4in diameter (available from specialist

shops)


clear polyurethane




Before assembling the top part cut out the opening for the windows in each side A. Don't cut the semi-circular shape to fit over the wheels until later. Notice when you screw the pieces together that they fit flush at the corners and that the back of the cab C is $1\frac{1}{4}$ in shorter than the sides A to allow the sides to extend over the base sides F.

After assembly, hold the cab in place on the base while you drill one \(\frac{1}{4} \) in diameter hole X in each side at the front. Drill straight through sides A and F to form a pivot, allowing the cab to tilt forward and expose the engine which is simply made from various scrap pieces of wood which are glued together.


Cut off two 9in lengths of $\frac{3}{8}$ in diameter dowel as axles and attach the four rubber toy wheels as shown in the drawing.



Cut two 1in lengths of ¼in dowel, then temporarily insert them as pivots into holes X and draw the semi-circular shapes on sides A over the wheels. Remove the pivots, cut the semi-circles, then attach the cab with the pivots again.








HIGH CHAIR

This is really an ingenious design which is very simple to make out of half a sheet of $\frac{1}{2}$ in thick plywood. The pieces simply slot together and no complicated joints are involved. The tray is secured with a clever lift-off detail which doesn't require any hardware. When the child isn't using the high chair, remove the footrest F and turn the chair on its side to serve as a writing desk with built-in seat, shown left. And when it has outlived its usefulness as a high chair, it can easily be turned into a racing car with the addition of wheels and painted numbers.





Making the high chair

CUTTING LIST

½in plywood 1 piece 30 × 38in,

cut in half as shown A


2 pieces 13 × 15in B

2 pieces 11 × 15in C and D 1 piece 9 × 15in E

1 piece 7×15 in F 2 pieces 2×15 in G

First cut out all the pieces. Accuracy isn't as crucial in cutting out since

plywood	½ standard sheet, ½in thick 1½ × 30in, ¼in thick
hardware	10 finishing nails or brads, 1½in long 20 finishing nails or brads, ¾in long
plus	wood filler sealer and paint




all the pieces overlap, but when you are cutting the halving slots be careful not to make them too large. An over tight fit can be corrected, but there is nothing you can do about a loose fit and the stability of the chair depends on the joints fitting together tightly. Don't forget that the paint will make the joints a little tighter.


Mark the lines for each slot exactly ½in apart, then cut on the waste side of the lines, using a sabre saw or a panel saw. Chop off the waste at the end with a ½in chisel. Round the ends of all the pieces as shown, including the ½in thick strip H. Notice that slots X on both pieces A are parallel to the sloped sides.

The pieces should not fit together too tightly as the coats of paint will make the joints tighten.

Now cut angled slots in the tray supports G. Use a fine blade such as a coping saw or a fret saw and save the small waste pieces Y. Fit the waste pieces back into the pieces from which you have cut them and then lay one of these tray supports on piece A so that the top edges line up. Glue and nail the small waste pieces to the side A using $\frac{3}{4}$ in nails. Make sure the tray support G doesn't move as you nail.





Slot the whole chair together and then clamp the tray D to its supports as you carefully glue and nail it down with 1½ in nails. The curved back edge of the tray should be just above the front edge of the seat E.





After nailing in about four nails, remove the tray and finish with a few more nails. Set the nail heads then glue and nail piece H around the edge of the tray, bending it tightly and nailing with $\frac{3}{4}$ in nails.





Finishing the high chair

Take the pieces apart and sand them carefully paying special attention to the edges of the plywood. Fill the rough edges and any gaps between the tray and the lip with wood filler and after this has dried, sand it off again

with fine sandpaper so that the edges feel smooth. Apply a coat of sealer to all the pieces and then finish the chair in a bright glossy colour or in two tones for a more exciting effect as was done with this chair. As when finishing any project for children, check that the paint is non-toxic.

DOLL'S HOUSE

There are three steps in making this doll's house which measures about 12 × 25 × 22in high. First cut out the pieces, then glue and nail them together and finally decorate and paint before the dolls move in.

CUTTING LIST

in plywood

2 pieces 11 × 21in, for gable ends A 2 pieces 11×17 in, for internal

walls B and C

1 piece 17×25 in, for front D

1 piece 9 × 11in, for floor E

1 piece 6 × 11in, for floor F

1 piece 9 × 11in, for floor G

1 piece 11 × 24 in, for top H

1 piece 13 × 27 in, for


ground floor I

3 pieces 3 × 6in, for stairway J

in plywood


1 piece 17 × 25 in, for back

2 pieces 6 × 25 in, for roof K



Cutting the pieces

It is best to cut the pieces with a circular saw to get a straight even cut (page 208). However, the cutting can be done with a sabre saw, or a hand saw, if you plane the edges after they are cut to make sure they are straight and even. Place the face side down when cutting with a sabre saw.



7 in -- 1in 43 in 43 in 2 in ... 21 in - -

Cut out the shapes of the gable ends A, the walls B and C and the front D. Use either a sabre or coping saw to

cut out the door and the windows. The windows are $2\frac{1}{2} \times 4\frac{3}{4}$ in and are


lin apart.


174 in

Assembly


Mark the rooms and walls on the top H. The central hall is 6in wide, the rooms on each side of it 9in wide and the two walls gin thick.

Glue and nail the gables A and the walls B and C to the top H, following the guide marks, using 1in nails.






SHOPPING LIST 2×4 in softwood, 12in long / $\frac{1}{4} \times \frac{1}{2}$ in batten, 3ft long wood 4 × 5ft plywood, in thick / 254 × 31in plywood, in thick 12in dowel, Jin diameter hardware 4 no.8 countersunk steel screws, 1in long about 30 finishing nails or brads, 1in long about 20 finishing nails or brads, in long pair of brass hinges, 14in long with 4in screws plus various wood scraps, such as triangular moulding for stairway doll's house wallpaper or gift wrapping paper




Glue and nail floors E and G in place so that all the rooms are 8\frac{3}{2} in high. Use the doorway cut-outs as a guide.


Attach the ground floor I, first marking the wall locations on it. Notice that it extends I in beyond the gables in each direction.




Cut floor F to serve as a landing. To attach it and the stairways, first glue and nail battens to the walls B and C.



Make the stairway by gluing triangular blocks onto the two pieces J, then glue these onto the battens.



The chimneys are simply made of two 6in lengths of 2 × 4in softwood with 1/2 in dowels drilled and glued into the top for chimney pots. The chimneys are fixed against the gable ends A with glue, adding a couple of



Finally nail on the back and attach the front with hinges.


Decorating


Here's where you can really have fun with this project. Buy paper in various patterns such as slate roofing, brickwork, parquet flooring and wallpaper from specialist shops selling things for dolls' houses, or use gift wrapping paper with small patterns. Glue it in place with any adhesive suitable for paper.

Glue in wide wooden strips under the windows and either paint them or leave them plain as here. Also add small strips across the windows for mullions. Make a front door and paint it, then add the details for a letter box and a door knob and an arched lintel.

Cover the roof edge with 1in wide wooden strip which can be painted to match the door or left plain.

And when this is all finished, start thinking about the furniture . . .





CRADLE

This is a copy of an early American cradle design, and it is just as handsome and functional today as it was then. Early American furniture was most often designed to be sensible and straightforward with clean proportions and functional details like the cut-out handles on

this cradle which make it easy to carry, or even to hang up. It is undoubtedly easier today to obtain suitable boards for this project than it was in the eighteenth century when making a cradle like this meant felling and hewing a tree which would then have to be hand sawn into boards. Cherry, oak and walnut were often chosen for fine pieces of furniture and it would be


well worth the extra cost and time to use one of these woods to make a real family heirloom. This cradle is made from less expensive pine, but you can just as easily use $\frac{3}{4}$ in thick plywood, painted and decorated with stencils of early American motifs. The instructions are for a 12×36 in mattress and you must alter the dimensions to suit any other size.

Making the ends


CUTTING LIST 1 × 5in 3 pieces 36in long


After cutting the three pieces to length, glue them together to make the two ends (page 231). There is no need to dowel joint the boards. If they are nice and straight, the glued butt joints should hold very well. Arrange the boards so that their end

grain alternates so as to minimize warping. Use three bar clamps when gluing up, alternating them over and under the boards.



While the glue is setting, follow the diagram to make a template for shaping the ends. The template is best made by first drawing a grid of lin square lines on a piece of cardboard and then following the diagram to draw the shapes out freehand. Take your time and smooth out the curves on the drawing afterwards until they are pleasing to the eye. Each square on the diagram is lin on the cardboard.






Plane off the gluetop boards, then trace two outlines of the end panel, using the template. Cut the panel in half then use a sabre or a coping saw to cut out the shapes. If the sabre saw is powerful enough, clamp the pieces together and cut through both at once. This will mean less hand work later on when you come to plane the pieces to the same size.




Cut on the waste side of the line, then clamp the two roughly shaped



pieces in a vice while you plane the edges down to the marked outline. Work from both ends towards the middle to avoid splitting the wood. Smooth the curved top edges with a file or a Surform.

Clamp the two end pieces to the bench, keeping them lined up. Then trace the outline for the handle from the diagram and transfer it to the wood. Drill two lin diameter holes within the waste area and cut out the handle shapes with a sabre saw. Smooth the rough edges with a file and then with sandpaper, rounding the edges and making the handles feel smooth and comfortable to hold.



Making the sides and base

CUTTING LIST


 $1 \times 6in$

4 pieces 48in long, for sides

 $1 \times 5in$


3 pieces 48in long, for base

First glue each pair of 1 × 6in boards together to make two side panels, each measuring approximately 11½ × 48in. Use three bar clamps for the gluing operation, one in the centre and the other two about 6in



before, using a sabre saw and cutting out both sides at once if possible. Use a rounded file to smooth out carefully the curves in the shapes. Work slowly, checking that the curve is regular.


Cut the slope at each end either with a sabre or a panel saw. Finish off with a plane so that they are straight and smooth, and slope at the same angle as the end pieces so that they will be flush when joined together. To make the base, simply glue and clamp the three 48in long 1×5 in boards together and trim the ends square to a length of $38\frac{1}{4}$ in.



7 in - 3 in -

from each end. Just as in gluing up the ends, there should be no need to dowel joint the boards if the edges of the boards are straight and smooth.


Mark the cutting outline on the pieces in the same way as for the ends, using a cardboard template on which you have enlarged the outline shown in the diagram. Cut out the shapes for the sides, exactly as




Cutting out the rockers


CUTTING LIST 1×6in 2 pieces 28in long

Make a cardboard template and trace out the shape of the rockers and cut them both out with a sabre saw. It is important that the curves on which the cradle rocks are identical so, if possible, clamp the pieces together in a vice and cut out both at once. After cutting the pieces




roughly to shape, clamp them together and shape them with a file or Surform. Smooth the wood evenly to the marked line.






The rocker edges are quite fragile so cut them out and smooth them with care. If an end should break off, glue it back in place, reinforcing it from below either with two $\frac{3}{8}$ in dowel pegs, cut off flush with a saw, or with two no.8 screws, $1\frac{1}{2}$ in long. Countersink the screws or hide them with wooden plugs, cut off flush.

Assembling the cradle




First drill the clearance holes for the screws at the ends of each side. If you conceal the screws with plugs cut from matching wood (page 214) the cradle will have a more finished appearance, so counterbore the screws by first drilling a $\frac{3}{8}$ in diameter hole about $\frac{1}{4}$ in deep. Then drill the $\frac{3}{16}$ in diameter clearance hole straight through the sides.

Clamp the sides to the ends using the




angled scraps under the clamps to make the clamping easier.

Make sure that the end pieces line up flush at the joint before marking through the holes with a marking awl.




Drill the four holes in each end with $a\frac{3}{32}$ in diameter drill bit about 1 in deep, and then screw the pieces together with the $1\frac{3}{3}$ in countersunk





screws before plugging the holes. Plane the lower edges of both sides so that they are flush with the ends.

Screw the base of the cradle to the assembled pieces using two round head screws per side. Since the screw joint tends to restrain the bottom from expanding and contracting, drill the clearance holes oversized using a 5 in diameter drill bit. Put washers under the screw heads to help the screws to move sideways as the wood expands and contracts with the changes in the moisture in the air. The joint which was screwed earlier between the ends and the sides will not be affected by expansion and contraction since both pieces tend to move in the same



Finally attach each rocker to the cradle, screwing from the inside with three round head screws in oversized holes. The screw heads will be hidden by the mattress, so there is no need to hide them unless you want a perfectly neat finish. If so, use countersunk screws instead and sink them below the surface of the wood, covering them with matching wood plugs. Locate the rockers 6in from each end of the base.

Finishing the cradle


Sand all the pieces well, paying particular attention to all the curved surfaces which were cut with the sabre saw. All the edges should be rounded so that there is nothing sharp protruding to hurt the baby.

Apply two coats of clear polyurethane, sanding with fine sandpaper between each coat. To give the cradle an extra smooth finish, apply a coat of wax and buff well. Polyurethane is a non-toxic finish so it is safe for the cradle. If you decide to use plywood and to paint it, be sure to use non-toxic paint.

ROCKING ELEPHANT

The most important step in making this delightful rocking elephant which stands 27in high, is to get the shapes of the head, ears, legs, trunk and tusks just right. So spend a little time drawing the pieces out on paper so that they can then be transferred to the plywood for cutting. Follow the diagram in laying out the pieces, then trace the shapes and cut them out with a sabre saw.


You will need a fairly sturdy saw to cut through the lin thickness of plywood so be sure to check the manufacturer's instructions on the capacity of your saw. Buy coarse blades for this rough work which, although they don't cut as cleanly,




go through the wood more easily. It will not take you long to clean up the cut edges of the plywood.

To mark the arc for the runners use a piece of string. Lay the plywood runners on the floor and have someone hold the circle centre 7ft away while you wrap the other end of the string around a pencil to mark the arc. Notice that the centre line is not in the middle of the runner because the elephant's centre of gravity is toward the front.

After cutting out all the plywood pieces, hold them in the vice and smooth them and round the corners with a rasp or a Surform.




Before attaching the body pieces to the runners, mark and cut out matching notches in the legs and runners so that they fit together snugly. Make the notches about 1½ in deep on each piece and position them as shown so that the length of the slats for the body will be 23 in.



Next screw the legs to the runners using one 2½ in screw per leg. Hide the screw head with a wooden plug if possible.

Now cut twenty five slats each 23in long to make the body of the elephant.

Before screwing the slats on with the brass screws and decorative cup



SHOPPING LIST

wood

4 × 4ft of lin thick plywood (or glue two thinner pieces together) 50ft of \(\frac{3}{4} \times 1\frac{1}{2}\)in softwood battens


hardware

7 no.10 countersunk steel screws, $2\frac{1}{2}$ in long 10 no.10 countersunk steel screws, $1\frac{3}{4}$ in long 50 no.6 countersunk brass screws, $1\frac{1}{4}$ in long 50 no.6 brass screw cup washers


plus

clear polyurethane

washers, either sand or plane the top edge of each piece to smooth off any rough edges on the elephant's back and bevel each top edge slightly with a plane.



Next screw the ears to the head with three $2\frac{1}{2}$ in screws. Mark parallel lines so that the head will be attached vertically exactly in the centre of the ears.



To attach the ears to the body, first turn the elephant upside down and place blocks to support and steady the rounded shape. Then glue and clamp the ears to the front of the



body. When the glue has set, remove the clamps, drill holes and insert $\sin 1\frac{3}{4}$ in screws from the inside.



Turn the elephant right side up and before allowing the children to try it out, add the finishing touches. Glue and screw the tusks in place hiding the four 1\frac{3}{4} in screws with plugs, and add the eyes either by painting them on or by inserting a plug cut from a dark wood. Finally thread a piece of thick rope through a drilled hole and knot it from the inside to form the tail.

Finishing

The best protection is a few coats of clear polyurethane, rubbed down between coats with fine sandpaper or steel wool so that the body is smooth to sit on.

Storage cabinet



Simple shelving system


WORKROOM AND **STORAGE PROJECTS**



Honeycomb wall unit



Large work table



Storage and work space are always at a premium. This section includes all manner of useful projects to solve this problem; an easy-to-assemble honeycomb wall unit for the kitchen or living room, two designs for shelving systems, one supported on the wall by track and the other free standing, a large work table with drawer legs, a sturdy workbench and tool cabinet and a real pièce de resistance — a roll top desk in solid hardwood.




Workbench



Boxes and cubes



Storage cabinet



Roll top desk



Tool cabinet



Versatile trestles


VERSATILE TRESTLES


Trestles are immensely versatile. They can be used with a couple of planks as a platform for painting or wallpapering, and they serve just as well as a base for a dining or work table. These trestles are 29in high and 24in wide. They fold up flat for easy carrying and the cut-out handles make it easy to hang them on the wall within easy reach when they are not in use.

Preparation

CUTTING LIST chipboard 4 pieces $23\frac{3}{4} \times 29\frac{1}{2}$ in A 4 pieces $6\frac{3}{4} \times 11\frac{1}{2}$ in B continuous hinge 2 pieces 23½in long 6 pieces 11 in long

Cut out the pieces following the cutting diagram, then cut out the





SHOPPING LIST to make two trestles

chipboard 4 × 6ft, 3in thick

hardware 10ft chrome-plated continuous hinge

with in screws

sealer, undercoat, black glossy paint plus


flush hardboard door, about 30 × 78in

slots in the four pieces A. Start by carefully marking the openings, working with a large try square if possible, to make sure they are square.

Before cutting out the slots with a sabre saw, drill a hole in one corner inside the waste area of each rectangle to make it easier to get the saw blade in. If you are using a compass or keyhole saw, drill holes

first in all the corners to start each straight cut.

Cut two openings in each of the four pieces, one for the handle and one for the folding flap, then use a file and sandpaper to clean off and smooth the inside edges of the openings. At the same time, sand all around the outside edges to remove the saw marks and to round the edges slightly.









Assembling the trestles

The assembly is very easy. Lay the pieces A down on the bench in pairs with the handle ends tight together. Then carefully lay the long lengths of continuous hinge centrally over the join and mark through four holes with a pencil, two on either side, one hole at each end of the hinge. The easiest way to make a small clearance hole for the $\frac{1}{2}$ in screws is to use a bradawl or even a nail.




Insert these four screws to hold the hinge in position and continue fixing the rest of the screws.

Attach the B pieces using the short lengths of hinge. Lay one piece in each opening tight against the outside (bottom) edges and attach the hinges as before. Make sure that the two edges are aligned so that the flap won't be askew when opened.



Finally stand the trestle on its side and connect the two flaps from underneath with another piece of hinge.



Now fold the trestle up to make sure the flaps lie flat in the openings. It may be necessary to take them off and trim a bit off here and there.

Notice that the bottom edges don't sit flat on the floor. Plane off the ends to the correct angle for a firm footing.

Making the table top

The top is easily made from a flush hardboard door available in various widths; 30 or 36in are the most versatile widths. Paint the top, first sanding it smooth and applying a coat of sealer.

You can make other trestles using plywood or even acrylic sheet for an elegant desk or dining table base.

You can also use glass or acrylic sheet as the table top which looks extremely attractive. Place lengths of rubber strip over the hinges to protect the top.

Finishing

The table looks best with a shiny finish. Apply a sealer, undercoat and at least one coat of glossy paint, rubbing down lightly. These trestles and top were painted black to contrast with the red chairs.

HONEYCOMB WALL UNIT


Ready-to-use panels of sin thick plastic laminate-covered chipboard are very convenient for the quick assembly of cabinets, shelves and wall units. The 8ft long panels are available in various widths from 6 to

24in wide in a selection of colours with matching iron-on edging. This storage wall unit consists of shelves, five uprights, a top and a bottom surface and requires two standard sheets of hardboard for the

backing. The pieces are connected with screw-together block joints (page 226). The shelves are adjustable, using small plastic shelf supports which fit into holes drilled at 2in intervals along the uprights.

To make the base


CUTTING LIST 6in wide panels 2 pieces 96in long, for front and back 5 pieces 9in long, for cross pieces



To make the wall unit

brown panels
5 pieces 94½in long,
for uprights
2 pieces 96in long,
for top and bottom
orange panels
20 pieces 23½in long,
for adjustable shelves
4 pieces 23½in long,
for fixed shelves

For adjustable shelving refer to the instructions on page 115 for making a drilling jig for the plastic shelf




support studs. The diameter of the drill bit and the depth of the holes will depend on the type of shelf studs you buy. It's best to experiment on a scrap piece first to get the drilling right. Using the drilling jig clamped to the board, drill two lines of holes in each upright starting about 12in from either end of the board. Space the holes 2in apart. Then tap the stud sockets into the holes.

It is best to assemble the unit on the floor and then lift it onto the base. Before assembly, apply edging to the ends of the top and bottom pieces.

Alternative shelf supports

It is very tedious to drill hundreds of holes so, as an alternative, you can attach the shelves by gluing and nailing 3 × 3in battens to the uprights. Paint the battens brown to match the uprights before attaching them. Mark out the shelf locations by measuring from the bottom of each upright and then squaring across with a try square. The shelves can then either rest on the battens or be glued and nailed rigidly to them.




Then carefully mark out the locations of the uprights on them. The spaces between uprights should be exactly $23\frac{1}{16}$ in allowing about $\frac{1}{16}$ in clearance for the adjustable shelves.

Attach the block joints and join the uprights to the top and bottom pieces. Use two plastic block joints at each connection.



To keep the uprights rigid, also attach the four $23\frac{3}{16}$ in long shelves with block joints, positioned about 36in from the bottom.

With the pieces still flat on the floor, nail the hardboard backing in place. Nail two corners, then use the



hardboard as a guide to square up the assembly before nailing the other corners. Nail at approximately 16in intervals. Attach the base with six block joints from underneath. Get help to lift the unit upright and install the adjustable shelves. To make sure that the unit doesn't topple over, attach it to the wall either with a few screws through the back, or preferably with a couple of brackets attached to the top.

SHOPPIN	G LIST to make a unit $8 \times 8 \times 1$ ft deep				
laminate- covered chipboard	13 panels 8ft long, 12in wide (7 brown and 6 orange) 3 panels 8ft long, 6in wide for base components (brown				
hardboard	2 standard sheets, ½in thick				
hardware	about 75 finishing nails or brads, $\frac{3}{4}$ in long 46 plastic block joints with $\frac{3}{4}$ in screws about 320 plastic shelf sockets about 80 plastic shelf support studs				
plus	8ft length of brown iron-on edging, §in wide				



SIMPLE SHELVING SYSTEM

Two standard sheets of plywood are enough to make four uprights and eleven shelves for a 12ft wide shelving system. To make a smaller 8ft wide system, use only one 4 × 8ft sheet to make three uprights, five shelves and one drilling jig. You can use chipboard equally well to make a

SHOPPING LIST to make a system 4ft high and 12ft wide

plywood 2 standard sheets, $\frac{3}{4}$ in thick 4×6 in, $\frac{1}{4}$ in thick for drilling jig

dowel 8ft of $\frac{1}{4}$ in diameter, cut into 2in lengths

hardware 48 no.10 countersunk steel screws, $1\frac{3}{4}$ in long 24 finishing nails or brads, $1\frac{1}{2}$ in long and sixteen $\frac{3}{4}$ in long


polyurethane or paint / 1ft of $\frac{3}{4} \times \frac{3}{4}$ in for drilling jig

less expensive system. The shelves simply plug into the uprights at any height you require with ¼in dowel peg supports. However, drilling the

plus

holes in the uprights and shelf ends must be accurate so that the shelves fit tight against the uprights to stabilize the system. CUTTING LIST


ain plywood
cut the sheets into
twenty four 4ft lengths:
11 pieces 9\frac{1}{4}\text{in wide,}
for shelves A
8 pieces 5\text{in wide,}
for uprights B
4 pieces 9\frac{1}{4}\text{in wide,}
for uprights C
1 piece 5\text{in wide,}
for drilling jig D






Making the uprights

First make a drilling jig (page 115) for in holes spaced 2in apart to drill the uprights B. The two rows of holes




should be exactly $3\frac{1}{2}$ in apart as shown. Measure in $\frac{3}{4}$ in from one edge for the first line. Place the uprights B in pairs on the bench on top of a piece of waste plywood, then put the drilling jig carefully on top and clamp the pieces tight to the bench aligning one side and one bottom edge exactly. Drill straight through with a $\frac{1}{4}$ in diameter drill bit. Make sure not to drill through the waste piece into the bench.



Mark the bottom edge on each pair. After drilling the four pairs of uprights, mark each one along the centre with two lines $\frac{3}{4}$ in apart, as a guide for attaching the middle piece C.


Spread glue along the long edges of uprights C, then nail the two B pieces to piece C with 1½in nails to hold them in place temporarily. Before putting in screws to fix the pieces rigidly, check that the middle piece C is centred.



Then carefully drill six countersunk screw holes spaced about 6in apart through the outside B into the centre upright C. Fit six 1\frac{3}{2}in no.10 screws per side and fill the holes to hide the screw heads.


Drilling the shelves

Make a small jig by drilling a hole in a 6in long piece of $\frac{3}{4} \times \frac{3}{4}$ in softwood with a $\frac{1}{8}$ in diameter drill bit, exactly $1\frac{3}{8}$ in in from the end as shown. Use a drill stand if possible to



make the hole absolutely straight. Then glue and nail on a 2in long end stop out of the $\frac{3}{4} \times \frac{3}{4}$ in softwood. Also glue and nail two 2×6 in pieces of $\frac{1}{4}$ in plywood to the sides as shown with the $\frac{3}{4}$ in nails.

Hold this over the end of the shelves and drill holes 1 in deep, four holes per shelf. It is vital that the drilling be done accurately, so the shelves will be correctly aligned. Spend enough time making the jig to ensure that the spacing is precise and use a depth stop when drilling the holes. To assemble, simply push the 2 in pegs through the holes in the uprights B and into the shelves at the far corners.



Finishing the shelves

Finish the shelves and uprights as here by painting the plywood to suit your taste and decor. After sanding the edges and faces carefully, apply a sealer, undercoat and one or two coats of glossy paint to get a really smooth finish.

Alternatively, if you use a good grade of birch plywood, you can leave it natural and just seal it with two or three coats of clear polyurethane, like the wall unit shown on page 124. Leave the plywood edges exposed or nail on half round or other moulding, setting the nails and filling the holes before painting the moulding.

UPRIGHT BOOKCASE


This bookcase with adjustable shelves is 33¼in wide and 7ft high, but you can adapt the instructions to make a bookcase of any size. Make it in teak veneered lumber core plywood or out of painted or stained chipboard. Six of the shelves are adjustable and rest on brackets which slot into sockets set into the uprights at 2in intervals. Brass sockets and studs look best with teak, but white plastic ones would look handsome on painted chipboard.

Preparing the pieces

CUTTING LIST

\$\frac{3}{4}\text{in lumber core plywood} 2 pieces \$9\frac{1}{4}\text{in} \times 7ft, for uprights A
9 pieces \$9 \times 31\frac{3}{4}\text{in}, for shelves B
3 pieces \$2 \times 31\frac{3}{4}\text{in}, for supports C

Cut the lumber core plywood into six strips as shown, scoring the veneer with a knife before sawing. The uprights are ¼in wider than the shelves to allow for setting in the back. Don't trim the ¼in plywood sheet for the back until the bookcase is assembled.




Making the uprights

First cut a rabbet to hold the back panel along the back edge of each upright. Use a rabbet plane (page 200) or router (page 216). Carry the rabbet through to the board ends.





Now make a drilling jig about 36in long out of a piece of waste plywood 9in wide as shown. Clamp it to each upright in turn, using it to drill ¼in diameter holes centred every 2in along the length of the uprights. Make sure the end of the drilling jig matches up exactly with the bottom of the upright so that the first pair of holes will line up on both uprights and the shelves will be horizontal. Move the jig further up the upright by pushing a pair of ¼in dowel pegs through the jig into the last pair of



drilled holes. Remember to use a depth stop as shown to make the holes the exact depth required to fit the shelf sockets.

SHOPPIN	G LIST					
teak veneered	1 standard sheet, ‡in thick					
lumber co	re plywood					
plywood	I standard sheet, in thick for back (veneered to match)					
hardware	12 no 10 steel screws, 2in long					
	18 no.8 brass screws, 13in long					
	18 no.8 brass screw cup washers					
	18 no.8 fibre wall plugs, 1in long					
	about 30 finishing nails or brads, \$in long					
	about 160 brass shelf sockets with 12 matching brackets					
plus	seven 8ft lengths of teak iron-on edging, ain wide teak oil or clear polyurethane					


Making the shelves

The bookcase shown here has nine shelves B. Six of these are adjustable and the remaining three are screwed to the 2in supports C. Screw the supports to the underside of the three shelves 1in from the front edge using four 2in screws per shelf. Sink the screws \(\frac{1}{2}\)in into the strip by first drilling a \(\frac{3}{2}\)in diameter hole exactly \(\frac{1}{2}\)in deep. You can of course make more or fewer shelves for the bookcase.

holes every 2 in

- 9 in -

5 in 2in



Making a drilling jig


Drilling holes at regular intervals is made easier by using a jig made from a piece of plywood ½ or ¾in thick. Cut one end so that it is exactly square and mark it with an arrow so that you will remember to start at this end.

Also mark one edge as the front edge. Measure out 2in intervals with a tape measure or ruler, then square

lines across the board at each mark with a try square. Finally draw two lines from the arrowed front edge, one 2in in from the edge and the other 5in from the first. Use a centre punch to mark carefully all the holes. Drill the holes with a ¼in drill bit. If possible use a drill stand to get the holes exactly vertical (page 214). If one is not available, stand a try square next to the drill as a vertical guide.


Applying the edging

To match the teak veneer, apply \(\frac{1}{2}\)in wide iron-on teak veneer strips to the front edges of all the shelves B, uprights A and supports C. The back of each strip is covered with Scotch glue which is the same type of glue used in traditional veneer work. It




Finishing the bookcase

Finish the bookcase by sanding with fine sandpaper. Wipe with a clean, dry, lint-free cloth and then rub in two even coats of teak oil, allowing the surface to dry between coats. Alternatively you can apply two coats of clear polyurethane. has the advantage of melting at a low enough temperature to allow you to remove or relocate the veneer by applying a medium hot iron until the glue melts. The glue sets almost as soon as the heat is removed. Trim off any excess edging with a sharp block plane and then carefully sand the edges smooth so that there is no join and it looks as if the boards are solid teak.



Assembling the bookcase

Mark the insides of the uprights A with a light square line 36in from the bottom as a guide for the middle shelf. Lay one upright on the bench or on the floor and hold the middle shelf in place while drilling through from the outside with a 1/6 in diameter drill bit. Hold the shelf in position flush with the front edge of A while you drill straight through about lin into the ends of the shelf. Push a wall plug through the upright into the hole in the shelf, then screw a 13in brass screw with the cup washer into the wall plug. Drill a second hole through the upright into the shelf and screw it tight, and finally drill a third hole into the end of the 2in support C. Repeat for the other end of the shelf and for the top and bottom shelves, holding them straight while drilling. Use a bar clamp to hold the shelf tight.



Remember to allow for the back by setting the shelves ¼in in from the back edge of the uprights.


Finally lay the bookcase flat with the back upwards and measure the exact size required for the back panel and trim the ¼in sheet, Nail it onto the uprights and the backs of the three fixed shelves with ¼in nails.

STORAGE CABINETS

Spice rack

It shouldn't take more than an hour or two to make this simple pine spice rack which measures 14 × 30in. To make it really easy, the shelves are The cabinet is strengthened by nailing on a hardboard back. Make the spice rack as small or as large as you like. You can even make it to fit into an alcove as shown on page 16.


> holes with filler. Sand smooth and finish with two coats of clear polyurethane or paint the shelf unit in a colour to match your kitchen. If you don't want to paint the hardboard back, finish painting the shelves first.




just glued and nailed to the uprights. To make the spice rack CUTTING LIST softwood 6 pieces 12in long 2 pieces 30in long First mark the shelf locations on the two 30in uprights with a try square. Mark both uprights at the same time to make them match up exactly. nails per joint. Make sure to hold each shelf between the marks as you Continue by turning the frame over and gluing and nailing the other upright to the shelves. Glue and nail the top shelf and then Finally lay it face down on the bench to nail on the bottom shelf to one of the uprights. Continue by attaching the the back. Use the in other four shelves using three 11in nails to attach the back, two per shelf and three for each upright. To make the spice rack look more finished, set all the nails with a nail punch and fill the



softwood about 12ft of 3 × 3in hardboard 131 × 30in, 1 in thick hardware 36 finishing nails or brads, 14in long 18 finishing nails or brads, sin long plus wood filler clear polyurethane








This cabinet which measures $10\frac{3}{4} \times 16$ in is made entirely of $\frac{1}{4}$ in birch plywood, glued and nailed

together. The dividers are slotted together to make internal spaces $5 \times 5 \times 6$ in deep. The drawers are made either 5×5 in, 24×5 in or $2\frac{1}{2} \times 2\frac{1}{2}$ in to fit either one, two or four drawers in each space. Drawers of three different sizes make the cabinet a perfect storage place for all kinds of sundries.

For the handles, mark six 3½ in diameter and six 2in diameter disks on the plywood using a compass, and cut them out with a coping saw. Then sand them round and smooth. Glue the disks together in pairs before fixing them on. Depending on the number of drawers in each space,

leave the disks as they are, cut them in half or in quarters to make the required number of handles for the cabinet. Fix the handles by screwing them to the drawer fronts from the inside. Paint the cabinet a bright



colour and accent the handles by painting them in a contrasting colour and fix labels to the drawers if you like.

Teak cabinets

Small cabinets with drawers are always useful. These handsome teak cabinets with drawers of varying sizes can be used to hold a variety of small items.

The cabinet must be made carefully so that the drawers fit smoothly. It is best to make the cabinet first and then make the drawers. It is usually necessary to fit the drawers and to plane off a little to make them slide

Both the cabinets shown here are made in the same way, but of course the larger version requires that much more time and patience. The instructions given are for making the small cabinet which is 131in long, 7½in high and 6¼in deep.

Then cut rabbets \(\frac{1}{4} \times \frac{3}{2} \times \text{in wide}\) along the back edge of pieces A and B for the 1 in thick back panel. Finally run a 1 × 1 in groove along the centre line of both pieces A for the divider C as shown. Remember to score the veneer with a knife before cutting the grooves.

To make the cabinet

CUTTING LIST teak lumber core plywood

2 pieces

 $6\frac{1}{4} \times 13\frac{3}{4}$ in, for top and

bottom A

2 pieces

 $6\frac{1}{4} \times 6\frac{1}{2}$ in, for sides B

in plywood

1 piece

6 × 6 in, for divider C


1 piece

 $6\frac{3}{4} \times 13$ in, for back D

1 × 1 in softwood

4 pieces 53in long

After cutting out the 3in lumber core plywood, cut $\frac{1}{4} \times \frac{1}{4}$ in tongues in the ends of sides B and matching grooves in pieces A for the corner joints. The easiest way is to use a lin straight cutter in a router with a guide (page



216) but you can also use a plow plane or combination plane (page


Before assembling the sides, screw the $\frac{1}{4} \times \frac{1}{2}$ in softwood along the sides as battens for the top two small drawers, using two kin countersunk screws per batten.

Don't add glue to the battens so they will be easier to move if necessary. The drawers are 15 in deep so the spaces between battens should be just deeper than this.


Assemble the sides by gluing them together and reinforcing the joints with two or three nails set below the



surface. Then cover the nails by applying iron-on teak edging over the ends of pieces A (page 115).



Glue the central divider C in place then finally apply iron-on edging to the front. Overlap the corners, cut through both pieces at a 45° angle using a sharp knife, and then remove the waste by warming the join with an iron so that the glue melts.



Making the drawers

CUTTING LIST

2 pieces 6 × 6in, for sides E

2 pieces $5\frac{1}{2} \times 6$ in, for front and back F

6 pieces 14 × 6in, for sides G

6 pieces $1\frac{1}{2} \times 5\frac{1}{2}$ in, for front and back H

in plywood

4 pieces 6 × 6in, for bottoms solid teak

3 pieces $2\frac{1}{8} \times 6\frac{3}{8}$ in, for fronts


1 piece 68 × 64 in, for front

3 pieces $1\frac{1}{4} \times 2in$, for handles

1 piece $1\frac{1}{4} \times 6$ in, for handle

Glue and nail together the drawer sides, backs and bases, making one large and three small drawers. Then slide these into the cabinet and number them and their locations so that you will remember where they go. Trim off with a plane where necessary to make them fit smoothly.

Before fitting the fronts, drill $\frac{3}{4}$ in diameter holes in the handles, then glue and screw them from the back



SHOPPING LIST

teak 8½ × 13in, \$\frac{1}{2}\$ in thick for drawer fronts and handles

teak 6½ × 42in, din thick

lumber core plywood

plus

plywood 13 × 36in, ¼in thick

 $13\times13 in, \frac{1}{3} in thick$

hardware 8 no.4 countersunk brass screws. Iin long


16 no.4 countersunk brass screws, ½in long 12 finishing nails or brads, 1in long

about 50 finishing nails or brads. In long

4 × In softwood, 24in long

8ft length of teak veneer iron-on edging, 4in wide


contact adhesive



to the loose fronts with the lin brass screws, countersinking the holes.

To fit the fronts, leave the drawers in the cabinet and spread contact adhesive on both surfaces. After the glue is touch dry, carefully glue on each front in turn, leaving a $\frac{1}{16}$ in gap between the small drawers. The front should overlap the $\frac{3}{4}$ in surround by about $\frac{1}{4}$ in on all sides. Then gently take the drawers out and reinforce the front by adding $\frac{1}{2}$ in

screws from inside the drawer. Finally, nail the cabinet back in place with $\frac{3}{4}$ in nails.



Finishing

The best finish for teak is linseed oil or teak oil. Sand the cabinet well, but be careful not to rub through the veneer. Then rub in two or three coats of oil, allowing the surface to dry between coats.


LARGE WORK TABLE

A table with a work surface this size, 3ft 3in × 7ft 3in, is ideal as a kitchen work table, as a sewing or hobby table or as a drawing table. The plywood legs, which are made large enough to contain either drawers or shelves, provide valuable storage space. They are simply glued and nailed together. And to keep the project quick to make, the drawers are made of push-together plastic sections with fronts made from plywood covered with bright plastic laminate.

Making the top

CUTTING LIST $1\frac{1}{2} \times 1\frac{1}{2}$ in

2 pieces 85 in long
2 pieces 34 in long
chipboard
2 pieces $3\frac{1}{4} \times 96$ in A
(to be trimmed)
2 pieces $3\frac{1}{4} \times 39$ in B
1 piece 39×87 in, for top laminate
2 pieces $4\frac{1}{4} \times 96$ in C
(trim after gluing)
2 pieces $4\frac{1}{4} \times 39\frac{1}{2}$ in D
(trim after gluing)




remainder, about 39\ × 87\in

for top (trim after gluing)

The chipboard edge boards A and B are joined to the top with $1\frac{1}{2} \times 1\frac{1}{2}$ in softwood battens glued and screwed to both the top and the edge for an extra strong fixing. Cut them out as shown and trim pieces A to length after screwing pieces B in place.


SHOPPING LIST softwood 22ft of 14 × 14in 22ft of 4 × 3in for drawer supports plywood 1 standard sheet. 4in thick I standard sheet, in thick I standard sheet, 3in thick chipboard plastic I standard sheet, white alabaster slate finish laminate small bright red pieces for drawer fronts hardware 28 no.10 steel screws, 14in long 40 no.6 round head steel screws, \$in long for drawer fronts 70 finishing nails or brads, 14in long 140 finishing nails or brads, \$in long plus 30ft of plastic drawer section, 4in wide, with 20 corner connectors and 20 front plates



contact adhesive for laminate

Fix the battens to the pieces B first, leaving a 2½ in space at each end. Glue them flush with the top edge of the chipboard then add three 1½ in screws from the chipboard side. Make sure to countersink these holes carefully so that the screw heads will not interfere with the laminate when it is glued on later.

Clamp and glue these two ends to the top with all the edges flush. At the same time measure the distance between the pieces B and cut the edge boards A to this exact length.



Glue and screw one 85in batten to each piece A with 1½in screws as before, then clamp and glue these in place as shown. Make sure to line up the

chipboard edges carefully before clamping.

After the glue has set, remove the clamps and turn the top over. Add 1½in screws through the top and into the battens along all four edges.

It is important that all the edges line up exactly so that the laminate will fit neatly and smoothly. Plane with a block plane and fill gaps with wood filler if necessary.

Gluing the laminate

Turn to page 46 for general instructions on cutting and gluing plastic laminates. Start with the end strips D. Glue them to the ends B and trim them flush on all four edges with a sharp block plane. Continue by cutting strips C with a panel saw ½in overlength. Glue down the top and then trim all around.


Making the legs


The legs consist of four boxes made of $\frac{1}{2}$ in and $\frac{1}{8}$ in plywood. The sides are simply glued and nailed together which makes them easy to assemble. Two of the boxes have open shelves which can be closed off, if desired, by attaching hinged doors (page 244). The other two each contain one large and four small drawers with fronts covered in bright red plastic laminate.

It is important to cut the pieces accurately. If possible use a table saw or a circular saw with a straight edge (page 208) to do all the cutting.



Number the pieces to keep them in order during assembly.






CUTTING LIST softwood 20 pieces 4 × 3in, 11in long. for drawer runners in plywood for cabinet sides A 8 pieces $3\frac{1}{2} \times 11\frac{1}{2}$ in, for cabinet fronts B 8 pieces $4\frac{1}{8} \times 12\frac{1}{9}$ in, for drawer fronts C 2 pieces 7½ × 12½in, for drawer fronts D 4 pieces 11\(\frac{1}{2} \times 11\(\frac{1}{2}\)in, for shelves E in plywood 4 pieces 12\(\frac{1}{2}\) × 31\(\frac{3}{2}\)in, for cabinet backs F 4 pieces 115 × 124in, for cabinet tops G 10 pieces for drawer bottoms H (size to be determined at assembly)

Start by making four identical boxes. First glue and nail the back F to the two sides A, using about five \(\frac{3}{2} \)in nails per side. Make sure the distance between the sides A is exactly \(11\frac{1}{2} \)in so that the fronts B and the shelves E will fit correctly. It is a good idea to hold a shelf E between the sides as a spacer.


Attach the two fronts B with two 1½in nails per side, keeping the edges carefully lined up while nailing. Fix the nails slightly askew so that they hold better.



Finally glue and nail the top G in place with $\frac{3}{4}$ in nails.

Open cabinet legs


Two of the legs have drawers and the other two have open shelving. Start with the open cabinets. The bottom shelf E sits directly on the front B. Mark a line, glue the edges, then hold the shelf in place while you nail it from the outside using three 1½in nails per side. Next decide on the location of the middle shelf, mark it with a try square then glue and nail it in place.




Drawer legs

Make the drawers from ready-made plastic drawer sections available in long lengths to be cut to size and simply pushed together using special corner joints available with the sides (page 247). It is important to follow the manufacturer's instructions carefully to determine both the


length of sides and back, and also to work out the exact locations of the $\frac{1}{2} \times \frac{4}{3}$ in drawer runners which run in a groove in the plastic sides. Cut the plastic with a fine saw.



Don't attach the plywood drawer fronts C until you have glued on the red plastic laminate and cut out the handle shape with either a coping saw, sabre saw or router. Notice that the 7½in fronts D have the same drawer backs as the 4½in fronts C, and all the handle cut-outs are identical.



After assembling the ten drawers with bottoms H, determine the exact locations of the $\frac{1}{2} \times \frac{3}{4}$ in drawer





runners by leaving a ½ in gap between drawer fronts. Lay the cabinet on its side and nail the runners in place with ¾ in nails. Then turn it upright to install the drawers. It may be necessary to adjust one or two of the drawers or runners to get the fit just right before finally adding a few more nails to make the runners secure.

Finishing

The cabinets can either be painted or varnished with two coats of clear polyurethane.

Before finishing the cabinets, make sure to trim off any protruding edges of laminate with a block plane, or with a router fitted with a special laminate-cutting bit. Set the nails with a nail punch and fill the holes with filler before sanding the cabinets carefully.

To assemble the table, lift the top onto the four legs so that the $1\frac{1}{2} \times 1\frac{1}{2}$ in battens sit on the legs. There is no need to screw the table top down, its weight holds it firmly in place.

BOXES AND CUBES

The only difficulty about making boxes is cutting the wood accurately. The sides must be square and the correct length for the pieces to fit together well. The best material to use is plywood. It is stronger and easier to join than chipboard and it is simpler to finish. However, it is also more expensive. This wall unit is made of $\frac{1}{2}$ in thick birch plywood with painted, half round edging nailed on. This type of edging requires mitre joints. For a butt jointed edging, use $\frac{1}{4} \times \frac{1}{2}$ in rectangular strips. The sides are simply glued and nailed together and the nails set and filled to hide the holes.

Wall storage system

Using only glue and nail construction, this is one of the easiest projects in the book. Yet with the teak veneer doors and the brown, half round edging, it is an elegant wall unit. Support the units, which are all 27in wide, with any adjustable shelving system, choosing a colour which complements the edging and wood.


Making three large boxes

The three large boxes along the bottom of the wall unit are the same basic box. One is made into a cocktail cabinet by adding a shelf and a door, one serves as a record cabinet, the third as a storage box.

CUTTING LIST


½in plywood
6 pieces 14 × 14in, sides A
6 pieces 14 × 26in,
tops and bottoms B
1 piece 8 × 13in, divider C
for cocktail cabinet
1 piece 8 × 9in, shelf D
for cocktail cabinet

½in plywood
3 pieces 14 × 27in, backs E



For each box, first nail the sides A to the tops and bottoms B with $1\frac{1}{4}$ in nails. Start the nails in one of the sides A, then glue and nail it to the top B. Make sure the edge fits flush along its length by feeling with your thumb as you nail.

Attach the bottom B, then turn the box over and nail on the second side.




Four ways of making boxes

1 Glue and nail. Start nails or brads in side pieces. Drive nails at a slight angle to increase strength. For $\frac{1}{2}$ in plywood use $1\frac{1}{4}$ in long finishing nails.




2 Glue and screw. Temporarily nail the pieces together with three nails, leaving the heads protruding. Then




pull out each nail in turn and drill straight through the nail holes at least lin into the end grain with a $\frac{3}{16}$ in diameter drill. Push a no.8 fibre wall plug in and add a no.8 screw. Start the screw in the plug then tap it with a hammer to push it to the bottom of the hole before screwing it tight. The screws can be countersunk and filled for painted work, or decorated with brass or chrome cup washers.

For chipboard, use special chipboard screws with coarse threads, countersunk in a $\frac{3}{8}$ in diameter hole and capped with a plastic screw cover on laminate-covered chipboard (page 226).


3 Corner block joint. This is probably the easiest way to join panels, but the blocks, which are exposed on the inside, tend to look clumsy, (page 226).




4 Grooved corner joints. Use a table saw or router to make matching grooves. This connection is often used for drawers (page 247). Glue the joint and reinforce with skew nails.




Adding the back
The simplest way is to nail or screw
the $\frac{1}{8}$ in plywood or hardboard back
directly onto the back edges of the
box. But to avoid leaving the edges
of the back panel exposed at the
sides, rabbet the back edges. Rabbets
must be 'stopped' before the end of
the board to avoid showing through.





Before fitting the back, nail the divider and shelves in place in the cocktail cabinet. Mark the location in the box with a try square. Glue and nail the divider C to the shelf D before nailing them into the box.



Then glue and nail the backs E in place using ½in nails. Use the back panel to square up the box. Nail one edge, then check all the corners for flush fit before nailing the other sides.

SHOPPING LIST

to make the unit shown which includes 6 boxes and 7 shelves

 $\begin{array}{ll} \textbf{birch} & 2\frac{1}{2} \text{ standard sheets, } \frac{1}{2} \text{in thick} \\ \textbf{plywood} & 1 \text{ piece } 14 \times 48 \text{in, } \frac{1}{4} \text{in thick} \end{array}$

½ standard sheet, ¼in thick

teak 1 piece 14×28 in, $\frac{1}{2}$ or $\frac{3}{2}$ in thick veneered (to be trimmed)

plywood 1 piece 24 × 28in, ¼in thick (or stain birch plywood

with teak stain)

hardware 150 finishing nails or brads, 14in long

150 finishing nails or brads, ½in long

for backs

150 finishing nails or brads, 3in long

for moulding

pair 1½in brass hinges with matching ½in screws

for fold-down door

small catch for fold-down door

sliding stay in chrome or brass with in long

screws for fold-down door

8 pieces adjustable shelving track, each

5ft long with screws for wall 20 brackets, 7in long 6 brackets, 12in long

plus

100ft half round moulding, ½in wide 5ft each matching top and bottom plastic door slide

for doors 1 in thick


8ft plastic channel for record cabinet dividers,

in thick

18ft teak iron-on veneer edging, 1 or 2 in wide, to match

veneered plywood, or use teak stain

contact adhesive clear polyurethane dark brown paint



Making two small boxes

CUTTING LIST

4 pieces 91 × 91in, for sides

4 pieces 9 × 26in,

for tops and bottoms

in plywood

2 pieces 94 × 27in, for backs

Make these boxes in exactly the same way as the large boxes. ñailing the sides to the top and bottom before attaching the backs.

One open box with dividers

CUTTING LIST

2 pieces 8 × 18in, sides A

3 pieces 8 × 26in,

top, bottom and shelf B


1 piece 8 × 15in, shelf C

1 piece 8 × 9in, divider D

1 piece 5 × 8in, divider E

in plywood


I piece 18 × 27in, back F



This box measures 18 × 27in. Follow the same procedure as before. Make the internal dividers and fix them as a unit into the box. Start by nailing divider E to shelf C, then attach these two to divider D and then finally to shelf B.

To make seven shelves

These shelves, which are $9\frac{1}{2}$ in deep, are small boxes without the top panel and are made using $\frac{1}{2}$ in instead of $\frac{1}{2}$ in plywood for the back panel.



CUTTING LIST (for each shelf) in plywood

2 pieces 9½ × 10in, sides A 2 pieces 9½ × 26in, shelf and back B

Finishing the unit

Set all the nails, fill the holes with wood filler and sand the boxes well. Pay particular attention to the filled holes, making sure any marks from the filler are sanded off. Then apply two coats of clear polyurethane to the boxes and dividers.

Sliding doors


Glue the plastic slides in place with contact adhesive. Attach the slides before trimming the ¼in teak veneered plywood doors to size. Cut

the doors 14in wide to overlap slightly and trim the height so they can just be pushed in place in the track. Drill holes or attach knobs for pulls before fixing the doors in place.

Fold-down door


The hardware for this fold-down door is somewhat more difficult to install and can only be done by trial and error to get the door to open and close smoothly. Attach the brass hinges and the catch to the door before screwing the hinges to the cabinet and attaching the sliding stay with matching screws.

To finish the edge of the veneered plywood, either cover it with ironon teak edging (page 67) or stain it to match.



Attaching the edging

The half round edging must be mitred at the corners. Use a small mitre box (page 205) and tenon saw to cut the moulding to fit the front edges of the boxes and shelves. Number each piece on the back as you cut them to avoid confusing the




lengths. Paint each strip with dark brown paint over the appropriate undercoat. Nail the pieces in place with ½in nails. To make T-joints for applying edging to the shelves, cut the ends in an arch with a coping saw so that they fit over the moulding.

Although a mitred corner looks more elegant it is much more work and also more difficult to do accurately. To make the job easier, use rectangular edging such as $\frac{1}{4} \times \frac{1}{2}$ in strips which can be simply butt jointed at the corners.

Record cabinet dividers

To attach the dividers to the record cabinet, first cut the plastic channel into eight 12in lengths. Then mark the location of each length inside the box and spread a line of contact adhesive along the lines and along the backs of the plastic channels. After fixing the channels, cut the ¼in plywood to size, round the corners with a coping saw and file or sand them smooth before giving them two coats of polyurethane and sliding them into place in the channels.





Other ways to use boxes


Storage boxes are very useful in the kitchen for the endless array of equipment needed. Hang boxes as shown here in a row on the wall, with L-brackets mounted inside, or stack them under worktops. These boxes, made of {in chipboard, are glued and nailed together and then painted with two coats of glossy paint over a sealer. The backing is white painted hardboard simply nailed on. To get the chipboard edges smooth before finishing, rub in filler and sand smooth. Notice that the top edges have been slightly bevelled.


Cubes are amazingly versatile. Make them out of chipboard, plywood or even ¼in hardboard. Stack them in any number of combinations or use them individually.





These cubes are made of white, laminatecovered chipboard which is available in many other colours in 8ft boards in widths from 6in to 21in, with iron-on edging to match. Use 15in wide boards to make these boxes. Plan out the cutting list for the five sides and dividers and then cut the boards and iron on the matching edging before joining the pieces. Use 13in chipboard screws countersunk and covered with white plastic caps to match the laminate. Three cubes have a central divider, one of which holds a simple drawer made from a pushtogether plastic drawer system (page 247). Arrange four cubes together as a coffee table. The cubes can sit directly on the floor or on a base made from four 2in high laminate-covered boards nailed together at the corners.





ROLL TOP DESK

No book of furniture making would be complete without including one really demanding project. This beautiful roll top desk is very exacting to make because the cabinet must be absolutely square and the lengths exact so that the roll top works smoothly. But with the right tools and plenty of patience, it is a very rewarding project to make. Even if you don't plan to make a roll top desk right away, the technique of making a roll top, or tambour, is useful. It consists of narrow strips which are glued onto a backing of heavy cloth or leathercloth so that it is flexible enough to run in a groove around corners.

A tambour can be used horizontally

SHOPPING LIST

sawn about 24ft of 1 × 9in / about 30ft of 1 × 6in

hardwood 34ft of $1\frac{1}{4} \times 3$ in

plywood 3 × 4ft, 4in thick (preferably veneered to match the hardwood)

 1×3 ft, $\frac{1}{4}$ in thick for template

hardware 8 no.6 countersunk brass screws, 14in long

35 no.6 countersunk brass screws, $\frac{3}{4}$ in long 18 no.4 countersunk brass screws, $\frac{1}{2}$ in long a few finishing nails or brads, $\frac{1}{2}$ in long brass cabinet lock with matching screws

plus 36 × 40in thin leathercloth (to be trimmed)

as it is for this desk or vertically for cabinets and chests. It is an extremely elegant and professional method of furniture making which not only looks attractive, but also saves space since the sliding door is contained within the cabinet. To make this desk you will need facilities for planing down the

hardwood which is usually bought rough sawn. A local woodworking shop will probably do this for a small charge, but make sure to specify the exact thickness that you want the finished boards. The main cabinet is made from $\frac{3}{4}$ in thick boards, but the other parts such as the interior dividers,

drawers and tambour require $\frac{5}{16}$ in thick pieces. The legs and rails are all

1 in thick.

The essential tools for making the desk are a table saw or radial arm saw for cutting the pieces to size and in particular for ripping the boards into the fine tambour slats, and a router for cutting the grooves and rabbets. See pages 210 and 216 for instructions on using these tools. Choose a rich, dark coloured hardwood which is relatively stable and straight grained such as South American mahogany, walnut or cherry.

This desk is made of muninga, a lovely African hardwood which is brownish red with orange patches in some boards. It has a sweet almost perfumed smell when it is being

worked.

The design of the desk has been kept modern and elegant in contrast to the usual roll top desk which is more old-fashioned and heavy looking. The desk has a good sized writing surface and ample space for storing stationery and writing implements in the drawers and open storage compartments. The leg structure too is kept light and elegant. Slanting the leg and rail not only makes it look interesting, but also gives the desk greater stability and allows more leg room by eliminating the need for a rail across the front.

You can of course make the desk larger to suit your requirements. It is difficult to alter the front to back dimension of the desk, but it is relatively easy to change the width by adding or subtracting a constant dimension to all the components which span across the width.

Preparing the wood

All the sawn boards must first be planed to the exact thickness required. If you are having them planed by your wood supplier or by a local woodworking shop, you should first cut the sawn boards to rough length and organize them in groups according to the required finished thickness. The shopping list allows for about twenty per cent waste in the length which is adequate for cutting off split ends and trimming the boards.

The base C and the top B are made from glued up 1 × 6in boards which must first be planed square and straight before they are dowel jointed and glued together to make a surface (page 231).

List of parts for cabinet


name	location	no. of pieces	material	thickness inches	width inches		th remarks
A	sides	2	hardwood	3 81 291	291/2		
В	top	1	hardwood	34	$11\frac{1}{2}$	39	glue up two 6in boards
С	writing surface (base)	1	hardwood	3	253	38	glue up three 9in boards
D	inside top	1	hardwood	3	81/2	38	
E	front and back rails	2	hardwood	1	$1\frac{3}{4}$	39	
F	tambour stop	1	hardwood	3	3	377	
G	bottom	1	plywood	1/4	28½	38	
Н	back	1	plywood	1	61/2	38	
I	inside back	1	hardwood	5 16	53	$37\frac{1}{2}$	
J	tambour slats	60	hardwood	5 16	1/2	40	cut from three 1 × 6in boards
K	storage dividers	6	hardwood	16	43	81	
L	storage shelf	1	hardwood	5	81/4	121	cut from 9in board
М	drawer sides	8	hardwood	5 16	2 3 16	8	
N	drawer sides	4	hardwood	5	47/16	8	
0	drawer bottoms	3	hardwood	5	75	75	cut from 9in board
P	drawer and tambour handles		hardwood	16	1	$2\frac{5}{16}$	
Q	drawer handle	1	hardwood	5	1	$4\frac{11}{16}$	
R	front legs	2	hardwood	11	$2\frac{1}{2}$	30	to be trimmed to length
S	back legs	2	hardwood	11/8	21/2	30	to be trimmed to length
T	diagonal rail	2	hardwood	11/8	$2\frac{1}{2}$	30	to be trimmed to length
U	cross rails	3	hardwood	11/8	21/2	401/2	

To economize on wood, rip 1×6 in boards in half to make up two $\frac{5}{16}$ in thicknesses out of each board for making the drawer components and for the tambour. The appearance of the tambour is greatly improved if you arrange the $\frac{5}{16}$ in slats so that you re-create the grain pattern of the board. Carefully number the pieces as they come off the saw so that you can arrange them in the same order.


Preparing the sides A

For the tambour to slide smoothly, the sides must be absolutely square and parallel. You must take care in cutting the grooves and dovetails, and be very exacting in the assembly procedure to check and double check that everything is straight and square before the final gluing.






Start with the two sides A. First perform the delicate job of cutting the grooves for the cross pieces C and D and then the curved groove which holds the edge of the tambour. This can be done by hand, but it is a lot easier and can be done more evenly and accurately with a router. Cut the tambour groove with a template and use a straight edge guide to cut the straight grooves. You will need a router fitted with a template guide and 16 and ½ in straight cutters.



Make an accurate full scale drawing of the side view of the cabinet on a piece of ¼in plywood. Then make a template out of the plywood for cutting the tambour groove.

File the edges of the template and sand them smooth. It must be marginally smaller than the groove.




to allow for the template guide on the router.


Mount each side A within 1×2 in pieces nailed to the bench, then locate the template carefully with brads or temporarily spot glue it to the board with a piece of paper in between.

The $\frac{3}{16}$ in wide groove should be exactly $\frac{3}{16}$ in deep so that the tambour will run on the bottom of the groove not on the shoulders.

Run the router along smoothly in one movement. Notice that the end of the groove continues out to the edge along the bottom to allow the tambour to be run in from underneath when the cabinet is assembled. The groove usually has to be widened slightly at the curves. You can do this best by hand with a chisel, smoothing the groove out afterwards with sandpaper.




Use a straight edge to rout the ½in wide and $\frac{1}{10}$ in deep grooves to take the shouldered tongues of C and D. Next cut the stopped rabbets along the bottom and back edges. Cut the profile of each side A and finish the cut edges with a small plane. Leave the rounding of the edges until the cabinet is assembled.




Preparing the base C and inside top D

These two pieces will be joined to the sides. Each will have a shouldered tongue cut along the ends to fit into the grooves cut in the sides A.

First glue together the three prepared 1 × 9in boards C to make up the base, adding dowel joints for reinforcement (page 232). Then cut the base to size and check to make sure that it is absolutely square. This is critical, for the sides A must be parallel after assembly. Mark the top face on both C and D.



Cut the shouldered tongues, cutting the rabbets along the top so that the tongue is located along the bottom edge. This can be done by hand with a rabbet plane, but again it is more easily done with a router. Follow the same procedure in cutting the identical profile on the ends of piece




Then trim off the last in of tongue

the grooves which are stopped 4in short of the front.

The next step is to cut the 16 in wide grooves in these two pieces to take the storage dividers K. Lay out the dimensions carefully on the base (see below), cutting the grooves on the top face of C but on the underside of

Then run the router fitted with a in straight cutter against a homemade T-square guide to cut the grooves just a little over in deep. Notice the stop nailed to the Tsquare to make grooves 74in long.




It is important that the grooves in the top D match up exactly to those in the base C, so after cutting the grooves in the base, transfer the marks from one to the other by laying them edge to edge. Then after cutting the same stopped grooves in the top D, square off the ends of the grooves with a narrow chisel.


Preparing the top B and rails E

The top and rails are dovetailed to the sides (page 236). This is not only decorative, but also keeps the sides together accurately.

Before cutting out the waste, transfer the saw marks to the sides A with a light scraping of the saw teeth.




Remove the waste on B along the gauged line, first with a coping saw and then with a chisel. Finally cut the pins on A making sure to saw on the waste side of the scribed lines. Try the joint for fit, tapping it only partway home. Dovetails should only be fitted together at final assembly.




The single dovetails for the front and back rails E are cut in the same way, starting by cutting the tails in the rails E and finally cutting the pins.


+ 1 in+



Again try the joints partway to make sure that the fit is right and adjust by trimming if necessary. If the joint is too loose, you will have to add a filler strip later during assembly.




Before assembling the pieces, cut $\frac{1}{4} \times \frac{1}{4}$ in rabbets on the three dovetailed pieces B and E to hold the back and bottom plywood panels. Notice that the back rail has two rabbets.




Assembling the cabinet

Glue the two tongued boards C and D into their grooves. The tongues should be tight enough so that they have to be clamped gently together. Make sure the two boards C and D are arranged the right way, with the grooves for the dividers K matching




Then glue the three dovetailed B and E boards, starting with the top B and then the two rails E. Glue and clamp down the top, then glue the rails in place clamping front to back. Also glue the front rail E to the front edge of the base C.




Fitting the dividers and drawers

Prepare and fit the dividers and drawers. Start by cutting the 3 in tongues at the top and bottom of the dividers K to fit into the grooves. Cut them with a saw or router, cutting off the last in of the tongues. 13 in shoulder length Then slide them in from the back to make sure that they fit. Cut 3 in wide grooves in the central dividers to take the shelf L which has the same $\frac{1}{8} \times \frac{3}{16}$ in tongue. Before you finally glue them in position, make the three drawers. dovetailing or finger jointing the sides together. The sides have \ \frac{1}{8} \times \frac{1}{9} in grooves to take the battens. Glue the 5 in bottoms in place in grooves cut along the inside of all four sides. Then shape and

place in grooves cut along the inside of all four sides. Then shape and attach each handle from the inside with two \(\frac{3}{4}\)in long no.6 brass screws.





To fit the drawers, screw $\frac{1}{8} \times \frac{1}{2}$ in hardwood battens to the dividers locating them to match the grooved sides of the drawers precisely. Use two $\frac{1}{2}$ in no.4 screws per batten. You may have to adjust them slightly to get the right fit, so tack them temporarily in place until you find the right location.





Then shape two of the dividers K before sanding them and finally gluing them in position. With all the dividers and drawers in final position, screw on the inside back I to C and D with about eight $\frac{3}{4}$ in no.6 brass screws.









Making the tambour

First lay out all the $\frac{5}{16} \times \frac{1}{2}$ in strips preferably in the order in which they were cut from the board so that the grain of the board is re-created. Examine the 60 slats and choose 54, rejecting any which are not straight or perfect. Line up the ends against a straight edge, then clamp them together gently, clamping two




boards across the top to hold them down. Then put four or five strips of wide masking tape across the slats to hold them together.




With the strips still clamped down to the bench, trim the ends straight across with a straight cutter mounted in the router so that the strips are exactly $37\frac{2}{8}$ in long. Use a straight edge as a guide for the router and make sure it is mounted absolutely squarely.

Then move the straight edge sideways $\frac{3}{16}$ in to cut the tongues. This is a delicate operation so take your time. After completing one edge, repeat for the other edge, again making sure it is cut square and parallel.



After the tongues are cut, remove the clamps and turn the taped slats over and with battens holding them in place along the four sides, plane off any irregularities with a smoothing plane. After the surface is smooth, clean off all the dust and shavings in preparation for gluing down the cloth.




Leave the strips in place between the four battens. Then cut the leathercloth 37¼ in across the width so that it doesn't interfere with the tongues but leave it about 1 in longer at top and bottom.


Spread white woodworking glue over the rough side of the leathercloth and lay it over the planed tambour surface. Lay a weighted piece of plywood on top and let the glue set. Then trim the leathercloth making the back edge flush and leaving along the front edge.

Remove the tape and rub wax on the tongues and in the grooves. Then with the cabinet upside down on the bench, slide the tambour into the grooves and a $\frac{1}{4} \times \frac{3}{8}$ in rabbet along the rub or stick, where the grooves may need widening out a little more.


Prepare the tambour stop F, cutting a $\frac{3}{16}$ in tongue at either end to ride in the grooves and a $\frac{1}{4} \times \frac{3}{8}$ in rabbet along the length to take the leathercloth and cover strip as shown. Shape the two handles P as shown. Cut a groove for each on either side of F and then glue the handle so that it extends $\frac{1}{4}$ in beyond the stop.




After you have worked on the tambour until it rides smoothly, ease the stop F into the grooves by bending it slightly until it goes in.



Then glue the extending leathercloth to the back of the rabbet covering it with a small strip screwed in place with six ½in no.4 screws.



Fix the lock to the cabinet, marking and chiselling out space for the body and drilling out for the keyhole. Set the corresponding plate into the underside of the tambour stop F, then test the lock mechanism.




Now round all the edges and sand with progressively finer paper until all surfaces are smooth.

Making the leg structure


A structure involving pieces which join at an angle should be set out on a full scale drawing, so that all the angles can be copied accurately.







First draw out the end frame full size on a piece of cardboard or plywood following the diagram. Then cut the four legs and two rails T to exact shape.


Use a sliding bevel set precisely against the full scale drawing to mark the angles to be cut. Mark and cut the mortises for the exposed tenons. Do these very carefully to prevent the wood from breaking out along the back.






After you try the tenons for fit, tapping in part of the way, mark and cut the bridle joints for the diagonal end rails T.






Start by marking the joints on the legs, again setting the sliding bevel against the drawing, and then cut them out as shown, first with a saw to the gauged lines and finally chiselling out the waste on either




side. Also cut a $\frac{1}{8} \times 1\frac{1}{2}$ in notch at the top of the four legs as shown.




The ends of the diagonal rails are marked in the same way; first with the sliding bevel, then with the marking gauge left at the same setting as was used for the legs.

Cut out the slot and then try the joints partway to make sure that they fit tightly.


Then shape all the pieces, clamping them in matched pairs in the vice. Use a Surform, a spokeshave or a rasp, but make sure to stop the curve






before the joints so that the joints will fit together. You can round the legs at the joint after assembly.


After sanding the pieces, assemble the end frames. Glue both together at the same time with paper between them.




Then assemble the structure by adding the cross rails. Before gluing the tenons into the mortises make two sawcuts in each tenon. Add glue to the joints, then tap them in place with a soft-faced hammer or a mallet.




Make up twelve small wedges about in long from a dark wood such as walnut or teak. Make them about in thick at the top. Tap in the wedges and then plane the tenon end flush. Sand well, rounding all the edges. Clamp the base assembly across with bar clamps, checking that it is square. Use a try square or two pointed strips to check that the diagonals are equal.





Final assembly

First lay the cabinet upside down on blankets placed on the bench. Then place the leg structure on it with the back leg \(\frac{1}{2} \)in from the back of the cabinet. Drill holes from the inside, then screw the legs to the sides A using two \(1\frac{1}{4} \)in no.6 screws per leg.



Finally attach the bottom G and the back H with ½in long no.6 screws, notching corners and trimming to fit if necessary.

Finishing

The final finish of a hardwood project like this depends entirely on the preparation of the wood. If the wood is beautifully sanded at each stage as directed in the instructions, it will take a finish much better.

This desk was finished with three coats of wax polish made up from a mixture of carnauba, beeswax and turpentine. Alternatively you can apply an oil finish such as teak oil which is hard and durable.

Whichever finish you use, it should be well rubbed in and carefully buffed for a really deep shine.

Taking time to produce a good looking finish is important when you have devoted so much effort to a project.

WORK BENCH


You can make most of the projects in this book on temporary work surfaces such as an old table or a door laid across two trestles, or even on the floor. But this 2 × 5ft workbench, 361in high, makes your work so much easier and more professional. It is the right height for comfortable working and it has a well and a tool rack along the back and a large shelf underneath to store tools and equipment while working. Most important of all, it is sturdy without having a lot of complicated joints. The most useful feature besides the rugged vice is the replaceable top designed for the work surface. The first two layers of 3in plywood are screwed down firmly, but the final in layer is just nailed on so that it can be replaced with the minimum of trouble when it gets worn and dirty.

Making the frame

CUTTING LIST 3×3 in 4 pieces 34 in long, for legs A $1\frac{1}{4} \times 4$ in 4 pieces 21 in long, for end rails B 3 pieces 465 in long, for rails C

The basic frame is quite simple. It consists of two end frames joined together with four long rails.

Start by making the two end frames. Each is composed of two legs A and two end rails B. Mark the slots or halving joints on the legs, using a scrap piece of $1\frac{1}{4} \times 4$ in to measure the width correctly. Cut the slots 3in deep with a saw and chisel. Then simply glue and screw the end rails into the slots with the 21in screws and chrome cup washers. It is



SHOPPING LIST

1 standard sheet, 3in thick plywood 18 × 60in, lin thick

about 12 × 18in, 4in thick

softwood $12ft \text{ of } 3 \times 3in$

> 20ft of 11 × 4in 5ft of 11 × 6in 12ft of 4 × 2in

hardware 2 no.12 countersunk steel screws, 21 in long for rail D

3 no.12 countersunk steel screws, 1in long for bench stop

48 no 10 countersunk steel screws, 21 in long

22 no.10 chrome cup washers


15 no.8 countersunk brass screws, 14in long

18 no.8 brass cup washers

10 finishing nails or brads, 14in long 30 finishing nails or brads, 3in long

woodworker's vice with carriage bolt fixings plus

1 Record bench stop clear polyurethane



Screw the three rails C to the legs A with the 21 in screws, locating them at the same height as the end rails B. Two are fixed at the back, top and bottom, and only one at the front bottom. Notice that all three of the

each end of the three rails C. Then

hold the rails C in position to drill

A

the legs.

the pilot holes through the rails into

long rails C are attached to the insides of the legs A.

important that the ends are square so do this work carefully.

Notice that the legs and rails have bevelled edges and ends as a decorative touch. This can be done with a block plane or router.

Next place the two ends on their sides as shown, either on a bench or on the floor. Drill two clearance holes for the no.10 screws 14in from



Preparing the top, shelf and back

CUTTING LIST

 $1\frac{1}{2} \times 6$ in

1 piece

54in long, for front rail D

 $\frac{1}{2} \times 2in$

2 pieces

62in long, for tool rack E

3 pieces

4in long, for tool rack spacers F

in plywood


1 piece 24 × 60in, for top G

1 piece 18 × 60in, for top H

1 piece $14\frac{3}{4} \times 48$ in, for shelf I

1 piece $20\frac{3}{4} \times 48$ in, for back J


Cut out the pieces and then attach first the back J and then the shelf I.



Screw each in place using three 1½in brass screws with cup washers at either end.

To make the top, glue and nail pieces G and H together with $1\frac{1}{4}$ in nails. Keep the front edges flush, leaving a 6in well at the back. The top will be screwed down permanently later, so the $1\frac{1}{4}$ in nails are just to hold the two pieces together until the glue sets.


The top will later be covered with a ¼in layer of plywood.



Mounting the vice and bench stop

After the top has been firmly glued together, attach the vice and bench stop to the underside. If you are right-handed, the bench stop should be located near the front left corner of the bench, and near the front right corner if you are left-handed. The vice is usually located on the left, although there is no definite rule about the location.


Temporarily place the top on the underframe and mark the locations for the vice and bench stop. Be careful to locate the bench stop away from the end rail, about 3in from the end should be about right. Trace the outline of the wood block which is part of the bench stop onto the top, then drill several holes within the marks and finally chisel out the rest of the wood to form a clean rectangular hole into which the bench stop fits.



Place the ¼in plywood piece on top with the edges lined up exactly then trace the hole for the bench stop on it from underneath and cut out this hole in the same way. Put aside the ¼in top until later.


Turn the 1\(\frac{1}{2}\)in thick top over and attach the bench stop to the underside with the three no.12 screws.

Before fixing the vice, cut a lin deep notch in the bench top, the exact width of the front plate of the vice. This way the vice will be recessed with the front plywood 'softening' in line with the front edge of the bench. Then lay one or two small pieces of ½in plywood under the vice to pack it up so that the top of the vice is flush with the top of the bench.




Then mark and drill the holes for the carriage bolts which secure the vice to the bench.

Counterbore the holes in the top surface so that the bolt heads will be flush with the top, then bolt down the vice. Also measure and cut to size two pieces of ½in plywood softening for the vice faces to prevent the metal jaws from marking the work. Fix the plywood pieces to the vice jaws with machine screws in the holes provided.





Before turning the top over, cut out the notch in the front rail D for the




vice. Work carefully, marking and cutting a little at a time until you get the fit just right. After cutting out the notch, it may be necessary to add a couple of 2½ in no.10 steel screws into the rail from underneath on each side of the notch to reinforce the rail at the weak points.

Turn the top right side up and lay it on the frame so that there is an equal overhang on each side and the back edge is flush with the legs. This will leave a generous overhang at the front to allow you to clamp work down to the top.

Secure the top by screwing two 2½in no.10 screws into each end rail B and three 1½in no.8 brass screws with cup washers through the well into the back rail C. The 2½in screws should be countersunk flush with the surface.







Add the front rail D. Counterbore the screw holes with a \(\frac{1}{2}\) in diameter drill bit and after fixing D into each leg with two 2\(\frac{1}{2}\) in screws, plug the holes with plugs cut from a waste piece of the same wood (page 214). Then screw down the front of the top to the rail D with four 2\(\frac{1}{2}\) in countersunk screws.

Finally nail down the removable $\frac{1}{4}$ in plywood top surface thereby hiding the screws and bolts of the permanent top surface. Space the $\frac{3}{4}$ in nails evenly over the surface, then punch them well below the surface and fill the holes with wood filler.

Fixing the tool rack



The final step before applying the finish to the bench is to attach the tool rack to the back. First glue and nail the $\frac{1}{2} \times 2$ in pieces together with the 4in long spacers placed in between the two strips at either end and in the middle. Clamp the pieces until the glue sets, then screw them to the $\frac{3}{4}$ in plywood edge at the back of the bench with six $2\frac{1}{2}$ in steel screws and cup washers. Trim off



both ends flush with the bench. To hold chisels, you may want to arrange dowel spacers at more frequent intervals.

Finishing the bench


Some woodworkers prefer their benches to be unfinished but, to make it easier to remove glue and paint from the surface, it is best to apply at least two coats of polyurethane particularly to the top surface. The plywood shelf and back can also be painted a dark colour as a contrast to the light wood tones of the rest of the bench.

When working on the bench, keep the top clear of nails and screws and scrape off dried glue so that it will not damage the pieces you are working on.

TOOL CABINET

Hand tools such as planes, hammers, saws and chisels should be kept organized in a wall-hung tool cabinet so that they are within reach and not cluttering up the surface of your workbench. Some woodworkers make their tool cabinet of solid hardwood with hand-cut dovetail joints, but this cabinet is for the beginner who wants to make a quick storage place for tools. It is made of plywood simply glued and nailed together. The door knobs are two small wooden balls painted red and screwed on from the back of the door. You can of course vary the storage facilities and size of the cabinet to suit your own needs; this one measues 24in × 32in.


Making the cabinet




First cut all the pieces accurately and squarely, using a table saw or a circular saw with a straight edge (page 208). If the pieces are exact, the cabinet will go together very easily. Before assembling the cabinet, sand all the plywood edges.

Assembly

To make the box, glue and nail together the four sides A and B. Use three lin nails per corner. It is best to hold the pieces in a vice while nailing. Then glue and nail the back I in place with ½in nails to make the box square. Glue and nail the ½in thick spacers K in place with equal spaces between them. Continue by attaching pieces L to the sides to support the three shelves A, which are nailed to the supports.








Before attaching the plate C which holds the dowel pegs, lay the box flat on the bench and place your tools in it so that you can mark their locations and decide where to fix dowel pegs. Mark and drill $\frac{3}{8}$ in diameter holes for the 2in long dowel pegs. After the pegs are glued in place, attach the plate to the box by gluing and screwing from the back, with four no.6 screws.

Make the two door boxes in the same way. Glue and nail the sides D and E together, then add the backs J and attach the shelves and plates. Notice the chisel and screwdriver rack. The two pieces H are separated by a $\frac{1}{2}$ in space to hold the blades of the tools, and the guard D covers the blades and sharp points of the tools.


Attach the doors with two lengths of continuous hinge. Then add the catches and mirror brackets on the top and screw on the red painted wooden knobs from the inside of the doors. Seal the whole cabinet with at least two coats of clear polyurethane.



Making the drawers

Assemble the small drawers by gluing and nailing together the sides

M and the front and back N. Then nail on the bottom O. Make three identical drawers in the same way. Cut out a finger hole as shown. To decorate the drawers, either paint them red or glue bright coloured plastic laminate to the fronts.




Hang the box on the wall of your workroom from the two mirror brackets which should be more than adequate to take the weight. If the cabinet will be filled with especially heavy tools like planes, screw a 1 × 1in softwood batten to the wall under the cabinet for additional support.

LIVING ROOM PROJECTS


Projects for the living room include several designs for



Table lamp



Convertible sofa





Plywood end grain coffee table




Dual height table



Oak corner cupboard



Sofa with storage



Veneer lampshade





Mirror top coffee table



TWO COFFEE TABLES

These two coffee table designs can be adapted to go well with any decor. They are similar and both are quite easy to make. The first table has a frame which involves halving joints. The top is 3ft square, consisting of oak parquet flooring simply glued to a chipboard base. The second table frame is just glued and nailed together, making construction even simpler. It too can be made with a parquet inset top but, as here, a completely different look can be achieved by using a mirror top and painting the table glossy black.

Parquet table

Parquet flooring is sold by the square yard, ready to be glued down. It is available in various hardwoods such as teak, oak or mahogany. Whichever you choose, try to match it to the table frame either by using the same wood or by staining pine to match. The frame consists of 1 × 3in and 1 × 2in sections with simple halving joints at each corner.

SHOPPING LIST

wood about 22ft of 1×3 in 7ft of 1×2 in

12ft of ½ × lin

36 × 36in chipboard, ½in thick 1sq yd of parquet flooring


hardware 20 no.8 countersunk steel screws, 1½in long

16 finishing nails or brads, 1in long

plus contact adhesive


wood filler clear polyurethane

Making the frame



piece. It is best to counterbore the hole, sinking the screw about ¼in deep and then plugging it.

Alternatively, use a matching wood filler to conceal the screw or use a decorative brass screw with a washer.



CUTTING LIST

 $1 \times 3in$

2 pieces 43in long, for rails A

2 pieces 42½in long, for rails B

4 pieces 18in long,

for legs

 $1 \times 2in$

4 pieces 18in long,

for legs

× lin


4 pieces 34in long,

for battens


As always, make sure to cut the pieces accurately and squarely. Then mark and cut the halving joints on the four rails A and B. The important dimension on both is the 36in between the joints, leaving just the right space for the chipboard and parquet top. Mark the joints with a try square and marking gauge and be sure to make the saw cuts inside the lines so the joints will be snug. Test each joint with a 1 × 3in scrap and trim it with a chisel if it's tight.

Before assembling the joints, glue and nail the $\frac{1}{2} \times 1$ in battens to the insides of the rails 1 in from the top edge. Notice on the diagram that the rails are in pairs with the slots facing , downwards on one pair A, and upwards on the second pair B.

Next, glue and screw the L-shaped legs together. Each leg is made up of one 1×3 in piece and one 1×2 in



Assemble the frame by slotting the halving joints together. At each corner, clamp rail A to the 1 × 3in part of the leg while you glue and screw it in place. Hide the screws under plugs or wood filler.




Making the top

Before dropping the chipboard in place on the battens, glue the parquet flooring to it using the same procedure as that used for gluing plastic laminates (page 46). Spread a thin layer of contact adhesive on both surfaces, let them dry and then carefully position the parquet, putting it down in four 18in sections.

Finally, drop the top onto the battens, trimming the edges with a plane if the fit proves to be too tight.


Then sand the frame and finish the entire table with at least three coats of clear polyurethane. The top looks best with a deep finish so give it even more coats to make it really lustrous.



Mirror top coffee-table

This 20 × 30in coffee table is easier to make than the parquet flooring design because it doesn't involve cutting halving joints at the corners, and the connections are just glued and nailed. The table top is made by simply laying a mirror onto the chipboard.

Start by gluing and nailing the Lshaped legs together as for the parquet table. Use about four 1½in nails per leg. Then set the nails and fill the holes with a matching filler.



Making the frame

CUTTING LIST

 $1 \times 3in$

2 pieces 18 in long, for rails

2 pieces 30in long, for rails

8 pieces 18in long, for legs

l v lin

2 pieces 20in long

2 pieces 12in long

softwood about 22ft of 1 × 3in 6ft of ½ × 1in

chipboard 20 × 30in, ½in thick (cut to exact size after the frame is complete)

hardware about 40 finishing nails or brads, 1½in long 20 finishing nails or brads, 1in long for battens

plus mirror, ½ or ½in thick, with rounded edges (cut to exact size after frame is complete)


wood filler / wood primer

undercoat for black paint


black glossy paint

Glue and nail the ½ × 1 in battens with 1 in nails, along the insides of the four rails, ½ in down from the top edge. These will support both the chipboard and the mirror which lies on top. Centre the battens on each of the four rails.

Allow the glue to set on all the pieces, then glue and nail one leg to each end of the long rails, using about three 1½in nails per joint. Make sure the rail and leg are square by checking with a try square.




Join these two frames together with the short rails, again gluing and nailing the joints.



Making the top

Measure the exact inside dimensions between the rails and subtract about hin for clearance. Then cut the chipboard precisely to that size. Make sure to cut it square so that it will force the frame square as you drop it in place on the battens. You may want to bevel the chipboard edges slighlty towards the bottom to make it easier to drop it in place. Plane off the edges if necessary to make it fit right. Then subtract about in from the chipboard dimensions and have a glass supplier make up a piece of mirror with rounded edges to this exact size.



Finishing the table

Carefully set and fill all the nails so that they will not show under the paint, then sand the frame until it is smooth. Round the edges slightly with the sandpaper, particularly along the top edges of the rails. Apply first a primer then an

undercoat. Then apply the first coat of glossy black paint. Sand the surface with very fine paper (240 grit) between each coat so that the final surface will be perfectly smooth. Be sure to brush off the sanding dust before applying the next coat.

When the final coat of paint is dry,

simply place the chipboard and then the mirror onto the battens and the table is ready for use. If you would rather use glass instead of a mirror and chipboard, it will be necessary to provide a more elegant support for the top such as a few small metal brackets rather than the nailed battens used with the mirror.

SOFA WITH STORAGE

This design is really three pieces of furniture in one. It is a comfortable three-seater sofa, and it is long enough to serve very well as a spare single bed. There is also a

useful storage chest underneath with plenty of room for anything from blankets to toys.

It is truly easy to make. Once the pieces are cut out, the assembly shouldn't take more than an afternoon. The construction is straightforward as the sides simply screw into the back and the front, with fibre wall plugs being used in the plywood to give a better grip.


This sofa was made completely out of birch plywood which is an attractive wood that only needs polyurethane varnish to give it a beautiful clear finish. Notice that the ends are made of a triple thickness of plywood. The three layers glued together make an attractive decorative feature out of the thin layers of veneer which make up the plywood.

To make the sofa even more




economical you can just as easily use a in chipboard. Paint the finished sofa a bright, glossy colour with perhaps an edging painted a contrasting colour nailed on. Refer to the instructions for details on producing a really perfect finish on chipboard or inexpensive grade plywood.

Another possibility is to turn the project into an upholstered sofa simply by covering the chipboard with a suitable upholstery fabric. To make it softer, first glue 1in foam sheet to the chipboard before wrapping the fabric around it. Secure the fabric with fabric adhesive and upholstery tacks. For instructions to make cushions, see the convertible sofa on page 160.



SHOPPING LIST	
birch plywood	2 standard sheets, $\frac{3}{4}$ in thick 2 pieces, $28\frac{1}{2} \times 35\frac{7}{8}$ in, $\frac{3}{2}$ in thick for seat $28\frac{1}{2} \times 71\frac{7}{8}$ in, $\frac{1}{4}$ in thick for bottom
softwood	about 28ft of 1 × 1in
hardware	10 no.12 countersunk steel screws, 3in long 10 no.8 countersunk steel screws, 1½in long 10 no.12 fibre wall plugs, 1½in long about 30 finishing nails or brads, 1½in long
plus	clear polyurethane or paint

placed near the bottom of the sofa end will be hidden later under the seat.





Making the sofa ends


CUTTING LIST

\$\frac{3}{4}\text{in plywood} \\
6 \text{pieces} \\
23\frac{3}{4} \times 31\frac{3}{4}\times 1, for ends A

After cutting up the pieces, make the two ends by gluing three pieces
A together for each end. The easiest way to do this is to select carefully the best face and lay it down on the bench or floor with a blanket underneath to protect it from being marked. Then spread a thin, even








layer of glue over the plywood and lay the next piece on top. The pieces may not be identical so keep two sides, for example the bottom and left-hand edges, lined up and trim the others later.


To help locate the plywood pieces, put in three or four nails. Then apply glue to the second plywood piece, add the last piece and nail it in place keeping the same edges flush throughout. These few locating nails

Repeat this procedure to make the other end. Then lay the two ends on top of each other, place heavy weights on top and leave them until the glue sets. Make sure not to put any glue between the two ends; wipe over the two surfaces to ensure that none has accidentally been spilled. Also wipe away any excess glue that oozes out between the layers of plywood. If you have a few clamps, it is also a good idea to clamp the edges to make sure that the glue bonds firmly and evenly.




After the glue has set, plane off all the edges to make them smooth and continued

even. A small block plane works very well on plywood end grain. Also, round the corners with a file.



Next mark and drill the five holes on each end for the screws. Use wood plugs to hide the screws. First drill in diameter holes about in deep to take the wood plugs, then drill straight through with a in diameter drill bit. Keep in mind that one end is for the left and the other for the right-hand side of the sofa.



It is important to drill these holes fairly straight so that the screws will go straight into the ends of the front and back pieces.

Assembling the sofa

To assemble the four sides you will need quite a bit of floor space and someone to help you hold the pieces while you work. To make the assembly easier, nail or clamp two pieces of 1 × 1in to the inside faces of each end, as shown. Leave the nail heads exposed for easy removal later, or if you don't want to leave marks in the plywood clamp the


Preparing the front and back

CUTTING LIST


1 piece 13 × 72in, for front B


1 piece 23½ × 72in, for back C

1 × lin softwood 4 pieces 7lin long




The lift-up seat and the bottor simply rest on battens which a attached to the insides of the f and the back C. Mark the local the battens, measuring from the bottom edge, then glue and na in place. Reinforce the top bat which will hold the seat, with 1¼ in long no.8 screws per batter.






1 × 1in pieces to the ends. Then nail the front A and the back B to these battens from the inside to hold them temporarily in place.




With all four pieces held together in this way, drill straight through the holes into the ends of the front and




back with the same $\frac{1}{4}$ in diamet bit. The drill bit should penetr about $1\frac{1}{2}$ in into the ends.

Now push the fibre wall plugs the holes. Make sure to push to the ends of the hole. Then inse 3in screws and give them a light with a hammer before screwin tight.



Fit a wood plug into the sin ho hide the screw. These can be n from two pieces of dowel as a







decorative feature or simply cut with a plug cutter to be glued flush with the surface.

Another interesting possibility is to attach the sides to the front and back using threaded dowels made with a special tool called a screwbox and tap, described on page 205. The screwbox makes threads on dowels ½ or ¾in diameter and the tap makes matching threaded holes in wood to take the dowel. You could, for example, glue the end of the threaded dowel into a block of wood cut into a hexagonal shape to look like a bolt head.

Before placing the seat and bottom on the battens, drill four finger holes about 1 in diameter in the bottom piece, one near each corner. Also drill two holes near the front edge of each of the seats as finger holes to make it easier to lift up to get into the storage compartment.



Now lay the bottom piece onto the lower battens. Then lay the two seat pieces on the top battens. The seat can just rest on the battens but, if you wish, you can attach butt hinges along the back edges to make it easier to open and close the storage compartment.



Finishing the sofa

For a clear finish on birch plywood, apply two or three coats of polyurethane to the well-sanded plywood. When sanding, pay particular attention to the thick edges of the two ends. It is especially nice when exposed end grain like this is very smooth to the touch, so, sand the ends first with rough, then medium and finally with very fine sandpaper.


To make a sofa with a darker finish, the birch plywood can be stained in a wood tone such as mahogany or oak before the polyurethane is applied. If you used chipboard or an inexpensive grade of plywood, apply a fine layer of filler overall to fill the grain and allow it to dry. Then sand smooth and apply two coats of paint over a sealer. This will result in a really smooth and professional finish to even the roughest boards.

Making the cushions

You can easily make soft cushions such as these filled with kapok or less expensive foam chips. Make each seat cushion $24 \times 28\frac{1}{2} \times 5$ in thick and the back cushions $24 \times 10 \times 5$ in thick.

The cushions can be made with inexpensive firm cotton fabric, machine stitched around three sides with one end left open for stuffing. Before filling the pillows, turn them to the right side and then fill with foam chips or kapok making the cushion firm but not overfull. Close the opening by oversewing by hand.

Use furnishing fabric to suit your decor when making the cushion covers. These have a zipper along the back seam so that they can be removed for washing or dry cleaning.



DUAL **HEIGHT TABLE**

In small city apartments there often isn't enough space for both a dining table and a coffee table. This table is designed to serve both functions. It takes only an instant to convert this handsome design from a coffee table with a general shelf space underneath into a dining table of full height which can seat four people

comfortably. All you have to do is remove the top, stand the under frame upright and replace the top, locating the under frame against battens screwed to the underside of the table top.

The table is basically very simple in design and construction, but for its dual role to work successfully it must be accurately made. Drilling precise holes in the large dowels is quite difficult without a drill stand so, if possible, buy or borrow one for this job. Alternatively use 2 × 2in softwood for the legs instead of dowels. These are easier to drill accurately since they will lie flat on the bench.

Making the frame

Before making the frame, prepare the in top and the in plywood shelf by sanding them and staining both sides blue or any other bright colour.

CUTTING LIST 13in dowel

4 pieces 18in long, legs A lin dowel

4 pieces 25 in long, struts B

2 pieces 35in long, surround C $1\frac{1}{2} \times 1\frac{1}{2}$ in

2 pieces 18in long, holding jig

The first step is the most difficult. The two holes in the large dowels A

SHOPPING LIST	
birch	32 × 45in, ∄in thick for top
plywood	24×36 in, $\frac{1}{2}$ in thick for shelf
	(this piece must be square and accurate)
	about 6 × 18in,
	½ or ¾in thick for holding jig
dowel	32ft of 1in diameter
	7ft of 1∄in diameter for legs (or use 2 × 2in softwood)
softwood	17ft of $1\frac{1}{2} \times 1\frac{1}{2}$ in
hardware	18 no.10 countersunk steel screws, 13in long
	6 no.8 countersunk brass screws, 2in long
	8 no.8 countersunk brass screws, 1½ in long
	14 no.8 brass screw cup washers
	20 finishing nails or brads, 1½in long

must be drilled accurately so that they are parallel and so the frame will be square when it is put together.


blue stain

clear polyurethane


plus

To make it easier, make up a holder out of a piece of plywood, about 6×18 in and two pieces of $1\frac{1}{2}\times1\frac{1}{2}$ in batten about 18 in long. Glue and nail the first batten to the plywood then use one of the legs A as a spacer to nail the second batten.


For each leg A, mark the centre of the dowel, then mark the hole




centres $\frac{3}{4}$ in on either side of the centre line so that they are $1\frac{1}{2}$ in apart. Centre punch both holes and with the dowel in the holder, drill the two lin diameter holes. Set the depth stop so that the holes are exactly $\frac{7}{8}$ in deep. Drill two holes in each of the four legs A in the same way.




Make two end frames by gluing a pair of struts B, to a pair of legs A. If they are loose, wrap paper around the ends to ensure that it is a tight fit. Make sure that the two legs are parallel by measuring the distance






between them at both ends, and also make sure the struts are as far as they will go into their holes.

Now mark and drill another lin diameter hole, §in deep into each leg.




These should be located exactly in the centre as shown. Again, use the drill stand to ensure that the drilling is accurate and square.

Put one end frame on the floor and glue the two lin dowels C into the drilled holes. Then, before sliding the stained ½in plywood shelf in place, make a cut-out in each corner with a coping saw.



Drop the shelf in place between the two struts and glue the top end frame to the two dowels C. Before the glue sets, screw the plywood shelf in place with three 2in long no.8 brass screws and screw cup washers through the struts B at each end, and four 1½in long no.8 brass screws and screw cup washers through the two dowels C.



Making the top

CUTTING LIST

lin dowel

2 pieces 48in long D

2 pieces 36in long E

1½ × 1½in battens

2 pieces 27in long F


2 pieces 39½in long G


4 pieces 4in long H

Lay the 3in top face down on a blanket so that the surface will not be scratched while you are working with it. Glue and screw one short batten F 23in in from one end with an equal space on either side, using three 13in screws. Then stand the frame on the plywood with two of the legs A butting against the batten. To locate the other three battens, mark around the other pair of legs, then

glue and screw the other battens in place so that the battens hold the four legs in a rectangle as shown.


Turn the frame over so that the legs now lie on the plywood against the battens. Measure in from





both edges to make sure the dowels are located centrally in the frame. Then mark the locations for the four blocks H, which when screwed down will serve to locate the legs when the table is used at dining height.

Now stand the table up with the top in place and attach the lin dowel edging D and E to the top, mitring the corners carefully. Glue and nail the edging to the plywood edge with the 1\frac{1}{2}in nails, punching them below the surface.



Finishing the table

Fill the holes left by the nails around the edging, using light wood filler. Be sure to let the filler dry completely and then sand the edges smooth. Apply two coats of clear polyurethane over the whole of the table—the blue-stained surfaces as well as the unfinished dowels.

Applying clear polyurethane on top of a stained surface gives a particularly lustrous final finish. Make the final coat of polyurethane matt if you don't want the surface to be too shiny.

OAK CORNER CUPBOARD

The corner cupboard is a wonderful piece of furniture which provides storage and display space without taking up too much room. As here, the door can have a glass panel to show off china or silver or it can be of solid wood, to enclose a cocktail cabinet for example.

This cupboard is made from oak veneered chipboard with matching iron-on edging. It may be necessary to go to a large supplier to find oak chipboard, but if you have trouble buying it, you can use oak veneered shelving panels which are widely available in several widths. Remember to buy sheets with oak veneer on both faces. Sheets are often sold with the 'good' face in oak and a balancer of mahogany on the other side.

Alternatively you can use a good grade of plywood to make the cupboard and stain it oak or another suitable shade.

Making the cupboard

CUTTING LIST oak veneered chipboard

I piece 24 × 24in, for top A and base B 1 piece 24 × 24in, for shelves C 1 piece $20 \times 31 \frac{1}{2}$ in, for back D t piece 191 × 31 lin, for back E 2 pieces $3\frac{1}{2} \times 31\frac{1}{2}$ in, for side panels F 2 pieces 24×32 in, for door sides G (to be trimmed) 2 pieces 2\(\frac{1}{2}\) × 24in, for door stiles H (to be trimmed)

Follow the cutting list in marking out the pieces. Remember when you are cutting the pieces first to score the veneer along the cutting line to prevent it from breaking out when sawing. Fit a new blade in a trimming knife and score the veneer in two or three light strokes along a metal straight edge. Then saw along the side of the scored line. If you use a hand saw or a sabre saw, it is best to saw about 16 in away from the line and then finish off by planing.

SHOPPING LIST

wood

I standard sheet, In thick chipboard, oak veneered on both sides about 20ft of 1 x gin oak battens (or pine stained to match the oak)

hardware


about 50 no.8 countersunk steel screws, 14in long (or use special chipboard screws with plastic plugs which hold better) 30 finishing nails or brads, \in long 30in brass continuous hinge with 3in screws small catch with screws antique finish handle with matching lin screws 2 brass mirror brackets with §in screws

for hanging cupboard on wall


plus

3ft of \$in diameter dowel cut into 8 pieces, 2in long and 12 pieces, 1 in long for pegs six 8ft lengths of oak veneer iron-on edging, 3in wide piece of glass cut to size to fit finished door

clear polyurethane




The best procedure to follow is to iron the veneer edging onto each piece in turn before you join the pieces together, omitting any edges which will be hidden.





Start by joining the two backs D and E. Glue and screw them together using the 11 in long screws.


Prepare the two side panels F by sawing or planing off one long side so that the edge forms a 45° angle. To do this by hand, draw the 45° angle on each end, then draw the line along the side as a guide line for planing.




Since you are dealing with triangular-shaped pieces it is rather difficult to cut the shapes absolutely correctly. To make it easier to get the top and bottom and the two shelves identical, make a template out of cardboard. Place the joined back pieces D and E on a piece of cardboard or paper and use a try square to make sure they form a 90 angle. Hold them firmly in place while you trace along the inside edges (lines X) on the cardboard. Then hold the side panels F in place











The top and bottom pieces A and B are larger than the shelves C so first cut out the template along lines X and Z. Then use this template to trace two outlines on the 24×24 in piece for the top A and base B.


Cut the template along line Y and trace this shape on the other 24 × 24in piece for the two shelves C.

All this template cutting and tracing sounds complicated but it is really the simplest way to get the shapes right. Triangular pieces are always tricky to cut so by getting the shapes directly from the cabinet you shouldn't go wrong.


Score the veneer along the pencilled cutting lines and then cut out the four pieces. To make the two pairs identical, hold them in pairs in a vice and plane the edges until both pieces








are the same. The top and base are easy to locate since they are flush with the sides but, before attaching the shelves, measure and mark the spaces along the inside of the backs D and E using a try square. Draw lines ‡in apart to give an exact location for the shelves.




Glue and screw first the top and bottom and then the two shelves in place. Notice the two C clamps which hold the shelf in position.



It is useful to drill the screw clearance holes for the shelves from the inside through the backs before the shelves are added so that you can centre the holes between the



lines. To finish the assembly, attach the side panels F by dowel jointing them to the main frame with six 1in long dowels per side (page 232).




Making the door

Measure the opening and make the door to fit it, subtracting $\frac{1}{8}$ in along the width for the hinge and $\frac{1}{16}$ in along the height for clearance.


Then follow these dimensions to cut

the pieces G and H to the exact size before dowel jointing them with $\frac{3}{8}$ in diameter dowels, 2in long to make the door frame. The door on this cupboard was mitred at the corners and then dowel jointed but this is much more difficult than a straight butt joint.

Before fitting the door, glue and nail $\frac{1}{4} \times \frac{3}{8}$ in stripping along the back edge of the door opening so that the strip just overhangs.



Screw the continuous hinge to the door. Then hang the door in place by screwing the other side of the hinge to the frame.



Finally buy a piece of glass to fit inside this frame, and after finishing, install the glass, holding it in place with $\frac{1}{4} \times \frac{3}{8}$ in stripping.

Finishing the cupboard

Finish the cupboard by leaving it natural or by giving it a coat of oak stain to make it look antique. In either case, seal the surface with two or three coats of clear polyurethane. Finally add the door pull and the two mirror brackets, and hang the cupboard in a corner, fixing a batten to the wall underneath for additional support if it is to hold a heavy weight like china, bottles or metal ornaments.

FLOOR LAMP

This elegant floor lamp, similar in design to the table lamp, consists simply of six dowels glued together and screwed to a plywood base. The thin electrical wire just fits into the

space between the three large dowels. The larger the dowel you use, the easier it will be to pull the wire through the hole. Use a minimum diameter of 1½ in dowel.



SHOPPING LIST

wood three 4ft lengths of $1\frac{1}{4}$ in diameter dowel three 4ft lengths of $\frac{1}{4}$ in diameter dowel

12 × 12in piece of plywood, 3in thick

hardware 3 no.10 countersunk steel screws, 21/4 in long

3 no.10 fibre wall plugs, 1 in long

plus 10ft of fine electrical wire


bulb holder and small switch

contact adhesive / dark brown matt paint

To make the floor lamp


Glue the three large dowels together, tying them tightly with tape or string until the glue sets. Be careful not to use too much glue as it may block the central hole through which the electric wire will run.

Cut out the base from $\frac{3}{4}$ in plywood. You can cut the base into a shape as shown or, if you prefer, just leave the shape square and round the corners slightly with a rasp or Surform.



Drill a ½in diameter hole in the centre to allow the electric wire to be threaded through.

Hold the dowels in a vice and pin the base onto them, then drill three $\frac{3}{16}$ in diameter holes through the base, one into the end of each dowel. Drill deep enough so that you can insert the $1\frac{1}{2}$ in long fibre wall plugs into the dowels, then screw the no.10 screws in tightly.



Paint the dowels and the base with two coats of dark, matt brown paint. Then, when the paint is dry, glue the natural coloured ¼in diameter dowels in place using contact adhesive.

Cut three small pieces from the waste plywood and glue them under the base to serve as feet. They don't have to be perfect circles; three small disks will give the base stability and provide a space for the wire which has to run from the lamp to an electric socket.

Finally attach the electric fittings. First pass the wire through the centre of the dowels, using a piece of sturdy wire to pull it through if necessary. Then connect the wires and screw the bulb holder to the tops of the dowels, attach the switch and connect the plug.






TABLE LAMP

This lamp is made from black walnut and maple. If you don't have access to these planed hardwoods, use a softwood, preferably pine, and colour all but the thin strips with several coats of a dark stain.


Start by cutting the $\frac{1}{4} \times 2in$ section into two 4ft 6in lengths. Then glue these to the length of $1 \times 2in$, one on either side. It helps to nail them in a few places to keep them from slipping while you clamp them.







After the glue has set, cut the resulting section into four pieces each exactly 12in long A. Then glue one of these between two pieces of 2 × 2in. Make two of these sandwich constructions B. Finally glue the other two pieces A between these two B pieces, nailing and then clamping them together.



Trim the ends square, plane and sand the lamp base and, before connecting the wiring, finish with polyurethane, Cut a groove in the


SHOPPING LIST

plus

wood 4 pieces 2×2 in dark wood, 12in long 4ft 6in of 1×2 in dark wood 9ft of $\frac{1}{4} \times 2$ in light wood

hardware about 30 finishing nails or brads, ‡in long about 10 finishing nails or brads, 1½in long

> 8ft of electrical wire bulb holder and small switch lampshade clear polyurethane piece of felt for base



bottom as a channel for the wire. Glue on a piece of felt and finally fit the bulb and shade.

CONVERTIBLE SOFA


This delightful sofa design is just nailed together. It is designed to be a generous three seater that you can turn into a full sized double bed in seconds. You simply pull out the front panel and spread out the seat cushion which unfolds to become a 54in wide mattress. The main frame is made up of five flat panels, the two ends, front and back and the slat unit which supports the mattress. If you don't want to spend the time cutting and nailing all the diagonal slats – there are about 70 of them – you can make the four sides out of plywood or even chipboard, like the sofa on page 148. You can also simplify the job slightly by positioning the slats vertically or horizontally rather than diagonally. You should be able to make this good looking and versatile sofa over a single weekend.

The doubled-over mattress is made from two pieces of 3in thick foam. The five back cushions should be filled with foam chips, kapok or feathers so that they will be rounded and soften the look of the sofa. Check the telephone book for specialist firms which make cushions to order. Choose a hard wearing furnishing fabric for the cushion covers. Bright basic colours like green, orange and red contrast attractively with the natural shade of the wood, but


your choice will of course depend on your decorating scheme.

of the frames. The slats are attached at a 45° angle; however, the angle is not crucial so long as you attach all the slats parallel to each other and evenly spaced out across the frame.


Start by measuring one of the centre diagonal slats. Mark it so that it will overhang the frame by about 2in at each end. Then cut it to length and glue and nail it to the frame using two 1½in nails per end, nailed from the frame side. Use a try square to check that the frame is kept square as you glue and nail the first slat in place. Notice that you nail through the 1 × 2in frame into the slat, so that the nail heads will be hidden later by the cushions.



Continue with the rest of the slats, measuring and cutting them to length and then gluing and nailing them in position. Leave a narrow, evenly spaced gap between the slats.



Making the sofa ends



CUTTING LIST 1 × 2in


4 pieces 34in long, A for end frames 4 pieces 23½in long, B for end frames


³/₄ × 3in about 75ft cut into slats as required C

3 × 2in

4 pieces 38in long, for top and bottom edging strips D (to be trimmed) 4 pieces 28in long, for upright edging strips E (to be trimmed)

Start by making the two $1 \times 2in$ frames for the ends. Use two A and two B pieces for each frame, connecting the corners by nailing in two corrugated fasteners at each





corner (page 224). The frame does not have to be very rigid at this point as the slats, once they have been attached, will hold if firmly together.

The next step is to cut the $\frac{3}{4} \times 3$ in slats C and nail them onto each one

SHOPPING LIST

softwood 7ft of 1×6 in / about 160ft of 1×2 in 175ft of $\frac{3}{4} \times 3$ in / 55 ft of $\frac{3}{4} \times 2$ in / 8ft of $\frac{3}{4} \times 1$ in 3ft of $\frac{1}{4}$ in wide stripping for spacer


hardware 4 no.10 countersunk steel screws, 1½in long
12 no.10 countersunk steel screws, 1½in long
6 no.10 countersunk brass screws, 2½in long
about 400 finishing nails or brads, 1½in long
about 75 oval wire nails, 1½in long
32 corrugated fasteners, 2in long

32 corrugated fasteners, 2in long 3 metal L-brackets with ½in screws

zippers or snaps for cushion covers

plus wood filler / clear polyurethane 2 pieces medium density foam, 27 × 75in, for seat/mattress, 3in thick filling for five pillows, three 18 × 25in


tilling for five pillows, three 18 × 25in and two 12 × 25in, all 6in thick firm cotton fabric for pillow linings about 10yds upholstery fabric, 54in wide for cushion/mattress covers




Use a ½in wide batten 3ft long as a spacer between the slats to ensure that they are an even distance apart. If the amount of space left over for the last few slats is a little larger, space the slats out evenly by eye.

After you have filled the whole side frame, including the small corner pieces, trim the slats flush with the frame using a circular or panel saw.

It is best first to clamp a straight board on top of the frame as a guide




for the saw so that you make a perfectly straight cut. If you use a circular saw, it will be essential to clamp a straight edge to the top as a guide for the saw, as shown.



After trimming the edges, it will probably be necessary to run over them with a plane to make them even and smooth. Next glue and nail the $\frac{3}{4} \times 2$ in edging to all four sides of the frame. Start by trimming the two upright edging strips E to the exact height of the finished end panel. Glue and nail these in place, then trim the two long pieces D to length and glue and nail them to the top and bottom.

Use five or six 1¼ in long nails for each edge. Set the heads with a nail punch and fill the holes carefully before sanding the surface smooth. You can round off the edges of the frame slightly with sandpaper or a file or bevel the edges with a block plane to make the sofa arms smooth to the touch.



Making the front and back of the sofa

CUTTING LIST

1 × 2in

2 pieces 74in long F,
for back frame

2 pieces 73 in long G,
for front frame

2 pieces 23 in long H,
for back frame


2 pieces 6 in long I,
for front frame


3 × 3in about 100ft cut into slats as required J

× 2in
3 pieces 76in long K
(to be trimmed)
2 pieces 28in long L
(to be trimmed)
2 pieces 13in long M
(to be trimmed)
× 1in

1 piece 76in long N (to be trimmed)

Make the front and back panels of the sofa in exactly the same way as the ends, by first joining the large 27×75 in back frame with two F and two H, 1×2 in pieces and then the small $10\frac{1}{4} \times 74\frac{3}{4}$ in front frame with two G and two I, 1×2 in pieces. Notice that the front frame is $\frac{1}{4}$ in shorter than the back so that it can be moved in and out easily when the sofa is being converted to a bed.





Cut and attach the diagonal slats J, using a batten as a spacer to arrange the slats evenly on the framework as before. Also attach the $\frac{3}{4} \times 2$ in edging strips. Notice that the top edge of the small front frame is a $\frac{3}{4} \times 1$ in N piece and not the usual $\frac{3}{4} \times 2$ in. This is to allow the bed slats to sit on top of the frame behind the narrow $\frac{3}{4} \times 1$ in edging.

You will need a lot of space for the next stage of the project so, before continuing, clear a large work area. Referring to the drawings below, temporarily assemble the back and two ends by clamping or nailing them together.

Attaching the bearers for the slat bottom

CUTTING LIST

1 × 6in

1 piece 76¾in long O

1 × 2i'n


1 piece 70½in long P

(to be trimmed)

2 pieces 32in long Q

(to be trimmed)

Remove the front panel then start by screwing the 1×6 in piece O along the front so that the top edge is







screw the 1 × 2in slat bearers P and Q

to the two sides and back. These will

support the bottom slat structure.

Screw the long piece P to the back

diagonal slats with five 11 in no.10


supports Q 91 in off the floor with

screws so that the top edge is exactly

101 in from the floor. Attach the end

exactly 101 in from the floor. Secure it to the inside edge of the end frame uprights B with two 11 in no.10 screws per end. Notice that a short piece of $\frac{3}{4} \times 1$ in pinned in place beneath the 1 × 6in helps to position and support it.

Trim to length and then glue and




Making the slat base

CUTTING LIST $1 \times 2in$ 1 piece 761 in long R 16 pieces 32in long S 17 pieces 25in long T


Start by gluing and nailing slats T to piece R. Position the slats by using a scrap of $\frac{3}{4} \times 3$ in as a spacer so that the gap between each slat is about 23in wide.

Place the first and last slats 1in from the ends of R and attach them with the 11 in oval wire nails - spread the glue then use one nail in each end. You should now have seventeen pieces of 1 × 2in attached at one end to piece R. The other ends of the slats will be attached next.



Then gently carry this assembly over to the sofa and position it so that the ends of the back piece R rest on the end supports Q, which have been screwed to the sides.

Place the short front panel of the sofa so that the other end of the seventeen slats T rests on the 1 × 2in piece G behind the $\frac{3}{4} \times 1$ in strip nailed on earlier.



The slat assembly should now be positioned so that it can be pulled out easily. It may be necessary to reposition the outside slats slightly if they rub on the sides as you pull out the front.

Now screw three metal brackets underneath, one at each end and one in the centre. Screw them to the slats T and to the frame G as shown earlier to keep the front rigidly attached to the slats.


This is the first stage in making the

slatted base which forms the convertible part of the sofa. Notice that by lifting the front slightly you can slide the slatted base structure in and out quite easily.

Pull the front out to get inside the sofa and then glue and nail the longer slats S in place between the short slats T, using one 1½ in nail per end. Glue and nail the back ends to the bearer P and the front ends to the 1 × 6in piece O. Space them out so that they are parallel to the short slats T, with equal spaces between them to allow the short slats to move smoothly back and forth without rubbing.


Assembling and finishing the sofa

To fix the sofa ends rigidly to the back, drill three holes through the end frames into each end of the back frame and insert three 2½in no.10 brass screws in each end.



Sand off all marks and scratches and set the nail heads. Then carefully fill all the nail holes with wood filler, sanding them smooth when dry.

You can leave the wood unfinished, or, for a more durable surface which is easier to wipe clean, apply a couple of coats of thinned clear polyurethane finishing with a matt coat. Alternatively you can paint the wood any colour after first applying a coat of sealer, or you could stain the sofa in a darker wood tone to match your other furniture.



Making the cushions

The sofa seat unfolds to become the mattress and is made up of two layers of 3in thick foam, so the seat is 6in thick and measures 27 × 75in. When it is folded out, it becomes a standard double sized mattress 3in thick and measuring 54 × 75in.

A specialist store is probably the best place to buy the foam as it will have the facilities for cutting the foam exactly to the required size. You can usually find a supplier in the telephone book.

The sofa has five back cushions: two 12 × 25in cushions, 6in thick for the sides and three 18 × 25in cushions, 6in thick for the back. Soft, round, well-filled cushions look especially attractive because of the way they contrast with the simple, straight


lines of the ends of the sofa. So instead of using foam blocks for the cushions, sew a cotton lining for each cushion and fill it either with foam chips or with kapok.


Alternatively, to make the sofa really luxurious, you can use feather filled cushions. You will probably have to have cushions like these made up to size by a specialist supplier.

The cushion covers should be fastened with a zipper, buttons or snaps along one edge for easy removal when you want to clean them. You could also use decorative piping along the edges of the cushion covers as an attractive contrast with the main fabric, particularly if you decide to use unpatterned fabric for the cushions.

The pieces of foam used for the

seat/mattress do not need a lining.
Just make up two large cushion
covers to size and connect them
along the long front edge so that you
can unfold the double thickness
to convert the seat into a mattress.





PLYWOOD END GRAIN COFFEE TABLES

The effect of cutting plywood into strips and then gluing all the strips together on edge is stunning. It is hard to believe that it is really plywood. These instructions are for a luxurious coffee table 4ft square,


but the instructions can just as easily be adapted to make a rectangular coffee table measuring 2 × 4ft. The alternative table shown here has turned beech legs attached with metal brackets.

Preparing the plywood

Cutting plywood strips accurately should ideally be done on a table saw (page 210). It can also be done with a portable circular saw with a rip fence (page 208), using a fine blade.

CUTTING LIST

in plywood
64 strips 2 × 48in A
8 strips 5 × 48in, for legs B
(to be divided)
4 strips 3 × 46in, for rails C



Making the top

The 64 strips A have to be glued together to make up the top. It is best to divide the work up into eight sections each containing eight strips, which makes it easier to handle.

Apply glue to each strip in turn and spread it with a brush in a thin even layer. Then nail the strip to its neighbour with six nails, keeping the edges lined up. Glue and nail one strip at a time. Finish one eight piece section, put it aside and begin on the next section.

Be very careful to line up the top and edges of the strips exactly. The more even you make the surface at this stage, the less sanding you will have to do later.


If possible, use clamps to hold the eight pieces together until the glue sets. Clamping isn't absolutely essential however, as the nails should hold the sections firmly enough.

Remember to clean off the excess




glue with a damp rag before it sets. After the glue has set, lightly plane off the surface of each 6in section.

After planing off all eight sections, glue them together to make the table top. Use bar clamps, again making sure that the top edges line up.




Making the legs and rails

Cut the eight 5in strips B into 32 lengths, each 11\frac{3}{4}in long. Use eight of these pieces per leg. Glue and nail as for the top, but remember not to nail the last piece so that no nail heads will show on the outside. Instead, clamp the last piece on to hold it until the glue sets. After the glue has set, plane and sand until the legs are smooth.



The rails C are quite easy to make. Simply notch the four identical pieces as shown so that they slot together snugly. Mark out the width of each notch using a scrap of plywood. Saw on the waste side of the line and then chisel out the waste to the marked line.





birch plywood	2 standard sheets. 3in thick
hardware	16 no.10 countersunk steel screws, 2in long 12 no.8 round head steel screws, 1in long 12 no.8 fibre wall plugs, 1in long 12 metal shrinkage brackets 24 no.8 round head screws, ½in long for brackets about 400 finishing nails or brads, 1½in long
plus	wood filler clear polyurethane


Assembling the table

First trim the edges of the top with a circular saw then round the edges and corners with a file, sabre saw or router. Make up the leg and rail assembly. Slot the rails together, then screw them to the legs with the 2in screws, using two per rail end.

Screw the metal shrinkage brackets to the rails, three per rail, with two \{\}in screws per bracket.

Finally, place the top upside down on the bench or floor putting a blanket underneath to protect the surface and attach the rails and legs with the lin screws.

Since the screws don't hold well in the end grain of the plywood, first fit a fibre wall plug into the plywood and then insert the screw.



Finishing

Sand thoroughly with a belt sander to get a good, smooth finish. Then rub in a clear filler (page 248) to seal the grain before applying four or five coats of clear polyurethane, rubbing with fine sandpaper or steel wool between coats.

VENEER LAMPSHADES

Both these lampshades are made from Oregon pine veneer, available in strips of varying width and length. Most veneer merchants who advertise in the telephone book sell Oregon pine. If you have trouble finding it, use any other light coloured veneer, preferably with a grain pattern to make the lamps more interesting. There are also mail order

firms which sell various tools and supplies and a good selection of veneers. These companies are listed in hobby or woodworking magazines.

Round lampshade

Cutting the veneer strips

Lay the lengths of veneer on a cutting surface, such as a piece of hardboard, plywood or another piece of scrap sheet material, so that you do not score the top of the workbench. Then measure and cut the six strips with a sharp knife against a steel ruler. The secret of success is to score the veneer with a couple of light strokes first, then cut through firmly.

After cutting all the pieces to length, trim them so that they are all exactly 6in wide.

Assembling the lampshade

With a coping saw, cut two plywood disks $7\frac{1}{2}$ in in diameter. Drill a $\frac{1}{2}$ in

SHOPPING LIST


Oregon about 30ft of 6in wide, cut into 3 strips 60in long A pine and 3 strips 50in long B

pine and 3 strips 50in long veneer

plywood 8 × 16in, 4in thick


plus contact adhesive / bulb holder with electric wire

hole in the centre of one and in the other cut a 5in diameter hole. These will form the top and bottom of the lampshade respectively.




Lay the second disk in the centre of a piece of paper or cardboard on which you have drawn six lines 30° apart, as a guide for the strips.

Start with the three short strips B. Glue the first strip to the disk and then glue each in turn on top of the last, so that the strips are centred along every other line. Spread contact adhesive on both surfaces and allow it to become dry to the touch before bringing the pieces together carefully and pressing down firmly.



After gluing down the three short pieces B, continue with the three long pieces A, gluing each along the lines between two short pieces.




Turn the whole assembly over and, before gluing to the top disk, cut through the veneers around the 5in



hole to make a hole in the base so that you can change the bulb.


Cut through the veneer carefully with a sharp trimming knife, and then sand around the edges of the hole using fine sandpaper to make the opening smooth and even.

For the next stage of the work, bend and glue all the lengths to the top ply wood disk. Glue each end in turn, holding the underside of the disk with one hand while you press the end of the veneer strip down firmly with the other. The strips should be glued down in the same order as before, first the three short lengths and then the three long lengths.




To hold the lampshade firmly while gluing the last two ends, put your hand through the hole in the bottom.

If you have any difficulty in getting the last few strips to stay glued down, it may be necessary to put in a few staples or nail in a few small brads to secure them.




Finally, cut through the layers of veneer to make the ½in hole in the top of the lampshade. Then push the electric wire through this hole and connect the bulb holder. After attaching the holder and putting in the bulb, simply let the lampshade hang from the bulb holder.



Slot together lampshade

Make this attractive, slot together shade out of the same Oregon pine or any similar veneer. If possible, buy a thick grade of veneer, but if this is not available, buy twice as much and glue two pieces together with contact adhesive.



Cut 60 pieces of veneer $1\frac{1}{2} \times 6in$, then cut four slots $\frac{1}{4}$ in deep in each piece with a tenon saw. To make this easier, make a template by cutting slots in two pieces of $\frac{1}{8}$ in plywood, $1\frac{1}{2} \times 6$ in as shown. Then sandwich


SHOPPING LIST

Oregon about 10ft of thick veneer, 6in wide veneer (or 20ft of thin veneer)


plywood 6 × 6in, ½in thick

plus bulb holder with electric wire

ten to fifteen strips of veneer between the plywood templates in a vice and use the slots in the plywood as a guide for sawing.



Slot the pieces together so that each 6in square is diagonally above the next. Add a dab of glue to each joint as you go along.



To support the bulb holder, slot a 6in square of $\frac{1}{8}$ in plywood between layers near the top and drill a $\frac{1}{2}$ in hole for the wire.

OUTDOOR PROJECTS

The selection of outdoor furniture in this final projects section includes a good looking, fold-down picnic table and benches to make in weather resistant redwood, teak or cedar, an outdoor lounge chair that folds down for sun bathing, a barbecue cart handsome enough to use as

a serving cart in the dining room and planters to be

used indoors or out.



Picnic bench



Parquet planter



Barbecue cart, picnic table and benches



Outdoor lounge seat



Barbecue cart



Bench planter



Slat plant stand



Pine plant container



Outdoor lounge seat



PICNIC TABLE AND BENCHES

This luxurious picnic table measures a full 3 × 5ft yet, like the benches which accompany it, it folds up flat in seconds for easy carrying, or for storing when not in use. It is also attractive enough to be used as a spare table indoors.

If possible use redwood, cedar, teak or the teak substitute called iroko which was used here, all of which are weather resistant. This means that you can leave the table outdoors without damaging the wood. The natural oils or resins in the wood provide enough protection from the elements. With the exception of the bench legs, which are made of 1 × 3in section, all the wood is conveniently of one section,

sturdy table. If you are unable to find a supplier of one of these weather resistant woods, use pine instead and make sure to protect it well with several coats of clear polyurethane. Also make sure to finish the edges between the slats well with several thin coats to prevent dripping. The slatted construction is very straightforward. The top of the table is made up of nine boards screwed to the rails underneath, one located at each end. Notice that the screws are hidden by plugs cut from another, contrasting dark wood which adds a nice decorative touch. The plugs shown here are made of American walnut.

The legs require accurate marking and cutting. It is particularly important to locate the holes correctly so that the table will fold up easily.

Study the diagrams and make sure to double check all the measuring and marking before you drill the holes. You will need a 1in diameter drill bit, either a flat bit for the electric drill or an auger bit for the brace, to countersink the bolt heads so that they don't protrude and interfere with the mechanism when the legs



are folded up. The instructions require the drill to be set up in a drill stand which is very convenient for getting the holes located correctly, but the drilling can also be done carefully freehand.

Making the table-top

1 × 4in, which ensures that it is a

CUTTING LIST

 1×4 in

9 pieces 60in long, for slats A 5 pieces 35in long, for rails B

First make two thick rails by gluing four of the 35in long pieces B together in pairs. Save the last piece B for later use. Make sure to use SHOPPING LIST to make a table $3ft \times 5ft$ and two benches 5ft long

teak, cedar, 150ft of 1×4 in redwood 15ft of 1×3 in

or pine


hardware 84 no.8 countersunk steel screws, 14in long

15 no.8 countersunk brass screws, 14in long

12 machine bolts $\frac{3}{8}$ in diameter, two $2\frac{1}{4}$ in long and ten $1\frac{1}{2}$ in long with


nuts and washers

plus polyurethane or teak oil



waterproof resin glue as the table will need to withstand the elements when used outdoors. Clamp the pieces together in pairs until the glue sets, then follow the diagram to round the ends and to locate the hole in each rail.

To drill the holes, mount the drill in a drill stand if possible. First drill a lin diameter hole $\frac{3}{6}$ in deep to take the washer and the bolt head and then drill straight through the rest of the way with a $\frac{3}{6}$ in diameter drill bit for the bolt. Drill from one side, then turn the piece over and finish the




hole from the other side to avoid having the wood break out around the hole. Notice that the lin counterbore is on the opposite side on the second piece.


Before screwing the slats A to the rails B, round the edges with a file, a plane or, most easily, with a rounding-over bit fitted into a router (page 216). Then sand the slats well. It is much easier to do this now rather than after they have been screwed down when they will be too closely spaced for you to be able to sand between them.

After sanding smooth remember to handle the pieces carefully to avoid marking them during assembly. It is a good idea to lay an old blanket on the bench to protect the wood. Start by drilling holes in the slats A. two per end, placed 3in from the ends of the boards. Mark and punch the hole centres, then counterbore the holes with a gin drill bit about gin deep for the wood plugs. Then drill the screw clearance holes with a 3 in diameter drill bit, straight through the board.

Place the two rails at either end of the bench so that the lin countersunk holes face away from each other.




To make the slatted table top, screw the first of the nine top slats A to the rails. Place it so that it extends lin and 2in beyond the rail as shown. Hold it in position and check with a square before you mark through with an awl or nail to locate the screw holes.




Drill pilot holes for the 1 in steel one end. Before screwing down the other end, check with a try square and make sure that the distance between the rails is exactly 53in as shown.


Following the same procedure now screw down a second slat at the other end of the rails. Again check with a try square and measure the distance between rails to make sure that it is assembled correctly.




Lay the other seven slats down in between these two, spacing them out evenly with about 1 in between each one. Use a lin thick board as a spacer if you find that it is necessary. It helps to pin a small board to the end of the first and last slat so that you can automatically line up all the ends.




After screwing down all the slats, make 3in diameter plugs out of a scrap of a contrasting wood and glue them into the holes over the screws with waterproof glue. In this case walnut was used for the plugs to contrast with the iroko table. After the glue has set, carefully cut the plugs off flush with a chisel and sand the surface smooth.



Turn the top over onto a blanket laid on the bench to protect the surface.




Screw the remaining 35in long 1 × 4in B piece across the middle using one brass screw per slat placing it centrally.



Making the underframe

CUTTING LIST 1×4 in 4 pieces 39in long, for legs C and D 2 pieces 52% in long, for braces E



After cutting the pieces to length mark the rounded ends of the legs C and D with a compass, or a jar or



can of approximately the right diameter. Also carefully mark the bolt hole locations as shown. Notice that two legs C have two holes whereas each leg D has only one hole.


Drill the holes as before; first \$in deep with a 1in diameter bit and then straight through with the \$in diameter bit.

The two holes on each leg C are countersunk on opposite sides. Cut the rounded end shapes with a sabre saw or, if necessary, with a coping saw. Sand the pieces well and then lightly mark the bottom ends as shown, above right.


Temporarily bolt legs C to legs D to make two X-shaped end frames. The

centre counterbores face outwards on both C and D so that the bolt head and nut are flush with the surface.


Hold the bolted frame against a try square so that the legs are exactly square with one another. Then mark the bottom edge of one leg as shown. Turn the bolted frame over and mark the bottom edge of the other leg. The braces E will line up against these marks later.




Lay each frame on the bench with the marked bottom ends pointing in opposite directions and legs C on the outside. Place one of the 527 in long braces E so that each end rests on a leg C. Place it so that its top edge is exactly along the mark made earlier and is flush with the end. Then drill holes and glue and screw it to C, using two 14in steel screws per end. Counterbore the holes and cut gin diameter plugs from a darker coloured wood. Glue them in place with waterproof glue, chisel them off flush and sand them smooth when the glue is dry, exactly as for the table top.



Place the other 52% in brace E across the two ends in exactly the same way against the marks. The ends of this brace should also line up flush with the edge of leg C as shown. Glue and screw it to legs D, again using two hidden 1½ in screws per end, hidden by plugs as before.









Assembling the table


Take out the bolts in the legs to separate the two halves of the underframe and, after re-positioning the frame into its final position as shown, put the 1½ in bolts back in with washers under the bolt head and nut.



Lay the table top upside down on the bench once again, spreading a blanket to protect the sanded top. Get someone to help you support the underframe while you bolt through leg A and the rails with the $2\frac{1}{4}$ in bolts to complete the table.



To fold it flat, lay the table on its side and tilt the top over sufficiently to allow enough space to push the legs together. Then lay the top down gently on top of the folded leg structure. The table takes up very little storage space once it has been folded.



Finishing the table

For teak, iroko or redwood, rub in several coats of teak oil, making sure to oil all the crevices between the slats. Buff each coat with a soft cloth after drying for twenty to thirty minutes. Redwood can also be varnished. Cedar can be left completely untreated and will age a pleasant silver grey colour. If you use pine, the table and benches will have to be carefully finished with several coats of clear polyurethane to make them weather resistant. The bolts should also be painted, oiled or varnished to prevent them from rusting or alternatively, they can be stove enamelled.

Making the two benches

CUTTING LIST


1 × 4in
6 pieces 60in long,
for slats A
6 pieces 11in long,
for rails and
battens B
4 pieces 52\frac{2}{8}in long,
for braces C

1 × 3in

8 pieces 19in long, for legs D and E

Cut all the pieces to length. Before assembly, round the edges with a file, plane or a router with a rounding-over bit. Sand all the pieces well. Then assemble the two bench tops, using three slats A and two 11in long shaped


rails B per top.




Space the rails 53in apart as for the table. Then screw down the top slats A, again hiding the $1\frac{1}{2}$ in screws with plugs of a contrasting wood.

To finish the bench tops, screw a single 11 in long 1×4 in batten B flat to the underside of each bench. Position the batten in the centre to hold the top slats in place, using one

brass screw to each slat. Bevel the edge of batten B before you fix it in place.



To make the legs, proceed exactly as for the table. First mark the ends and hole centres for the legs D and E, then round the ends, drill the holes and bolt them together while you attach the cross braces C. Notice that the top edges of the braces C are placed 9in from the bottom edge of the legs, so the legs do not form a right angle when opened. Use four $1\frac{1}{2}$ in bolts per bench, one to bolt each pair of legs together and two to bolt the legs to the rails. Finish in the same way as the table.








SLAT PLANT STAND

This simple plant stand is quick to make and adds a decorative touch to a large plant standing on the floor, as well as protecting the carpet and allowing air to circulate beneath the pot.



SHOPPING LIST

softwood 11ft of $1 \times 2in$ cut into nine 13in strips 2 pieces of $1 \times 1in$

13in long

plus

18 finishing nails or brads, 14in long

After cutting the pieces to length, sand them and slightly round the edges. Use the two 1 × 1 in slats as the base. Glue and nail these to the nine 1 × 2 in slats starting with one at each end and spacing the others out evenly in between. Use a piece of 1 × 1 in scrap as a spacer. Finish the plant stand with two coats of clear polyurethane or oil-based paint over a sealer coat.

PLANTER WITH PARQUET INLAY

The dimensions given here are for parquet with 4½ in square sections. Before cutting the hardwood frame, check the size of the parquet. If it is a different size, work out another cutting list.

Making the sides and ends


CUTTING LIST

 $1 \times 2in$

4 pieces 32½ in long A 10 pieces 4½ in long B

4 pieces 8 in long C

Assemble each of the two identical sides by clamping two A and three B





SHOPPING LIST

plus

hardwood 19ft of 1×2 in mahogany or teak (planed size about $\frac{3}{4} \times 1\frac{3}{4}$ in)

about 24ft of $\frac{3}{8} \times \frac{3}{8}$ in beading in the same hardwood

plywood 8 × 32in, in thick (trimmed to size at assembly)

dowel 48in of \(\frac{1}{4} \) in diameter for pegs

hardware about 70 finishing nails or brads, 4in long

parquet flooring, one piece about 18 × 18in consisting of at least fourteen 4½in squares

clear polyurethane

pieces together while drilling and through dowelling (page 232). Place the third piece exactly central to leave two identical windows for the parquet.

For an interesting effect, hide the dowel by inserting a short plug cut from a matching piece of waste wood (page 214).

To assemble the two ends, use the $8\frac{1}{8}$ in pieces C on top and bottom with the $4\frac{\pi}{2}$ in pieces B in between. Clamp, drill and dowel them exactly as for the sides.


SLOT TOGETHER PLANTER

The bottom panel of this planter can be slotted in at any level to accommodate a small or a large plant. To make a larger or smaller sized planter, change the length of the sides keeping the slots exactly the same.

Follow the diagram (right) in cutting the plywood into sixteen strips, 3×18 in long and four strips, $1\frac{1}{2} \times 18$ in long.

The sixteen 3in strips are marked identically. Mark lines for the 5in

The parquet is held in place by pieces of beading nailed around the openings. Cut one strip at a time, then glue and nail it flush with the front edge. These beads may be mitred or butt jointed.



To secure the parquet, cut off a row of three squares for each wide opening and one square for each of the ends. Lay it in the window against the beading and nail it carefully to the beading from the back.

Assembly


Before assembling, glue and nail beading at the bottom of each side to hold the plywood base. Join the four sides with through dowels and cover with a plug, Drill $\frac{3}{4}$ in holes in the base for drainage before trimming it and dropping it in position.

Finishing


Sand the sides smooth and finish with several coats of clear polyurethane.

plywood 28 × 36in, ½in thick 12¾ × 15in, ¼in thick, for bottom plus green stain

green stain polyurethane



deep slots, 2in from the ends, using a piece of ½in plywood to get the width right so the pieces will fit together snugly. Saw on the waste side of the lines and chisel out the waste. Make one slot and test for fit



before cutting the rest to be sure they are right. The $1\frac{1}{2}$ in strips have slots on one edge only.

Finish the pieces by sanding smooth and applying green stain and then two coats of clear polyurethane.

To assemble the planter, start with two 1½ in strips and build up the sides by simply slotting the pieces together. The two remaining 1½ in strips go on top. Slide the base in at the desired height.



OUTDOOR PLANTERS

Attractive plant containers are surprisingly expensive to buy, but in fact they are easy to make yourself. These two planters have been designed to be used outdoors, but they could just as easily be made smaller and used for indoor plants. Try to use a wood which will stand up to the weather like redwood, cedar, teak or mahogany. If you use pine, seal it well with several coats of clear polyurethane.




Bench plant holder

Making the planter


Cut the $1\frac{1}{2} \times 6$ in into two 3ft 6in lengths for the top and four 13in lengths for the legs. Save the remaining piece for the cross braces, which are measured and cut after the legs are attached.

First bevel or round the edges with a plane or with coarse sandpaper and then sand the face of the pieces well.

Assemble the pieces first by drilling the holes and then screwing the legs to the top pieces, holding them with a clamp to leave your hands free. Notice that the legs extend about 1in above the top boards. The screws are set into \(\frac{3}{8}\)in diameter holes drilled about \(\frac{3}{8}\)in diameter holes drilled about \(\frac{3}{8}\)in deep. The countersunk screws are hidden by filling the holes with plugs cut from a matching wood (page 214). This means that the screws will not rust.



It is easier when clamping the legs to the top to place a lin strip between the two top boards to space them evenly apart. After attaching the four legs, cut off two lengths for end braces so that they extend about 4in beyond



the legs. Then screw these in place, making sure the legs are square. Glue the matching wooden plugs into the holes and carefully sand off any marks which were made during assembly.

Measure the neck of the flower pots you are using. Mark the circles and cut them out with a sabre saw. Four pots is a good number for a planter of this length, but you can of course make a longer one or use small diameter pots. You could also make a matching bench.

Leave the wood unfinished if you have used a wood that will withstand the weather. Otherwise, protect it with several coats of clear polyurethane.

SHOPPING LIST

wood

14ft of $1\frac{1}{2} \times 6$ in (redwood, mahogany, teak or cedar)

hardware

16 no.10 countersunk steel screws, 2in long

Pine plant container

CUTTING LIST

1 × 5in

16 pieces 15in long A

1 × 2in

4 pieces 20½in long B

4 pieces 19in long C

4 pieces 24in long D

(to be trimmed)


½in plywood

1 piece 20¾ × 20¾in


4 pieces 3 × 17in

After cutting the boards to length, make each of the four sides by laying out four boards A, spacing them about $\frac{1}{2}$ in apart and nailing the 1×2 in pieces to them as shown with a $\frac{1}{2}$ in overhang at the bottom. On two panels the 1×2 in pieces B are flush with the edge, and on the other two, the 1×2 in pieces C are nailed on leaving a $\frac{3}{4}$ in gap at each end.


To make the planter more decorative, draw heart shapes on the boards and cut them out with a sabre saw. Sand the edges well.




Then join the sides together using two metal brackets at each corner. To finish off the sides, trim the edging D to length and then nail the pieces to the top edges of the four sides so that the ends of the boards will not be exposed to the weather. Set the nails and fill the holes to keep the nails from rusting.



To make the base, nail the four small pieces of plywood together to form a square, then nail the large piece onto



the square. The sides of the planter simply rest on the base. The planter is thereby raised off the ground to protect the wood from moisture.



SHOPPING LIST	
softwood	22ft of 1 × 5in 24ft of 1 × 2in
plywood	2 × 3ft, ½in thick
hardware	8 metal corner brackets with ½in screws about 90 oval wire nails, 1½in long
plus	clear polyurethane

Finishing the planter

Seal all the pieces of the planter with several coats of clear polyurethane if you have used pine, paying special attention to the inside edges, end grain and the base pieces to keep the weather from spoiling the wood. You can stain pine with a coloured or wood tone polyurethane first. If you use mahogany or teak for the planter, finish it with linseed or teak oil.

OUTDOOR LOUNGE SEAT AND TABLE


This adjustable lounge seat is both a stylish and practical design. The pine battens are simply screwed to two supports to make a chair with a backrest that can be adjusted for sitting upright or for lying down. The small wheels at the back make it easy to move. You simply lift the front and roll it away. Instead of finishing with clear polyurethane as shown here, you could paint the chair and its matching table in shiny white or in a bright colour to cheer up a patio or garden. The

construction is quite easy. The only part which is tricky is fitting the backrest but, as always, if you read the instructions and study the diagrams carefully before beginning, you shouldn't have any difficulties. The two small wheels should be quite easy to find. Large hardware stores usually sell wheels like this. Alternatively, buy large toy wheels such as those used for the truck on page 94. As a last resort, use a couple of wheels from an old baby carriage.

Preparing the supports for the lounge seat


CUTTING LIST 14×8in 2 pieces 6ft 5in long, for supports A 14 × 14 in 2 pieces 6ft 5in long B I piece 3ft 6in long C

After cutting the pieces exactly to length, sand them well as it is easier to do now than when the pieces have been joined. Use a sanding block and medium then fine sandpaper to make the wood smooth and pleasant to touch. Temporarily nail one $1\frac{1}{2} \times 1\frac{1}{2}$ in piece B to the edge of one support A, and the second piece B to the second support A. Nail each piece with five or six 11 in nails avoiding placing them near the ends as you will be making a saw cut later. Make sure not to add any glue at this stage.



mark and cut the remaining 13 × 13in C into six mitred pieces as shown.

Screw one of these to one end of each support as shown. This becomes the front end of the chair. Use two 14in long screws per piece, counterboring the hole about \$in into the piece and then hiding the screw with a plug or with wood filler. Save the other four pieces as they will be of use for making the table.



SHOPPING LIST

20ft of 13 × 8in for softwood supports 95ft of 3 × 4in for slats

25ft of 14 × 14in


plywood 2 pieces 3 × 24in, 4in thick

dowel two 24in lengths. lin diameter

hardware 125 no.8 countersunk brass screws, 14in long 125 no.8 brass screw cup washers 22 no.8 countersunk steel screws, 14in long 30 finishing nails or brads, 14in long 3 brass hinges 13in long with matching lin long screws two 4-5in diameter wheels or castors with


I piece of 2in thick plus foam, 23 × 80in 24vds of heavy cotton fabric, 54in wide


fittings



The top slats will be screwed into the 14 × 14 in pieces B attached to the supports. Part of piece B will be cut off so that it can be attached rigidly to the support, but the remaining part which holds the slats for the adjustable backrest will not be fixed down, to allow it to be lifted up and

Measure exactly 44in from the front end of the support as shown, then cut the 14 × 14 in at this point. Also






make a cut 3in from the back end as shown. The middle piece Y will form the adjustable backrest. Screw the pieces X and Z down rigidly, using four 1½in long screws on piece X and one on piece Z. Sink the screws about ½in into the wood and hide each screw with filler or with a matching wood plug. As well as hiding the screws, this also seals them from the weather and prevents them from rusting.

The next step is to glue and nail the plywood pieces in place, one to the inside of each support near the back to hold the adjustable prop.

Start by cutting out the shapes shown with a sabre saw or a coping saw. Notice that the top edge of the plywood piece is lined up with the joint between the $1\frac{1}{2} \times 1\frac{1}{2}$ in B and the $1\frac{1}{2} \times 8$ in support A. Spread glue over the plywood, then hammer in six $1\frac{1}{2}$ in nails per side.



Attaching the slats

CUTTING LIST


½×4in
20 pieces 33in long
1 piece 24in long A
(to be trimmed)

Cut all the slats, then sand them making sure to round the edges and ends so that there will be no sharp edges to catch on clothes.

Drill two 3/16 in diameter screw clearance holes at both ends of each




slat. It is a tedious job drilling 80 holes so it would be a good idea to speed up the job by making a drilling guide out of a scrap piece of $\frac{3}{4} \times 4$ in with three battens on the



sides. Drill two $\frac{3}{16}$ in diameter holes, $5\frac{1}{4}$ in from the end. Hold this jig over the end of each slat in turn and drill straight through the guide holes into the slat.

Place the two supports on the floor about 21in apart and attach one slat at each end placed at a 45° angle as shown. Use a combination square set at 4½in as a gauge to get an equal overhang on both sides of the supports. Screw the slats down using 1½in brass screws with cup washers. Make sure the overhang is equal on all sides so that the supports are parallel.




On one side nail a small board to the ends of these two slats so that it forms a guide for lining up the rest of the slats.




Now screw down one slat near the middle so that it lines up on the X side of the saw cut in the $1\frac{1}{2} \times 1\frac{1}{2}$ in. Trim the 24in slat A so that it fits tightly between the supports and screw it

under the middle slat aligned with the edge with three brass screws, as shown.




Screw down another slat directly behind with the edges touching and attach the three hinges to the two slats. Don't cut recesses for the hinge flaps. Simply hold them in place, centred between the two slats and make screw holes with a bradawl. Then screw down the hinges with the ½in long screws.



Now screw down the rest of the slats in between, spacing them out evenly.

Finally screw one slat vertically to the end at the front and one at the back and remove the strip which was nailed on as a guide.



the batten. Repeat this for the other side using the other prop.

Flip the backrest over completely so that it lies flat. Lay the props inside the battens B with the holes lined up and push one of the ½in diameter dowels straight through the holes so that it goes through all four battens.

Constructing the adjustable back rest

CUTTING LIST


1½ × 1½in

2 pieces 24in long as props

The backrest, which is hinged to the front, can now be lifted up. It is only held down to the support with a few temporary nails. Lift it up and try to pull out the temporary nails from the back with a pair of pliers. If it is too difficult to pull the pin heads straight through the wood, just hammer them over, punch them below the surface with a nail punch,


and fill the holes with matching wood filler.

Round one end of both the $1\frac{1}{2} \times 1\frac{1}{2}$ in props with a file and smooth off the wood with fine sandpaper. Drill a $\frac{1}{2}$ in diameter hole in each end of both props exactly as shown. Hold one prop in position with the bottom square end resting in the plywood cut-out and tilt the backrest until the prop just touches the slat. Copy the outline of the $\frac{1}{2}$ in diameter hole onto the $1\frac{1}{2} \times 1\frac{1}{2}$ in batten Y which is screwed to the slats, then drill a $\frac{1}{2}$ in diameter hole where marked, straight through



Trim the other dowel so that it fits loosely between the two supports, then push it through the bottom holes of the two props.

The backrest should now fold flat with the prop resting flat on the inside. Check to make sure it works all right and make any adjustments if necessary.







Finally fit one wheel to each back end of the support so that it extends about 1½in below the support.



Making the table

CUTTING LIST $1\frac{1}{2} \times 8in$ 2 pieces 33in long $\frac{3}{4} \times 4in$ 10 pieces 33in long

Start by adding the four $1\frac{1}{2} \times 1\frac{1}{2}in$ feet cut out earlier when making the chair. Screw them to the bottom ends of the $1\frac{1}{2} \times 8in$ pieces with two $1\frac{1}{2}in$ long screws. On the top corner of each end of the two pieces, cut off



the corner at a 45° angle in the same way as for the chair. Drill the two $\frac{3}{16}$ in diameter holes at the end of each slat using the drilling guide made for the chair. Then screw down the ten slats, starting with the two angled ones at either end and spacing the others out evenly against a guide temporarily nailed to the two end slats.

Finishing the chair and table

Sand off any marks made during assembly and then apply about three coats of clear polyurethane to the entire chair and table. Pay particular attention to the ends of all the boards and slats, making sure that they are thoroughly finished to prevent damage by the weather.

Making the cushion

The bold stripes used here are an attractive pattern for the lounge seat. You can make the cover for the cushion with the pattern running up and down or across the cushion or, if you don't mind using about 50 per cent more fabric, you can have the pattern running diagonally, as shown here.

Cut out the fabric to match the piece of foam exactly allowing for a ½in seam all round. Sew a full length zipper down one side so that the cover can be removed for washing. Make eight 6in long ties from the same fabric as the cover and sew them to the underside of the cushion, two to each corner. Use these to tie the cushion down firmly to the slats.

BARBECUE CART

This cart with four interchangeable trays is an ingenious design and is very easy to make. One tray houses a built-in double hibachi or brazier with a tile surround so that you can barbecue right on the trolley wheeled close to a picnic table. The barbecue tray lifts out so that you can barbecue wherever you want and place it on the table for serving if you like. The second tray holds bottles and glasses firmly in cut-out holes, a third is a large chopping board and the fourth is a flat tray for stacking plates and cutlery. You can make one each of the trays as shown here or, if you prefer, make two trays for glasses or two plain trays depending on how you want to use your trolley. When the hibachi is not in use, you can move it to the bottom shelf of the cart or put it away completely. For indoor use, you can remove the barbecue tray and use it as a serving cart. The large castors ensure that it is steady and sturdy enough to bring dishes to the table. The cart is remarkably easy to make. The basic framework screws together very simply and the built-in barbecue is the only section which requires extra care. Buy a standard sized double hibachi measuring about 10 × 17in, It comes with a handle which can be screwed to the tray to make it easy to carry.

Making the cart framework

CUTTING LIST

 $1 \times 2in$

4 pieces 27in long, for legs A

3 × 2in

2 pieces 43in long, for rails B 2 pieces 35in long, for rails C

3 pieces 21 in long, for cross rails D

1 piece 17in long, for cross rail E

 $\frac{3}{4} \times \frac{3}{4}$ in

4 pieces 35in long,


for battens F

4 pieces 18in long, for battens G (to be trimmed)

in plywood

2 pieces 17 × 35in






Start by drilling holes in the exact centre in the bottom of the four legs to take the castor sockets. Tap a socket into each hole with a hammer, but be careful not to split the wood. The castor manufacturer will usually supply instructions for installing the castors with the diameter and depth of holes required.

On the inside of each leg, mark two lines, one 4in up from the bottom and one $\frac{1}{4}$ in down from the top as guide marks for the rails.


Lay two legs on the bench about 3ft apart with the marks facing up. First glue and nail one bottom rail C so that the bottom edge is against the marks on A and the ends of the rail are exactly flush with the legs. Use two



SHOPPING LIST 7ft of $\frac{1}{2} \times 5$ in / 10ft of 1×2 in / 33ft of $\frac{3}{4} \times 2$ in pine 11ft of 1×1 in / 22ft of $\frac{3}{4} \times \frac{3}{4}$ in plywood 18 × 18in, 3in thick 36×54 in, $\frac{1}{4}$ in thick dowel 17in of 13in diameter 18in of §in diameter hardware 6 no.8 brass screws, 13 in long 24 no.8 countersunk brass screws, 14in long 18 no.8 brass screw cup washers 26 no.6 countersunk brass screws, 3in long 50 finishing nails or brads, 14in long 100 finishing nails or brads, 1in long 4 castors with socket type fittings 6 no.8 fibre wall plugs, 1in long plus 3 pieces of bright red plastic laminate, 2 pieces $17\frac{1}{4} \times 35\frac{1}{4}$ in one piece 17 × 17in contact adhesive 8 tiles 41 in square (or trim 41 in tiles) tile cement hibachi measuring 10 × 17in clear polyurethane


 $1\frac{1}{4}$ in nails per end, and check with a try square before nailing.

Next nail and glue the top rail B, ¼in from the top of the leg. Attach one end first, flush with the leg, then glue and nail to the other leg making the frame square, Notice that the other end of B extends about 8in beyond the leg.




After attaching the two rails to the two legs to form one side frame, reinforce each glued and nailed joint with one 1½ in brass screw, countersunk flush with the surface.


Make another side frame identical to the first except that the top rail extends 8in in the opposite direction to that of the first frame. This way you will have one left-hand and one right-hand frame to form the two sides of the cart.



Prepare the three cross rails D by drilling two $\frac{3}{16}$ in diameter screw clearance holes $1\frac{1}{8}$ in from the ends and about $\frac{3}{8}$ in from each edge.



Lay the side frame on the bench and glue and screw two of the cross rails




BARBECUE CART continued

D to the front legs using two 1¼in screws with cup washers for each end.

Locate the rails so that they line up exactly with the long rails B and C, covering their ends.


Stand both side frames upside down on the bench and attach the other ends of the cross rails D to the front legs.




It is important that the distance between the insides of the rails B at the top and rails C at the bottom is exactly 17in. To get this right, hold the 17in long cross rail E tight between the long rails as you screw on the cross rails D.

Screw the third cross rail D to the back legs in exactly the same way. Line up with the bottom rails C, again making sure the distance between the long rails is 17in by holding rail E in between.

Glue and screw rail E between the top rails. Locate it so that it lines up with rail D below, making the distance between it and the front cross rail exactly 35in. Use two 1½in long brass screws with washers per end and screw them into fibre plugs.




Next turn the assembly on its side and glue and nail two of the $\frac{3}{4} \times \frac{3}{4}$ in battens F to the insides of the long rails flush with the bottom edges. Use about five lin nails per batten.




Turn it over on its other side to attach the other two battens F in the same way. Then trim the battens G to fit along the cross battens and glue and nail them in place, three nails per batten.

This forms a ledge at the top and bottom of the cart to hold ½in



After trimming the edges flush with the plywood on both panels, spread glue on the $\frac{3}{4} \times \frac{3}{4}$ in battens and drop the panels in place securing each from underneath with eight $\frac{3}{4}$ in brass screws through the battens.

To finish off the trolley, glue and screw the 1½ in diameter dowel handle between the long rails B. Spread glue on the ends of the dowel and then screw one 1½ in long brass screw with washer through the rail into a fibre plug. Finally, push the castors into their sockets at the bottom of each leg.





Making the barbecue tray

CUTTING LIST


- $\frac{1}{2} \times 5$ in
 - 2 pieces 18in long A
 - 2 pieces 17in long B
- $\frac{3}{4} \times 2in$
- 2 pieces 17in long C
- 1 × lin
 - 2 pieces 17in long D
 - 2 pieces 18in long E
 - (to be trimmed)
- in plywood
- 1 piece $8\frac{1}{2} \times 17\frac{1}{4}$ in F
- in dowel
 - 6 pieces 2½in long

Prepare the sides by gluing and nailing the battens C and D to the sides. Attach one batten C






continued



along the bottom of each side B so that about $\frac{1}{2}$ in of batten extends below the edge. Use four 1 in nails per batten. Then glue and nail a 1×1 in batten D near the top edge of the same sides, $\frac{1}{2}$ in down from the top edge. Use four $1\frac{1}{4}$ in nails per batten.


To assemble the tray, glue and nail the sides A to the sides B using four 1¼ in nails per corner. Then trim the 1 × 1 in battens E so that they fit in between the battens D which are attached to the sides B.




Turn the tray on its side and glue and nail these battens E to sides A, placing them ½in from the top edge to line up with the other battens.

Trim the ½in plywood piece F to fit, and nail and glue it in place with eight lin nails.

To protect the box from the heat, the hibachi is perched on six small dowels which are attached to the 1 × 1in battens.



Hold the hibachi in place to determine the dowel locations and then drill six ‡in diameter holes in the 1×1 in battens. Cut six dowel pegs, $2\frac{1}{2}$ in long and glue them into the holes. Then place the hibachi on the pegs to be sure that it fits securely. Make adjustments, relocating the pegs if necessary.



Glue the tiles to the plywood by first spreading a thin layer of tile cement on the surface using a serrated spreader. Then place the tiles in position, pressing down firmly to make them even. Trim the last tile with a tile cutter if necessary, or gently sand off the edge if the fit is snug. Allow the tile cement to set for 24 hours before using the barbecue.




Making the drinks tray


CUTTING LIST

\$\frac{3}{4} \times 2 in
2 pieces \$17\frac{1}{2}\$ in long
\$\frac{3}{6}\$ in plywood
5 strips, \$3 \times 18\$ in

Start by gluing the $\frac{3}{4} \times 2$ in battens to the two end plywood strips so that $\frac{1}{2}$ in of plywood extends beyond




the batten. Simply spread glue along the full length of the batten and then place it on the strips. Fix the other three strips in between, spacing them about $\frac{3}{4}$ in apart, and allow the glue to set. After it has set, reinforce the joints $\frac{3}{4}$ in with one 1in brass screw per end.



Without turning it over, draw the circles for the glasses, bottles and perhaps small bowls to fit into the tray. Trace around the glasses and bottles themselves to make sure to get a tight fit. Centre each circle around the $\frac{3}{4}$ in space between the strips.

Then cut out all the circles using a sabre saw and clean up the edges with sandpaper. Sawing from the bottom means that the top edges of the holes will be neat and free from splinters.




The tray drops onto the sides of the trolley with the plywood ends sitting on the long rails.



Making the chopping board

It is easiest to buy a maple or beech chopping board, 18×18 in, but if one isn't available follow the instructions on page 231 for gluing together planed boards to make one. Glue a short piece of $\frac{3}{4} \times 2$ in underneath near each corner to hold the chopping board within the rails on the trolley.




Making the tray


CUTTING LIST

- $\frac{3}{4} \times 2in$
 - 2 pieces 18in long A
 - 2 pieces 17in long B
- 4 pieces 2in long C
- $\frac{3}{4} \times \frac{3}{4}$ in
 - 2 pieces 18in long D
- in plywood
 - 1 piece 18 × 18in

Glue and nail the sides A to sides B as shown, using two 11 in nails at each corner. Then glue and nail the 1/2 in plywood panel to the bottom edges, using four Iin nails per side. Trim any protruding edges of plywood with a block plane. Trim the 17×17 in laminate panel to fit inside the wooden frame and glue it to the plywood with contact adhesive. Glue and screw the two $\frac{3}{4} \times \frac{3}{4}$ in battens D to the sides, flush with the top, to serve as handles. Use two 14in brass screws and cup washers for each handle. Finally glue the four small $\frac{1}{4} \times 2$ in blocks at the corners placing them so that they fit within



the rails with the tray in place, exactly as for the chopping board.



Finishing the cart

Oil the chopping board with one or two coats of salad or olive oil and renew the oil finish from time to time. Finish the rest of the pine pieces of the trolley and trays with at least two coats of clear polyurethane. Rub down all the surfaces with fine sandpaper or steel wool between each coat to achieve a really smooth finish. If you plan to use the cart outdoors a lot, it will be a good idea to give the wood a third coat of polyurethane so that it is really well sealed against the weather.

WOODWORKING TECHNIQUES

This section is really a book in itself with a tremendous amount of information packed into 64 pages.

It can be used as a general reference book on woodworking techniques, for detailed instructions on using machines, hand tools and on making joints, and for buying, cutting and finishing the wood. Also included are detailed directions for making jigs and other devices to make your tools more versatile. There is no reason, for example, to buy a table saw since you can make one out of the portable circular saw following the instructions on page 209. But this section has also been designed to be used in conjunction with the projects with frequent cross references between the two to make it easy to check from one to the other for additional information. So it is a good idea when planning out a project to read through the instructions and make a note of the various techniques you may want to refer to before starting work.


HAND TOOLS AND HOW TO USE THEM

measuring and marking

Measuring, marking and squaring off happens constantly in woodworking. In many ways, it is the most important step of all. Without accurate marking, it doesn't matter how well you saw, the measurements will not be exact. The dimensions of a project must be accurate for a good fit.

TAPES AND RULES

A tape measure is adequate for most measurements. For very accurate dimensions use a good quality boxwood rule for long lengths and a steel rule for short lengths. Always hold the rule with the marked edge against the wood for greater accuracy.






Use a sharp, fine pencil for most marking but, again, take more care and use a marking knife when really accurate marking is required. A marking knife or a trimming knife is particularly useful for marking chisel lines because the score in the wood serves as an accurate guide for the chisel blade.

CALIPERS

Calipers are essential for measuring thicknesses accurately. It isn't necessary to buy an expensive engineer's precision pattern – the cheapest one available is adequate for woodworking. Most calipers have arms for both interior and exterior measurements and a vernier scale for greater accuracy when making precise measurements.






GAUGES

The simplest way to mark lines parallel to the edges of boards is to use marking or cutting gauges. A marking gauge scores a line parallel to the grain. Hold the marking gauge with the body firmly against the edge. Pull the gauge toward you with the point sloping away as shown.

When marking across the grain

at the end of a board, use a cutting gauge which is exactly like the marking gauge except that it has a small knife blade instead of a point for easier marking across a board.


The marking gauge can be used for marking mortise slots but it must be set twice. Using a special mortise gauge with two adjustable points, this operation is done more accurately and in one stroke.



SQUARES AND BEVELS


The try square is used constantly in the workshop to draw square lines across boards, to transfer lines from one face to another and to check the square of saw cuts and of planed surfaces.

Buy two good quality try squares, one 4 or 6in long and the other 12in long. On most squares, the blade is set in a hardwood handle with brass studs, but plastic handles are actually better since they will not warp.





The combination try and mitre square is extremely useful. Besides its use as both try and mitre square, it also serves as a useful depth gauge and the

blade can be removed to be used alone as a rule or straight cutting edge when necessary.



For marking any angle, use a sliding bevel. Set the angle of the blade against a protractor, then tighten the wing nut and use it like an ordinary try square. If you are marking several pieces at the same angle, it is best to check the angle on a piece of scrap or against a protractor before final marking to be sure it is correct.





The panel gauge is used for marking parallel lines on wide boards or on sheets of plywood. You can easily make your own out of good quality hardwood. Cut a slot in the head to take the arm. This is adjustable and is held in place with a peg. A hole drilled in the end of the arm holds a

pencil which is held in place by a screw fixed from the side of the arm.

To mark large circles, either make a homemade jig from a strip of wood with a nail for the centre, or buy two trammel points which adjust along the strip for any size of circle.



hammers and mallets

Hammers most often used in furniture making are the Warrington hammer for driving brads and the claw hammer, used for driving larger nails and for pulling out nails. The lighter tack hammer has a smaller head for use in fine work, as, for example, with veneer pins.




Striking tools used in woodworking. Left to right: tack, Warrington, claw hammer and wooden mallet.

For general work buy a 10oz Warrington hammer and a 16 or 20oz claw hammer, whichever you find most comfortable to use. The ash handles, which are replaceable, are held in the head with two metal wedges. It is important to keep the face of the hammer clean and polished by rubbing it periodically on emery cloth.


The brad push is used instead of a hammer for holding and driving small brads and for nailing thin plywood. The brads, which fit into the tube, are driven by pushing hard on the handle, or if necessary driving with a hammer.




It is impossible to give instructions for using a hammer. After a little practice and a few bent nails, you will soon acquire the knack.




Start very small brads with the cross pein and if you are going to hide the nails by driving them below the surface, stop nailing when the brad head is just above the surface. Then use a nail punch of the correct size to drive the nail below the surface. Finally, fill the hole with filler to hide the nail.




Pull nails out with the claw hammer, using a block of waste



wood to prevent marking the workpiece. You can also use a pair of pincers which have a fine claw on one end of the handle for getting under nail heads.



The beech wooden mallet should always be used for striking chisels, for tapping in dowels and generally for adjusting pieces of wood and knocking together joints. To prevent damage to valuable pieces of wood, cabinetmakers tape layers of cardboard over the face of the mallet and use it as a substitute for a soft-faced mallet which is made with a soft nylon head.



NAIL PUNCHES AND CENTRE PUNCHES

Nail and brad punches are used to drive nails below the surface. The square shanked type are best since they are easier to hit with a hammer. Nail and brad punches are available in sets to suit varying sizes of nail heads, but two or three sizes are enough for



general use. Centre punches should always be used before drilling to make a centre mark as a starting guide for the drill bit.

drills

For hand drilling use either a hand brace or a hand drill.


The brace is available with a ratchet mechanism and with

several sizes of handle. The 8 and 10in sweep handles are the most common, and they are manufactured in a range of sizes for special applications



such as drilling between joists. The brace is used mostly with auger type bits with square tapered shanks, but it will take straight shanked twist drills up to in diameter.

To fix the bit into the chuck, first open the chuck jaws by



DRILL BITS USED IN A BRACE


- 1. Jennings pattern auger bits, for general cabinetmaking. From 1 to 1in diameter.
- 2. Solid centre auger bit. Similar to Jennings but with extra strength and faster chip clearance
- 3. Single spur solid centre bit. Primarily for deep boring in harder wood.
- 4. Forstner bit, used either in a drill press or brace. Does not split wood and is useful for thinner pieces like plywood

and for drilling shallow holes.

- 5. Expansion bit. Variable diameters for drilling shallow holes in softwood. Two sizes: 4 to 14in and 7 to 3in diameter.
- 6. Centre bit. Less expensive than auger bits, cuts shallow holes efficiently.
- 7. Jennings pattern dowel bit.
- 8. Countersink bit.
- 9. Screwdriver bit for turning screws in quickly.



Use bits with a tapered square section tang for a firm grip in the brace. From left to right: centre bits and two sizes of solid centre bits.



The hand drill is used with twist drills up to &in diameter, with dowel bits which are available up to 4in diameter and can also be fitted with a useful bit for countersinking screw holes.

Twist drills are intended for drilling metal, but nonetheless, they are universally used in woodworking for general work such as drilling clearance holes for screws.




The bit is mounted in the chuck in the same way as in the brace, by turning the handle while holding the chuck.

For more accurate work use dowel or brad point bits available for use in the hand drill in 1, 5, 3 and 1in diameters.

Another extremely useful tool, for making small clearance holes for nails and screws, is the bradawl. Use it so that the edge cuts across the grain to avoid splitting the wood, twisting back and forth into the wood to make a small hole. Sharpen the bradawl with a fine file and finish by rubbing on an oilstone.

It is a common fault to inadvertently lean the brace over when drilling which results in a hole that is not vertical. Drilling vertically comes with practice. On occasions when it is important that the holes are absolutely vertical, such as for dowel joints, check the alignment either by standing a try square on the bench or by having someone else sight along the drill to guide you.




When drilling to a required depth, for instance in dowelling work, use a depth stop, either bought from a shop or made from a scrap of waste wood


SHARPENING DRILL



Sharpen auger bits with a special smooth file, making sure to file lightly and remove as little metal as possible.

First file the spurs. Lean the bit against the bench and file the inside of the spurs. Never file the outside as this reduces the cutting diameter. Then hold the bit against the top of the bench to sharpen the cutters. File only the underside of the cutters, i.e. the tapered side.






Cut a 4 to 5in length of 1 or 13in square scrap wood,

depending on the diameter of the drill bit. Fasten it in the vice with an extra clamp to prevent splitting, and carefully drill a hole down the centre. Then work out the exact length required for the depth stop, cut off that length, and slide it on the drill bit.

Taper the end slightly with a knife or chisel to prevent it from marking the wood.




handsaws


Sawing is the most basic operation involved in making any project. You will have to cut long boards to rough length then trim them square and to length before beginning the work of cutting joints or assembling pieces.

Even though the portable circular saw does the job much quicker, handsaws are still indispensable to the woodworker.

The teeth of the saw, which are bent or 'set' out from the blade alternately to the right and left, score two parallel lines along the wood and the waste in between crumbles away as sawdust, leaving a space called the kerf.



The use of the saw depends on the fineness of the teeth. The more teeth or 'points' to the inch, the finer the cut. A large ripsaw for example may have only six points to the inch, whereas a dovetail saw can have as many as twenty two points per inch for especially fine cuts.



Handsaws are divided into three main types.


- Large saws such as rip, crosscut and panel saws for rough work.
- Backsaws such as tenon, dovetail and gent's saw for fine work.
- 3. Fine saws with narrow replaceable blades such as bow, keyhole, coping and fretsaws for cutting curves.

THE RIP, CROSSCUT AND PANEL SAWS


The ripsaw, about 26in long with four and a half to six points per inch, is used for cutting along the grain, called 'ripping', for example to cut a 6in wide board into two 3in boards.

The crosscut saw is also about 26in long but has seven or eight points per inch and is used for cutting across the grain, to cut boards roughly to length.


The panel saw, about 22in long, is a smaller crosscut saw with about ten points to the inch. If it is kept well sharpened, it is an extremely versatile hand saw because it is small enough to handle well and the teeth are just fine enough to give a fairly smooth cut.



When sawing, hold the handle with the index finger pointing along the blade for better control. Using your thumb as a guide, start the saw cut at a low angle, then raise the saw to about 45°.



The work should always be well supported on trestles, clamped to the bench or held in a vice. During ripping, some boards have a tendency to spring together as you cut,




Panel crosscut saw, left; ripsaw, right.

jamming the saw blade. The easiest remedy is to place a short wedge or a nail in the cut to keep the edges apart.




When crosscutting it is important to prevent the end



from splitting off before you finish the cut. Either support both sides of the cut as you finish, or as experienced woodworkers do, finish the cut with one smooth powerful motion to leave a clean finish.

When ripping or crosscutting with a large saw, it is a good idea to saw about $\frac{1}{16}$ in away from the marked line, leaving enough waste to allow you to plane smoothly down to the line.




Cutting large sheet materials by hand is hard work but, in the absence of a power saw, it can of course be done. Support the sheet on two or three boards laid on trestles, with one board on each side of the cut. Use boards sturdy enough to allow you to climb on top to saw near the centre of a large sheet. On very thin sheets such as in hardboard, it helps if you hold the saw at a very low angle. Remember to move the sheet over when you get near the trestle to avoid cutting into


handsaws

BACKSAWS


The blades of the smaller crosscut saws are stiffened across the top with a rib or 'back' of steel or brass. The tenon saw, which is about the most useful of all the handsaws, is about 12in long with twelve to fourteen points to the inch. It is used for most fine crosscuts such as trimming off small boards to exact length, cutting joints such as halving joints or tenons, and for other small sawing jobs:




The 8in dovetail saw, with eighteen to twenty two points, produces a finer cut and should be reserved for cutting



dovetails and other fine cuts only. It should not be used instead of the tenon saw for general work.



Another useful backsaw which is even finer than the dovetail saw, is the bead or gent's saw. It is convenient for cutting off small sections like dowels or beadings, using a bench hook.



The bench hook is a simple and ingenious device which helps you to hold small pieces like dowels and mouldings during sawing.

Make it from a piece of $\frac{3}{4}$ in thick plywood or hardwood, about 8×10 in, with two 6in long 1×2 in hardwood battens screwed on as shown to the top and bottom. You can hide the

screws with wood plugs (page 214) to avoid harming the saw.


Hold the bench hook with the bottom batten against the edge of the bench and support the work against the top batten as you cut.

When the top surface gets worn, turn the bench hook over and use the other side.

CUTTING SHAPES


There are several purposemade handsaws for cutting irregular shapes in wood. If you do a lot of work in wood which requires irregular cuts, a good sabre saw or jigsaw is very convenient because it will cut easily through solid wood as well as sheets of plywood and chipboard (page 215).

The most useful handsaw for cutting curves is the coping saw which uses easily mounted, disposable blades. The direction of the blade can be altered to make it easier to guide the saw along a curve.





It is important to support the work well when using a coping saw. Either clamp the work in a vice and use it like an ordinary saw with the blade mounted so that the teeth point away from the handle, or support the work on a home-

made jig with a V-shaped top and use the saw vertically with the teeth pointing downwards.



Use the coping saw to cut wood up to about lin in thickness. To replace the blades, first unscrew the handle a few turns, then hold the saw between your body and the bench to reduce the tension as you take out the old blade. Insert the new blade top first into the slots at each end before tightening the handle to increase the tension.






Top to bottom: gent's saw, dovetail saw, tenon saw.

handsaws


continued from page 197

The coping saw has a narrow 'neck' which limits its use to short distances in from the edge of the wood. The fretsaw which is used with finer replaceable blades, has a longer neck and can therefore cut further in from the edge. It is used in the same way as a coping saw, with various grades of blade to make fine cuts in thinner wood.

Use the fretsaw for cutting out intricate shapes such as in decorative fretwork. To make jigsaw puzzles, glue a picture or drawing to a piece of \$\frac{1}{8}\$ in thick plywood with contact adhesive, draw the shapes of the jigsaw pieces and cut them out with a fretsaw.



The bow saw is an oldfashioned saw which is still popular for cutting shapes. Although it is quicker to use and will cut through much thicker material than the coping saw, the bow saw will not cut such intricate shapes with sharp curves.




Replaceable blades for the bow saw are held, teeth pointing away from the handle, with tapered pins at each end. Tension the blade by winding the wedge around until the twine is taut, then keep it from unwinding by holding the wedge against the crossbar.

As with the coping saw and fretsaw, it is important to hold the work firmly clamped to the bench or in a vice as you use the bow saw.


SHARPENING SAWS

It is difficult as well as dangerous to cut with blunt saws. It is therefore very important to keep your saws sharp and in good condition at all times. When storing the saws wipe a light coating of oil over the blades to prevent rusting.

As soon as a saw loses its sharpness, before it is dull, either take it to a large hardware store for a 'saw doctor' to deal with it or sharpen it yourself.




To sharpen a saw, first set the teeth to the required angle, alternately left and right, using a special saw set which adjusts according to the fineness of the teeth. Then sharpen the edges of the teeth with a fine triangular file, removing as little metal as possible. Clamp the saw in a vice between two pieces of wood then file the tips of the blades, holding the file horizontally.




To sharpen the crosscut saw, file at a 60° angle following the original sharpened angle of the teeth. For a ripsaw, file at a 90° angle straight across the saw blade.

INTERIOR HOLES


To make an interior hole, such as a cut-out drawer handle, first drill a hole in the waste area. Remove one end of the blade of the coping saw or fretsaw from its fixing and thread it through the hole before re-fitting the blade to cut the interior shape.



The keyhole saw or padsaw, with a small narrow blade, is easier to use for cutting interior shapes because there is no need to undo the blade as with frame saws. It can also be used as a substitute for the sabre saw for cutting openings in plywood, as for example in the captain's bed project on page 60.



Frame saws for cutting curves. Left to right: bow saw, fret saw and coping saw.




chisels and gouges

There are various types of chisels such as bevel edge, firmer and mortise chisels for use on particular types of work. The mortise chisel for example has a stout, heavy blade for cutting out mortise slots. For most jobs only bevel edge chisels will be needed. Buy the $\frac{1}{4}$, $\frac{1}{4}$ and $\frac{3}{4}$ in sizes first, adding other wider chisels as you need them.

The handles are made either from a hardwood such as boxwood or ash, or from shock resistant plastic. The wooden handles may feel and look better, but the plastic ones last longer.

Gouges, in widths from $\frac{1}{4}$ to $1\frac{1}{2}$ in, have curved blades for cutting rounded shapes or grooves. There are two types of gouge. The firmer gouge, used for cutting grooves, has the ground bevel on the underside and the scribing gouge has the bevel on the inside.




USING CHISELS


Chisels cut with a wedge-like action so they tend to split the wood fibres apart as they go into the wood. When cutting along the grain be sure to cut in the right direction to prevent the point from digging into and splitting the wood.

Chisels are used mainly for paring away wood both horizontally and vertically for joints and shaping.

Always support the work well, hold it in a vice for horizontal paring and on a waste board for vertical chiselling. When cutting a halving joint, pare away slices from both sides with the cuts slanting upwards before final levelling. This reduces the risk of splits caused by cutting straight through from one side only. Guide the chisel with one hand while you provide the force with the other hand, or with a mallet.



Vertical chiselling is very similar. Clamp the wood onto a flat piece of waste wood and with your hand over the chisel, firmly pare away small slices at a time. When cutting across end grain like this, there is of course no danger of the chisel digging into the wood. At the same time, cutting across the grain requires more force so remove a small amount of wood at a time so that the chisel does not slip.




To cut a mortise joint, use a mallet for greater driving power. Using a chisel the exact width of the mortise slot, carefully chisel away the wood with firm taps from the mallet. Remove the bulk of the wood first by drilling holes within the waste area to the correct

SHARPENING CHISELS AND GOUGES


Chisels should always be kept razor sharp by frequent honing on an oilstone. Most chisels are ground at an angle of 22° to 25° by the manufacturer and usually honed on an oilstone to a second cutting bevel of 30°.



However, for all but the most heavy work, one long bevel at 25° for bevel edge chisels gives much better results. It takes practice to rub the chisel back and forth at a constant angle to get a flat bevel, so invest in a honing guide which holds the blade at the correct angle.




When sharpening all cutting irons for chisels, planes and spokeshaves, first hone the bevel side, then turn the blade over and rub back and forth a few times across the stone to remove the burr of metal that will have formed.



Firmer gouges are sharpened in a similar way, first by honing on the rounded edge of a special oilstone and then removing the burr on the inside with a curved slipstone.



Chisel points which are nicked or very worn must be reground on a grinding wheel. Grinding on a wheel leaves a curved, slightly hollow shape which must be honed flat on an oilstone.




depth and then cleaning out the slot with a chisel.

When cutting out waste to a marked or gauged line, remember that the bevel on the chisel forces the blade in at an angle away from the direction of cut. Always cut away a recess within the waste area first, then pare away gradually up to the line.

Use a gouge in the same way as a chisel, either using hand force or a mallet to cut away curved shapes.

To cut a curved groove use the correct width gouge and make successively deeper cuts until you can pare away the final layer in long, smooth cuts.




planes

In a furniture workshop, most planing is done by machine. The sawn planks are run over a surface planer or jointer to get one good face and a square edge from which all measurements are taken.

Hand planing requires considerably more skill and hard work but it is infinitely more enjoyable and rewarding. Several of the projects in this book are made from hardwoods like beech or maple which are usually available only in a rough sawn state and it requires a great deal of hard work to plane them smooth by hand. In this case it is probably best to have the boards planed by a woodworking shop or by the supplier.

Hand planes are nonetheless required for many jobs in the shop such as 'truing up' boards when joining several boards into a table top, for squaring off ends and for many other small jobs.




The cutting blade of a plane is usually either 2 or 2\(^2\) in wide and must be kept sharp by rubbing on an oilstone. The blade can be adjusted for a finer or heavier cut by means of a knurled knob. There is usually a lever which is moved sideways to adjust the blade parallel with the base.

The blade is attached to a cap iron which is mounted about $\frac{1}{16}$ in back from the tip of the blade depending on whether a

fine or heavy cut is required.

The cap iron breaks up the wood shavings and prevents the wood underneath from splitting along the board.






Left to right: try, jack, smoothing and block plane.

GENERAL PURPOSE PLANES


Modern metal planes are available in lengths from 8in to 24in. For most work only three or four planes will be needed. For 'truing up' boards and general levelling, buy a 22in try plane. For rougher work a 14 to 15in jack plane is very useful and for final surfacing the 8 or 9in smoothing plane is a good size. The small block plane is also very handy for planing ends of boards.

Before using any plane, make sure that the blade is razor sharp and that the cap iron is correctly set. Then sight along the bottom and adjust the lever to get the blade set parallel to the base. When planing, make sure the board is held on a firm, horizontal surface. For long pieces either use the bench stop mounted in the workbench top, or nail a batten to the bench as a stop

for the board. The plane will gradually take off high spots on the board until it is even. Remember that the longer the plane, the more accurate the work.



Work with a smooth motion applying even pressure along the whole length. Don't lift the plane up until the plane is beyond the end of the board.



On narrow edges it is difficult to keep the plane square. To help support the plane, hold one hand along the edge as a guide. Check the work frequently for straightness by sighting along the length and for squareness by using a try square.




PLANING A TABLE TOP




Several of the projects in this book involve gluing up boards to make wide, solid surfaces. After the joints have been glued or dowelled, it is best to finish by making the top smooth and even using a long plane such as a jointer or try plane. Depending on how much wood will have to be

removed to smooth the top, set the blade to take as fine a cut as possible. Then after scraping off any dried glue, start by planing the surface of the boards diagonally.

Plane in one direction then in the other, checking continually for high spots by holding the plane on edge or by using a straight edge.



After the top is fairly flat and even, plane along the length of the boards. Finish off the surface with a very fine setting to leave a smooth and even surface, ready for sanding.





Clockwise from top right: rabbet, shoulder and combination plane with blades.


RABBET PLANE

The blades on ordinary planes don't extend the full width of the plane so they can't be used to cut rabbets.


The rabbet plane is extremely useful in cabinetwork. Many of the projects in this book require rabbets to hold back panels, for example the bookcase on page 114.

A portable router is the easiest way to cut a rabbet, but for the experienced woodworker the rabbet plane is just as quick. The rabbet plane has an adjustable fence for the width of the rabbet, and a gauge to set the depth. For through rabbets, which extend to the end of the board, use the blade in the normal position and run the plane along the wood, pressed firmly against the side.


It takes a little practice to get this right so make a few trial runs on scrap pieces before planing your piece of work.



For stopped rabbets, chisel out the first inch or so, then place the blade in the forward or bull-nose position and cut the rabbet in stages beginning at the chiselled end and working gradually back toward the other end.



MAKING A SHOOTING BOARD




The shooting board is a useful holding device for accurately planing the board ends or the edges of thin, awkward boards. Make the base from two ¼in thick hardwood boards or from plywood, 30in long. The 6in wide top board is glued and screwed to the 9in

wide base. The stop is made from a 1½ in square section of hardwood and screwed absolutely square to a groove cut in the top. To use the shooting board, hold the wood firmly against the stop and run the plane on its side so that it takes off fine shavings.


SHOULDER PLANE

The shoulder plane is a small plane for cleaning up the shoulders of tenons and other joints.

Adjust the depth of the blade with the screw at the back. To remove the blade for sharpening, pass it through the bottom.



SPECIAL PURPOSE PLANES
Two kinds of plane which may




moulding plane. The combination plane is a multi-purpose plane which comes with interchangeable cutters for cutting grooves, rabbets, mouldings and even tongue-and-groove edges. It is rather expensive, but for a furniture maker who relies on hand tools it is a versatile plane.

There are various other planes used for special jobs, such as adjustable compass planes for planing along arcs, and plow planes for making grooves.

Moulding planes take the place of the router which is widely used to cut decorative edges on furniture. Wooden moulding planes are still available with variously shaped blades to cut moulded edges by hand.

Cabinetmakers once made their own moulding planes, grinding the cutters to shape from old files and fashioning the body of the plane in beech or similar hardwood.




clamps

Clamps are essential for even the smallest woodworking jobs. They not only hold wood together tightly while glue sets to form a permanent bond, but clamps are frequently used to hold pieces leaving both hands free to work. They are also useful during assembly to pull and hold joints together and to straighten out framework constructions.


Probably the most frequent use of clamps is to hold work down securely to the bench while you saw, rout, drill or chisel it. A workshop can never have enough clamps of various sizes. You always seem to need one more at a critical moment. But it is best to start off with three or four clamps and then add to your collection as need arises rather than investing in expensive clamps before you know exactly what you require.

There are various types and sizes of clamp. The most common small clamp is the C or G-clamp which comes in sizes from 2in to about 8in maximum opening size. The basic tool kit should include at least two C-clamps, one 6 or 8in and one about 4in.




Another useful type of clamp, in sizes from 4 to 24in, is the fast action type which can be opened and closed in one movement. This type is fitted with plastic pads on the ends of the jaws so no additional padding is needed to protect the work. The handle can be given extra force by inserting a screwdriver or bar into a hole.


The old-fashioned wooden handscrew is particularly good for clamping at an angle.




The two screws operate separately along the two wooden heads which can be set at any angle.



To clamp large pieces such as boards to make up table tops, bar clamps, also known as sash clamps, are required. The best type has an integral bar with holes to take a locking pin on the moveable head. As a less expensive substitute, buy separate components and make




Clockwise from top: bar clamp, hand screw, pipe clamp heads, C-clamps, small and large fast action clamps.



Use different lengths of pipe or wood and with just a few sets of clamp heads, you have a complete range of bar clamps from, say, 2ft to 7ft.

USING THE CLAMPS




The most important rule about clamping is to always put a sturdy piece of waste wood under the clamp heads, unless they are already protected with plastic pads, to avoid leaving indentations on your work. Do it automatically whether you are clamping a piece of plywood down as a guide for the saw, or holding two components together while glue sets. That way you will not mark the work.

the other on lengths of plumbing

pipe. The advantage of these

clamps is that you can make

them as long as you wish.




Notice that the fast action clamps which are available in up to 24in lengths do not require padding. They are often used to hold pieces firmly together leaving two hands free to do the work.

When gluing boards up into a single surface, use several bar clamps and alternate them under and over the surface to keep the boards flat. It is a good idea to use a stout batten under the clamp heads along each side, both as padding for the clamp heads and also to spread the clamping force evenly along the length.

Without dowel pegs in the edges the boards tend to slip

clamps

SPECIAL CLAMPS





There are many special clamps such as mitre clamps and web clamps which are used for specific jobs. Mitre clamps are used in sets of four to clamp a mitred frame together. Alternatively, you can make a

simple string device with cut corner blocks which makes the job even easier.

A web or band clamp is a special device which is convenient for gluing

awkwardly shaped objects. It is often used when repairing broken chairs to hold the legs together until the glue sets.






HOMEMADE CLAMPING DEVICES

over and under as with bar

Clamps are expensive and it is often necessary to improvise for jobs which don't justify buying additional clamps for the workshop. Instead of bar clamps, you can screw stops onto stout battens, then tap pairs of hardwood wedges between to tighten up the boards. Place them alternately

clamps.

Another old-fashioned device suitable for light work is shown in the diagram. The battens A and B are moved sideways to bring them closer




slightly as you apply clamping pressure. This results in an uneven surface which requires considerable work in planing flat. To minimize slipping, apply only modest pressure and pay close attention to the joints, gently tapping them flat with a rubber mallet if necessary as you tighten up the clamps.

Lay a straight edge across the boards as a final check for flatness when you tighten up the clamps.




Also use bar clamps to hold frameworks together until the glue sets. Clamp straight across the joints using softening to

protect the wood and tighten slowly pulling the joint together gradually until it is tight. You may have to add a clamp from the other side to keep the joint tight on all sides. Put the clamps at a slight angle to correct the frame if it is not square.



together. When they are tight enough, a nail or screw next to A and B holds them in place until the glue has set.

Another clever device uses wedges, again placed between two strong battens screwed to a base. Alternatively, screw one batten to the workbench and use the vice to tighten up against the other side.



shaping tools

SPOKESHAVES AND DRAWKNIVES

For shaping irregular surfaces there is no substitute for hand tools. Even the most modern furniture factories employ craftsmen who are skilled with the spokeshave and drawknife and can use these tools quickly, with an experienced and accurate eye.

The drawknife is the most basic shaping tool and is used




to remove large amounts of wood or to get a piece roughly to shape.


The spokeshave is a finer tool and if kept sharp and properly set, is capable of producing a finish on hardwoods which will require no sanding. There are several types of spokeshave with either wood or metal handles. The metal variety can be plain or adjustable. The blade on the adjustable type can be set by fine screws. It is a precision instrument well worth buying if you will be working with hardwoods.

USING A DRAWKNIFE

The drawknife is ideal for removing large amounts of wood in a short time. It must be kept razor sharp by honing the bevelled edge with a handheld oilstone and then rubbing with the stone to remove the burr on the underside.



Always cut along the grain to avoid digging into the wood. Hold the tool with both hands and control the cutting angle with the thumbs. The drawknife can be used bevel downwards for light cuts or for cutting convex shapes, but it is usually used bevel up.



USING A SPOKESHAVE

As with all cutting tools, the success of working depends a great deal on keeping the blade very sharp. If you use the spokeshave frequently, sharpen the blade often as you work. The blades of metal-handled spokeshaves are flat so they can be sharpened just as plane irons, but those for wooden spokeshaves must be honed with a small hand-held slipstone.








Use the spokeshave with a light wrist action in a slight shearing or diagonal direction to give a smoother surface. Work from the middle of the curve toward the ends. On the screw-adjustable types, adjust the set of the blade with both setting screws until you get just the right thickness of shaving.

On the wooden type, the tangs which protrude through the body must be tapped gently with a hammer to get the adjustment just right.

RASPS, FILES AND SURFORMS

You can also use rasps and files for shaping wood. The edges are rounded on many of the projects in this book to make them look softer. This can be done equally well with a Surform, rasp or a file. The rasp is a very coarse file used for preliminary shaping to remove a large amount of wood. Buy a 10in long rasp with one side rounded and one side flat for all-purpose work.




The Surform is a more recent shaping tool and is an improvement on the conventional rasp. The replaceable blades have perforated, raised teeth so that the sawdust can escape.



The variously sized blades are held in an array of handles to cut flat or round shapes. They are excellent for removing wood quickly but they must be used carefully.



Use Surforms with the blade set either for a pushing motion like a plane or for a pulling motion for rounded shapes.



Files give a smoother cut than rasps and Surforms and are used for finer work or for cleaning up after preliminary shaping. Various types are used but the most useful general file is the bastard double cut which gives a medium cut.


All files and rasps should be kept clean and hung up when not in use. To remove the clogged wood from the teeth, use a wire brush or a wire file card, or if the tool is especially clogged gently heat it over a flame to burn off the dust.



screwdrivers

Besides hammers and saws, the screwdriver seems to be the most frequently used tool in the workshop. It should of course be used only for turning screws and not used to prise open cans of paint and to do odd jobs. The main types of screwdriver are the standard screwdriver, the ratchet type, the spiral pump action ratchet or Yankee screwdriver, and the Phillips screwdriver.

All of these are available in different lengths from about 3 to 16in long. It is important to notice that screwdriver tips also come in a range of widths and to choose a screwdriver to







match the screw you are driving. For fine work, get into the habit of using the right sized tip for each job, to avoid damaging the screw or the wood, see left. The same is true of Phillips screwdrivers which are used for screws with cross slots in the head.

A few sizes of screwdrivers will be adequate for most work. It is always useful to have one really long screwdriver for large screws and one very small one. A ratchet screwdriver allows you to set the blade for forward, normal or reverse action and allows you to turn the screw with one hand without having to change grip.

The pump action or Yankee screwdriver is very convenient. It comes in sizes up to 28in long and each size has interchangeable blades for variously sized screws. It can be used closed like an ordinary screwdriver for better control or opened full length with



pump action. To use it this way, first put the screw in a few turns so that it is secure, then place the tip of the screwdriver in the slot and push down on the handle.




But be careful as the blade can easily slip and damage your work or injure you. Remember that after frequent use all screwdriver tips become rounded and dull, which increases their tendency to slip. Always keep the tips ground square and sharp to give a good grip.

miscellaneous hand tools

PLIERS AND PINCERS

There are many other hand tools and devices which are sometimes required in woodworking. Pliers and pincers for example will come in handy for a variety of jobs in the workshop from pulling out nails and staples to stripping wire for fitting a new plug.

An adjustable wrench is also indispensable in a workshop for tightening nuts on machines and for fixing bolts in wood. Buy a good quality adjustable wrench as it will last longer and give better service than a cheap one.



CABINET SCRAPER

Cabinet scrapers are pieces of thin, flat metal available in various sizes and used to give a very fine finish to hardwood surfaces. They are inexpensive to buy, but are very useful for fine work. They must be sharpened carefully with an oilstone file and burnisher to bring up a burr along the



bottom cutting edge. Use the scraper with both hands, curving it slightly as you push it along the grain. A sharp scraper should bring up a fine shaving of wood, not just dust.


WOOD SCREW AND TAP

Another interesting device which opens up all sorts of possibilities is the wood screw box and the matching screw tap. Although it is available only from specialist suppliers and is quite expensive, it allows you to make threaded wooden screws and matching threaded holes. You could for example make wooden bolt connectors and matching nuts.



MITRE BOX AND MITRE BLOCK


There are various devices for cutting accurate mitres with a tenon saw. The mitre box is





Sanding blocks are made of cork or felt-faced wood in a convenient size to fit the hand, using a quarter of a standard sheet of sandpaper. You should always use blocks rather than your bare hand to back up the sandpaper to apply even pressure. To get into moulded shapes, make up small sanding blocks using dowels or wood scraps.

inexpensive to buy and quite accurate to use. Screw a long base plate to the base of the box to support the work and to avoid marking the mitre box.




POWER TOOLS AND THE HOME WORKSHOP


workbench and accessories




VICES



Vices are available in various weights and sizes. The woodworker's vice is a heavyduty model which bolts or screws onto the bench from underneath. It is available with or without a quick release mechanism which allows you to open and close the vice by just pushing or pulling instead of turning the handle. The face plates should be fitted with pieces of plywood so that the work is not damaged.



You can also buy vices which clamp onto the bench or table



top. These are not as strong but will hold light work very well. For planing, use a bench stop which fits into the bench top. The hardwood block is mounted from underneath and raised through a slot cut into the top of the bench to hold the work steady.



Woodworkers frequently use clamps to hold the work down on the bench. This is a good technique for large pieces which cannot be held by a vice. Benches and vices are expensive, but you can use substitutes such as trestles, Workmate or a sturdy table.

TRESTLES AND SAWHORSES

Trestles or sawhorses are indispensable in a workshop. They can be made the traditional way using softwood sections, or they can be put together quickly using two pieces of chipboard hinged together as shown on page 108.

Use the trestles or sawhorses in

THE WORKBENCH AND SIMPLE SUBSTITUTES


Much of the furniture in this book can be made on a temporary work surface but it is much easier if you have a workbench set up in a spare room, garage, garden shed or basement. It is very convenient to have a workshop area, however humble, where you don't feel inhibited about sawdust and where you have enough space to work on large sheets of material.


A woodworking bench is important because it gives solid support and has a vice to hold work steady. There are complete instructions for making a solid screw-together workbench on page 136. The bench has a plywood top which can be replaced when it gets too worn. Alternatively, you can buy a bench made from a hardwood such as beech with a side vice for holding small pieces and also an end vice for holding longer pieces while planing.


THE WORKMATE

The Workmate is a fairly recent invention which is becoming extremely popular and for good reason. It is sturdy and has a built-in vice which grips work of most sizes while you work, leaving both hands free. When it is not in use, it folds flat so that it can be hung on the wall out of the way.











When crosscutting long heavy pieces, it is a good idea to turn one trestle sideways along the wood and set the blade so that it just cuts through the wood. Position the cut so that both



workbench and accessories

ends are supported to prevent the saw from jamming or the wood from splitting.

Use the trestles for working on large sheets. To saw a sheet of plywood or chipboard for example, lay a couple of stout boards on the trestles under the sheet on each side of the cut. Climb up on the surface if



the cut.

To assemble work or for doing finishing work like sanding, lay a piece of plywood on the trestles and cover it with an old blanket to protect the surface of your work. A pair of trestles can also be used as a workbench. A solid door or 2in thick boards can be screwed down to make the work surface.





necessary to reach the end of

STORING WOOD

Storing wood is always a problem. If you do work continuously, the scraps will accumulate very quickly. It is always difficult to throw pieces of wood away so the best method is to keep a cardboard box for scraps and to empty it and start again when it fills up.

For storing larger pieces, either make a rack on the wall for storing boards flat with enough supports to prevent sagging, or store the pieces






vertically against a wall, first sorting them into lengths.

Store large sheets in the same way, standing them on edge leaning against a wall. Be careful to store them so that they cannot fall over. It is a good idea to provide a stop to



wall. Lumber core plywood must be stored flat.




Overhead racks can be a nuisance because the wood is hard to reach and pieces tend to get buried. They can also be dangerous unless they are strong enough to take the full weight of a load of wood.

Dowels, mouldings and other pieces of hardwood should be stored in a warm, dry place and should not be subjected to changes in temperature and moisture or they may warp.


STORAGE IN THE WORKSHOP

All tools are better hung up within reach rather than slung in drawers where they are easily blunted or damaged. Perforated hardboard is the best material to use as a base for hanging tools.




Draw the outline of each tool on the board and screw in hooks or nails before hanging it, so that you can replace tools in the right place.

You can also make a slat wall unit similar to the one shown on page 22 for hanging up your tools. For chisels and screwdrivers make a simple rack from lengths of wood



with dowel dividers as on the workbench on page 136.

For those tools which you want to keep locked up or away from dust, make a wall-hung tool cabinet such as the one shown on page 140.



There are also numerous racks and plastic drawer systems which you can buy to house screws and hardware and all the other small bits which inevitably accumulate in a workshop.

the circular saw

The portable circular saw is a worthwhile investment for anyone who does a lot of woodworking. You can fit a saw attachment to the electric drill, but it isn't very powerful and it's time-consuming to switch back and forth from saw to drill while you are working. The best answer is a 5in or preferably a 7¼in circular saw. The 7¼in diameter model is powerful enough to cut cleanly through fairly thick softwood and

hardwood and through heavy plywood sheets. Also with more power you get greater accuracy and safety. The more powerful saw will cut straight and clean and has less tendency to bind in the wood or kick back.

The essential features of the circular saw are the 1. motor, 2. blade, 3. guard, 4. adjustment knobs, 5. base plates and 6. detachable rip fence.



- 1. The motor should be at least he to do most medium work. For heavier construction work a larger, 2hp model will be necessary.
- The blade is locked on the shaft or arbour. There are various types of blades available for different jobs.
- 3. The spring-loaded guard is an important safety feature. It comes down automatically to cover the blade as soon as you move the saw away from the work. It is also raised automatically when you start a cut.
- 4. There is a knob for adjusting the depth of the cut

- indicated on a scale on the side of the saw. On some saws there is a second knob for locking the blade at any angle up to 45° to allow for bevel cuts.
- 5. The base plate rests on the wood as you push the saw along. Keep the base plate clean and rub a hard wax candle over it occasionally to reduce the friction. Notice the small notch at the front of the base plate ahead of the blade which is used as a guide when you are using the saw to cut freehand.
- The rip fence is adjusted and locked in position for use in guiding the saw parallel to the edge of the work.


CHOOSING THE RIGHT BLADE

Blades are available in various diameters to suit specific saws and in various types for specific uses.

The rip blade and crosscut blade are used for the two basic functions, cutting along and cutting across the grain of the wood. The combination blade both rips and crosscuts.

The planer blade is also a combination blade but it is hollow ground to leave a very smooth finish. Carbide tipped blades can also be used for both ripping and crosscutting. The hard tips stay sharp much longer than ordinary blades and cut more cleanly, even in harder woods. These are much more expensive than the ordinary blades but they soon pay for themselves.

You can also buy special blades for cutting through



floorboards and the occasional nail, and blades which cut non-ferrous metals. Refer to a manufacturer's catalogue for a complete list of available blades.

rough lengths, use the saw

front of the base plate as a

guide. You can also rip free-

freehand with the notch at the

hand but it is more accurate to


fit the rip fence as a guide for

cutting parallel to the edge.


Notice the strip of hardwood

USING THE SAW


You can use the circular saw in various ways; freehand or with guides for ripping or crosscutting, with the blade tilted for angled cuts or with a shallow set to make grooves or saw kerfs. You can also mount the saw in a stand to make a very useful table saw.



For quick crosscuts, for example to cut a board into




If the cut is too far in from the edge for the rip fence to reach, clamp a straight edge or a straight piece of plywood to the work as a guide.




the circular saw


MAKING OTHER CUTS



Make angled cuts in the same way, running the saw against a guide. To make grooves, set the blade to the required depth and make a series of cuts moving the fence a short distance for each cut.



You can bend wood by first cutting a series of closely spaced grooves called kerfs, along the inside to within about ¼in of the bottom face. Test for depth of cut and for spacing of kerfs to get it right.




CONVERTING TO A TABLE SAW


To make the portable saw into a table saw, you can buy a special metal table sold by the manufacturer, but this table is quite small and is not adequate for cutting large sheets.




Make your own table out of a piece of 30 × 40in plywood ¼in thick, with stiffening battens screwed underneath. It can be nailed or screwed to a pair of sawhorses or placed on its own structure. Cut a hole in the plywood top to allow the saw blade and guard to pass through, then bolt the saw to the underside with



Always disconnect the power before changing blades. Then remove the locking nut with the wrench or Allen key provided with the saw. If necessary hold the blade stationary against a block of wood or the edge of the bench when undoing the nut.



Refit the new blade so that the arrow printed on the side of the blade is pointing in the correct direction. Then tighten




the locking nut with the wrench provided. The thread of the tightening nut is reversed so that it will tend to tighten when the saw is working.

countersunk machine screws. To make a crosscut fence, cut a 2in wide groove exactly parallel to the blade about 12in away, then make an absolutely square fence with a batten underneath which fits snugly

in the groove to allow it to run back and forth.

The rip fence can be set by measuring for parallel each time, or it can be made to run in two grooves cut square to the blade. When using the saw, wedge a block of wood into the handle to keep the switch on, then connect the cord to an extension cord with a switch wired into it, which should be placed nearby for quick access.




MAKING AN 8FT LONG STRAIGHT EDGE GUIDE

Screw a 12in wide strip of \$\frac{1}{2}\text{in thick plywood to a 5in wide board of \$\frac{3}{2}\text{in plywood.}\$

Screw from underneath and countersink the \$\frac{1}{2}\text{in no.6}\$


screws to leave a smooth surface.

Then clamp this over the edge of the bench and run the saw along the 3 in board, cutting off the 1 in piece.




To use the guide, clamp it to the work with the edge of the in plywood flush against the measured marks.

To make a shorter version of the guide for crosscutting and



cutting smaller panels of plywood, screw a 3in piece of plywood underneath, positioned absolutely square. This is then used like a try square against one mark to make square cuts.

table saw



Whether you buy a table saw, or improvise with a plywood stand and a circular saw (see page 209). it will prove to be the most valuable tool in the workshop. Almost all the cutting work can be done on it, not just crosscuts and rips, but with a little ingenuity you can also cut bevels, tongues-and-grooves, rabbets, tapers and so on.

For most people the job of cutting boards accurately to length so that they are truly square isn't as easy as it sounds, and yet the success of every project depends on it. With a table saw, you can do it easily and automatically.

The main features of the table saw are 1. motor assembly, 2. blade guard, 3. splitter and anti-kickback fingers, 4. rise and fall control, 5. tilt control and of course the table


itself with 6. sliding crosscut and mitre fence, and 7. rip fence.

It is important to select a table saw which is sturdy and robust, and which has all the necessary safety features. Don't buy a cheap saw, it isn't worth it, because the resulting inaccuracies in your work will waste more wood than it would cost to buy a good saw.

The more power a saw has, the better. You should avoid one with less than $\frac{1}{2}$ hp. The effective cut of a saw blade is roughly $\frac{1}{3}$ its diameter, so an 8in blade will cut $2\frac{2}{3}$ in material.

It is important that the area of the table around the saw blade is filled in with a metal or wooden insert, to prevent small pieces of wood from getting wedged next to the saw blade. The saw should have






easily operated controls for raising and lowering the saw blade and a separate control and indicator for tilting the blade.

Most good saws have all these features and more and it's a good idea, as with all tools, but particularly with this one, to buy the best you can afford.

SAFETY

The table saw is a dangerous tool and is always treated with respect and a small measure of fear even by professionals who have been in the trade all their lives. Many of the serious accidents happen on the table saw.

It is very important to develop the right habits and never to take chances with the saw. Safety laws vary from country to country but it's always wise to have a guard and splitter and anti-kickback fingers fitted. During ripping some boards release their built-in tension and spring together closing up on the blade. This causes the saw blade to throw the piece of wood backwards towards the operator with tremendous force. This is prevented by the splitter and anti-kickback fingers.





The best way to prevent accidents is to keep your hands away from the blade. Use a push stick every time you rip a board and when you are cutting small pieces, clamp them to the fence rather than gripping them dangerously close to the blade.

Another safety point worth noting is the use of a support behind the saw to prevent long boards which are being ripped from tipping down and lifting the other end up into the saw blade. Make a table to stand behind the saw or, even better, a roller on a trestle as shown.





table saw

SAW BLADES

The saw blades used in the table saw are basically the same as those used in the portable circular saw. The crosscut, rip, combination, and carbide tipped blades are shown on page 208. In addition, you can use a marking head and also a dado head blade for cutting grooves and dados. It has two outside cutters and inside blades of different thicknesses to cut grooves of varying widths.




USING THE TABLE SAW


Crosscutting




The main function of a table saw is to crosscut boards accurately and squarely. Hold the work firmly against the crosscut or mitre fence as you push it slowly through the saw. It's a good idea to attach a board to the mitre fence to give better support. Always



support small, difficult to hold pieces with a stick or by clamping them to the fence.




To cut off several identical lengths, clamp a stop to the crosscut fence as a guide. For shorter pieces, clamp the stop to the rip fence instead. Place the stop well in front of the saw blade so that the scrap pieces will not bind between the stop and the blade.



It's quite easy to make tenons, housings and halving joints on the table saw. Use a piece of scrap as a trial piece to set the saw blade at the required depth. Make a cut and measure it to make sure it's the correct depth. Then set one stop on the crosscut fence and the other on the rip fence as guides for the first and last cuts. Remove the waste as shown below with successive runs of the saw. Again use a piece of scrap to make sure the width of the halving notch or the tenon is exactly right and make any fine adjustments necessary before cutting the pieces.


Cutting mitres

To cut mitres, set the fence at 45°. Test by cutting two mitres and holding them together against a try square. They should make an exact 90° angle.




In cutting mitres, the work tends to move or creep slightly if not held firmly. To prevent this, either clamp a small scrap to the fence as a stop, or alternatively hammer a couple of brads from the back of the wood fence so that their heads just protrude to keep the work from moving.







You can cut mitres to make picture frames or doors (see cupboard on page 155). For hexagonal or other shapes, set the mitre gauge to the appropriate angle and use a stop to make all the pieces identical.




To cut boards along their length use the rip fence. Adjust it for each cut by checking the scale indicator or by trial and error against a mark on the piece to be cut. When ripping, always push the wood firmly at a slow constant rate, guiding firmly against the fence with the left hand or a push stick.

If the board is wide enough, you can push it through with







through. Push it straight

table saw


continued from page 211


that it won't bind against the fence and get thrown back. For smaller pieces, use two push sticks; one to push from behind and one to keep the piece down and against the fence.

Remember when ripping long boards to support the end behind the saw to keep it from dropping down which would result in the front end jamming against the blade.

When ripping boards on their edge into thinner boards, called resawing, it may be necessary to make two runs if the sawblade isn't large enough to cut it in one. Make the first cut then turn the board over, keeping the same side against the fence, to make the second cut.

When resawing it is a good idea to hold the work down with a special board clamped to the fence. Cut the board with a coping saw or sabre saw to produce feathers. With the board clamped at the right height, the feathers allow work to be pushed through but prevent it from being thrown back.






Make the push stick out of a piece of straight hardwood or good quality \(\frac{3}{2} \) in plywood. Follow the diagram to cut out the shape, then round the

handle with a file to give a better grip.

Make another push stick with a more delicate tip for guiding the work against the fence when ripping small pieces.




Cutting wedges


Wedges have many uses in the workshop, such as for making the homemade clamping jigs on page 203. To cut wedges,



hold the wood in a jig or holder made from a piece of $\frac{3}{4}$ in plywood.




To cut rabbets, set the saw blade to the required depth and cut along the edge of the board first. Make the second cut with the board flat.



Make bevels and mitred edges simply by tilting the blade. When making mitre cuts it's a good idea to clamp a piece of wood to the rip fence and raise the blade so that it just cuts into it. Then rip the piece as usual.

To cut mitre joints reinforced with a plywood spline, first cut all the pieces of wood at 45° as shown, then lower the blade to cut the groove the width of the sawblade. The groove should extend about ¼in into each side.





side.

Cutting tapers

To cut tapers to make tapered pieces for this trestle table base for example, make a jig out of a jin plywood which holds the piece at an angle while you push it through the saw against the rip fence.

There are many other possibilities for using the





versatile table saw. Jigs can be improvised as the need arises. You should always save a jig for another occasion, marking it and hanging it in a place reserved for jigs. Every workshop accumulates many of these jigs to make the next job quick and easy.

Many other cutters can be fitted to the saw, such as dado heads, shaped moulding cutters and sanding disks to extend the use of the table saw, making it an extremely adaptable piece of equipment. Check manufacturers' catalogues for accessories.

radial arm saw

The radial arm saw is an extremely useful and versatile machine. With the right attachments it can become an entire workshop. It will crosscut and rip at various angles doing away with the need for a table saw and because the blade can be rotated to almost any position, it will cut grooves, circular shapes, rabbets, finger joints and a wide variety of other shapes.

You can buy attachments to make it into a shaper, a sander, a planer, a drill or a jigsaw. But keep in mind as with all types of multi-purpose tools, that it takes time to change over from one function to another. So if you use the machine frequently, it is best to use it mostly for crosscutting for which it is best suited and buy other tools to do shaping, sanding and so forth.






The radial arm saw is easier to use to make crosscuts than the table saw, since the work remains stationary. The saw rides on an overhead arm and when making crosscuts it is pulled towards the operator over the work which is held firmly against the fence.


Ripping

The motor and saw blade are rotated in a number of ways to make different cuts. For ripping, the saw is rotated 90° and clamped firmly. The work is fed into the blade against the rotation, with the kickback fingers against the blade to prevent the work from being thrown back.

The saw can be set in two different positions for ripping. To cut narrow pieces, set it so that the blade faces back toward the column. For wider cuts, up to about 18in, set the saw in the other direction with the blade facing outwards. To cut even wider pieces it is




necessary to move the wooden fence further back to gain slightly more space for maximum clearance.




OTHER RADIAL ARM SAW CUTS

Halving joints

Both pieces are cut at the same time. Use stops to the left and right as guides.




Grooves and housings



Cut grooves and housings with successive cuts using an ordinary blade, or with one cut using a dado blade.


Kerfing

To bend wood, make close crosscuts to within about 1 in of the bottom face.




Rabbets

Rabbets are cut with the ordinary saw blade, or better yet, with a dado blade, set horizontally.




Mitres are easily cut by setting the crosscut to 45°. Use a 45°




Bevel cuts

With the radial arm saw it is also easy to make bevel cuts both in crosscutting and in ripping. Tilt the blade to the required angle indicated on the bevel scale and lock the saw firmly in position before making the cuts.

To make horizontal cuts such as grooves, finger joints and rabbets, swivel the saw so that the blade is horizontal.



electric drill



There are several types of drill available. The basic single speed drill is adequate for most woodworking and household jobs but the two or four speed drill gives more flexibility in drilling different materials.

Some drills have a hammer action which causes the drill to hammer back and forth as it rotates, making it go through hard masonry materials much more easily.

You can extend the use of a drill into a mini-workshop by fitting it with many different attachments. For example, the


drill can power a circular saw,

drill can power a circular saw, sabre saw, lathe or mortise attachment, or it can be fitted to a horizontal drill stand with a sanding disk, wire brush, or grinding wheel.


Keep in mind though that it takes time to change the drill from one use to another. For frequent use it may be better to buy integral tools like a portable circular saw or a sabre saw as they are more powerful than the drill attachments.

USING THE DRILL


To fit a drill bit, open the jaws of the chuck, insert the bit then lock the jaws with the chuck key.



Always centre punch holes to give an accurate guide for the drill bit. Holding the drill



upright requires practice. You can stand a try square beside the drill as a guide, but a more accurate method is to get a second person to sight in one direction while you check the other.



The best way to use the drill is to mount it in a vertical stand. The stand holds the drill firmly and absolutely vertical. It also allows you to hold the work with one hand while you lower the handle to bring the drill down to the work. The adjustable depth stop allows you to drill holes to a predetermined depth.

DRILL BITS

Several types of drill bit are used in power drills. The shanks are usually round although flat bits for drilling large holes have triangular sides for a better grip.

Drill chucks come in three sizes $-\frac{5}{16}$ in, $\frac{3}{8}$ in and $\frac{1}{2}$ in. Check the capacity of the chuck on your drill before you buy a bit or attachment. Taper shanked auger bits are intended only for use in a brace, never try to fit them into a power drill.


A. Twist drills

Twist drills, available individually or in sets up to in in diameter, are strictly intended for metalwork but they are used extensively in woodworking, particularly for drilling small holes such as screw clearance holes.

B. Dowel bits or machine bits
These are special wood drilling
bits available in diameters from
\$\frac{1}{2}\$ in. They are used for
drilling clean, accurate holes
for general work, but
particularly for dowel jointing.


C. Flat bits

Flat bits are only for use in power drills. They are inexpensive and available in sizes from ½in to about 1½in in diameter with extension shafts for drilling very long holes.



PLUG CUTTER

Plug cutters are used to cut small plugs which can then be prised out of the wood with a screwdriver and used to fill counterbored holes over screw heads. They are available in various sizes up to ½in in diameter. You can use plugs in a contrasting wood for a decorative effect or a matching plug which will be hardly noticeable.




When drilling holes to a specific depth, you can also use a depth stop made from a piece of dowel or 1 × 1in scrap, cut to length to suit the required depth (page 195).

The drill stand is also useful for drilling out the waste in mortise slots before cleaning out with a chisel. Hold the work by hand or in a special vice if it is too small.

Alternatively, use a C-clamp.

To drill holes in dowels, cut a V-shaped notch in a small block and drive in a couple of brads leaving the heads protruding to hold the dowel.



To drill at a 45° angle, make a jig as shown on page 24 for the kitchen work island.


sabre saw



The sabre saw or power jigsaw is a versatile portable tool. It is primarily used for cutting out irregular shapes in solid wood and in plywood.

The blade cuts at speeds which vary from 2500 to 4500 strokes a minute. It cuts on the upstroke so cutting should always be done with the less attractive face of the wood facing upwards so that the ragged edges formed by the exit of the blade will not show.


Some saws have variable speed controls and bases which tilt for making bevel cuts. However, the most important



characteristic to look for is an orbital cutting action which is preferable to the straight up and down action. It produces a cleaner cut with less blade wear.


USING THE SAW

Hold the saw firmly when sawing freehand to cut circular or irregular shapes, guiding the saw by eye along a marked line.




A good saw will handle plywood 3/4 in thick and hardwoods up to 1½ in thick.

To make straight cuts, use the rip fence or clamp a straight edge to the work as a guide.



For crosscutting, make a T-square guide out of two pieces of wood glued and screwed exactly at right angles. Leave the end overlong as shown then cut it off with the saw. The cut end can then be quickly located against a mark on the board.



MAKING AN INTERIOR CUT

To make an interior cut, start by drilling one or more holes in the waste area. Alternatively, start the cut by tilting the saw forward, holding it very firmly while the blade cuts through the line.



CHOOSING BLADES

Use coarse blades with fewer teeth per inch for rough work, but change to finer blades for more delicate work. Special hollow ground blades with no set give a very smooth cut but are not intended for constant use. There are also blades for cutting metal, linoleum and a variety of other material. Refer to manufacturers' catalogues for complete details of blades to fit your saw.

sanders

Use a power sander to make the laborious work of sanding easier. There are several types intended for different jobs and suitable for all but the most delicate work.

ORBITAL SANDER

The most useful sander is the orbital type. It works with an oscillating motion so it can be used equally well with or across the grain.




Special sized sanding sheets can be bought in various grades, or cut from ordinary sheets of good quality sandpaper. The paper is mounted in grooves at each end of the sander. The bottom of the sander is covered with a replaceable rubber pad which provides a soft base, convenient for sanding corners and edges.

If the paper becomes clogged the orbital sander can leave small circular marks on the surface of the wood which are difficult to remove, so always replace the sandpaper as soon as it is necessary.

BELT SANDER

The belt sander is intended for rougher work such as stripping paintwork. It can also be used, instead of a plane, to level off boards which have been glued together to make a table top, such as the pine table on page 12, providing not too much wood needs to be removed.



Work diagonally at first, then along the boards using a coarse paper. Finish off with a smooth belt along the grain. It takes practice to use this heavy machine on delicate tops without digging in. Keep it moving around with the weight evenly distributed.






To sand smaller pieces, you can clamp the sander upside down in the vice and hold the work against the moving belt. To change the belt, push down on the front wheel to release the old belt, fit the new belt, then force the wheel back in position to tighten the belt.

router


The router is probably the least understood of all the power tools, which is strange because it is so versatile and is certainly the most enjoyable tool to use. Fitted with different cutters it will cut grooves and housings, make circular shapes, mould edges, cut rabbets and dovetails and even trim plastic laminates.



The router is basically a motor with a vertical shaft that holds the cutter. The base plate adjusts up and down to expose more or less of the cutter so that you can vary the depth of the cut.

The cutter rotates at very high speeds producing a fine, smooth finish. You can buy a

low priced, lightweight router which will do most jobs very well, but for frequent use buy a commercial model with at least ½hp motor. Buying a router is a compromise between the weight, which should be as light as possible, and the price, which varies enormously from one end of the range to the other.



MOUNTING THE CUTTERS

Mounting the cutters is easy. First shut off the power and unplug the machine. Then remove the base plate and with the wrench provided, loosen the locking nut. Some routers have removable collets in the shaft so that they can take shafts of both $\frac{1}{4}$ and $\frac{3}{8}$ in diameter.




Push the cutter in all the way then tighten the locking nut before finally replacing the base plate.

USING THE ROUTER

The router is often used to make grooves or dados like the housing grooves for the roll top desk on page 128.

To make grooves, fit the router with a straight cutter preferably of the same

diameter as the width of the groove. To make grooves across a board, use a homemade straight edge guide which is clamped to the work. Make it out of two pieces of ¾in plywood, then try it on a piece of scrap wood. The groove made in the front piece can then be used to line up all subsequent cuts.



If you are using a smaller bit than required, say a ½in diameter bit for a ¾in groove, add a second straight edge as a guide for the other side.

The cutter rotates clockwise and it should always be fed 'into' the work or it will tend to pull away.

CUTTERS

You can buy a wide variety of cutters for specific jobs, but they are quite expensive so it's best to buy them as you need them and build up a supply over the years.

Cutters are usually made of high speed steel which can be re-sharpened. They are also available with tungsten carbide tips to give an even cleaner cut and a longer life. Carbide tipped cutters, however, are much more expensive.

Cutters are available with shafts of $\frac{1}{4}$, $\frac{3}{8}$ or $\frac{1}{2}$ in diameter,

but most of the light models take a 4in shaft.

 Straight bit for cutting grooves, rabbets and trimming edges. In sizes from ½ to ¼in diameter. 2. V-grooving bit


3. Core box bit for making rounded grooves as for the draining board on page 20.

4. Rabbeting bit


5. Chamfering bit

6. Beading bit


7. Rounding-over bit for cutting decorative edges as for




For stopped grooves, attach a small stop onto the straight edge then square off the rounded end of the groove with a chisel.



To make grooves along a board, clamp a straight edge to the board as a guide. Alternatively, use the adjustable fence provided with the router for making cuts parallel to the edge.



To make grooves in drawer sides to take a ¼in plywood bottom, for example, use a ¼in straight cutter and adjust the fence so that the cut is ¾ to ¼in



the drawer front on page 26, or for simply rounding edges.

8. Cove bit

- Dovetail bit for cutting dovetails slots as shown, and for use with the dovetail jig.
- 10. Laminate trimming bit is tungsten carbide tipped with ball bearing guide.

You can also have cutters made to your exact specifications by specialist machine toolmakers. Provide an accurate full sized drawing of the cutter required and allow several weeks for delivery.


CUTTING CIRCLES

Fitted with a simple circle cutting attachment, the router can cut disks and make circular cut-outs with decorative edges.




Drill a ¼in diameter hole to take the guide pin, then simply run the router in a circle to make the cut.

For cutting straight through heavy material make several passes, lowering the cutter about 1 in each time. You can




then decorate the edges of the cut-out by running a moulding cutter around the inside.

To cut out large circles, to make round table tops for example, make your own guide out of a piece of 1 in plywood, about 6in wide, attached with two small machine screws bolted through the base of the router. Then drill a small hole at the circle centre. To use the guide simply pin through the plywood at the centre and cut along the perimeter for perfect circles. Use the same board with holes for various radii to cut out circles of different sizes.




from the edge as required. The cuts can be made to an exact depth in one run and stopped, or run through to the end.

Cutting decorative moulded edges for table tops, drawer fronts, shelves and so on, is very simple with the router. Notice that all the moulding cutters including the rabbet cutter, have a guide pin which extends below the cutter. This pin runs along the edge of the work to guide the cutter along an even path. Any irregularities in the edge will be reproduced in the cutting.




The guide pins tend to overheat and burn the wood. To prevent this from happening use the fence as a guide instead, setting it so that the pin just misses the wood. This method will work only for straight runs. For curved and circular shaped edges, such as


a round table top, use the circular guide instead. On some machines the same guide performs both functions by means of a simple adjustment.



To cut moulded shapes on curved edges, adjust the circular guide by trial and error to get the exact setting required. Then simply run this along the edge as you cut the shape.




Another advantage of the router is that it can get into corners to cut moulded shapes, around the inside edge of a door frame for example. The



door frames on page 70 were decorated by running the beading bit around the insides. It leaves an attractive curved shape in the corners.



When putting a decorative edge on the end of a board the wood tends to split when the router reaches the end. To prevent this, clamp a piece of scrap wood at the end. If all four sides are to be shaped, for example to decorate a drawer front like the one on the kitchen work island shown on page 24, cut across the ends first. The subsequent cuts along the sides will then remove the split sections.




router


continued from page 217

CUTTING DOVETAILS

The dovetail cutter can be used not only to make dovetail joints but also to cut dovetail dado grooves. This makes an extremely strong and durable joint and is useful for projects like bookcases. The dovetail shape at each end of the shelf fits exactly into the dovetail groove or dado in the upright. It is a particularly useful joint because it locks the verticals in position so that unlike an ordinary housing joint, the sides can't come apart.




Cut the end of the shelf first. Clamp it in a vice with identical blocks of wood on each side located exactly flush with the end of the board. Set the fence to give just the right depth of cut, then run the cutter first along one side then the other to leave a male dovetail section.




Next cut the matching groove in the upright. Mark the exact area to be cut. Before cutting with the dovetail cutter, make a cut with a straight cutter to the required depth along the centre line of the cut to remove most of the waste. This makes




it easier for the dovetail cutter to cut through in one run. Use the try square guide shown clamped to the board, set to make the right size of groove.






Making perfect dovetail joints is straightforward with the dovetail accessory. You cut both members of the joint at the same time. Clamp them together in the jig, one piece vertically, the other horizontally, then cut each dovetail shape in turn.

There are two sizes of template available for use




with the dovetail attachment. One is for use on wood from $\frac{7}{8}$ to 1 in thick, the other is for thinner pieces, from $\frac{5}{16}$ to $\frac{5}{8}$ in thick.


MAKING A SHAPER OUT OF THE ROUTER



To extend the use of the router even further, you can turn it over and fix it into a simple homemade table to make it into a very useful shaper or spindle moulder.



Make the table of 34in plywood. Cut semi-circular slots in the sides to take the clamp heads which hold it to the bench. You can also screw a board underneath to clamp the table



in the Workmate. Cut a slot in the top large enough to get the router through, then fit a ¼in plywood top over it, cutting out a rectangular opening which is bolted to the router base with two or three machine screws countersunk flush. The plywood top is held in place flush with the top by the fence.




The fence is pivoted at one end with a bolt fixing and moves back and forth at the other end in a slot cut in the base. After adjustment, fix the fence in place by tightening the bolt. The slot cut in the fence

behind the cutter allows the shavings to fall clear.




USING THE SHAPER


You can now cut grooves and moulded edges with accuracy. The rounded edges on the dining chairs on page 32 were cut in exactly this way.



To cut the dovetail ends on the shelf mentioned earlier, you could make a simple holder which clamps to the work and holds it square and straight as you push it by the cutter, as above. When cutting across the end of a board use a push stick behind for safety.



other woodworking machines




When working in hardwoods which are usually only available rough sawn, you can as suggested in this book, take your boards to a nearby woodworking shop, but eventually it may be necessary to buy a planer. A jointer or


surface planer is used to plane first one face side smooth and straight, and then the face edge square with the face side. A thicknessing planer is then used to plane the other sides parallel. A combination planer/ thicknesser can do both jobs.

BANDSAW

The bandsaw is another useful machine which can be used not only to cut curves and irregular shapes but, if the motor is powerful enough, to make fairly accurate crosscuts and ripcuts, which are cleaned up with a plane.


It can be fitted with homemade crosscut and ripping fences to make this process easier. With the larger, heavyduty models available you can even rip logs down into boards. The first cut is made by eye against a chalked line and each successive cut is then made against a rip fence.






The table jigsaw cuts delicate shapes in thin wood. It is primarily a hobbyist's tool, used for making jigsaw puzzles


and other fine work, but it has its place in the workshop too for model making and small, accurate work.




The lathe attachment for the drill consists of a bed fixed to a base, a horizontal fixing for the drill, a tool rest and an adjustable tailstock. Alternatively, buy an integral

lathe with a more powerful motor for turning larger and more ambitious pieces. You will also need special turning tools such as gouges, chisels and parting tools.





GRINDER



A grinder is almost essential for sharpening tools. It should be bolted to a bench at a comfortable height and fitted with tool rests and eye shields. Ideally there should be a light just above it to avoid shadows.

Larger grinding wheels have a coarse stone wheel at one end and a fine wheel at the other end. Alternatively you can fit a grinding attachment to the electric drill and mount it in a

horizontal stand. Use the grinder to re-grind and sharpen chisels, plane irons and spokeshaves and to repoint screwdrivers and drill



Stand a bucketful of cold water beside the machine and dip the tip of the tool in it occasionally to prevent overheating the metal and ruining the cutting edge.

MATERIALS AND FITTINGS


wood characteristics

STRUCTURE OF WOOD

As a simplified model, the tree's cells resemble bunches of drinking straws. The walls are composed of cellulose and are bonded together by a natural substance called lignin. The sap, made up of water and minerals and collected by the roots, is carried up to the leaves through the hollow cells. In turn, the leaves convert the sap through photosynthesis into starches which travel down the tree just inside the bark. They are distributed to the inner parts of the tree through another network of tubular pores called medullary rays. These rays which run radially across the annual rings from the bark to the heartwood are clearly visible in some species of wood.

This structure of fibres and hollow cells gives wood its strength and relatively light weight. But the porous structure also means that all wood, even wood in a piece of antique furniture, constantly absorbs and gives off moisture from the atmosphere. When the wood picks up moisture, it expands and this must be allowed for. A solid table top for example, may be up to $\frac{1}{4}$ in wider at one time of the year than at another.

To allow for this seasonal expansion and contraction to take place, you can use various



devices such as slotted brackets as shown above, to connect a table top to the rails. The screws hold the top in place but are allowed to slide in the slots which are always aligned across the grain.

WOOD GROWTH

The growth of a tree takes place in a thin, sensitive layer inside the bark called the cambium. Each spring there is a time of new growth and the resulting 'spring wood' is formed with large pores to carry all the sap.


During the slower summer growing season, the pores created are smaller and the cellwalls are thicker. This results in stronger summer wood. It is this variation in spring and summer growth which gives the tree its characteristic annual rings which enable you to count the age of the tree from a cross section of the log.

The layer of live, sap-carrying wood is called the sapwood. As the sapwood ages, it becomes inactive and turns into heartwood. It is the heartwood, which is denser and therefore harder and stronger, which forms the structural rib or backbone of the tree.

SOFTWOODS AND HARDWOODS




Wood is classified in two groups, hardwoods and softwoods. Hardwoods, which may actually be quite soft, are those from deciduous trees, that is those which shed their leaves in winter. Softwoods such as pine, Douglas fir and cedar come from evergreen, cone bearing trees with needle



pointed leaves. Softwood species grow faster and have larger cells, and are therefore less expensive than hardwoods. Softwoods are generally available ready planed up in a wide variety of standard sizes.

Hardwoods such as ash, beech, oak, mahogany, walnut and maple must usually be bought from specialist suppliers. Hardwoods normally come in sawn planks either with square sawn edges or sometimes with 'wany edges', with the bark



still on. The planed and polished colour of the wood bears little resemblance to the rough unfinished surface of the sawn boards.


wood characteristics

SEASONING AND MOVEMENT IN WOOD

When a tree is felled, its pores are full of water which must be removed before the wood is stable and usable, and safe from fungal attack. A felled tree would eventually lose much of the moisture naturally but this could take many years and is therefore not commercially viable. To speed up the drying process, the wood is either air or kiln dried.

AIR DRYING

In air drying, the tree is cut through and through into planks which are then piled up outdoors under cover with sticks in between each plank to allow circulating air to dry out the wood over a year or two depending on the thickness of the planks and the species of wood. The advantage of air drying is that the moisture evaporates slowly minimizing shrinkage and distortion.



KILN DRYING

Kiln drying is an artificial process which reduces the drying time to a few weeks. The wood is placed in closed compartments much like ovens and moist, heated air is passed through to dry the wood at a controlled rate to a specified moisture content.

MOISTURE CONTENT


Moisture content which is the percentage of water to dry weight of wood varies from about 60 per cent in newly felled wood to about eight per cent in very dry wood.

All wood used in furniture making must be dried to a moisture content which does not exceed twenty per cent. Below that level, the wood is fairly immune to dry rot and other fungal attack. The moisture content required will depend on the eventual use of the wood. Outdoor furniture and construction grade boards can be up to fifteen per cent, whereas wood to be used for furniture should be between nine and twelve per cent. For most woodworkers, it is not possible to control the

moisture content of the wood with any accuracy. The wood you buy may have been standing in open sheds and your workshop may not be heated at all times.

When making a fine piece of furniture, it is important to keep the wood in a warm dry place for a month or so before beginning work and to see that it is not exposed to fluctuations in heat and moisture.

If possible, try to accumulate a supply of wood which can be stacked horizontally off the floor with spacer sticks placed about 12in apart along the boards to allow air to circulate. You will have to keep the storage area at a constant temperature for this seasoning to be effective.



The effect of too rapid drying of a board is distortion of the shape. As it dries out, it shrinks in every direction except length and too rapid drying will result in shrinkage that is not uniform in all directions. The direction in which the plank distorts will

depend on how it was cut from the log. A tangentially cut plank will pull in on the underside away from the heart where the rings are longer. A radially cut plank is more stable as most of the shrinkage is across the thickness which will not affect the shape.


DISEASES AND PESTS

Wood decay caused by fungal attack is a serious problem and must be treated when it occurs. Dry wood is relatively safe as fungal attack usually only occurs in wood that is over twenty per cent in moisture content.

Dry rot is the most serious wood disease. It starts when the wood is in a damp, badly ventilated condition and spreads over wide areas while these conditions exist. The affected wood must be removed and burned and all nearby wood must be treated with a suitable fungicide to prevent spreading.



Insect pests such as deathwatch A, lyctus B, and furniture beetles, C, which are collectively known as woodworm, usually attack the softer sapwood species.



Wood should be inspected periodically, particularly the unfinished backs of furniture and should be treated immediately if found to be infested.

Vacuum off the surface to remove the dust from the insect holes. Then brush the surface liberally with a suitable insecticide or preservative.


wood characteristics

continued from page 221

DEFECTS IN WOOD


Natural defects

The most common defect. found in most softwoods, is knots, the result of branches going through the wood.



Branches which fell off or were cut early in the life of the tree will be healed by the tree to form a live knot, A. Where

a mature branch is broken, the stump dries and shrinks resulting in a dead knot, B. Live knots may be acceptable in the wood, but dead knots, which tend to fall out leaving a hole, should be avoided.




Splits along the grain resulting from weaknesses between the spring and summer wood layers are called shakes. This splitting usually occurs during the seasoning process.

Artificial defects

caused by rapid or uneven

species of wood than with



BUYING WOOD

Wood can be bought either sawn or planed. Softwoods are usually bought planed whereas hardwoods are most often available only as sawn planks which must be planed before use. Softwoods are available in many standard sized sections. The size of the board is stated as nominal even though the planed size is actually somewhat smaller. Thus a 2 × 4in is actually about $1\frac{1}{2} \times 3\frac{1}{2}$ in once it has been planed although it is still referred to as a 2 × 4in. In some

cases the letters PAR are added to the size to indicate that the board has been planed all round.

The instructions and cutting lists throughout this book have allowed for the planed sizes of wood. When buying softwoods, try to select the boards yourself if the supplier will allow you to. Wood is expensive so it is not unreasonable to insist on buying straight, clear boards, fairly free from knots and splits. Don't accept any boards

which are warped or twisted as they are not usable.

Avoid wood which has been stored outdoors. Even in open sheds, the wood picks up a lot of moisture and this wood will be prone to warping and splits as it dries in your workshop.

Many wood dealers will cut the boards to length for you for a nominal extra charge. This is a very convenient service for people with limited workshop facilities or who have no facilities for transporting long

boards or large sheets.


Bring along a cutting list of the lengths needed and be sure to check the boards for length and square to be sure that they are cut accurately.

It may be difficult to find a good selection of hardwoods at a local supplier. Look in the telephone book for large wood yards or check specialist magazines for suppliers in your area. Then phone up to check that they will sell small amounts.

	characteristics	construction and furniture				
SOFTWOODS Douglas fir	resinous with pronounced attractive straight grain					
Red Baltic pine	fairly stable and straight-grained with frequent knots	widely available for construction and furniture				
Western red cedar	contains oils which prevent insect and fungus attack	used as cladding for walls and ceilings, also outdoor furniture				
HARDWOODS Mahogany	African and South American, wide straight boards	furniture as veneers or as solid boards				
Oak	English, Japanese and American, stable and easily worked	ideal for furniture, both indoor and outdoor				
Maple	hard and close-grained, takes finish well	used for furniture				
Beech	European and American, close even-grained, relatively unstable	widely used for furniture particularly bentwood				
Walnut	European and American, straight, close grain	valued for veneer, ideal for furniture				

sheet materials

Solid wood is expensive and is subject to defects and to expansion and contraction with changes in the weather, so is not always the best choice of material for a project. Manufactured boards like plywood, lumber core plywood and chipboard have many advantages over wood. Although they are not as attractive and possibly not as rewarding to work with, they are stable and available in large sheets which makes it easy to make up large surfaces with a minimum of waste and with no gluing up of boards.




Plywood is made up of layers of veneer glued together to form sheets of standard sizes and thicknesses. The successive layers, called plies, are glued with the grain of the layers at right angles to one another, effectively locking the grain together to keep the sheet from expanding or warping.

The more veneer layers, the greater the strength of the plywood. Good quality plywoods like Finnish birch plywood have many thin layers with an exterior surface of birch veneer making a board which finishes well and is ideal for furniture. Other types of plywood are faced with wood such as Douglas fir, redwood or beech veneer. You can buy sheets with decorative veneered surfaces in finishes of oak, mahogany and teak.

The edges of the plywood can be covered to match the surface with special iron-on veneer edging usually available in two widths from specialist suppliers. It has a Scotch glue backing which melts when you pass a medium-hot iron over it and then quickly sets giving a firm bond.

The type of glue used in manufacture determines whether the plywood is suitable for exterior use or only for interior work. Make sure to specify which you require when you buy plywood.




You can buy plywood sheets in various grades and sizes. The most common sheet size is 4×8 ft which we have used as the standard size for the projects throughout this book. Other sizes which are sometimes available are half sheets, 4×4 ft, or 5×5 ft and larger 4×9 ft, 4×10 ft or 5×10 ft sheets.

Thicknesses range from $\frac{1}{8}$ in to lin in $\frac{1}{8}$ in graduations. The most commonly available thicknesses are $\frac{1}{2}$ in and $\frac{3}{4}$ in. Thinner sheets are used primarily for drawer bottoms, cabinet backs, jigs and templates.

LUMBER CORE PLYWOOD

This is made up of a core of wood strips glued together between outer layers of veneer. The surface veneers are either single or double layers of such woods as birch, beech or Douglas fir.
Like plywood it can be bought with decorative veneered surfaces in teak, oak and mahogany. These are either on one face of the sheet with a less expensive 'balancer' veneer on the other side, or applied to both faces.


Lumber core plywood is ideal for furniture making as it has many characteristics of solid wood without some of the disadvantages. The core of wood strips means that it can be joined by traditional joints.



But remember that it is much stronger in the direction of the core strips than across the sheet. Shelves made of lumber core plywood must be cut from the length of the sheet.

Sizes commonly available are the standard $4 \times 8ft$ sheet and also $4 \times 9ft$, $4 \times 10ft$ and $5 \times 10ft$ sheets. It is sometimes available in sheets up to $5 \times 16ft$ from specialist suppliers. The common thicknesses are $\frac{1}{2}$ in, $\frac{5}{8}$ in, $\frac{3}{4}$ in and 1in.

PARTICLEBOARD AND CHIPBOARD



Particleboard or chipboard is made by mixing wood chips with resin glue and then pressing it into rigid sheets in standard sizes. It is inexpensive and widely used in the furniture industry as a stable base for veneers. It can be bought unfinished, or ready primed with paint, or veneered on one or both faces with a


variety of woods. Chipboard is sold in panels of various widths, usually in 8ft lengths.

Plastic laminate-covered chipboard in various colours is also sold in standard sheets and in special time-saving panel sizes. These are especially useful, particularly in making kitchen and bathroom units.

Both plastic laminated and veneered chipboards can be edged with matching iron-on trim backed with Scotch glue.

Standard sheets are the same as for plywood and thicknesses range from ½in to lin with ¾in a versatile thickness for most work


HARDBOARD



Hardboard, which is made from wood fibres mixed with glues and pressed into sheets under heat, is also sold in the standard 4×8 ft sheet size in $\frac{1}{8}$ and $\frac{1}{4}$ in thicknesses. It is available in standard grade and in a harder and more durable tem-

pered grade. It is used for drawer bottoms and cabinet backs.

It is also sold in a variety of decorative cut-out patterns such as the perforated pattern, which is useful for hanging tools.




nails

Nails, which are sold by weight, are available with different shaped heads and cross section of shank and in lengths from ½in to about 6in. When driven into the wood, the nails separate the fibres and hold by friction. Since they tend to split the wood, nails shouldn't be placed near the end of a board. Use two or three nails per joint, spacing them out evenly.

TYPICAL APPLICATIONS

Nailing corner joints. Nail at alternating angles for more strength. Skew or toe nailing for butt joints.



To strengthen joints that do not show, bend nails over on the other side.




TABLE OF NAILS

Common or round wire nails

Oval wire nail

General purpose nail, more often used in joinery work as less likely to split wood than the round nail. Length: 1 to 6in.

Flooring or lost head nail

O Common or round wire nails

General purpose nail, more often used in joinery work as less likely to split wood than the round nail. Length: 1 to 6in.

Has a tapered head which is easily driven flush with or below the floor surface. Length: 1 to 6in.

the surface. Length: 1/2 to 11/2 in.

Finishing nails or brads

Deformed nails

Spiral nail or annular rings for better holding power. Used in construction work. Length: 1 to 3in.

Thin nails with a small head, ideal for use in joinery and furniture

making to avoid splitting the wood. Head is usually punched below

Upholstery 🕞


Staples

Domed heads available in decorative finishes like copper, bronze, chrome. Used in upholstery work. Length: $\frac{1}{4}$ to 1in.

Corrugated fasteners

Used for quick framing joints where strength is not important. Sizes: $\frac{1}{4}$ to 1in deep, 1 to $1\frac{1}{2}in$ long.

Applied with a hammer or a staple gun. Used in upholstery work



sliver of wood with a chisel and insert the nail. Glue the sliver back in place to hide the nail head.

and to fix thin hardboard.

nails or leave them in for added strength.




In rough work, hold joints together with nails while glue sets. Then either remove the

screws

Screws are sold by length and a gauge number which is a measure of the diameter. Countersunk steel screws which are the type most frequently used are available in lengths from about $\frac{3}{8}$ in to 6in and gauges from 0 to 20.

TYPICAL APPLICATIONS

To fix a screw, first drill the shank hole, then the clearance hole, the pilot hole and the countersink.



To hide the screw, counterbore the hole §in deep then drill the clearance and pilot holes. Fill the hole with a wood



TABLE OF SCREW TYPES

Countersunk
For general work. Flat head is driven flush with, or slightly below, the surface. Available in steel and brass.

Round head

Used for fixing hardware or for decorative uses. Available in steel, brass and black japanned finish.

Oval or raised head



Decorative head, used for fixing hardware. Usually chrome plated.

Phillips head






Cross slotted heads are driven by special screwdrivers fitting only these heads. Less likely to slip than ordinary straight slotted screws.

SCREW GAUGE NUMBERS

	1	2	3	4	5	6	8	10	12	14	16	18	20
Clearance hole	<u>5</u> 64	3 32	7 64	$\frac{1}{8}$	9 64	5 32	11 64	3 16	7 32	$\frac{1}{4}$	9 32	5 16	11 32
Pilot hole softwood	1/32	1 32	<u>3</u> 64	3 64	16	1/16	1/16	3 32	7 64	7 64	7 64	9 64	11 64
Pilot hole hardwood	<u>1</u> 32	16	1/16	5 64	5 64	5 64	3 32	1 8	1 8	<u>5</u> 32	3 16	3 16	7 32

The table above gives drill sizes for screws. Notice that the pilot holes for softwood and hardwoods are different. In softwood, pilot holes for



small screws can be made with a bradawl. For a decorative finish, use either type of screw cup under the countersunk heads as shown in B.

plug, see A.

adhesives

Good gluing habits are essential in woodworking. You must use the correct type of glue, chosen for its strength, resistance to heat and water and its gap filling properties.

Gap filling properties are important in some applications particularly in woodworking joints where the pieces being joined may not be a perfect fit. For example, when gluing up mortise and tenon joints where the sides are not smooth, a gap filling glue such as synthetic resin glue is ideal.

Most woodworkers use mainly two types of adhesive: PVA white woodworking glue available in plastic squeeze bottles for general work, and synthetic resin glue which is sold in powder form to be mixed with water, for joints and waterproof work. In addition it is a good idea to have quantities of contact adhesive on hand for gluing down plastic laminates and tubes of epoxy for special jobs.

Scotch glue, the traditional woodworking adhesive, is an animal glue and comes in the form of sticky sheets or in granules. It is dissolved in warm water in a glue pot and must be used while it is still warm. For maximum strength, the joint being glued should be warmed too, so that the glue doesn't set too quickly.

Scotch glue is brushed on and the joint is clamped until the glue sets. It has the advantage that the joint can be unmade again simply by heating until the glue melts. It is therefore the ideal glue to use for veneer

type of glue	description and uses	strength	water resistance	gap filling	setting time	preparation	cleaning method warm water on cloth	
animal glue Scotch glue	general woodworking glue, widely used for veneering since re-heating allows lifting of veneers. Applied to back of iron- on edgings	good	poor	poor	2-4hrs	melt under heat		
casein glues	general woodworking glue for indoor work	excellent	poor	poor	4-6hrs	mix powder with cold water	water on cloth	
PVA white glue	general indoor work	good	poor	poor	20-40min	ready mixed	water on cloth	
synthetic resin	excellent for all work, including outdoors	excellent	excellent	excellent	4-6hrs	mix powder , with cold water	warm, soapy wate	
contact adhesives	rubber based, used mostly for laying plastic laminates. Applied to both surfaces, leave to touch dry before bringing in contact. No clamping required.	poor	good	poor	on contact	ready mixed	acetone nail polish remover	
epoxy resin	glues almost anything well	excellent	excellent	excellent	½-6hrs depending on type	two parts are mixed together	methylated spirits, denatured alcohol	

work so that the veneer sheet can be moved. Scotch glue is applied to the back of ready to use iron-on veneer and plastic edgings which are used to cover the edges of sheet materials.


Most joints require clamping until the glue sets, so if several components have to be glued together such as in carcass work, it is an advantage to use a glue like PVA which sets quite quickly so that the clamps can be used for the next job. Instead of clamping, the joint can be held together with nails or screws which can be removed or left in place for added strength after the glue has set.

GLUING PROCEDURE

- Make sure both surfaces are straight and true and free from dirt, oil and dust. Test the joints for fit.
- If mixing glue, mix only as much as is required and use it as soon as it is mixed.
- 3. Spread adhesive evenly on joint with brush, stick or glue spreader.
- Bring joint together, clamp or fix with nails or screws, but do not clamp so tight that all the glue is squeezed out.
- Check that the work is held correctly; that frameworks are square, surfaces are straight, joints are flush.
- Clean off excess glue on work and from work surfaces.
 Then clean applicators and glue containers.

MIXING AND APPLYING


If you use synthetic resin glue regularly you can speed up the mixing by making a beater to fit your drill by bending a rod as shown. Put the correct proportions of glue powder and cold water in a plastic container. Use the drill at slow speed to mix the glue. Clean the beater after each use.



Keep a selection of different sized containers for mixing glues in the workshop. For resin glues, use plastic containers with fairly high sides. You can then let the remaining glue set and simply flex the sides of the container to remove the glue once it has hardened.

Keep mixing sticks, spreaders and brushes clean between applications and be sure to close all tubes and bottles well after use so that the glue does not harden in the container.

The glue spreader is a very convenient but expensive tool, for applying synthetic resin glue to even surfaces such as boards being glued up. If you do a lot of work of this kind it is a good investment. Pour the mixed glue into the container. The rubber roller spreads it evenly over the surface. The only difficulty is that it must be cleaned immediately after use or the glue will be very



difficult to remove. Take the spreader apart and soak all the pieces in warm soapy water.

connectors


Using hardware like screws or brackets to join wood is more common today both in manufactured and in homemade furniture than the traditional woodworking joints.

Sheet materials like plywood and chipboard are much more easily joined using the special connectors as shown on on page 240. Most fittings such as bolts, brackets and plates are easily obtainable from hardware stores, but you may have to find specialist or mail order suppliers for some of the less common ones such as the bolt and cross dowel fitting for example.

BOLTS AND NUTS


Bolts, nuts and machine screws are frequently used in furniture construction, particularly for rough work requiring strong, easily made fittings. Bolts are easy to fit since the only preparation required is a hole drilled through both pieces.

Carriage bolts



Carriage or coach bolts, such as those used on the bathroom bench on page 74, have domed heads. Insert the bolt into a hole drilled slightly larger than the shank. Place the washer and nut on the threaded end and tighten with a wrench to pull the square shank under the domed head tight into the wood so that the surface is flush.


Machine bolts



Machine bolts are not very common in woodwork but they provide a sturdy fixing and can be painted bright colours as a decorative touch. The hexagonal bolt head and

nut can be left on the surface or they can be set into a counterbored hole so that they are flush with the surface as on the folding picnic table and benches shown on page 172.


Machine screws



Machine screws are small bolts with round or countersunk heads. They are available in diameters from about $\frac{1}{8}$ in to $\frac{5}{16}$ in. They are frequently used in woodworking particularly

to attach wood to metal. For example, the metal router base was bolted to the plywood strip to make the circle template which is shown on page 216.

Dowel screws




Dowel screws have threads on both ends to provide a secret fixing for attaching wooden knobs such as those used on the kitchen work island on page 24. Drill clearance holes in both pieces and attach the dowel screw to one piece before tightening it into the second hole.


FIXING BOLTS

Bolts are not only extremely strong but they are also very easy to fix.

1. First hold the two (or three) pieces to be joined together either by clamping or temporarily nailing. Make sure to hold them firmly so that they don't move during drilling.




 Drill straight through with the correct sized drill bit. The hole should be slightly larger than the shank diameter so that the bolt can be pushed right through the hole without any difficulty.



3. Fit the nuts and washers and tighten up using a wrench. The advantage of bolted connections is that they can be easily unbolted and reassembled again so furniture can be moved or stored.


PLATES AND BRACKETS




Metal brackets are very useful for making or strengthening corner and T-joints. The corner bracket is used inside on the corners of structures like drawers or children's toy

Corner bracket

The corner bracket is used inside cabinets, such as kitchen cabinets, to fix units to a wall. First screw the bracket to the cabinet, then drill through the back hole into the wall to fix the unit in position.




boxes, whereas the L and Tplates are used on front or back edges to reinforce a joint. These metal plates are also available with attractive finishes such as brass or chrome for the construction of wall units.



Mirror plates

Mirror plates are thin brass plates with round or key shaped holes for hanging mirrors, lightweight frames or small cabinets such as the bathroom unit on page 76.



connectors

KNOCK-DOWN FITTINGS


Knock-down fittings are a recent development which allow furniture to be assembled and taken apart easily. They are particularly convenient for mass production because furniture can be shipped flat in narrow cardboard boxes, making large savings in shipping and storage costs. Knock-down fittings are

easy to install and mean that you build furniture which is easy to ship or store when not in use.

Many knock-down fittings are only available through the trade, but a few, like the block joint and cross dowels, are more generally available in hardware stores or through mail order firms.


Block joint

Block joints are an easy to install method for joining




panels to make cabinets, wall units and even built-in closets. Each half of the joint is screwed to a piece being joined and these are brought together and fastened by a machine screw (see honeycomb wall unit page 110). The two halves of the block have to be very accurately positioned for this method of joining to be successful. Block joints come in brown or white plastic.

Corner table plate




This is a very strong and efficient fitting for fixing the two rails to each leg at the corner of a table. The bolt has a wood thread on one half for fixing into the leg and a machine thread on the other half to take the wing nut. The bracket is held in narrow slots which are cut in the rails with a saw, and it is fixed to the rails with screws. The legs can therefore be removed for easy transporting (see kitchen work island, page 24).

Shrinkage plates and angles




These fittings are used to fix solid wood panels to a rigid framework, such as table tops to the rails underneath. Because wood expands and contracts across its width, it would crack or split if it was fixed rigidly with glue or




screws. Shrinkage brackets allow the screw fixing to move back and forth with the wood. Use round head screws with small washers under the head. Always fix the screw to the slot that is perpendicular to the grain.

Flush mounts




Flush mounts make a convenient knock-down fitting. They consist of two interlocking plates. One is fixed to a wall, the other to the back of a mirror or a cupboard for example, which can then be lifted on or off the wall quite easily.




Bolt and cross dowel

The bolt and cross dowel is an ingenious fitting, widely used in manufactured furniture, not just for panels but for solid wood joints. The bolt has an attractive round head with a hexagonal recess which is turned by an Allen key.




The cross dowel is inserted into a hole drilled in one piece and the bolt is screwed into the dowel. Use at least two bolts for each joint to make it rigid.

Plastic dowel plugs




Plastic dowel plugs are an ingenious hidden fixing often used in chipboard furniture. One end of the dowel is fitted into a drilled hole in the edge of the chipboard before a peg is inserted to hold it tight. The hole in the other piece fits onto a projecting part of the dowel together, the plug expands to the pieces are brought firmly together, the plug expands to hold the joint securely.

Corner plates and knock-down plates



Round head screws are placed in slanted slots which pull the work together to tighten the joint. There are two types. The L-shaped plate is used at corners to join two pieces at right angles. It is made in left and right-hand versions.




The flat plates are used in the same way to join two boards together edge to edge.

hinges

BUTT HINGE


The butt hinge is the most common type of hinge and is used for all kinds of doors. The hinge leaves are set flush into recesses.



The fixed pin butt hinge is used in general work for hanging large doors and also in furniture making for smaller, more delicate doors. Butt hinges are available in steel and brass in various sizes from about 1in to 6in. They are also available in plastic to be used in light work where appearance is not important.


LIFT-OFF HINGE

The lift-off hinge makes fitting easier because the two halves can be screwed on separately and then the door lifted onto its mating fitting. The door can then be lifted off without removing the hinge. The liftoff hinge is available in brass or steel finish in a range of sizes.



PIVOT HINGE

Like the cranked hinge, the pivot hinge also called the centre hinge, opens 180° and clears the adjacent door. It is fixed at the top and bottom edges of the door.




CONCEALED HINGE

Used with lay-on doors which overlap the cabinet opening, this hinge opens 90° or 180°. It is fitted by drilling a hole in the door with a special drill bit.




BACK FLAP HINGE



The back flap hinge is a butt hinge with oversized leaves making it a stronger fixing than the standard butt hinge. It is used on the gate leg table on page 280.

FACE FIXING HINGE




This type of hinge is most commonly used for fitting lightweight doors, such as those used for kitchen cupboards or closets. It fixes flat onto the door and frame.


FITTING A BUTT HINGE

First decide on the position of the hinges using two for light cabinet doors, three for heavy room doors.

1. Clamp the door to a bench or place it in the Workmate. Mark the outline of the hinge with a knife. Notice that the hinge knuckle should extend halfway beyond the face.




2. Using a sharp chisel, cut along the scored line to the




depth required to set the leaves of the hinge flush with the door.

3. Clean out the waste with the chisel by first making several cuts in the middle, then paring down from the side.



4. Rest the door on two wedges, attach the centre screws and check the hang of the door. If the hinge recess is too deep, pack it with cardboard, if it is too shallow, remove the hinge and shave off more wood. Then fix the remaining screws.



CRANKED HINGE






TABLE HINGE



CONTINUOUS HINGE



Also known as the piano hinge, this hinge is sold in long lengths in either chrome or brass finish, which are cut to the required length. The hinge


is screwed directly to the surface and is excellent for long edges requiring a strong fixing. It is used for the corner cupboard on page 155.

miscellaneous fittings

Locks, catches and other hardware are an important consideration for every piece of furniture. They must function smoothly and correctly and should also match the furniture in style and in weight. It is no use installing a heavy catch to a small delicate cabinet for example, nor a small barrel lock in a domestic door where a heavy duty one is required.

LOCKS


Cupboard lock




These are widely used for all sizes of cupboard and closet doors. There are several types of cupboard locks available. The straight cupboard lock, left, screws directly into the inside face of the door. The cut cupboard lock is mounted in a recess cut in the door and is bought in left or right-hand versions. The mortise cupboard lock is fitted in a slot in the edge of the door.

Barrel lock

This lock is easy to fit into a drilled hole and is therefore used in production furniture for both doors and drawers.




Piano mortise lock



This lock is used for the rolltop desk on page 128. It is fitted into a slot or mortise in the front rail of the desk and a matching plate is fitted to the sliding tambour. The keyhole is drilled from the front after the mortise is cut.

CASTORS


Castors are available in various types and styles. They are quite simple to fit. A hole can be drilled into the bottom of the piece of furniture to take a pin from the castor. The other type of castor has a plate which screws to the underside of the furniture with four screws. Choose light, medium or heavy duty castors depending on the amount of use the piece will get and its weight.




CATCHES

Ball catch


The ball is spring loaded and mounted either on the inside of the door or in a hole drilled in the door edge. The ball catches in the hole in the plate which is screwed to the frame. This catch is available in various sizes depending on the weight of the door.




Push-pull latch



Magnetic catch




These catches come in two pieces. The magnet part is screwed to the cabinet and the matching plate to the door. Fine adjustments are made by sliding the magnet part



backwards or forwards. A cylindrical type is used for small delicate cabinetwork and works on the same principle but the cylinder is placed in a hole drilled in the edge of the frame.

This catch is screwed to the inside of the cupboard door and allows you to open the door without a handle. The latch, which must be accurately mounted, swings the door open automatically when you press on the door.


STAYS



Available in chrome or brass finish, the stay is widely used for all types of drop doors. The stay folds in half as you close the door and folds up neatly. Only one stay per door is required mounted on the right or left side. This type of stay was used for the cocktail cabinet on page 124.

Sliding flap stay

This stay is also commonly used for light drop doors and has become more popular than the cranked stay. Instead of folding up at the middle one end of the stay pivots and slides on a track. The track can be vertically, horizontally or even diagonally mounted inside the cabinet as is required. The other end which is also pivoted simply screws onto the face of the flap.



WOODWORKING JOINTS


preparing the wood

The most crucial part of any job is the preparation. When working in solid wood, each piece must be sawn and planed so that it is accurate and square. Softwoods such as Douglas fir and pine are available with the four sides already planed up and these

present less of a problem than hardwoods which are usually bought in the sawn state. But softwood boards, once brought into a heated house, often warp and bend just enough to require a few strokes with the plane to make them straight enough to use.

SELECTING AND CUTTING TO LENGTH

Always buy boards long enough to allow for cutting off the ends which are often split or damaged. Lay the boards out and select the lengths by first examining both sides for knots, splits and other defects.



This step is more important than most people realize because you are deciding on the location of the boards, using the best ones for fronts and tops. Plan out the cutting carefully so that you have as little waste as possible.

Always cut the longest lengths first so that if you make a mistake there is enough wood to cut another one.

Cut the boards about 2 to 3in overlength to allow for final trimming. Label each piece according to the cutting list.

THICKNESSING





To thickness the board, that is to plane the other face parallel to the first, mark the required thickness along all four edges with a gauge then plane to the marks, checking straightness as before. Similarly, to plane the second edge to the exact board width required, mark with a gauge on the sides and ends, and plane the edge straight.

The final step is to trim and square the ends. Mark one end first about 1in from the end, and cut it off to the line with a crosscut or panel saw.

Plane off the cut end in the shooting board, or if it is too bulky, hold it in the vice. Finally mark the exact length with a tape measure or ruler. Saw the other end about $\frac{1}{16}$ in outside the line to allow final planing in the shooting board, exactly to the line.


Of course, with a table saw you can trim the ends quickly and accurately. You can also rip the board to width, but remember that sawn edges will require final planing before they can be glued together in edge to edge joints.






With pre-planed boards check for straightness by sighting down the length. For wider boards place two identical 'winding sticks' across each end to check if the boards are warped.


Planing many boards by hand is tedious work so it may be worthwhile taking the boards to a nearby supplier or woodworking shop to have them machine planed.



Select the best face, place it on the bench against the bench stop and use a try or a jack plane to plane up the board. Work along the board with the grain. Constantly check for straightness with the straight edge along and across the board and check for twisting with the 'winding sticks'.




With a bit of practice you can usually tell how straight the wood is by the evenness of the plane shavings. Always mark the prepared best face with a pencilled loop called a 'face mark'.




Prepare the best edge by planing along the length, again

with a try or jack plane. The board is usually straight when the plane removes a long, even shaving, but make a final check with a straight edge. Also check that the edge is square to the face by checking with the try square at several points along the length.




Correct any bevels, not by tilting the plane in the other direction, but by planing along the edge while supporting the plane with your fingers to keep it square. Finally, mark the face edge with a pencilled mark, as shown left.




edge to edge joints

Edge joints are used to glue up boards into a larger surface such as a table top. The boards can be held together with glue alone or they can be reinforced with dowels or tongues set in grooves.


First prepare the pieces to make the edges straight and the thickness constant. After you have planed the edges straight it is a good idea on long boards to take off a thin shaving or two from the edge along the middle of the board starting a few inches in from the end. This keeps the ends,



which are the weakest part, pressed tightly together during clamping.



After preparing the boards, lay them out on a couple of battens on the bench. All the best faces, which have been marked, should be up but it may be necessary to turn one or two over, alternating the grain pattern to minimize warping.



REINFORCED JOINTS


To strengthen edge to edge joints and also to help align them during gluing up, you can reinforce them with dowels or tongues-and-grooves.

Edge joints with dowels
After laying out and marking
the boards, hold them on edge
in pairs to square lines across
and align the dowel holes.
Then use a marking gauge,
always working from the

marked face, to mark the hole centres which should be centre punched before drilling.



Refer to dowel joints on page 232 for instructions on drilling with or without a dowelling jig.




If the boards are thick enough and if the wood is not oily or resinous, like teak or pitch pine, the boards can simply be glued together with a woodworking adhesive. White woodworking glue is quite strong and sets quickly, but resin glue is waterproof, gap filling and stronger.

First check the joints by clamping lightly across to see if there are any gaps. Also mark the top with a diagonal pencil line so that you can re-position the boards during gluing. Undo the clamps, stand the boards on edge and apply the glue evenly with a brush or stick. For frequent gluing, you can buy a glue roller which applies glue quickly and evenly (page 225).

Bring the boards together to the marks and clamp across, using a long batten on each side to prevent the clamps from marking the wood and also to spread the pressure of the clamps.


You shouldn't have to use too many clamps, nor tighten them too much. If badly made joints are pulled together the strain will eventually cause the joints to open up. Place one clamp at each end then alternate clamps over and under the work to keep the surface straight.


To keep the surfaces lined up, apply clamping pressure gradually and tap the boards with a rubber-faced hammer. Or, clamp the ends together until the glue starts to set.




Tongue-and-groove edge joints

This joint is more cumbersome to make by hand than the dowel joint. The grooves are easily cut by machine with a table saw or a router. To cut by hand, use a plow plane or a combination plane, working from the marked face.





Cut the tongues to fit snugly in the grooves. The easiest way is to make the tongues first out of $\frac{1}{8}$ or $\frac{1}{4}$ in plywood and cut the grooves to match. If you don't want the ends of the tongues to show, stop them a few inches from the end of the boards.




Make sure to make the groove a touch deeper than the tongue so that it doesn't prevent the joint from closing up, and don't make the tongue too thick or the wood will split when the joint is assembled.





Check with a straight edge across the surface and release the clamps to take out any arching or to align the boards.




Also remember to wipe off excess glue at this stage with a damp cloth. It is much less work than cleaning it off with a plane after it has set.

dowel joints

The dowel joint is used extensively in the furniture industry principally as a mortise and tenon substitute because it is quick, efficient and strong. It is a perfect joint for the home workshop as it requires very little equipment and is quite easy to make accurately, even for the beginner. A dowelling jig makes the drilling easy and accurate and is a worthwhile device for anyone planning to make several pieces of furniture using dowel joints.

DOWEL PEGS

Ready-made dowel pegs are available in several diameters: $\frac{1}{4}$, $\frac{3}{8}$ and $\frac{1}{2}$ in but most craftsmen prefer to make their own from lengths of dowel. The pegs must fit tightly in the hole and extend a minimum of $\frac{3}{4}$ in into each piece of wood. The flutings or grooves allow the trapped air and excess glue to escape as the dowel is driven in with a mallet. Notice that the ends of the pegs are




chamfered. This serves to guide them more easily into the hole and to prevent them from splitting when being driven in.

MARKING THE HOLES

The dowel holes in the pieces to be joined must line up exactly. To get this right, the marking must be accurate. The easiest and most foolproof method is to use a dowelling jig which clamps on the wood and centres the holes the set distance from the edge of the wood on both pieces. Use common sense in spacing the holes and centre them on rail ends as far apart as possible leaving enough strength above and below. A minimum of two dowels is required, but for heavy work, three or even four staggered holes are necessary.


To mark the hole centres, start by marking the rail location on the stile or leg with two square lines. Then clamp the rail and




leg together in the vice, face sides out, and use a try square to mark the hole centre lines straight across both pieces. Then use a marking gauge set to half the rail thickness to locate the centres from the face sides.

MAKING YOUR OWN DOWEL PEGS

Dowels are available in diameters of 4in to about 11in. For dowel pegs, you will need three sizes: $\frac{1}{4}$, $\frac{3}{8}$ and $\frac{1}{2}$ in diameter. Be sure to use straight dowels. Keep a few lengths of each diameter in a dry place to use for pegs. As dowels may vary slightly in diameter, check the size in a drilled hole. Reject dowels which are too small, but those which are slightly oversized can be sanded down or driven through a homemade metal dowel pop A, after cutting each peg to length on a bench hook. Make sure to test one of the pegs for snug fit before cutting the rest. To make the grooves, carefully run each dowel peg back and forth over a saw clamped in a vice. Then chamfer the ends slightly using






a pen knife, rasp or a special tool called a dowel sharpener. These jobs become almost automatic with a little practice and it is worthwhile making a batch of common lengths in the three sizes and keeping them on hand in the workshop.

MAKING A MARKING TEMPLATE


Make a template the exact size of the end of the board. Make the top piece out of $\frac{1}{8}$ in plywood or metal plate and screw it to a piece of $\frac{1}{2}$ in wood. Carefully mark, punch and drill hole centres to accept the top of the marking tool.



along the length. Marking for the pegs is made easy by clamping the pair of boards together face sides out, centre marking both boards with the gauge and then squaring across.


Another method is to use a homemade marking template. Always use the template from the face side to first mark the rail and then the leg or stile.


Use a marking awl to mark the centres. It is best to make up a new template for each size rail and you will soon build up a collection of templates to match common wood sizes. To strengthen edge joints in boards for table tops, a few short dowel pegs are added



DRILLING THE HOLES

In order to locate the drill bit before drilling the hole, always use a centre punch to make a centre mark. Use a homemade depth stop (page 214) made from a length of 1 × 1 in to make the holes just slightly deeper than the dowel pegs. It is best to use a drill with a special dowel bit or, alternatively, a brace and auger bit. The holes should be straight and true in both directions, but it is better that any slight slant be along the board rather than across it. Therefore it is best to stand near the end of the board to drill the hole, standing a try square on the bench to serve as a vertical guide. To make drilling easier and more accurate, use a dowelling jig






which can be used with \(\frac{1}{4} \) or \(\frac{3}{6} \) in diameter dowels. The holes are adjusted and set the required distance in and no marking is necessary. The jig is clamped along the guide marks and you just drill the holes to the correct depth. The jig also prevents you from leaning the drill over, enabling you to drill accurate vertical holes.

The manufacturer includes complete instructions with each dowelling jig for making several types of joint including edge to edge and mitre joints.


After drilling, countersink the holes slightly. This makes it easier to locate the dowel pegs and also collects any overflow of glue.

ASSEMBLING THE JOINT

For the final assembly, the pegs are driven into the rail ends first, then the rail is immediately joined to the leg. Apply glue to the holes only to prevent swelling the dowel peg, and tap the pegs in with a mallet, not a hammer. Use light taps to prevent splitting the ends. If possible, use a block of wood next to the peg when tapping it in so that you will leave identical lengths of peg exposed. It is not usually




dowel joints




necessary to clamp the work. The pieces are tapped home with a mallet and the glue allowed to set.

If the holes are out of line so that the dowels cannot be pushed in, fill the faulty hole with another dowel of the correct diameter, cut it off flush and re-drill a new hole in the correct location.




A quick and effective way to make joints is to use a through dowel. Clamp the two pieces to be joined and drill straight through one piece into the end of the other. Then tap a dowel peg in place and cut the end off flush. However the exposed dowel end can be used as a decorative feature especially if it is left slightly above the surface.

USES OF DOWEL JOINTS




Dowel joints are used in all types of work. They are ideal for light work such as cabinet frameworks and doors, and for table legs and rails. The closet doors on page 70 and the table on page 12 were joined with dowels. Notice that the ends of the rails are rounded to fit round legs. In this case it


is best to drill the dowel holes first before shaping the ends of the rails.




Short dowel pegs are also used extensively in inexpensive chipboard furniture instead of screws which split the brittle chipboard. They are often used to strengthen joints such as mitres where two short dowel



pegs are added instead of nails to reinforce the corner. Dowel pegs are also important in




reinforcing edge to edge joints, for example in a table top. The pegs not only strengthen the joint, but they also serve to keep the edges of the boards lined up as they are clamped together. This saves considerable hard work in planing and then sanding the top smooth afterwards.



mortise and tenon joints

The mortise and tenon joint is frequently used in woodwork because of its strength. It is used in furniture such as tables, chairs and cabinets and in making door frames of all types.




Basically the joint consists of a tongue cut in the horizontal piece, called the rail, which fits into a matching slot in the vertical member, called the stile or leg. But there are many variations depending on whether the tenon is haunched or not, whether the mortise goes


straight through the wood or is stopped or 'blind', and whether the tenon is wedged through, called 'fox wedged'.

For most furniture applications however, there are only a few variations on the basic joint which is quite straightforward.


For most furniture applications




mortise should be about one third the width of the wood so a ½in chisel is used for ¾in thick wood and a ¾in chisel is about right for 1in thick wood.




Using the gauge, mark the mortise on the stile and the tenons on the rail at the same




time. Then with a drill bit slightly smaller than the mortise width, drill out most of the waste. If possible use a drill stand as shown on page 214, so that you can set the depth accurately. Alternatively use a depth stop on the drill.




Clamp the board to the bench to chisel out the waste. It's a good idea to place a small Cclamp or thumbscrew across the end as shown to prevent the wood from splitting during chiselling.



Use a mortise chisel if you have one, but an ordinary bevel edge chisel, although it isn't as robust, will do just as well.




Remove the wood in the centre of the mortise first. Turn the chisel one way then the other to remove chips. Work with a mallet until you get within about $\frac{1}{16}$ in of the mark, then pare away the waste vertically in one shaving.



To mark the shoulders of the tenon, always use a utility knife or a sharp chisel to score lines around on all four faces. This leaves a clean edge and forms a starting groove for the saw.

CUTTING THE BASIC MORTISE AND TENON




The basic tenon, used in this example for making a cabinet door, is a blind tenon, that is it does not go all the way through the stile.

When preparing the wood, it's always best to leave an extra inch of wood at the end of the stiles to be cut off later. Having more wood at the end prevents the wood from splitting while you are chiselling out the mortise. Also remember to make all measurements and mark all gauge lines from the marked face and edge.


First mark the position of the

rail end and the mortise on the stile, leaving the 1in waste at the end and squaring across with a try square.




Set the mortise gauge to the exact width of the chisel. The


mortise and tenon joints




Saw the cheeks before the shoulders. For the first cut, place the rail at an angle and saw with the tenon saw to the scribed line. Then turn the rail around and place it upright to finish the cut.




Finally, place the rail flat in the bench hook to cut off the waste at the shoulders. The V-shaped groove, made with the chisel, forms a guide for the saw.



To size up the width of the tenon, offer it up to the mortise, and mark the width of the slot before cutting off the waste with the saw. When trying the joint for fit, you may



want to clamp across the mortise again in case the tenon is too large. For final fitting, you can also bevel the ends of the tenon slightly to make it easier to fit. The pieces should fit moderately tightly.




When gluing up, don't tap the joint together with a mallet as this will mark the work. It is better to add the glue to both tenon and mortise, then gradually tighten the joint with a clamp.

OTHER TYPES OF MORTISE AND TENON JOINTS

Haunched tenon


In most good quality work, the basic tenon shown would have a haunch with a corresponding stop cut in the mortise, to make the joint more rigid. The haunch can be 'ordinary' or it can be cut slanted as a 'secret haunch'.



Through tenons

Where the appearance isn't so important the tenon can go straight through the stile. The joint can be held as usual by glue alone, or it can be wedged for strength. For a decorative effect, the wedges can be made from a contrasting wood.

Notice that the mortise is sloped out on the other side to make room for the wedges,




which should be cut to match the shape cut in the mortise.

Loose tenon

Another clever variation of tenons used for knock-down furniture is the loose tenon. The tenon is cut slightly small to fit loosely. It is locked in position from the other side with a tapered wedge. This joint is frequently used to connect the cross rails on refectory tables, for example.




To strengthen a stub tenon, cut the mortise wide at the bottom. Start the sloping sides ½in down from the top. Insert the wedges in the saw cuts and clamp the joint tight, forcing the wood apart for a rigid joint.



The wedges must be of the right length and the mortise should be about ½in deeper for clearance. Once the joint is assembled, it is almost impossible to get it apart.

Draw bore tenon


Tapered dowel pegs can be used to lock tenons in position.




Slide a waste piece into the mortise to drill the peg holes. Take out the waste piece, slide the tenon in, then use the drill to mark the centre on the tenon. Remove the tenon and drill the holes about 16 in in toward the cheek from the mark. The joint will be pulled tight by the tapered peg during assembly.

dovetail joints


Dovetail joints are shaped so that the component pieces cannot pull apart. This makes them ideal for frameworks where strong and immoveable joints are required. Drawer fronts, for example, are pulled constantly but a dovetail joint prevents the front from being pulled away from the sides.



Dovetails are ideal for connecting two sides of a cabinet rigidly. By dovetailing the corners of bookcases the sides remain fixed and the shelves between, which are usually housed in grooves, will stay in place.




Dovetails are usually cut across the width of the board, as for a bookcase, but in many applications a narrow rail is connected to the carcass sides with a single or double dovetail for greater rigidity. The front and back of the roll top desk on page 128, were





dovetailed to the sides to keep the sides absolutely parallel for the successful operation of the sliding tambour.

There are many variations of the dovetail joint. The most common is the through dovetail in which the joint is visible on both faces. This is used when the joint is a decorative feature.



The lap dovetail is hidden from one face and is therefore often used for drawer work to connect the front of the drawer so that the joint will be hidden when it is assembled.





However, in many applications, the dovetail is used as a decorative feature, visible from both faces. In that case the plain through dovetail is used or it can be made more interesting by varying the sizes and shapes of the pins in the joint.

On the roll top desk for example, notice that the dovetails of the top are left exposed to enhance the appearance of the desk. Dovetails were traditionally cut by hand using a chisel, fretsaw and a dovetail saw, which is a fine-toothed version of the tenon saw (page 196). Today almost all the dovetails which are used on manufactured furniture are cut all at once by machine.


To cut dovetails, either use a dovetail attachment on the router, or cut them in the traditional way, by hand, using a chisel and mallet.

CUTTING DOVETAILS BY HAND


Setting out

First make sure the ends of the boards are square. Plane them if necessary in the shooting board. Then gauge a line in from the end equal to the thickness plus $\frac{1}{32}$ in to allow for trimming later. Set out the tails so that they are wider than the pins. There are no exact rules for the size of the tails but generally, in structural work, make them about as wide as the thickness of the boards. In fine work they can be as thin as you like.


The slope of the tail can vary from about 1 in 5 where strength is required to about 1 in 8 for very delicate work. A slope of 1 in 6 is usually about right.



Set the sliding bevel by setting out five divisions in and one over on a piece of wood, as shown.




If you plan to do a lot of dovetailing by hand make a template out of a piece of hardwood cut to a shape to simplify the job.




Decide on the number or size of tails making the width of the pins equal at their widest part. Draw lines through the middle of each end pin, then divide the distance between the two end lines into equal spaces by laying the ruler at an angle. Then draw in the tails with the sliding bevel.

dovetail joints




Finally, square the lines across the end with a try square as a guide for the saw and be sure to mark the waste with pencil marks so that you don't make the classic mistake of cutting away the wrong pieces.




Cutting the tails

Hold the wood at an angle in the vice so that the saw is cutting vertically. Saw on the line square across, down to the gauged line, then tilt the wood the other way to cut the opposite sides.




Some woodworkers prefer to mark the pins by scribing through the saw cuts with the saw onto the other piece at this




stage, before the tails are cut. However, in the method shown here, the tails are cut out before the pins are marked.


Remove most of the waste with a coping saw, but don't saw to the line. Leave the last $\frac{1}{16}$ in or so of waste to be cleaned out with a chisel.

Clamp the work down to the bench with a piece of waste wood underneath, then pare down to the gauged line using a bevel edged chisel. Turn the wood over and make the final cut from the other side.






Hold the other piece in the vice while you place the tails over it and mark the pins with a knife or a fine sharp pencil. Take the wood out of the vice and square the lines down to the gauged line.




Before cutting out the pins, mark the waste with X marks. When cutting, hold the wood




DOVETAILING WITH THE ROUTER

Choose the finger template to match the wood thickness, then clamp both pieces of the joint perpendicular to one another in the jig.



Check to make sure the two pieces match up perfectly, then add the finger template and set the depth of the cutter and cut




each slot separately. The dovetails will fit perfectly since both sides of the joint are cut at the same time. For more detailed instructions on how this is done, refer to the booklet included by the manufacturer.

BOX JOINTS

The box joint or finger joint, like the dovetail joint, can be cut by hand but is most often made by machine. It is frequently used in drawer work. The pine kitchen drawers on page 16 were cut with a jig on the table saw.


To make the joints by hand, clamp the two pieces together in the vice and mark both pieces across with a try square. Make the fingers about ¼in wide. To make it easy to cut, keep both pieces in the vice but move one sideways so that you can cut in the waste area on both pieces.



vertically in the vice and make sure to saw on the waste side of the line, otherwise the pins will be too small. After sawing to the line, cut out most of the waste with a coping saw in the same way as for the tails, then pare away the final waste with a chisel.

Assembling


Dovetail joints should only be fully assembled once, ensuring that the fit is tight. But to check that the joint will go together, push the joint partially home, cutting down any over-sized pieces if necessary. To assemble, glue both pins and tails lightly, then tap them together with a hammer on a piece of waste wood.



mitre joints


The mitre joint is used to connect two pieces at right angles. Each piece is cut to 45° so that when they are fitted together they form a 90° corner. Mitres can also be cut at other angles, but the most common is the 90° joint.

This is used most frequently to connect mouldings for picture frames and for decorative infills on panels and doors. But reinforced mitre joints can also be used in light framework for doors. For example, the glass panelled door for the corner cupboard on page 155 was mitred and reinforced with dowel page.




To cut pieces of wood at an accurate 45° angle use a tenon saw and a mitre box. Mitre boxes are quite inexpensive so it is not really worth making one especially as it is difficult to make one really accurately.


Before using the mitre box, screw a long piece of waste wood to the inside from underneath to prevent marking the base of the mitre box itself. Place the piece to be cut in the box and saw with light, even strokes through the slots in the mitre box. Then




To make frames, you will have to cut mitres on all four ends. Keep in mind that the opposite sides of the frame must be identical in length for the joint




Mitre joints must be reinforced since the end grain connection has virtually no holding power when it is just glued. The simplest way is to fasten the corners by skew nailing finishing nails or brads from both sides. Drill the brad holes first to avoid splitting the wood when the nails are driven in.



The splined mitre joint is most easily cut on the table saw as shown on page 210. The plywood spline is glued into both pieces to hold the joint firmly in place.




Dowel reinforcements on larger joints are best drilled using a dowelling jig. Use two to three short dowel pegs per joint, spacing them evenly along the end.




USING THE MITRE SHOOTING BOARD

For most work, the cut made by the tenon saw is good enough to give a smooth surface for gluing up. For very fine work, trim the ends on a mitre shooting board made by screwing an accurate block to a base. Hold the piece against the block and run the plane sideways against it to trim the end.



GLUING UP

Use mitre clamps, either singly to do one corner at a time, or in sets of four to glue the whole framework in one operation.




A far simpler and cheaper method of gluing up mitre joints is to fix a cord tightly around the frame with small wooden blocks at each corner. First tie a stick to the cord ends and tighten the cord by turning the stick round and round. Then hold the stick firmly against the frame while the glue sets.



There are several other ways to cut mitres. Using the table saw it is simply a matter of setting the mitre guide at 45°. Refer to page 210 for full instructions on using the saw.


Another easy way to cut



mitres is on the radial saw as shown on page 213. Alternatively use a professional mitre saw with fine teeth for a very smooth cut. This saw is rather expensive but it is very useful since it can be set at any angle to make square as well as angled cuts such as mitres.


halving and bridle joints


Halving joints are very common both in rough carpentry work and in cabinetmaking where they are mostly



used to joint light frames such as the cabinet doors on page 16. They are easy to make either by hand or with a table saw (page 210).


When the two pieces are of equal thickness, make the cut grooves of equal depth. Mark the pieces first with a knife or chisel as a guide for the saw, then with a marking gauge to set off half the thickness. Always mark the waste area with a pencilled X.





To cut away the waste, first saw away the shoulder in a V-shaped groove. Saw exactly to the gauge mark, then place the piece in the vice in the same way as for cutting tenons and saw on the waste side of the gauge line to remove the waste.

For cross joints, where the halving occurs in the middle of the piece, make the two saw cuts on either side, then pare away the waste as shown below.



grain as solid wood.

The plywood children's high

chair on page 96, for example,

is made entirely with halving

joints and the pieces are held

together without nails or

screws.

The bridle joint is similar to the halving joint, but it is stronger because it has more glue area. The leg structure for the roll top desk on page 128 uses bridle joints both for strength and as a decorative feature.

housing joints


Housing joints are wide grooves, usually cut across the grain to hold boards to a vertical. The groove can be cut right across the board, called a through housing, or it can be stopped short of the front with a matching step in the shelf, called a stopped housing.

Although the groove is usually only $\frac{3}{16}$ in deep, the housing joint relies on tight fit to hold the pieces together firmly. The joint is glued up in assembly, but it is the tightness of the joint which provides strength.


The groove is easily cut with a router fitted with a straight cutter. Run the router against a square straight edge guide as shown on page 216. For a stopped housing, fix a block to the straight edge to stop the router at the appropriate point, then square off the end of the groove with a chisel.

Mark the setback on the stopped housing with a marking gauge and use it at the same time to mark the notch in the end of the shelf, which should be cut slightly smaller.


Cut the housing groove by hand using a saw, chisel and hand router as shown. First score two lines the width of the housings, then use a chisel to form a V-groove against the scored line for the saw. Saw down to the required depth with a tenon saw, then clean out the waste with a chisel and, if possible, a hand router which is set to the required depth and run back and forth to remove the waste. To make a stopped housing, first cut a small notch at the front with a chisel, then proceed in exactly the same way.




For a more rigid joint, use a dovetailed housing joint. The groove and shelf end are cut using a dovetail cutter fitted to



a router. They are then slotted together for a permanent joint. To cut by hand use separate bevelled battens as guides.





working with sheet materials


Traditional woodworking joints are not often used for joining sheet materials. Plywood, lumber core plywood and chipboard have properties which differ from solid wood so that joints like mortise and tenons are unsuitable. Sheet materials are thin, planar surfaces whereas wood is linear. This means that most sheet joints are along narrow edges which must be reinforced with screwed brackets or nailed battens.

The strength of sheet materials also differs from that of wood which tends to split along the grain. Plywood with its alternating layers of glued veneers is strong in both directions so that a groove can be cut near the end without splitting the material.


Lumber core plywood is strong in one direction but weak in the other so, depending on the direction, it can be joined by traditional joints. It is possible for example to cut dovetails in lumber core plywood. Chipboard has no grain and tends to break easily and must be well supported along the edges with battens, for example, to give it strength. Screws driven into the end grain of chipboard have almost no holding power unless fibre or special plastic plugs are first inserted in the holes to give the screw thread something to grip.

The details shown below give a few examples of joints used in the book for projects made with sheet materials.


CORNER JOINTS OR T-JOINTS




The easiest corner connection for joining sheet materials uses a reinforcing batten which is glued and nailed or screwed to both pieces (captain's bed page 60).




Joining the corners with nails at alternating angles is surprisingly strong. Hide the nails by punching them below the surface and filling the holes (wall unit page 124).



A groove and rabbet joint for plywood and lumber core plywood is stronger than ordinary butt joints (page 118).




Screws don't hold very well by themselves in the end grain of chipboard or plywood. To strengthen the joint use a fibre wall plug or a special plastic plug inserted in a drilled hole



EDGE TREATMENTS



Plywood edges can be left exposed as a decorative feature (kitchen page 44).




Use iron-on veneer edging to match the surface veneer (bookcase page 114).



Solid wood lipping is either glued on and held with clamps until the glue sets or just glued and tacked in place with the brads punched below the surface and the holes filled (kitchen cabinets page 16).




' Chipboard edges are often covered with plastic laminate for kitchen counters. Notice the bevelled top edge (kitchen page 44).




Strips of moulding pinned to the edge have many decorative uses such as shelf edging or as decoration for drawers as on the chest of drawers shown on page 64.

in the end grain. The plug expands when the screw is applied (bookcase page 114).




Special plastic block connectors are quick and easy to use. The block halves are screwed to the pieces separately, then joined (wall unit page 110).




Traditional dowel pegs are often used as a method to reinforce chipboard joints. They require accurate setting out and drilling as shown on

page 232. Use two or three $\frac{3}{8}$ in diameter pegs per joint (corner cupboard page 155).




For adjustable shelving there are several systems to use. You can drill holes at regular intervals using a homemade drilling jig as shown on page 112. Then insert either plastic or brass cups into the holes to take small moveable brackets which support the shelves (kitchen page 44).

Metal brackets are oldfashioned but still very useful. The L-brackets are used for inside corners. The flat L- and T-shapes are fixed on the front face. Metal brackets are




available in ordinary steel or in decorative finishes such as chrome and brass (see example shown on page 242).




The splined mitre requires a table saw for accurate cutting. See page 210 for instructions.


GROOVED AND RABBETED PANELS




Thin plywood is often used for drawer bottoms. Hold it in place by fitting it into a groove cut in all four drawer sides. See page 216 for instructions on using a router to cut the groove to hold the bottom.




Alternatively glue and screw a batten to the sides of the drawer to support the bottom (captain's bed page 60).




Cabinet and bookcase backs are usually cut from plywood $\frac{1}{8}$ or $\frac{1}{4}$ in thick. For solid or veneered bookcases use a plywood veneered to match (bookcase page 114). Standard sheets in various veneers are available from large suppliers. For kitchen cabinets use white hardboard for the backs to match the cabinet. The backs are either screwed or pinned into a rabbet cut in the edge of the cabinet.



A plywood back panel can also be simply nailed or screwed into the back edges. But notice that the edge can be seen from the side (wall unit page 124).



Plywood door panels are usually held in a rabbet by a strip of thin beading which is nailed in place. Use fine veneer nails to avoid splitting the beading and set them below the surface to hide them (closets page 70).




Alternatively the door panels can be held in grooves (kitchen page 16).






The alternating bands of light and dark veneer in plywood end grain can be used as an attractive feature, as in the sofa with storage, page 148, and kitchen worktop, page 44.


HARDWARE



Plywood and lumber core plywood take screws well but to strengthen the screw fixings in chipboard for hinges for example, either use fibre plugs or glue dowels into the end first and then drive the screw into this so that it has something to grip into.



Continuous hinges are very easy to fix. The large number of screws means that no reinforcement is required even in chipboard which doesn't take screws well (trestles page 108).



Plywood gussets can be used to make quick and sturdy joints in construction work. Glue and nail the thin plywood gussets on both sides. For heavy work such as the wood racks on page 206, use $\frac{1}{2}$ or $\frac{3}{4}$ in plywood and hammer in the nails at an angle to strengthen the fixing.

BASIC FURNITURE CONSTRUCTION

The most important consideration with any piece of furniture is that it be attractive and suited for its purpose. This usually means that it should be strong, square and rigid. But there are other factors such as lightness, durability of finish and choice of material. Most of the planning involved in making a piece of furniture becomes fairly intuitive with experience, but it is a process of learning by mistakes. Sagging shelves, swaying cabinets and split table tops are either the result of bad design or bad workmanship and both usually improve after a few minor disasters. As a guide to good construction, refer to the many standard joints which have been developed over centuries. For quicker, less traditional but equally sturdy joining methods, modern connectors should be used, particularly when working with sheet materials.

There are also many standard construction procedures and hints or dealing with problems which are very useful to study as examples for your own work.


It is fine to learn all about cutting perfect joints, but it is no use having good joints unless the assembly procedure is also well thought out and the construction is designed for squareness and stability.

Many of the standard procedures used in furniture construction are shown in detail in the various projects in this book. However, no written instructions can ever be as informative as actually solving the problems as they arise in making your own furniture.

decorative touches

ROUNDING CORNERS

On doors or table tops and many other pieces of work, rounding the corners helps to take away the square, clumsy appearance. It not only makes work look more graceful but it is also nicer to touch. Refer to the kitchen doors on page 44 and the baby's bed on page 88 for good examples.




CUTTING OUT SHAPES
A sabre saw or coping saw is easy to use to cut out many different decorative shapes such as the heart shaped cutouts on the plant container on page 178 or the arches on the Welsh dresser on page 36.


MOULDED EDGES


You can cut many shapes on the edges of shelves, drawer fronts and table tops with a router. Refer to page 216 for instructions on how to use the router and to see the great variety of profiles available.




Alternatively apply moulded sections by gluing and nailing them to the edges. Set the nails and fill the holes with filler.









sanding smooth when dry. This is a useful way to cover the edges of plywood as in the wall unit on page 124).









EXPOSING THE WOOD JOINTS


Instead of hiding the joints in a piece of furniture, make a decorative feature of them. The exposed dovetails in the cabinet of the roll top desk for example, give the desk a nice, handmade look.




HARDWARE



Hinges, handles and pulls can add decorative final touches to a piece. The brass drawer pulls on the chest of drawers (page 64) for example make the whole piece of furniture sparkle.




bookcases



cabinets and doors

There are many different ways of making cabinets such as chests of drawers, desks and wall-hung units. In traditional construction, the basic




framework is made from lengths of wood joined by dowelling, mortise and tenon or other woodworking joints. The framework is enclosed with infill panels of either solid wood or plywood set into grooves or rabbets in the frame. Modern construction techniques use sheet materials to do both jobs of framing and covering with one panel. The panels are usually connected by a combination of traditional and mechanical joints.


Cabinets are similar in construction to bookcases. The

shelves must not sag and the whole structure must be rigid. Squareness is particularly important so that the doors will fit properly. Strengthening methods are also similar to those shown for bookcases. The back and side panels usually make the cabinet rigid.


Another method often used is to attach side pilasters both for strengthening and for aesthetic effect. The traditional oak veneer corner cupboard shown on page 155 is strengthened by this method.





A pilaster is a vertical version of the horizontal braces shown for the bookcases. This idea is often incorporated into the design of the cabinet in the form of plinths and cornices, as for the chest of drawers page 64.



The plinth can be projecting as in most traditional work or recessed as in much modern furniture.








MAKING SIMPLE BOXES

Boxes, which are very easy to make, can be used in a number of ways to make wall units such as on page 124 or toy bins on castors, or any number of small and large cabinets. Various methods of connecting the sides are shown on page 226.


 To make a box, cut the sides accurately, and check with a try square.



Make sure to cut any grooves or rabbets and to drill any holes, as for adjustable shelves, before assembly.




Assemble the four sides.Then before adding the back, attach any dividers.



Use the back panel to pull the box square, attaching it with nails or screws.

For larger boxes, it is a good idea to connect the shelves to


one side and the back before attaching the last side.



Finally add any hardware to the box such as hinges or stays or plastic channels to hold the doors. Refer to the details on page 242 for decorating the edges of the box to make it look more finished.

cabinets and doors

Cabinets must also be designed to hold together so that the uprights don't tend to move apart, resulting in loose joints and a wobbly structure.



The back panel helps to tie the whole framework together (A) but the horizontal rails and shelves must do most of the work. Dovetailed joints such as those used on the roll top desk

are the strongest way (B) but the rails can also be screwed and plugged to the front and back edges in less fine work (C). Alternatively, use metal brackets in unobtrusive places to hold the rails (D).

In cabinets with drawers, the drawer runners are treated

differently for solid wood sides than for sides made of sheet materials which have no tendency to expand and contract. For solid wood sides, place the runner in a groove without attaching it and keep it in place by dowelling or grooving it into the front and back rails which are rigidly

groove (A) or rabbet. The


front and the panel held in

place with a small bead (B) or decorative moulding (C) using


rabbet can be cut at the back or

small brads or fine veneer brads.


joined to the cabinet sides. For sides which are made of plywood, blockboard or chipboard, the drawer runner can be glued and screwed since there are no problems with movement of the materials. This was done for the chest of drawers on page 64.









Cabinet doors can be made very simply out of pieces of plywood with rounded corners as in the town kitchen on page 44. Or, they can be made in the traditional way with a frame and infill panel as in the country kitchen on page 16 or the bedroom closets on page 70.




Traditional door construction uses mortise and tenon (A), dowel (B) or halving joints (C). The panel is held either in a



Α____




Plan corner joints so that any grooves or rabbets do not show. They can be stopped short of the joint, or the joint




can be cut to accommodate them, such as the haunched mortise and tenon joint.

Light sliding doors made out of plywood, hardboard or glass can run in plastic channels.


These are available in matching pairs to suit different thicknesses of material in single or double track versions. They can be screwed in place or just glued down with contact adhesive.



Heavier closet doors are best suspended from rolling hardware available in a variety of types and grades.



tables



construction method is quite simple. Basically the top is attached to the rails which are fixed to the legs at the corners. There are, of course, variations. The table can have

rails near the bottom, the ends can be solid or trestle-shaped with bracing rails fitted at midheight, or if the table is

circular, it will usually have a central pedestal base.

Basically, the stability of a table comes from the rail to leg connection which must therefore be solidly made.

Trestle tables rely on a wide central rail for rigidity. The two end trestles, which are dowelled or joined by a




mortise and tenon, support the top. The connection between the trestles and the cross rails is usually made so that the table can be dismantled for easy moving.

The traditional joint used is the pegged through tenon which is strong and easily taken apart. A modern substitute uses the bolt and cross dowel shown on page 226. The flat brass bolt heads are decorative but the short cross dowels are hidden in holes drilled in the top and bottom of the rail.

Tops made from plywood or chipboard can be attached from underneath by screwing

CORNER JOINTS


The traditional mortise and tenon joint can be made with tenons that just meet inside the mortise, or the tenons can be mitred or stopped.




Dowel joints must be well made with at least two, preferably three, 3 or 1 in diameter dowel pins.




Wood or metal corner blocks or brackets are easy to fix and hold very well. See the kitchen work island on page 24 for instructions on how to fix the metal brackets. This or the traditional wood bracket is particularly handy because the legs can easily be removed.



For fixing rails to round legs use dowel joints and shape the ends of the rails to match the shape of the leg.





down with slotted shrinkage brackets to allow the wood to expand and contract according to changes in the seasons or in the moisture content of the room.

The angle type of shrinkage bracket screws directly to the inside of the rail but the flat

brackets must be set in recesses in the tops of the rails. Always attach them so that the round head screw is free to move back and forth across the width of the table, perpendicular to the grain as the wood expands and contracts.

246




drawers

In fine work, drawers are made from hardwearing hardwoods such as oak or maple, but in modern work most drawers are made from plywood or lumber core plywood. The bottoms can be solid wood, in which case they must be loose in the grooves to allow them to shrink. But usually the bottoms are made from ½in plywood which is stable and therefore can be rigidly attached to the sides to help strengthen the drawer.


The joining methods vary according to the material and the type of project. In fine cabinetmaking dovetails are required but for ordinary work screwed corners may be sufficient.

CORNER JOINTS

Traditional dovetails are the strongest and best looking joint for drawers.




The groove and rabbet joint is convenient for plywood sides.





The simplest corner joint is the butt joint reinforced by a batten or a more attractive

quadrant moulding glued and nailed in place.




Screws do not hold well in the end grain of plywood but by inserting fibre wall plugs into the end grain the screwed joint is strong and permanent.






A simple alternative is to use plastic drawer kits. The side section comes in long lengths and is cut off to length with a saw according to instructions. Corner joints simply clip on with hand pressure and lock


tight. Grooves for the plywood bottoms and the drawer runners are part of the moulded section. These drawers were used for the work table on page 120 and the night table on page 56. Plywood bottoms can be held in grooves which are usually stopped to avoid showing at the ends, by screwing a batten underneath or simply by gluing and screwing them directly to the bottom edges of the drawer sides.



It's easy to attach a separate piece to the drawer to serve as the front, screwing it on from the inside. This technique is useful for drawer fronts which overlap the opening, such as the drawer in the kitchen work island on page 24.




Alternatively, the drawer fronts can be an integral part of the drawer with the front side exposed. Since the joints will show, use dovetails or perhaps finger joints for a decorative effect, as on the country kitchen drawers on page 16.




DRAWER RUNNERS


The drawers can run on battens screwed to the cabinet sides as in the bins for the closets on page 70.




The oversized drawer bottom can run in plastic or metal channels screwed to the sides.



The traditional method is to put a groove in the drawer side which runs on small battens screwed to the side of the cabinet as in the kitchen work island (page 24).



Metal drawer runners with rollers are easy to fix and very smooth running. As examples, see the kitchen on page 44, or the captain's bed on page 60.



FINISHING TECHNIQUES

wood finishing

The fashion in wood finishing changes periodically. During the last decade, most people preferred a shiny, gloss finish on furniture, whereas today the trend is for the wood to look as natural as possible with no heavy build-up of lacquers.

Wood doesn't necessarily have to be finished at all. In Scandinavia, beautiful hardwood furniture is sold unfinished.

So long as the furniture is kept in a dry environment and any marks are removed by scrubbing or rubbing with steel wool or very fine sandpaper, it is not necessary to apply a finish.

But generally, finishes are applied both to enhance the

beauty of the wood and to protect it from moisture which causes it to warp and creates unsightly stains. If the wood is attractively grained, the finish should enhance the pattern. Lighten or darken the tone of the wood by bleaching or staining to match existing furniture.

You can protect the wood by sealing the surface with a variety of finishes such as oil, wax, shellac, lacquer or paint. The finish you choose will of course depend on the type of wood used and the kind of effect you want the finish to have.

No matter which finish or technique is used, the secret to a beautiful finish is in the preparation.

PREPARATION FOR FINISHING

First the wood must be made smooth by planing, scraping or sanding. Any noticeable nicks or bruises must be removed by careful planing. In order not to create a hollow in the damaged spot, plane over a larger area with a fine set plane until the mark is removed.

Scraping produces a very fine finish on hardwoods which will require little or no sanding. Use a sharp cabinet scraper as shown on page 205 to remove a fine, even shaving of wood. Sharpen the scraper often to keep it sharp.

Sanding is the best method of getting a really smooth finish. There are different types of abrasive papers available, glass or sandpaper, garnet paper and aluminous oxide paper. Garnet paper is preferred by woodworkers because it is harder than glass or sandpaper and therefore cuts more quickly and cleanly. Aluminous oxide, also used for woodworking is even harder.

The size of particles or grit governs the roughness of the paper. Although most people buy papers by the general terms rough, medium and smooth, the abrasives are technically graded by grit size – 60 or 80 grit is equivalent to coarse grade, 100 is medium, 120 to 150 is fine and 180 to 240 is very fine or flour grade.

When sanding, start with the finest paper appropriate for the particular surface. For a rough, open-grained wood like oak you may have to start sanding with 80 grit, but birch plywood, for example, is already quite smooth and a rubbing with 150 or 240 grit may be all that is required.

Hold the work firmly on the bench or in a vice, use a sanding block to hold the paper and sand with short even strokes, with the grain.

On fine work, it is a good idea to brush off the dust as you work since loose grits from the abrasive paper may mar it.

Work from coarse to medium to fine paper until the surface is very smooth. Remember that the smoother it is at this stage, the better the finish will be.

POWER SANDERS

To make the work easier, use an orbital sander (page 215). Never use a disk sander on furniture as it leaves marks which are very difficult to remove. Don't use a belt sander unless you are experienced in using it.

An orbital sander works in a circular motion. Bear down gently on the sander as you work. Be careful to examine the surface periodically by eye and also by touch to find any imperfections.

Brush away the dust from time to time so that loose grit does not imbed in the sanding belt and mar the surface. Always finish sanding by hand, working along the grain to remove any marks.

To get a really smooth finish, adopt a method used by furniture makers. Brush off the sanded surface and then wipe it with a damp cloth to raise the grain slightly. Let the wood dry and then sand again with very fine flour grade paper. This will prevent the grain from being raised when you apply the finish.

FILLING AND PATCHING

Small holes and scratches can be filled either with store-bought or homemade wood filler. Fillers or stoppers can be bought in a variety of shades to match various woods, but keep in mind that they will never match the wood perfectly and it may be just as well to leave a slight mark rather than to draw attention to it by filling it.

Another method is to carefully drill a hole, removing the mark, then fill the hole with a wood plug (page 214).

Painted and stained work is easy to fill as the finish will cover or mask the filler.

To make a filler which matches the wood perfectly, spread a small amount of white woodworking glue on a scrap of the same wood and then produce fine sawdust with a scraper or chisel and mix it with the glue. Make it into a paste and apply to the hole immediately. Sand smooth when dry.

GRAIN FILLING

For a really glossy finish, the wood surface must be very smooth before the finish is applied. Coarse grained woods like oak, ash or mahogany have fairly rough surfaces even after careful sanding and it is a good idea to fill the grain before the final finish is applied but after any stain is applied.

Fillers are sold in either liquid or paste form to match the type of finish you will be using, whether oil or lacquer.

Rub the filler into the grain with a stiff brush, then rub it off with a coarse cloth before it is completely dry. The aim is to fill the pores leaving no filler on top of the grain to cloud the finish.

If in doubt about the type of filler to use, ask a specialist supplier who will recommend the right one to go with the sealer you intend to use. Try it out before you proceed.

STAINS

Most woods look good left natural. Even the most ordinary species such as pine, Douglas fir and beech have their own warmth and beauty even if the grain figuring is not dramatic.

When you want to tone the colour slightly or even darken it dramatically, use a water or oil based wood stain. Water based stains are the easiest type to apply, and they tend to penetrate more deeply into the wood to yield a more even and clear tone than the oil stains. Raise the grain with a damp cloth and sand smooth before applying a water based stain.

wood finishing

Apply the stain with a sponge, cloth or brush, testing the colour first.

Brush the colour on liberally and evenly and when the surface is finished, wipe the stain with a clean cloth to get an overall even tone.

Remember it is always better to put on two or three diluted coats of stain than one heavy coat which may go blotchy.

Oil stains don't raise the grain as much so there is no need to dampen the wood before application. Apply the stain with a cloth, working it over the whole surface and then wiping it with a clean cloth to even out the colour while the stain is still wet. Unlike water based stains, oil based stains dry slowly so there is plenty of time to work in the colour. Don't use oil stains under lacquer finishing coats; use water based stains which will not react with the lacquer.

BLEACHING

To lighten the tone of woods you can apply special wood bleach to the boards. You can make a homemade mixture using oxalic acid, but it is safer to use a commercial bleach sold at hardware stores. Bleach is dangerous to use as it will burn skin and clothing so wear rubber gloves and an apron and use the liquid carefully avoiding any contact with the skin.

Bleaches are usually sold in two parts; the bleach itself which is applied with a fibre brush or a sponge and the neutralizer which is applied to stop the action of the bleach.

Follow the manufacturer's instructions carefully and after bleaching, sand the work lightly before applying finish. Never put bleaches into metal containers; keep them in the plastic bottles in which they are sold. If you mix your own, use glass, earthenware, or plastic containers.

VARNISH

Varnishes consist of copal gums and linseed oil mixed with turpentine.

Varnishing is the traditional technique for producing a clear finish, though it is often used with pigments for toning or staining at the same time.

Today, varnish has been largely replaced by synthetic lacquers like polyurethane which dry more quickly and are more water and stain resistant.

SHELLAC

Shellac is also a traditional finishing material long favoured by craftsmen because it is easy to apply and is quick drying. Unlike varnishes and synthetic lacquers, it penetrates into the wood surface, filling the pores so that it creates a beautiful deep polish. It is often used as a combination sealer and filler. One or two thin coats applied under a coat of wax produces a beautiful and natural finish.

Shellac is also used in French polishing but because it stains easily and has little resistance to water or alcohol, it too has been replaced by synthetic lacquers.

LACQUERS

Modern synthetic lacquers produce an extremely hard, clear finish which resists heat, water and other stains very well. Lacquers are therefore ideal for surfaces like table tops and children's furniture which must withstand a lot of hard wear. It is non-toxic, and easy to apply making it a perfect all-purpose finish for many types of furniture.

Non-synthetic nitro cellulose lacquers are still widely used in industry but for home and small workshop use, polyurethane lacquers are unrivalled for their ease of application and durability of finish.

Rubbing with pumice powder

As a final touch to varnished surfaces, rub them down with a fine abrasive to take away the glossy look and to give the surface a deep, lustrous and smooth finish.

You can buy various rubbing compounds, but the easiest method is to rub the surface with a mixture of pumice powder and oil. Teak oil is suitable, or you can buy a special polishing oil for the purpose.

Pumice powder is available in

different grades and only the finest should be used for finishing. Either mix the powder and oil together to make a liquid the consistency of cream or dip a cloth first in oil and then in the pumice powder. Rub it in really well, working with the grain. Renew the oil and pumice finish from time to time.

The pumice acts as an abrasive to remove any imperfections on the surface. Once the surface is well rubbed, go over it again with oil alone, buffing well to make it really shiny and smooth.

APPLYING POLYURETHANE LACQUER

The best finish is produced by spraying but for finishing an occasional piece of furniture, a brush is the best applicator. It is recommended that you apply a sealing coat first with the lacquer thinned down. Let this dry completely and then rub with flour grade sandpaper or with fine 000 grade steel wool before applying the first full coat. You can also buy a special sanding sealer which dries in minutes and forms an ideal base for the final coats of lacquer.

Rub down the surface between each coat with flour grade paper or grade 000 steel wool and wipe off all dust carefully with a clean cloth before applying the next coat of polyurethane.

Polyurethane lacquer is widely available for home use from most hardware and paint stores. It is available in matt, satin or gloss finish. To get a matt or semi-gloss finish, apply a thinned sealing coat, then one or two coats of gloss before applying the final matt coat.

First brush against the grain, then with the grain, finishing off with fine, feather-like strokes to even the surface.

For a more natural finish, apply only one coat of lacquer over the sealer coat or use a special penetrating sealer, available for finishing floors, and finish off with wax.

WAX FINISH

Wax can be used either on the bare wood or on top of a sealer for a deep, matt finish which is beautiful, natural looking and which can be renewed easily. Buy a good quality commercial paste wax, not a spray or liquid, or better yet, make your own wax paste.

The standard craftsman's recipe is to mix about one pound of pure beeswax,

available from specialist stores, with ½ pint of turpentine. Mix these together in a metal container placed in hot water until it forms a paste. To make the wax finish harder, add a little carnauba wax to the beeswax before melting it with the turpentine. Store the wax in a container leaving the applicator pad on top and the lid tightly closed.

This formula produces a wax

wood finishing

continued from page 249

which is harder than commercial preparations and which is therefore better for applying straight onto bare wood.

Apply the wax as a paste, thinning it with turpentine if necessary. Use a clean lint free cloth to apply the paste and allow it to harden for about ten minutes. Then buff with a soft cloth to achieve a really fine sheen. The more buffing you do, the more lustrous the finish. Build up two or three thin coats of wax, buffing well between coats with a soft cloth for a really beautiful finish.

To make the wood more resistant to stains, first finish with a thin sealer coat of lacquer and then apply the layers of wax, rubbing them in well.

OIL FINISH

Some fine grained woods like walnut, sycamore and maple look good with a natural oil finish. The traditional linseed oil requires many coats and is not very resistant to heat and water. Modern oils such as teak oil and Danish oil contain oxidizing agents which make the finish more durable and only two or three coats are necessary. Be sure to buff well, using a soft cloth between coats.

Like wax finishes, the advantage of an oil finish is that it can be renewed. A scratch in a table top for example can be rubbed out easily with fine sandpaper or steel wool and then the bare wood can be refinished with oil to match the rest of the surface.

Apply teak oil with a cloth, rubbing it into the grain. Let it stand for about 30 minutes, then wipe the surface with a clean soft cloth to remove any oil which has not dried. Buff the surface to polish it and then repeat this two or three times for a deep and beautiful finish.

SPRAY FINISHING

Spray finishing with a pressure-fed spray gun is quick and simple and produces the best finish. You can buy small and relatively inexpensive guns and compressors such as the one shown here for applying lacquers, water based paint, oil paint, varnish and even stains. Its use isn't limited to furniture. Household jobs such as painting rooms, door and window frames and spray work on a car are easily done with a spray gun.

Applying paint with a gun takes a little practice so it is important to try the gun out on a sheet of hardboard or plywood so that you develop the right touch before you spray a piece of work.

The most important part of spray painting is the preparation of the material.

Preparation for spraying

Most finishing materials are suitable for spray application but if you are in doubt, ask the paint supplier or the manufacturer of the spray equipment for advice. Before you fill the gun, you must follow certain steps to prepare the liquid you are spraying.

First stir the paint or lacquer thoroughly to be sure that the colour is well mixed. Check the viscosity of the liquid before you fill the gun. This is an important consideration as liquids that are too thick will spray a blotchy surface and if the liquid is too thin, the paint will run.

Use a viscosity cup supplied by the spray gun manufacturer to check that the liquid is the right consistency. The cup is filled with paint and the time that the liquid takes to run out is timed. Thin the liquid with the appropriate solvent if it is too thick.



In the absence of a viscosity cup add a small quantity of the recommended thinner and stir thoroughly to mix with a clean stick. Withdraw the stick and hold it at a 45° angle. When the

paint runs from the end of the stick in a continuous stream, it should be at roughly the right consistency for spraying.



It is also good practice to strain the paint before use and remove all impurities to minimize wear of the moving parts of the spray gun as well as helping to achieve a better surface finish. You can strain the liquid by pouring it through a single layer of nylon stocking mounted over the top of a container. As with all finishes, the surface to be sprayed should be clean, dry and free from dust.



Spraying should be done in a large, clean, well ventilated area with good lighting. Cover everything which is not being sprayed. It's also important for your own safety to wear a mask to cover your mouth and nose when using spray equipment.


If you are spraying outdoors, do it on a still, dry day and do the work early in the morning to minimize insects settling on the surface. Cover the area around the work with a plastic sheet or newspapers secured with adhesive tape.





wood finishing

Using the spray gun
Make sure that the fluid
control adjustment on the gun
is correctly set. While
practicing, experiment with
the adjustment, starting from
an almost closed position to
create a small pattern. Adjust
the spray gradually to widen
the pattern created. Notice that
the more liquid which is
sprayed through, the more the
spray tends to break up or
atomize into large particles.

Practice spraying both vertically and horizontally with the adjustment set to a fine spray in a flat fan pattern until you are satisfied with the result. When spraying, it is important to use the correct techniques. The gun should be held at right angles to the work with the distance between the surface and the face of the gun maintained at 6 to 8in. The best idea is to practice on an old piece of furniture which will allow you to make mistakes.









Each stroke is made with a free arm motion across the face of the work surface with the wrist kept flexible so that the gun is kept at right angles to the surface and at the correct distance from it at all times. Keep the speed on each stroke constant to maintain a uniform thickness of coating. To

prevent the building up of paint at the beginning and end of each stroke, the movement of the gun should be started before you pull the trigger and the trigger should be released again before the movement of the gun is finished at the end of the stroke. Do not jerk the gun or move it abruptly.



Overlapping strokes





The edges of the spray pattern taper off slightly so to cover the surface evenly, it is necessary to overlap the previous stroke by about 50 per cent. To do this, aim the



gun at the edge of the previous stroke to get the right overlap. Then finish off the ends with one cross stroke.

To cover a large area, spray with a series of straight overlapping strokes and also overlap the ends as shown.





Cleaning the equipment
It is essential to clean the spray
equipment after each use and
the sooner you clean it, the
easier the job.

Use the correct cleaning fluid to match the finishing material.

When spraying is completed, stop the compressor and pull the trigger to relieve air pressure. Unscrew the paint cup and allow excess paint to drain out. Empty the paint cup and clean thoroughly with solvent.

Pour some thinner into the paint cup, reassemble the gun and spray until pure thinner is passed out. Switch off and take the paint cup off again. Dry all the pieces well. Remove the air cap and soak in thinner, cleaning the slot with a wood toothpick.

Wipe all the pieces with a soft rag and keep in a dry, dust free place when not in use. Be sure to keep the compressor clean and clean the air inlet filters and inside the air hose each time.

Abrasive papers, 248 Adhesives, 225 Air drying of wood, 221 Aluminous oxide paper, 248 Armchair, 35 Auger drill bits, 194, 195 Jennings pattern, 195 solid centre, 195 Baby-proof lock, 90 Back flap hinge, 228 Backsaws, 196, 197 Ball catch, 229 Bandsaw, 219 Bar or sash clamps, 202, 203 Barrel lock, 229 Beading bit, 216 Beds baby's, 88-90 bunk, 82-7 captain's, 60-3 double, 58-9 traditional pine, 52-5 Belt sander, 215 Bench hook, making a, 197 Bench plant holder, 180 Bench stop, 206 Benches picnic, 177 sauna, 74 work-, 136-9 Bevel cuts, 212, 213 Bevel edge chisels, 199 Blade guards (on saws), 208, Rlades circular saw, 208, 209 drawknife, 204 plane, 200, 208 sabre saw, 215 saw. 198 screwdriver, 205 spokeshave, 204 Surform, 204 table saw, 210, 211 Bleaching, 249 Blind tenon, 234 Block joints, 227 Block plane, 200, 201 Bolt and cross dowel, 227 Bolts (and nuts), 226-7 carriage or coach, 226 fixing, 226 machine, 226 Bookcases, 243, 114-15 Bow saw, 196, 198 Box joints, 237

making simple, 244
wall unit, 124–5
with dividers, 126
Brace, 194–5
drill bits used in a, 195
Brackets, 226–7, 240–1, 246
corner, 226
Brad punches, 194
Brad push, 194
Bradawl, 195
Brads, 224
Bridle joint, 239
Bullnose plane, 201
Butt hinge, 228
Butt joints, nailing, 224

Cabinet scraper, 205 Cabinets, 244-5 bathroom, 76-7 drawer, with circular handles, 117 kitchen, 17-18, 44-5 night table, 57 record cabinet dividers, 126 teak, 118-19 tool, 140-1, 207 wall-hung, 48-9 Calipers, 193 Cap iron (of plane), 200 Carbide tipped cutters, 216 Carbide tipped planes, 208, Carriage bolts, 226 Casein glues, 225 Castors, 229 Catches, 229 ball, 229 magnetic, 229 C-clamps, 202 Centre bit, 195 Centre punches, 194 Chairs armchair, 35 convertible high, 96-7 dining, 32-4 folding director's, 42-3 upholstering, 35 Chamfering bit, 216 Chisel lines, marking, 193 Chisels, chiselling, 199

bevel edge, 199

firmer, 199

mortise, 199

sharpening, 199

cutting a mortise joint, 199

marked or gauged line,

horizontal chiselling, 199

vertical chiselling, 199

cutting out waste to a

Chopping boards/blocks, 11 barbecue, 191 built-in, 48 Circles cutting, 217 marking, 193 Circular saw, 208-9 changing a blade, 209 choosing the right blade, 208 converting to a table saw, cutting kerfs, 209 making angled cuts, 209 making edge guide, 209 making grooves, 209 ripping and crosscutting, 208 Clamps, 202-3, 206 bar or sash, 202, 203 C- or G-, 202 handscrew, 202 homemade devices, 203 mitre, 203 padding for, 202 quick action, 202 web, 203 Claw hammer, 194 pulling nails out with, 194 Closets, bedroom, 70-3 Clothes rail, 72 Coffee, tables mirror top, 146-7 parquet, 145-6 plywood end grain, 166-7 Combination plane, 201 Combination saw blades, 208, 211 Combination try and mitre square, 193 Compass planes, 201 Concealed hinge, 228 Connectors, 226-7 block joints, 227 bolts and nuts, 226 dowel screws, 226 knock-down fittings, 227 machine screws, 226 plates and brackets, 226-7 for sheet materials, 240-1 see also Joints Contact adhesives, 225 Continuous or piano hinges, Coping saw, 196, 197, 198 Core box bit, 216 Core bit, 217 Corner brackets, 226

Corner cupboards, 155-7

brackets for, 226

Corner joints for boxes, 124

for drawers, 247 nailing, 224 for sheet materials, 240 for tables, 246 Corner plates, 227 Corner table plate, 227 Corners, rounding, 242 Corrugated fasteners, 224 Countersink bit, 195 Countersunk screws, 224 Cradle, 100-3 doll's, 92-3 Cranked hinge, 228 Cranked stay, 229 Crosscut blades, 208, 211 Crosscut saws, 196, 197 sharpening, 198 Crosscutting, 196, 208, 211, 213, 215 Cubes, 127 Cupboard lock, 229 cut, 229 mortise, 229 straight, 229 Cushions, making, 151, 164, Cutlery stand, 15 Cutters (for routers), 216-17 beading bit, 216 carbide-tipped, 216 chamfering bit, 216 core bit, 217 core box bit, 216 dovetailing bit, 217 laminate trimming bit, 217 rabbeting bit, 216 rounding-over bit, 216-17 straight bit, 216 V-grooving bit, 216 Cutting bevels, 212, 213 circles, 217 cross-, 196, 211, 213, 215 curves, 197, 198 decorative moulded edges, decorative shapes, 198, 217, 242 dovetails, 218, 236-7 grooves and housings, 213, 216-17 halving joints, 239 housing joints, 239 interior holes, 198 irregular shapes, 197 jigsaw puzzles, 198 mitred edges, 212 mitres, 211, 213, 238 mortise and tenon joint, 199, rabbets, 201, 212, 213

Boxes, 124-7

hang, 127

tapers, 212 chest of, 64-9 Firmer bevel, 199 concealed, 228 corner joints, 247 Firmer gouge, 199 wedges, 212 continuous or piano, 228 plastic drawer kits, 247 Flat bits, 214 cranked, 228 Cutting gauge, 193 Welsh dresser, 40 Flooring or lost head nail, face-fixing, 228 lift-off, 228 work table, 121-3 pivot, 228 Drill bits Flush mounts, 227 Dado grooves, dovetailing, Fold-down door, 126 table, 228 brace, 195 Dado head blade, 211, 212 making a depth stop, 195 Folding director's chair, Housing joints, 239 Danish oil, 250 power drills, 214 dovetailing, 239 Fold-out leg structure of Death watch beetle, 221 sharpening, 195 Housings, 66, 211, 213 Decorative shapes, cutting Drilling table, 29 at a 45° angle, 214 Forstner bit, 195 out, 242 Deformed nails, 224 holes in dowels, 214 Fox wedging, 234, 235 Iron-on edging, fixing, 67 Depth stop, 195, 214 out the waste in Frame saws, 198 mortise slots, 214 Fretsaws, 196, 198 Diseases and pests, 221 using a depth stop, 195, 214 Furniture beetles, 221 Jack plane, 200 Dishracks vertical, 195 Jennings pattern auger bits, hanging, 14 Drilling jig, 115 standing, 15 Doors Drills Garnet paper, 248 Jennings pattern dowel bits, brace, 194-5 195 bedroom closet, 72-3 Gauges electric, 214 Jigs, 212 cabinet, 18, 49, 245 cutting, 193 hand, 194-5 home-made 193 drop, stays for, 229 marking, 193 fold-down, 126 lathe attachment for, 219 mortise, 193 Jigsaw, 197, 219 twist, 195, 214 power, 215 locks and catches for, 229 panel, 193 sliding, 126 Drop doors, stays for, 229 Gent's or bead saw, 196, 197 Jigsaw puzzle, making, 198 Jointer, 200, 219 Dovetail cutter, 217, 218 Dry rot, 221 Glass paper, 248 Joints, 230-41 Dovetail dado grooves, 218 Glue roller, 231 Glues, 225 block, 227 Dovetail joints, 218, 236-7, Glue spreader, 225 box or finger, 237 Edge guide, 209 Gluing up joints, 225, 231, Edge to edge joints, 231 corner, 240, 246, 247 assembling, 237 with dowels, 231 235, 238 cutting by hand, 236-7 corner block, 124 gluing, 231 Gouges, 199 dovetail, 236-7 cutting with the router, 237 sharpening, 199 lap, 236 reinforcing, 231 dowel, 231, 232-3 Grain filling, 248 tongue-and-groove, 231 edge to edge, 231 through, 236 Grinder, 219 Edges exposing, 242 Dovetail saw, 196, 197, 236 moulded, 242 Grooved corner joints, 124 gluing, 225, 231, 238 Dovetailed housing joint, sheet material, treatment for, Grooves, cutting, 213, 216-17 grooved corner, 124 239 Dowel bits, 195, 214 Guide pins, 217 halving and bridle, 239 Dowel joints, 232-3, 246 Electric drill, 214 haunched tenon, 235 assembling, 233 attachments to, 208, 214, housing, 239 Halving joints, 211, 213, 239 drilling the holes, 233 219 mitre, 238 marking the holes, 232 drill bits for, 214 Hammers, 194 mortise and tenon, 234-5 claw, 194 uses of, 233 drilling holes at planing up, 230 tack, 194 using a marking template, a 45° angle, 214 preparing the wood, 230 drilling holes in dowels, 214 Warrington, 194 selecting boards and cutting, Dowel pegs, 232, 233, 240 drilling holes to Hand brace, 194 230 Hand drill, 194, 195 specific depth, 214 sheet material, 240-1 making your own, 232 Dowel plugs, plastic, 227 fitting drill bit, 214 Handsaws, 196-8 thicknessing, 230 Dowel screws, 226 hammer action, 214 backsaws, 197 tongue-and-groove edge, Dowel sharpener, 232 vertical stand for, 214 cutting shapes, 197-8 231 Dowelling jig, 232 End splits (in wood), 222 interior holes, 198 Epoxy resin glue, 225 rip, crosscut and Draining board, teak, 20 Expansion bit, 195 panel saws, 196 Kerfing, 213 Draw bore tenon, 235 Drawknives, 204 Exposing wood joints, 242 sharpening, 198 Kerfs, 196, 209 Drawer cabinet with circular Hand screw clamp, 202 Keyhole saw (or padsaw), 196, Hardboard, 223, 241 handles, 117 Hardwoods, 220, 222, 230 Drawer runners, 245, 247 Face fixing hinge, 228 Kiln drying of wood, 221 Haunched tenon joint, 235 Drawers, 247 Face mark, 230 Knife rack, 23 Files, 204 Hinges, 228 cabinet, 18, 49, 119, 141 Knock-down fittings, 227 Filling and patching, 248 back-flap, 228 bunk bed, 86-7 block joint, 227 butt. 228 bolt and cross dowel, 227 captain's bed, 63 Finnish birch plywood, 223

corner plates and knock-down plates, 227 flush mounts, 227 plastic dowel plugs, 227 Knock-down, plates, 227 Knots in wood, 222

Lacquers, 249 Laminate trimming bit, 217 Lamps, 158-9 Lampshades, 168-9 Lap dovetail, 236 Latch, push-roll, 229 Lathe, 219 Lift-off hinge, 228 Linseed oil, 250 Locks, 229 baby-proof, 90 barrel, 229 cupboard, 229 piano mortise, 229 Loose tenon joint, 235 Lost head nail, 224 Lumber core plywood, 223, 240, 241 veneered, 64, 223 Lyctus beetles, 221

Machine bolts, 226 Machine screws, 226 Magnetic latch, 29 Mallet, wooden, 194, 199 Marking, 193 Marking gauge, 193 Marking or trimming knife, Marking templates, 232 Measuring, 193 Mirror plates, 226 Mirror top coffee table, 146-7 Mitre block, 205 Mitre box, 205, 238 Mitre clamps, 203 Mitre joints, 238 cutting, 211, 213, 238 gluing up, 238 reinforcing, 238 splined, 238 Mitre saw, 238 Mitre shooting board, 238 Mitred edges, cutting, 212 Moisture content of wood, Mortise and tenon joints, 234-5

cutting, 199, 234-5

fox wedging, 235

gluing up, 225, 235

draw bore tenon, 235

haunched tenon, 235 loose tenon, 235 through tenon, 235 Mortise chisel, 199 Mortise cupboard lock, 229 Mortise gauge, 193 Moulded edges, 217, 242 Moulding planes, 201 Movement in wood, 221

Nail punches, 194, 224 Nails and nailing, 224 butt joints, 224 common or round wire, 224 corner joints, 224 corrugated fasteners, 224 deformed, 224 finishing, 224 flooring or lost head, 224 hiding, 194, 224 pulling out, 194 oval wire, 224 staples, 224 strengthening joints, 224 upholstery, 224 Nuts and bolts, 226

Oil finish, 250 Oil stains, 249 Oilstone, 199 Orbital sanders, 13, 215, 248 Oven unit, making, 47

Padsaw, 198

Panel gauge, 193 Panel saw, 196 Panels, grooved and rabbeted, Parquet table, 145-6 Particleboard, 223 Perforated hardboard, 207, Phillips head screw, 224 Phillips head screwdriver, Piano mortise lock, 229 Pilaster, 244 Pipe clamp heads, 202 Pivot hinge, 228 Planer, 219 Planes, 200-1, 230 block, 200, 201 bullnose, 201 combination, 201 compass, 201 general purpose, 200 jack, 200

plow, 201 rabbet, 201 shoulder, 201 special purpose, 201 Planing, 200-1, 230 shooting board for, 201 a table top, 200 Planters, 178, 179, 180-1 Plastic drawer kits, 247 Plastic dowel plugs, 227 Plastic laminated chipboard, 223, 240 Plastic laminates, working with, 46 Plates, 226-7 corner and knock-down, 227 corner table, 227 L- and T-, 226 mirror, 226 shrinkage, 227 Playpen, 91 Pliers and pincers, 205 Plinth, 244 Plow planes, 201 Plug cutter, 214 Plywood, 223, 240-1 edge treatment, 240 veneered, 223, 241 Polyurethane lacquer, 249 Pothanger, overhead, 20 Power jigsaw, 215 Pull-out bins, 73 Pumice powder, 249 Pump action or Yankee screwdriver, 205 Push-pull latch, 229 Push sticks, 212 PVA white glue, 225

moulding, 201

Rabbet plane, 201 Rabbeting bit, 216 Rabbets, 201 cutting, 66, 212, 213 Radial arm saw, 213 crosscutting, 213 ripping, 213 other cuts, 213 Rasps, 204 Ratchet screwdriver, 205 Record cabinet, 126 Rip blades, 208, 211 Rip fence, 208, 209, 211 Ripping, 196, 211-12, 213 Ripsaw, 196 sharpening, 198 Rockers (for cradle), 102-3 Roll top desk, 128-35 Rounding corners, 242 Rounding-over bit, 216-17 Router, 201, 216–18
cutters for, 216
cutting circles, 217
cutting moulded edges
and shapes, 217
dovetailing with, 236, 237
guiding pin on, 217
making a shaper out of, 218
making grooves, 216–17
mounting the cutters, 216

Sabre saw (or power jigsaw), 197, 215 choosing blades, 215 making an interior cut, 215 Safety of saws, 208, 210 Sanders, 215, 248 belt, 215 disk, 212, 248 orbital, 215, 248 Sanding, 13, 248 Sanding block, 205 Sandpaper, 248 Saw blades, 208, 209, 210, 211, 215 Sawhorses, 206 Saws backsaws, 197 bead or gent's, 197 bow, 198 circular, 208-9 coping, 197-8 crosscut, 196 dovetail, 197, 236 fretsaw, 198 handsaws, 196-8 jigsaw, 197, 215 keyhole, 198 mitre, 238 panel, 196 radial arm, 213 ripsaw, 196 sabre, 197, 215 sharpening, 198 teeth of, 196 tenon, 197 Scotch glue, 225 Scraping, scrapers, 205, 248 Screwdriver bit, 195 Screwdriver tips, 205 Screwdrivers, 205 Phillips head, 205

pump action or Yankee, 205

Screw gauge numbers, 224

countersunk, 224

gauge numbers, 224

ratchet, 205

dowel, 226

hiding, 224

Screws, 224

machine, 226 oval or raised head, 224 Phillips head, 224 round head, 224 Scribing gouge, 199 Seasoning of wood, 221, 222 Shaper (or spindle moulder), 218 Shaping tools 204 Sharpening tools chisels and gouges, 199 drill bits, 195 grinder for, 219 saws, 198 Sheet materials, 223, 240-1 cutting with handsaw, 196 corner joints or T-joints, 240 - 1edge treatments, 240 grooved and rabbeted panels, 241 Shellac, 249 Shelves, 112-13, 126 book-, 243, 114-15 open shelving unit, 21 Shooting board, 201 Shoulder plane, 201 Shrinkage plates and angles, Sink and hob, building in, 47-8 Skew or toe nailing, 224 Slat plant stand, 178 Slat wall units, 21, 22-3, 207 Sliding bevel, 193 Sliding doors, 126 Sliding flap stay, 229 Smoothing plane, 200 Soap dish, veneer, 78-9 convertible, 160-4 with storage, 148-51, 241 Softwoods, 220, 222, 230 Solid centre auger bits, 195 Spice rack, 116 Splashback, 19 Splitter and anti-kickback fingers, 210 Spokeshaves, 204 Spray finishing, 250-1 cleaning equipment, 251 overlapping strokes, 251 using spray gun, 251 Squaring off, 193

Stains, 248-9 Staples, 224 Stays, 229 cranked, 229 sliding flap, 229 Storage, storing cabinets, 116-19, 140-1 kitchen, 20-1 sofa with, 148-51 wall box unit, 124-5 wood, 207 workshop, 207 Storage racks, kitchen, 22-3, Straight bit, 216 Stripping paintwork, 215 Surforms, 204 Synthetic resin glue, 225 Table hinge, 228

Table saw, 210-12 avoiding accidents with, 210 blades, 211 converting circular saw to, 209 crosscutting, 211 cutting bevels and mitred edges, 212 cutting mitres, 211, 238 cutting rabbets, 212 cutting tapers, 212 cutting wedges, 212 ripping, 211-12 Table top, planing a, 200 Tables, 246 coffee, 145-7, 166-7 corner joints for, 246 corner plates for, 227 dining, 12-13 dual-height, 152-4 gate leg, 28-31 mirror-top, 146-7 night, 56-7 outdoor, 185 parquet, 145-6 picnic, 173-6 trestle, 108-9, 246 work, 120-3 Tack hammer, 194 Tambour (roll top), making, 128, 132-3

Tapers, cutting, 212

Tapes and rules, 193

Teak oil, 250

Template, marking, 232 Tenon joint see Mortise and tenon joint Tenon saw, 196, 197 Thicknessing planer, 219 Thicknessing wood, 230 Through dovetail, 236 Through dowel, 233 Through housing, 239 Through tenons, 235 Tiled hot stand, 48 T-joints, 240 brackets for, 226 Tongue-and-groove joints, Tool cabinet, 140-1 wall-hung, 207 Tool rack, 139 Tools grinder for sharpening, 207 hand, 193-205 hanging up of, 207 marking and measuring, 193 power, 206-19 shaping, 204 Toothbrush holder, 77 Towel holder, 23 Towel rails, 75, 79 Trammel points, 193 Tray, barbecue, 188-91 Trestles, 108-9, 206-7 Trolley, barbecue, 186-8, 191 Truing up boards, 200 Try plane, 200 Try square, 193 Twist drills, 194, 195, 214

Upholstering chair, 35 Upholstery nails, 224

Varnish, 249
Veneer lampshades, 168–9
Veneered chipboard, 223
Veneered lumber core
plywood, 64, 223
Veneered plywood, 223, 241
Vernier scale, 193
V-grooving bit, 216
Vice and bench stop, 138
Vices, 206
Viscosity cup, 250

Wall cabinets, 48-9 Wall units honeycomb, 110-11 slat, 21, 22-3, 207 Warping, 222 Warrington hammer. 194 Wax finish, 249-50 Web or band clamps, 203 Wedges, 203 cutting, 212 fox, 235 Welsh dresser, 36-41 Winding sticks, 230 Wire baskets, fitting, 45 Wood fillers, 248 Wood, 220-2 buying, 222 defects, 222 growth, 220 manufactured boards, 223 seasoning and movement, storing, 207 structure, 220 types of, 222 see also Joints Wood finishing, 248-51 applying polyurethane lacquer, 249 bleaching, 249 filling and patching, 248 grain filling, 248 lacquers, 249 oil, 250 power sanders, 248 preparations for, 248 rubbing with pumice powder, 249 Shellac, 249 spray, 250-1 stains, 248-9 varnish, 249 wax, 249-50 Wood screw and tap, 205 Woodworm, 221 Workbench, 136-9, 206-7 Workmate, 206, 218 Worktops, kitchen, 19, 45-6,

Yankee screwdriver, 205

Wrench, adjustable, 205

The publishers would like to thank the following for generously supplying the tools, equipment and accessories used to make the projects in this book.

Black & Decker Ltd
DeVilbiss Company Ltd
Dormer Tools (Sheffield) Ltd
Record Ridgway Tools Ltd
Sandvik (UK) Ltd
Stanley Tools Ltd
Stanley Power Tools Ltd

The following kindly supplied the materials used to make and finish the projects and to complete the locations in which they were photographed.

J D Beardmore and Co Ltd **Burmah Industrial Products Ltd Eaton Bag Company Evode Ltd** Finnish Plywood **Development Association** Formica Ltd Laura Ashley ICI Ltd Arthur Sanderson and Sons Ltd Sterling-Roncraft Ltd Swales-Sofadi Ltd Special thanks are due to Liberty & Company Ltd, for loaning props for photography and to 21 Antiques for assistance with props.

Addresses in the United States

Stanley Works, 195 Lake Street, New Britain, CT 06050

Black & Decker Manufacturing Co., Towson, Md., 21204

Evode, Inc., 403 Kennedy Blvd., Sommerdale, N.J. 08083

Formica Corporation, Subsidiary of American Cynamid Co., Wayne, N.J. 07470

ICI United States, Wilmington, Del., 19897

Alf Martensson has written several books on woodworking including Making Plywood Furniture (Finnish Plywood Development Association, 1976), Woodwork in Easy Steps (Studio Vista, 1977), and Basic Woodworking (Sundial/St Michael's 1978). He has, in addition, written many articles for woodworking journals in the US and the UK and his work is featured on the BBC Television series, Make Your Own Furniture.


Born in Sweden, he trained as an architect and designer in the US and as a structural engineer in England before becoming a full-time furniture maker. In addition to writing, he designs furniture for his company in London, called Woodstock, which makes limited production run hardwood furniture as well as individual commissioned designs.

THE BOOK OF FURNITURE MAKING

Step by step drawings show how to make attractive and useful furniture for indoors and out, including

- four dining tables two dining chairs
- two complete kitchens two sofas
- five coffee tables three bed designs
- bunk beds child's bed cradle
- high chair
 picnic table and benches
- · four planters
- desks
 work tables
 bookcases

and all the woodworking techniques you'll need in 64 extra pages



Chest of drawers page 64





Honeycomb wall unit page 110



Barbecue trolley page 186 Picnic table page 172



Slot together lamp page 168



Baby's bed page 88 Rocking elephant page 104